


MATERION

CONNECTOR ENGINEERING DESIGN GUIDE

MATERIAL SELECTION IN THE DESIGN OF SPRING CONTACTS AND INTERCONNECTIONS







A comprehensive guide to design, modeling, analysis, testing, and production of reliable connectors and other conductive springs utilizing Materion's high performance alloys.

www.materion.com/connectors

What design challenges are you facing today?

Connector Engineering Design Guide

Material Selection in the Design of Spring Contacts and Electrical/Electronic Interconnections

Section I - Introduction 8
- a) Purpose of This Guide. 8
- b) Connector Terminology. 8
- c) Executive Summary of Design Process 13

Section II – Connector Applications and Materion Solutions 14

Section III – Design Challenges and Industry Trends 26
- a) Connector Requirement Drivers 26
- b) Market Segment Trends 27

Section IV – Requirements on Connectors 30
- a) Mechanical Requirements 30
  - i) Contact Theory 30
  - ii) Contact Normal Force & Geometry 31
  - iii) Insertion and Extraction Forces 32
- b) Electrical Requirements 33
  - i) Connector Resistance 33
  - ii) Power and Signal Considerations 36
- c) System Requirements 36
  - i) Reliability, Cost & Package Envelope 36
  - ii) Standards and Specifications 37
- d) Material Requirements 37
  - i) Base Metal 37
  - ii) Housing, Interface, Lubricants, Epoxies & Insulator Materials 37
- e) Assembly of Contacts into Connector Housings 38
- f) Attachment & Termination Processes 39
  - i) Compression Mount & Press-Fit 39
  - ii) Insulation Displacement (IDC) and Crimp Connections 40
  - iii) Solder Processes and Surface Mount Technology 41
- g) Compatibility 41

Section V – Connector Base Materials and Properties of Interest 42
- a) Design Requirements vs. Material Properties 42
- b) Material Properties vs. System Properties 43
- c) Metallurgy 44
  - i) Strengthening Mechanisms. 46
  - ii) Grain Size and Strength 49
  - iii) Solid Solution Hardening (Alloying) 51
  - iv) Work (Strain) Hardening 54
  - v) Precipitation (Age) Hardening 54
- d) Temper Designations 56
  - i) Heat Treatable Tempers 56

MATERION

©2020 Materion Brush Inc.

ii) Mill Hardened Tempers . . . 57
e) Primary Mechanical Properties . . . 58
i) Engineering Stress and Strain . . . 59
ii) Tensile Properties . . . 60
iii) Poisson's Ratio . . . 60
iv) Bending Stress . . . 61
v) Yielding . . . 63
vi) Hardness . . . 67
f) Secondary (Time-Related) Mechanical Properties . . . 73
i) Stress Relaxation . . . 73
ii) Fatigue . . . 77
g) Tertiary (Interdependent) Mechanical Properties . . . 80
i) Normal Force . . . 80
ii) Friction, Insertion & Extraction Forces . . . 80
iii) True Stress & Strain vs. Engineering Stress & Strain . . . 82
iv) Permanent Set . . . 84
v) Elastic Resilience & Modulus of Resilience . . . 85
vi) Bauschinger Effect . . . 86
h) Electrical and Thermal Properties . . . 86
i) Coefficient of Thermal Expansion . . . 86
ii) Electrical & Thermal Conductivity . . . 86
iii) Connector Temperature Rise . . . 88
i) Composite Base Materials . . . 89
i) Overlay and Inlay Cladding . . . 89
ii) Electron Beam Welding . . . 90
iii) Dovetail Clad® Strip . . . 91
iv) Contour Profiling . . . 92
j) Aluminum as a Base Material . . . 93

Section VI – Interface Materials and Composite (Hybrid) Strip Technologies . . . 94
a) Contact Surfaces and Stability . . . 94
b) Key Coating Properties . . . 95
c) Switching Levels . . . 95
d) Coating Materials . . . 97
i) Gold (Au) . . . 97
ii) Platinum (Pt), Palladium (Pd) and Their Alloys . . . 98
iii) Silver (Ag) . . . 99
iv) Tin (Sn) and Its Alloys . . . 100
v) Nickel (Ni) . . . 103
vi) Copper (Cu) and Aluminum (Al) . . . 104
vii) iON Connector Materials . . . 105
viii) Contact Buttons . . . 106

MATERION

©2020 Materion Brush Inc.

e) Normal Force Requirements 107
f) Surface Coating Processes. 108
i) Hot Dipping 108
ii) Electroplating 109
iii) Electroless Plating. 111
iv) Cladding 111
v) Pre-Plating vs. Post-Plating. 113
g) Coating Technology and Base Metal Compatibility 115

Section VII – Materials for Other Connector Components 116
a) Plastic/Elastomeric Housing Materials 116
b) Metal Housing Materials. 118
c) Connector Lubricants 119
d) Dielectric/Insulator Materials 119
e) Epoxies and Potting Compounds 121

Section VIII – High Voltage, Power & Current Considerations 122
a) Breakdown Voltage & Electrical Arcing 122
b) Hot Plugging/Unplugging and Electrical Overstress 125

Section IX – EMC, SI, and Other High Frequency Considerations 126
a) High Frequency Definitions 126
b) Noise and Coupling Mechanisms 128
c) Impedance Matching 129
d) Cross Talk 130
e) Conducted EMI 131
f) Radiated EMI 132
g) Intermodulation Distortion 135
h) Controlling EMI 136
i) PCB Design and Filtering 136
ii) Twisted Pair Wiring and Coaxial Cable 137
iii) Connector Design and Bonding 138
iv) Connector Pin Assignment and Grounding 139
i) Electromagnetic Shielding 138
i) Distance and Coupling Mechanisms 139
ii) Shielding Theory 140
j) Signal Integrity (SI) and EMC Measurements 142

MATERION

©2020 Materion Brush Inc.

Section X – Considerations for Harsh Environments 146
a) Connector Requirements for Harsh Environments 147
b) Storage of CuBe 147
c) Shock & Impact Loading 148
d) Vibration 150
e) Elevated Temperature Exposure 151
f) Corrosion and Corrosion Mechanisms 152
g) Examples of Harsh Environments 163

Section XI – Regulatory, Environmental, Health & Safety Considerations 168
a) Product Regulations 168
b) CuBe Scrap 170
c) Health and Safety 170
d) Occupational Standards and EH&S Tools 174
e) Material EH&S Policy and Principles 177

Section XII – Miniaturization 178
a) Moore's Law and Miniaturization 178
b) Miniaturization Trends 180
c) Miniaturization Exercise 181

Section XIII – Design and Analysis 184
a) Methods 184
b) Spring Types 186
c) Loads and Support Conditions 188
d) Simulation 190
e) Caveats for Finite Element Analysis 194
f) Design Review 204
g) Performance Alloy Value-Added Services 205

Section IVX – Prototyping and Verification 206
a) EDM/Spark Erosion 206
b) Photochemical Machining 207
c) Laser Cutting & Waterjet Cutting 208
d) Milling 209
e) Material Directionality 209
f) Rapid Prototyping/Additive Manufacturing (3D Printing) 209
g) Design Evaluation 212

Section XV – Qualification 214
a) General Requirements & Environmental Tests 214
b) Standards and Specifications 216
c) Corrosion Testing for Consumer Electronics 217

MATERION

©2020 Materion Brush Inc.

Section XVI – Production 222
a) Progressive Dies 223
b) Formability 224
c) Caveats on Formability 231
d) Profiled Strip & Zone Annealing 232
e) Springback 233
f) Considerations for Thin Foils 235
g) Heat Treating and Heat Treat Distortion 236
h) Shape Effects 241
i) Residual Stress Effects 243
j) Drawing, Embossing, and Deep Drawing 250
k) Punches and Dies 250
l) Storage, Cleaning, and Solderability 251
m) Production of Parts Using Rod and Wire 252
n) Machinability 254
o) Crimping, Zone Annealing, and Distortion Prevention in Machined Parts 259
p) Quality 261

Section XVII – Cost Reduction Exercise 264

Section XVIII – Design Example – One-piece Automotive Terminal 272
a) Automotive Market Segment Trends and Reliability 272
b) Design Exercise 276

Appendix 292
a) Performance Alloys Product Offerings and Forms 292
b) Technical Materials Process Capabilities and Product Offerings 293
c) Cantilever Beam Transforms 295
d) Cantilever Beam Equations 296
e) Conversion Factors 298
f) Further Reading 300

MATERION

©2020 Materion Brush Inc.

MATERION

Connector Engineering Design Guide – 4th Edition

Material Selection in the Design of Spring Contacts and Interconnections

A comprehensive guide to design, modeling, analysis, testing, and production of reliable connectors and other conductive springs utilizing high performance alloys and coatings.

Section I – Introduction

Purpose of This Guide

Without connectors, electrical and electronic devices would not be able to function. The most advanced control system in the world can't help you if it's not receiving input from its sensors, or if its instructions are not being received by other components. As you will see, connector reliability is determined by a low, stable contact resistance. This resistance is governed by the choice of plating or cladding on the surface, as well as the base spring material and the applied contact force. These choices are determined by the operating environment, temperature, space available, and overall cost.

Base metals for electrical contacts possess varying combinations of strength, stress relaxation resistance, conductivity, formability, corrosion resistance and magnetic permeability. Choosing an alloy that best meets the complex needs of a new contact application requires an awareness of the characteristics and interrelationships governing material performance. This awareness is dependent on the designer's knowledge of the available alloys and their specific performance, manufacturing, quality and cost effectiveness characteristics.

In its capacity as a fully integrated supplier of beryllium-containing alloys, Materion's technological expertise spans the full spectrum of these alloys in strip, rod, wire, bar, plate, fabricated forms, casting and master alloys. Considering this total capability, Materion has structured this Design Guide to facilitate the design process by providing a framework from which you can:

- Understand, predict, and control reliability in connector terminal design.
- Understand the relationship among contact design, spring alloy properties, operating environment, and contact performance.
- Determine the general class of alloy necessary to fulfill the requirements of a connector application.
- Determine the temper that provides the optimum solution to the application's operating and manufacturing parameters.

This Design Guide includes the manufacturer's published material properties and testing conducted by Materion for the alloys shown in Table 3.

The material characteristics and properties of the copper beryllium alloys, presented in blue, demonstrate the available performance range obtainable with these products. In addition to its standard products, Materion manufactures custom materials specifically tailored to customer specifications.

Connector Terminology

Different companies have different definitions of contacts, connectors and components thereof. For the purposes of clarity, here is the terminology that will be used throughout this guide, Illustrated in Figures I-1 through I-5.

- **Connector** – This is the entire interconnection system, including the contact (base metal and coating), the housing, and the termination scheme. The connector typically has both a male half and a female half, with different requirements. Often, the male half of a connector is known as a **plug** and the female half may be referred to as a **jack**. There may be multiple contacts and terminations within each connector half.
- **Contact** – This is the spring member that applies the normal force between the two halves of the separable interface. It is usually a plated spring material like copper beryllium. Male contacts are typically referred to as pins and female contacts as **sockets**. If the pin is flat and wide, it may also be referred to as a **blade**.
- **Base Metal** – The monolithic raw material used to stamp the contact, not including any plating, cladding, solder, etc.
- **Coating** – Any metallic substance placed on the surface of the base metal spring to improve the electrical, corrosion, and/or wear performance of the contact interface. This could be precious or non-precious metal **plating, cladding, solder coating,** aluminum or gold for **wire bonding,** etc.
- **Housing** – The (usually) plastic insulation that contains the contacts and the termination scheme. In some RF connectors, the housing will be metal to function as **electromagnetic shielding** and/or to facilitate **grounding** and **bonding**, and may even conduct current or signals. In a two-piece contact (see Figure 1), the base metal surrounding the active spring member may also be referred to as the **contact housing**, differentiating it from the **connector housing**.
- **Termination** – This is how each half of the connector is integrated into the rest of the circuit. This is typically meant to be a permanent (non-separable) connection. This could be a **crimp** onto the end of a wire, a **post** or **compliant pin** inserted into a **plated through hole,** a **solder tail** for **surface mount** connectors, an **insulation displacement contact,** etc.

MATERION

©2020 Materion Brush Inc.

- **Signal Contact** – Any contact designed to carry low voltage, low current electrical signals, often at high frequency. Electrical characteristics of the interface are dominated by the plating. **Signal integrity (SI), power integrity, and electromagnetic compatibility (EMC)** are concerns in these contacts.
- **Power Contact** – Any contact carrying significant levels of current/voltage, often at low frequency or DC. Electrical characteristics are dominated by the conductivity of the base metal. Temperature rise and thermal stability are concerns in these contacts.

Figure I-1 Two-piece Female Contact Terminal Design Cutaway View




Figure I-1 Two-piece Female Contact Terminal Design

The inner piece is a copper alloy spring contact, exposed in this cutaway view. The outer piece functions both as a housing for the spring element and as a termination to the braided wire conductor.

MATERION

Figure I-2 Nomenclature – Male (Pin) and Female (Socket) Contacts




Figure I-2 Male and Female Automotive Wiring Harness Terminal Contacts
This shows the male (one-piece pin) and female (two-piece socket) contacts typically found in automotive wiring harness connectors.

Figure I-3 Nomenclature – Connector Male Half




Figure I-3 Male Half of Automotive Terminal Connector
This shows multiple female contacts (sockets) overmolded with plastic to form the male half (plug) of a connector. This illustrates the point that both the male (plug) and female (jack) halves of a connector can contain either male (pin) or female (socket) contacts.

Figure I-4 Nomenclature – Circular Connectors




Figure I-4 Nomenclature - Circular Connectors
Circular and military connectors usually have multiple pins and sockets in each connector. The housings are usually machined from metal, and retention is assured by threading the outside layers. The pins and sockets are electrically isolated from each other with a dielectric material, and hermetic sealing, if necessary, can be achieved by using a potting compound or a frit glass seal. In this example, the pin side connector would be mounted to a bulkhead to pass the signals through it. The threaded housings will complete a 360° seal around the contacts to shield the RF signals. The sockets may be machined from rod or wire, or they may be stamped and formed from strip.

Figure I-5 Nomenclature – Medical Connectors




Figure I-5 Nomenclature - Medical Connectors
Medical connector housings are usually molded from plastic, and typically incorporate strain relief on the cable end. The housings usually incorporate a bayonet or other latching mechanism to maintain connection. As in circular and military connectors, alignment or registration keys assure that the pins and sockets are properly aligned when the connector is mated.

©2020 Materion Brush Inc.

One-piece vs. Multiple Piece Socket designs

A one-piece socket features the housing and spring element stamped out of one continuous piece of metal, such as in the left side of Figure I-6. Alternatively, the one or more spring elements may be stamped out separately, and placed into the socket housing, as in the right side of Figure 1-6. Figure 1-7 shows different types of socket designs and how they are made.

Figure I-6 One-piece vs. Two-piece Terminals (Part of the Socket Housing Removed for Clarity)




Figure I-6 One-piece vs. Two-piece Terminals
The terminal on the left is stamped from a single piece of metal. The active spring beams are fully integrated with the housing. In the terminal on the right, the spring element is stamped separately, and the housing is formed around it in a second operation. Both designs accept a flat blade pin, but the two-piece arch spring design is inherently more stiff and reliable than the one-piece cantilever beam spring design.

Figure I-7 Types of Two-piece Socket Contacts




Figure I-7 Types of Two-piece Socket Contacts
Sockets may be formed in progressive dies by stamping, machined from rod (or wire) or constructed by welding wires into a cage-like structure. Note that in all these cases, when a circular pin is inserted into the sockets, there are multiple points of contact. This increases reliability. if the contact resistance is greatly increased at one point of contact, the current or signal will simply flow through another point of contact.

While one-piece designs are simpler to make, two-piece designs do offer some advantages in terms of performance, reliability and cost. By putting a small contact beam made from a high performance alloy in a softer copper alloy body, there is no need to sacrifice spring properties to provide crimpability in the terminal. You can use two-piece designs for both signal and power connectors, depending on the strength and conductivity of the insert. You can use a multipiece design for either flat or round pins with an insert based on arch, torsion, cantilever or even a coil spring design (as shown in Figures I-8 and I-9).

Figure I-8 Spring Types and Die Progressions




Figure I-8 Spring Types and Die Progressions
Even in a simple stamped and formed contact, you have freedom to choose among different spring designs. Three common choices are cantilever beam, louvered spring, and arch spring designs. Section XIII-Design and Analysis will go into more detail on the advantages and disadvantages of each type.

©2020 Materion Brush Inc.

Figure 1-9 Two and Three Piece Socket Designs (Housings Translucent for Clarity)




Figure 1-9 Two and Three Piece Socket Designs (Housings Translucent for Clarity)
In the three piece rectangular design, two die progressions are placed in the housing, contacting on each side of the flat blade. In the two-piece circular design, the die progression is bent into a circle to wrap around a round pin. Both examples here show the louvered spring design. It is easy to picture how the spring contacts will rotate and apply contact pressure to the pin when it is inserted.

Advantages of Two (or Three) Piece Sockets over one-piece Sockets:

- Allows greater design flexibility for power contacts (such as photovoltaic or electric vehicle charging connectors)
- Provides cost effective use of materials and efficient use of precious metal plating
- Produces a higher contact force in a smaller design
- Allows for controllable insertion force
- Provides multiple insertions with greater resistance to permanent set
- The large contact interface area creates a smaller temperature rise
- Permits more design options for connector miniaturization
- Creates multiple contact locations for redundancy
- Increases reliability

Interconnect Level Terminology

There are 7 or more commonly-defined levels at which electrical connections are made. They are as follows:

Level 0 – On-chip interconnects (etched into the semiconductor chip)

Level 1 – Connections between an IC chip and its package
Examples: wire bonds, solder balls

Level 2 – Connections between the chip package and the PCB
Examples: BGA sockets, LGA sockets, SMT terminations, plated through holes

Level 3 – Connections between PCB's, such as between motherboards and daughter cards
Examples: mezzanine connectors, backplane connectors, card edge connectors

Level 4 – Connections between subassemblies
Examples: ribbon connections, IDC connectors, mezzanine connectors

Level 5 – Connections between subassemblies and I/O ports
Examples: USB (female), audio jack contacts, antenna contacts, VGA connectors (female)

Level 6 – Connections between systems, or between a system and its peripherals
Examples: USB (male), modular jacks, IEEE 1394, HDMI, wiring harness terminals, etc.

Level 7(+) – Long distance connections
Examples: telecom, datacom, backhaul, wireless base stations, etc.

(Note: several proposals exist for defining multiple levels above 6, varying from 7 to 10 distinct levels depending on the organization.)

Note that the two mating halves of a connector may be classified under different levels. For example, a female USB contact permanently attached to the PCB would be a level 5 connector socket, while the mating half on a USB cable would be a level 6 connector plug.

This design guide will be focused mainly on separable connectors found in levels 3 and higher. The other connections are typically permanent, and either etched into the integrated circuit chip itself (level 0), or attached via soldering or wire bond (levels 1 and 2).

MATERION

©2020 Materion Brush Inc.

Figure 1-10 Design Process




Figure I-10 Design Process
This schematic illustrates the design process in flowchart form. Each step in this process is covered in detail in each section of this guide. This chart will be duplicated at the beginning of each section to highlight the step covered by that section.

Figure I-11 Design Example Flowchart




Figure I-11 Detailed Design Example Flowchart
This is a more detailed overview of the design process, including some additional considerations in each section. This process is the basis of the design example at the end of this guide.

The design process involves a number of steps. Industry trends drive and dictate connector requirements. From these requirements, one must isolate the critical design factors and identify the overall class of alloy needed. After determining this, the designer is then in a position to specify the material characteristics that will most closely meet the application's overall performance, manufacturing and cost requirements. A design review follows the detailed design and analysis step to ensure the achievement of requirements. Prototypes verify the final design. A qualification then certifies production level hardware. The qualification is a short term test to simulate long term performance. Once achieved, a connector is ready for the manufacturing challenges of production. The design flowchart Figure 1-10 illustrates the iterative process of connector design.

We will consider each of the design factors and the material properties dictating connector performance. Considering this analysis, we will examine the specific properties that the designer must assess in each instance. Each topic is discussed in a separate chapter in this guide.

Section XVIII – Design Example demonstrates the process of using the detail design flowchart shown in Figure I-11.

©2020 Materion Brush Inc.

Section II:
Connector Applications and Materion Base Metal Solutions

Connector design engineers face mace many challenges in their designs:

- Arcing damage
- Battery life extension
- Condensation
- Corrosion migration
- Corrosive environments
- Cost pressures
- Crimping
- Cross talk
- Drop testing
- Dust
- Electromagnetic interference
- Electrostatic discharge
- End-of-life recyclability
- Ensuring signal integrity (SI)
- Ergonomic constraints
- Fatigue
- Forming
- Fretting
- Galvanic corrosion
- Higher contact density
- Higher current
- Higher cycles
- Higher frequency
- Higher operating temperatures
- Higher power
- Higher voltage
- Hot swapping
- HPHT environments
- Hybrid functionality
- Humidity
- Impedance mismatch
- Increasing electrification
- Insertion loss
- Intermetallic formation
- Intermodulation distortion
- Joule heating
- Lighter weight
- Maintaining Electromagnetic Compatibility (EMC)
- Material compatability
- Meeting specifications
- Miniaturization
- Misalignment
- More features
- Non-coplanarity
- Parasitic capacitance
- Parasitic inductance
- Pb-free soldering
- Plating porosity
- Polymer adsorption
- Radio frequency interference
- Regulatory compliance
- Return loss
- RoHS compliance
- Salt spray
- Shock loading
- Signal attenuation
- Signal distortion
- Springback
- Stress corrosion cracking
- Surface contamination
- Sustainability
- Switching noise
- Temperature rise
- Thermal runaway
- Tight spaces
- Tight tolerances
- Tighter pitch
- Tin whiskers
- Tolerance stack-up
- Vibration
- Warranty costs
- Wear
- etc.

MATERION

©2020 Materion Brush Inc.

Materion and Technical Materials provide solutions for these challenges via:

- Conductivity
- Consistency
- Controlled insertion & withdrawal forces
- Corrosion resistance
- Cost-effectiveness
- Crimpability
- DFARS compliance
- Dimensional stability
- Elasticity
- Electromagnetic compatibility
- Fatigue strength
- Formability
- Heat resistance
- Heat treating capability
- High cycle life
- Isotropy
- Long life
- Low total cost
- Machinability
- Magnetic transparency
- Misalignment tolerance
- Recyclability
- Reliability
- Repeatability
- Resilience
- Robustness
- RoHS compliance
- Ruggedness
- Safety margins
- Shock resistance
- Signal integrity
- Signal transparency
- Stability
- Stress relaxation resistance
- Stiffness
- Strength
- Technical Support
- Toughness
- Wear resistance
- Worldwide availability

Material Solutions to Engineer Reliability into Your Most Demanding Design Applications

Connectors must provide and maintain adequate contact force over the life of the connector, without resulting in excessive insertion force.

- Requires strength, stiffness, formability/machinability, conductivity, stress relaxation resistance in base metal.
- Requires adequate hardness and lubricity in plating.
- Requires mechanical stability in the connector.

Low performance materials may be adequate in some designs with low performance requirements. However, in high reliability designs, high performance materials are a must, and may even provide the lowest total cost solution.

Materion provides materials with unique properties that solve problems in many applications, which are listed on the following pages.

MATERION

©2020 Materion Brush Inc.

Appliance Contacts



Application: Power Contacts

Design Requirements:

- Pass large amounts of current
- Maintain contact force under high temperatures

Necessary Material Attributes:


- Conductivity
- Stress relaxation resistance
- Elastic resilience

Materion Base Metal Solution:

- 3/17410 strip
- 190/290 strip

Materion Surface Coating Solution:

- Silver
- Nickel



Application: Electric Motor Brush Contacts

Design Requirements:

- Maintain constant pressure
- Pass high current

Necessary Material Attributes:


- Elastic modulus
- Conductivity
- Stress relaxation resistance

Materion Base Metal Solution:

- 25 strip
- 190 Strip

Materion Surface Coating Solution:

- Usually bare, with carbon brush on end



Application: Rotary Switches

Design Requirements:

- Wear resistance
- High number of operating cycles

Necessary Material Attributes:

- Hardness
- Elastic modulus
- Conductivity
- Formability
- Stress relaxation resistance

Materion Base Metal Solution:

- 25 strip
- 190 strip
- 290 strip
- 17410 strip

Materion Surface Coating Solution:

- Silver
- Nickel

MATERI

©2020 Materion Brush Inc.

Automotive Electronics



Application: Thermostat Switch Contact

Design Requirements:

- Repeatability
- Temperature resistance
- High cycle life

Necessary Material Attributes:


- Stress relaxation resistance
- Fatigue strength
- Conductivity

Materion Base Metal Solution:

- Alloy 25 strip
- 190 strip
- 390/390E® strip
- 17410 strip

Materion Surface Coating Solution:

- Nickel



Application: Switch Contacts

Design Requirements:

- Withstand high number of operating cycles
- Potentially pass high current

Necessary Material Attributes:


- Elastic resilience
- Formability
- Conductivity
- Fatigue strength
- Stress relaxation resistance

Materion Base Metal Solution:

- 190 strip
- 17410 strip
- 390 strip

Materion Surface Coating Solution:

- Riveted or staked contact buttons (Ag, AgCdO, etc.)



Application: Relay Blades

Design Requirements:

- High number of operating cycles
- Pass high current

Necessary Material Attributes:

- Elastic resilience
- Formability
- Conductivity
- Fatigue strength
- Stress relaxation resistance

Materion Base Metal Solution:

- 17410
- 190 strip

Materion Surface Coating Solution:

- Riveted or staked contact buttons (Ag, AgCdO, etc.)

MATERI

©2020 Materion Brush Inc.

Automotive Electronics



Application: Wiring Harness Terminals

Design Requirements:

- Maintain electrical & mechanical stability
- Withstand vibration
- Withstand high temperatures
- Withstand severe forming operations

Necessary Material Attributes:

- Elastic resilience
- Formability
- Conductivity
- Stress relaxation resistance


Materion Base Metal Solution:

- Alloy 190 strip for spring element in two-piece female contacts
- Alloy 17410 strip for one-piece female contacts

Materion Surface Coating Solution:

- Typically Sn plated
- Sometimes Ag plated for high reliability connections in harsh environments.

Semiconductor Test (Test Probes, Burn-in and Test Socket Contacts)



Application: Buckling-Beam Style Burn-in & Test Socket Contact

Design Requirements:

- Short conducting length (for low loop inductance)
- Compact height
- Elevated temperature resistance
- Wear resistance

Necessary Material Attributes:

- Elastic resilience
- Elastic modulus
- Formability/machinability
- Conductivity
- Stress relaxation resistance

Materion Base Metal Solution:

- 25 strip
- M25 wire
- Alloy 390® strip/390E strip

Materion Surface Coating Solution:

- Au over Ni



Application: Compression Contacts and Test Probes

Design Requirements:

- Short conducting length (for low loop inductance)
- Compact height
- Wear resistance

Necessary Material Attributes:

- Elastic resilience
- Elastic modulus
- Machinability
- Hardness

Materion Base Metal Solution:

- 25 rod
- M25 rod
- ToughMet® 3 rod

Materion Surface Coating Solution:

- Au over Ni

MATERION

©2020 Materion Brush Inc.

Circular and Military Connectors



Application: Circular Connector

Design Requirements:

- Mechanical stability
- Survive harsh conditions

Necessary Material Attributes:

- Elastic resilience
- Machinability
- Conductivity
- Stress relaxation resistance


Materion Base Metal Solution:

- 25 rod/wire
- 3 rod/wire
- Brush 1915® rod, 1916 rod/wire

Materion Surface Coating Solution:

- Au over Ni

Computers and Electronic Devices



Application: Power Contact

Design Requirements:

- Conduct current
- Mechanical stability

Necessary Material Attributes:


- Elastic resilience
- Elastic modulus
- Formability/machinability
- Conductivity
- Stress relaxation resistance

Materion Base Metal Solution:

- Brush® 60 strip
- Alloy 390® strip

Materion Surface Coating Solution:

- Au over Ni



Application: Processor Socket Contact

Design Requirements:

- Mechanical stability at very small size
- High temperature stability

Necessary Material Attributes:

- Elastic resilience,
- Elastic modulus
- Formability/machinability
- Conductivity
- Stress relaxation resistance

Materion Base Metal Solution:

- Alloy 25 strip
- 390 strip

Materion Surface Coating Solution:

- Au, Au over Ni

MATERI

©2020 Materion Brush Inc.

Computers and Electronic Devices



Application: Backplane, Midplane and Card Edge Connectors

Design Requirements:

- Matched impedance path
- Low inductive or capacitive parasitics
- Low insertion loss
- Low reflection loss
- Mechanical stability
- Thermal stability

Necessary Material Attributes:


- Yield strength
- Stress relaxation resistance
- Conductivity

Materion Base Metal Solution:

- Brush® 60 strip
- 190 strip
- 390 strip

Materion Surface Coating Solution:

- Au over Ni



Application: Electromagnetic Shielding Gaskets

Design Requirements:

- Maintain seal
- Maintain normal force
- Block electromagnetic radiation

Necessary Material Attributes:

- Elastic resilience
- Corrosion resistance

Materion Base Metal Solution:

- 25 strip
- 190 strip
- BrushForm® 158 strip

Materion Surface Coating Solution:

- Typically bare



Application: I/O Connectors

Design Requirements:

- Cycle life
- Mechanical stability
- Repeatable insertion/withdrawal forces

Necessary Material Attributes:

- Wear resistance
- Elastic resilience
- Formability
- Fatigue strength
- Conductivity

Materion Base Metal Solution:

- 25 strip
- 190 strip
- BrushForm® 158 strip

Materion Surface Coating Solution:

- Au over Ni

MATERI

©2020 Materion Brush Inc.

Industrial Components



Application: Fire Protection Sprinkler Head Washers

Design Requirements:

- Corrosion resistance
- Mechanical stability
- Decades-long life

Necessary Material Attributes:

- Elastic resilience
- Corrosion resistance
- Stress relaxation resistance

Materion Base Metal Solution:

- NiBe strip

Materion Surface Coating Solution:

- Typically bare or coated with PTFE



Application: Pressure Sensor Bellows

Design Requirements:

- Stable & predictable spring rate

Necessary Material Attributes:

- Elastic resilience
- Corrosion resistance

Materion Base Metal Solution:

- Alloy 25
- BrushForm® 158 strip

Materion Surface Coating Solution:

- Typically bare



Application: Pressure Sensor Diaphragms

Design Requirements:

- Stable & predictable spring rate

Necessary Material Attributes:

- Elastic resilience
- Corrosion resistance

Materion Base Metal Solution:

- Alloy 25
- BrushForm® 158 strip

Materion Surface Coating Solution:

- Typically bare

MATERION

©2020 Materion Brush Inc.

Smart Phones & Mobile Electronics




Application: Audio Jack Contacts

Design Requirements:
- Wear resistance
- Retaining force

Necessary Material Attributes:
- Elastic resilience
- Formability
- Fatigue strength
- Wear resistance

Materion Base Metal Solution:
- 290 strip

Materion Surface Coating Solution:
- Au over Ni




Application: Battery Contacts

Design Requirements:
- Mechanical stability
- Electrical stability
- Low resistance

Necessary Material Attributes:
- Elastic resilience
- Conductivity
- Fatigue strength

Materion Base Metal Solution:
- 290 strip
- Brush® 60 strip
- 390/390E® strip

Materion Surface Coating Solution:
- Au over Ni



Application: Board to Board Connectors

Design Requirements:
- Maintain matched impedance path
- Mechanical stability
- Impact resistance

Necessary Material Attributes:
- Elastic resilience
- Formability

Materion Base Metal Solution:
- 25 strip
- 290 strip
- Brush 60 strip
- 390/390E strip

Materion Surface Coating Solution:
- Au over Ni

MATERI

©2020 Materion Brush Inc.



Application: Ground Clips

Design Requirements:

- Mechanical stability in small size
- Maintain electrical continuity

Necessary Material Attributes:


- Elastic resilience
- Formability
- Conductivity

Materion Base Metal Solution:

- 25 strip
- 190 strip
- 290 strip

Materion Surface Coating Solution:

- Typically bare



Application: SIM Card Contacts

Design Requirements:

- Wear resistance
- Mechanical stability

Necessary Material Attributes:


- Elastic resilience

Materion Base Metal Solution:

- 290 strip

Materion Surface Coating Solution:

- Gold over Nickel



Application: Voice Coil Motor (VCM) / Optical Image Stabilization (OIS) System Springs

Design Requirements:

- Rapid damping
- Impact strength to survive drops/ impacts
- Stiffness

Necessary Material Attributes:

- Elastic resilience
- Elastic modulus

Materion Base Metal Solution:

- 190
- BrushForm® 158 strip

Materion Surface Coating Solution:

- Typically Bare

MATERI

©2020 Materion Brush Inc.

Telecom Infrastructure



Application: Modular Jack Contacts

Design Requirements:

- Mechanical stability
- Cycle life
- High strength (particularly pins 1 & 8)

Necessary Material Attributes:

- Elastic resilience
- Formability
- Fatigue strength

Materion Base Metal Solution:

- 190
- 290 strip
- 25 wire

Materion Surface Coating Solution:

- Au over Ni

Telecom Infrastructure



Application: RF and Coaxial Connectors

Design Requirements:

- Mechanical stability

Necessary Material Attributes:

- Elastic resilience
- Formability/machinability
- Fatigue strength


Materion Base Metal Solution:

- 25 & 190 strip
- BrushForm® 158 strip
- 25 & M25 wire

Materion Surface Coating Solution:

- Au
- Au over Ni

Medical



Application: Circular Locking Connectors

Design Requirements:

- Mechanical & electrical stability
- High reliability
- High cycle life
- Sterilizable in an autoclave

Necessary Material Attributes:

- Elastic resilience
- Formability
- Fatigue strength

Materion Base Metal Solution:

- Strip
- Wire

Materion Surface Coating Solution:

- Au over Ni

MATERION

©2020 Materion Brush Inc.

Photovoltaic System Connectors



Application: Circular Connectors

Design Requirements:

- Mechanical & electrical stability
- High temperature resistance

Necessary Material Attributes:

- Elastic resilience
- Conductivity
- Stress relaxation resistance


Materion Base Metal Solution:

- 25 strip,
- 25 wire,
- ToughMet® 3 wire

Materion Surface Coating Solution:

- Silver
- Gold over Ni

High Pressure, High Temperature (HPHT) Connectors



HPHT Connectors are used in downhole drilling applications. According to the American Petroleum Institute (API), HPHT environments are those in which the pressure is greater than 15,000 psi (103.43 MPa), and/or the temperature is higher than 350°F (177°C).

Application: HPHT Downhole Electrical Connectors

Design Requirements:

- Corrosion resistance
- High temperature resistance
- Vibration/impact resistance

Necessary Material Attributes:

- Elastic resilience
- Corrosion resistance
- Stress relaxation resistance
- Fatigue strength

Materion Base Metal Solution:

- Alloy 25, BrushForm® 158, and NiBe strip for stamped contacts.
- Alloy 25, ToughMet® 3 rod for machined contacts.

Materion Surface Coating Solution:

- Gold over Ni

MATERION

©2020 Materion Brush Inc.

Section III: Design Challenges and Industry Trends

In applications spanning the aerospace, automotive, computer, electronics, medical and telecommunications industries, material selection has emerged as the most critical task facing the connector designer today. Within these industries, a number of trends have emerged that drive connector requirements.

Connector Requirement Drivers

Industry trends can be both technology and market driven. Examples of technology driven trends are miniaturization, higher pin counts, faster operating speeds, higher operating temperature and so forth. Market driven trends include lower price and shorter development cycles. The following list contains examples of both.

Technology Driven:

- **Miniaturization** – Decreased volume for packaging dictates smaller centerline spacing, tighter tolerances and lower profiles that drive the need for smaller contacts and thinner strip material.
- **Reduced Insertion Force** – Ergonomic regulations dictate that connector mating forces should not exceed a maximum level (30 N for wire cross sections less than or equal to 2.0 mm^2 or 75 N for wire cross sections greater than 2.0 mm^2) for automotive connectors per SAE/USCAR-2 Revision 6 at the time of this writing).
- **Lower Normal Force** – Due to the limited deflections available in many new connector designs, and the desire for lowered engagement forces, the contact normal forces are being lowered while still requiring equivalent reliability.
- **Higher Pin Counts** – Higher levels of integration have increased the density of connectors up to and exceeding 100 contacts per inch and greater than 1000 contacts per connector. As chips shrink and gain processing power in accordance with Moore's law, the number of interconnects increases while size and pitch decrease.
- **Faster Operating Speeds** – In order to operate at higher speeds, connectors require minimized signal path length and matched impedance to the circuit, as well as adequate grounding, bonding and shielding.
- **Higher Operating Temperatures** – Increased power requirements and harsher operating environments drive higher operating temperatures as electronics usage penetrates more industries.
- **Surface Mount Soldering** – The connector supplies more mechanical support for the solder joint as the percentage of surface mount components is increasing per circuit board.
- **Lead-Free Soldering** – Newer lead-free solders flow at higher temperatures.
- **Less Conservative Designs** – The greater predictive ability through the use of Modeling and Finite Element Analysis is allowing designers to decrease the design safety factor with more confidence.
- **Higher Voltages** – After years of operating with 12 V platforms in their electrical systems, newer cars are operating at much higher voltages, with dual 12 and 48V platforms for internal combustion engines, up to 200-300 V for hybrid electric vehicles and up to 500-600 V for pure electric vehicles.
- **Integrated Electronics** – Some connectors now include active or passive circuit elements to control electromagnetic interference, or to convert back and forth between electronic and optical signals.
- **Built-In Shielding** – Many backplane connectors now have integrated shielding to keep the individual circuits electrically isolated and properly grounded.
- **Active Cooling And Heat Dissipation** – Some connectors contain channels to allow air to flow through in order to minimize temperature rise and keep the connector cool.

Market Driven:

- **Shorter Development Cycles** – The marketplace requires new products in increasingly less time, requiring shorter product development cycles. Shorter equipment life cycles also drive shorter development cycles.
- **Greater Durability and/or Ruggedness** – Some connector applications require up to 10,000 insertion cycles in their lifetime. Others may be used in high temperature, high vibration and/or corrosive environments.
- **Lower Power Consumption** – Consumers are looking for increasing battery life and less frequent charging in electronic devices (including electric vehicles).
- **Lower Price** – Industry competitiveness is forcing the price of the final product lower thereby driving the cost of components such as connectors lower.
- **Premium Pricing** – In contrast to most consumer electronics and commodity items, consumers have demonstrated willingness to pay premiums for high quality devices, such as $500 smart phones or luxury automobiles loaded with the latest electronic features, but expect and demand reliability and longevity in return.
- **More Features** – An expectation of an ever-increasing number of features in devices has created a demand to put more functionality into ever-shrinking spaces.

In many connector applications, the reconciliation of such diverse performance, manufacturing, quality and cost parameters prove to be a function of the contact material. In such instances, the success of connector design hinges on the designer's ability to specify the connector materials (base metal, surface coating, housing, dielectrics, etc.) providing optimum performance, ease of manufacturing and cost effectiveness.

©2020 Materion Brush Inc.

Market Segment Trends

A number of new technologies will be driving the electronics related industries in the early part of the 21st century. All of these trends have implications for connector design engineers. Existing applications and designs may be rendered obsolete, but there are plenty of new challenges and opportunities on the horizon.

Automotive:

- **Increasing Automotive Electrification** – More electronic devices requires higher power/voltages/current levels to run everything, increasing the temperature rise in connectors. Furthermore, more circuits must be passed through connectors, requiring smaller contacts spaced more tightly together, which in turn need higher stress levels to generate adequate electrical contact.
- **Automotive Light-Weighting/ Increasing Fuel Efficiency Standards** – Lighter weight cars mean less mass above the suspension, increasing the severity of shock and vibration transmitted through the suspension (and into the connectors). More sensors and electronic controls may be required to optimize combustion and fuel efficiency.
- **ADAS (Advanced Driver Assistance Systems) and Sensor Fusion** – These systems require an ever increasing number of sensors on each vehicle, as well as the electronic control units to process the information obtained. Connectors (particularly RF connectors) are required to network these devices together.
- **Autonomous Vehicles** – As with ADAS, requires additional cameras, sensors, vehicle to vehicle communication capability, and the additional control units to process the vast amounts of data generated.
- **Vehicle-to-Vehicle (V2V) and Vehicle to Infrastructure (V2I) Communication** – Vehicles will need to be able to communicate the driver's (human or otherwise) intent, road conditions, and obstacles to other vehicles and the surrounding infrastructure, and must be able to receive the same information in return from surrounding vehicles and infrastructure.
- **Automotive Sensors and Cameras** – Autonomous or not, vehicles need to detect potential hazards in their environment. Human drivers are limited to hearing (when not drowned out by ambient noise or the entertainment system) and vision (which is at the mercy of the weather and lighting conditions). Vehicles can also use RADAR, LIDAR, Infrared, Ultrasound, GPS signals, etc. in addition to visible light to determine the relative positions and velocities of themselves, other vehicles, the road, pedestrians, animals, ice, snow, standing water, other potential hazards, and the environment.
- **Advanced Driver Interfaces** – Future cars will see augmented reality and head-up displays, and will feature voice recognition and gesture recognition. Many more processors and electronic control units will be required to operate these devices, all of which must be connected together in high vibration environments.
- **Automotive and Consumer Electronics Convergence** – Consumers are expecting their vehicles to have seamless integration with their smart devices, or to at least exhibit some of the same functionality. This means that vehicles will function as WiFi hotspots, and will have more advanced infotainment options such as streaming video to the back seats.
- **EVs and HEVs** – Electric vehicles and hybrid electric vehicles operate at much higher voltage than those with traditional internal combustion engines. Wire harness terminal connectors need to function at higher voltages, currents, and temperatures. Additionally, pure EVs would need to be plugged into the grid to charge their batteries, requiring additional custom connectors to enable fast charging.
- **Fuel Cells and Hydrogen Infrastructure** – As with electric vehicles, fuel cells require high conductivity connectors to carry the high currents, and would need to operate at very high voltages.

Consumer Electronics:

- **Wearable Electronics** – Most wearable electronics would require some kind of battery, i/o device or button. High fatigue strength would be required for the button, and wear resistance for any i/o connectors.
- **Implantable Electronics** – Any parts on the outside of the devices would have to be biocompatible. The electronics on the inside would have to be highly reliable for extended periods of time. Any interconnects would require high impact strength, high yield strength, and great stress relaxation resistance.
- **Miniaturization of Electronic Devices** – When there is less room for electrical contacts, they must be made smaller. With less material available to create and maintain the required contact force, the design stresses must be made greater, requiring higher strength. Additional conductivity is required for power connectors with smaller cross sectional areas to carry the current.
- **Gesture Control of Electronic Devices** – Requires sophisticated optics and a lot of connected processing power to process the images.
- **Smart Devices** – There will be a proliferation of smart phones, smart watches, smart televisions, smart paper, flexible displays, etc. They will require battery contacts, board to board contacts, and perhaps some i/o connectors as well. Smart devices currently are premium devices, which demand high reliability in components.
- **Higher Data Rates/Streaming Content** – An ever increasing amount of data traffic and demand for faster downloading times has driven the need to continuously improve the rate of data transfer. This means connectors must be rated to higher frequencies, whether they are input/output connectors on the device or between components within the device.

©2020 Materion Brush Inc.

- **Pico Projection** – These devices will need to draw enough power to allow for bright image displays in rooms that are not totally dark. This requires conductivity in the contacts delivering this power.
- **4G, LTE, 5G, Small Cells Deployment** – Future mobile wireless communication networks will rely on higher data transfer rates and an increasing number of smaller cells to maximize coverage in congested areas. The networks will also require high frequency connectors between the antenna, the electronics, and the network.
- **Gaming** – Contacts in hand-held controllers (if not supplanted entirely by gesture recognition control) would need to be robust to withstand high accelerations and impacts. This requires high yield strength.
- **Near Field Communication (NFC)** – Advances in near field communication would result in lower need for i/o connectors, although repeatedly tapping devices together to exchange information or make payments may require more fatigue and vibration resistance in components within these devices.

Advanced Materials and Production Technology:

- **Advanced Materials** – The early 21st century has already seen many advances in materials, including smart coatings, self-healing materials, self-cleaning materials, nanostructured materials, nanotextured surfaces, metamaterials, and materials with embedded sensors. Programs such as the Materials Genome Initiative will ensure that there are many more materials to choose from, with properties and property combinations previously unimaginable. There will probably also be new manufacturing methods introduced, which may reduce the cost of manufacturing connectors.
- **MEMS and Nanotechnology** – MEMS (micro electrical mechanical systems) devices must be made from very uniform materials in very small quantities. Surface characteristics may be altered by the use of nanoscale texturing, or by surface coatings built up atom by atom.
- **3D Imaging** – For computers to "understand" 3D objects in 3D spaces requires a lot of image processing power. These distributed image processors must be tied back to the central processor, most likely via cables and connectors.
- **Additive Manufacturing/3D Printing** – 3D printing cannot currently be used to print metallic contacts, as it is currently not possible to replicate the cold work and bulk thermal processing required to obtain good properties in metal. It might be put to good use in generating complex shapes for connector housings, however.
- **The Internet of Things/Internet of Everything** – Sensors will be everywhere, and many of them will require connectors. There will be an explosion of devices requiring processors, all of which will have to be burned in and tested.

Energy:

- **Energy Production** – Oil and gas reserves are now found in increasingly hostile environments. Exploratory drilling equipment features highly sophisticated electronic measuring equipment that must be connected in high pressure, high temperature (HPHT), corrosive environments. This requires corrosion resistance, high impact strength and fatigue strength, and exceptional stress relaxation resistance.
- **Distributed Energy Production and Storage** – An increasing proportion of energy production will be occurring at widely distributed sites, in the form of wind, solar, tidal, hydroelectric, geothermal, nuclear, 3rd and 4th generation nuclear, or mini-nuclear power sources. Some of these sources produce less consistent power than others, which would necessitate batteries for energy storage, and careful voltage regulation and transformation to meet the demands of the grid. Conductivity would be required for power connectors, and strength for the connectors used for the necessary electronics in unforgiving environments.
- **The Smart Grid** – The smart electrical grid requires sensors and measurement equipment at generation, use, and distribution sites, as well as some means of conveying these measurements back to central processing units, with the goal of balancing production and usage in a stable, reliable manner. Connectors are required for the sensors and any distributed processors.
- **Energy Harvesting** – A number of smaller devices will generate at least some of their power by harvesting energy from the environment, typically by piezoelectric generation current from vibration and acceleration.
- **Solid State Lighting** – Solid state lighting is more energy efficient than incandescent or fluorescent, provided that adequate cooling is provided to remove excess heat. Connectors would require higher conductivity to minimize resistive heating, and close proximity to the LEDs would require stress relaxation resistance and elevated temperature strength.
- **Wireless Power & Charging** – Whether through induction or electromagnetic resonance, wireless transfer of power would reduce the need for traditional external power connectors.

©2020 Materion Brush Inc.

Lifestyle:

- **Smart Homes** – Smart homes would require many connected meters and sensors, high speed wireless networking, as well as actuators that can remotely turn lights on/off, lock/unlock doors, adjust the thermostat, etc. via a smart phone or similar interface.
- **Big Data/Cloud Storage** – Great amounts of data stored in the cloud would require a large number of server farms, generating lots of waste heat. These servers would need to be connected by card to card or backplane connectors, which require high conductivity to minimize temperature rise, good formability and high strength to fit many in a small space, and stress relaxation resistance to maintain contact force for long times at elevated temperatures.
- **Robotics** – Robots for home use are becoming increasingly popular, and are being used as ways to automate tedious tasks such as cleaning the floor, mowing the lawn, or clearing the rain gutters. They all require sensors and optical processors so the robot knows where it is at all times, where it needs to go next, and how to maneuver around obstacles.
- **Digital Health Care & Remote Health Monitoring** – Doctors will be able to diagnose and treat patients remotely, perhaps even in their own homes. This would require inexpensive home monitoring equipment, complete with adequate sensors and connectivity.
- **Medical Connectors** – Aging populations are driving an increase in the need for medical devices. Connectors for medical device are also increasingly being designed with multiple functions, often transferring fluids as well as signal and power, requiring better sealing technology.
- **Smart Cities** – Smart cities would have ubiquitous high bandwidth internet and cellular connectivity, as well as real-time monitoring of automotive and pedestrian traffic. Sensors and transceivers would be everywhere to provide seamless coverage and monitoring, and all these devices would need to be connected to the appropriate networks and power supplies somehow.
- **Civilian Unmanned Arial Vehicles (Drones)** – Drones may theoretically be used for delivering anything from packages to pizza; for deploying pesticides or fertilizer; for inspection of bridges, buildings, and power lines; or for personal photography and video recording. Connections are required between the electronics and the control surfaces, camera, navigation systems, etc.

Semiconductor Test:

- **Burn-in & Test Sockets** – The coming proliferation of smart devices and smart environments means nonlinear rates of growth in semiconductor production, which will need to be tested and burned in.
- **Test Probes** – As the number of semiconductors booms, increased amounts of testing at the wafer level will be required to handle the greater production volume.

MATERION

©2020 Materion Brush Inc.

Section IV: Requirements Placed on Connectors

The applications for high performance copper alloys encompass the full range of electrical-electronic connectors and interconnections. A connector must provide mechanical and electrical contact between two elements of an electronic system without unacceptable signal distortion or power loss. Depending on the requirements of a given application either performance or manufacturing considerations will assume primary importance. However, it is the total combination of properties that ultimately dictates alloy selection. Connector requirements break down into seven distinct categories. These are mechanical, electrical and thermal, system, materials, processing, environmental and regulatory. The first five are covered in this chapter, while environmental and regulatory requirements are covered in Section XI.

Mechanical Requirements

Contact Theory

In order to understand the mechanical requirements of a connector system, one must understand how contact is made. When two surfaces are brought into contact under pressure, they deform, resulting in an apparent area of contact. (Figure IV-1) Contact theory states that real surfaces are not perfectly smooth but consist of high regions (asperities) and low regions. Local regions of metal-to-metal contact are made when two conductive surfaces mate under sufficient load. Contact regions are where asperities from both surfaces touch, also known as A-spots (Figure IV-2). The number, density and size of these A-spots vary. Their characteristics depend on the load applied, surface hardness, surface geometry and the physical characteristics of oxide or contaminant films present on the surfaces. The sum of A-spot areas is the effective contact area.

Figure IV-1 Deformation Under Pressure of Two Surfaces in Contact




Figure IV-1 – Deformation Under Pressure of Two Surfaces in Contact
When two surfaces come into contact, the initial contact area is very small. As the surfaces deform to accommodate each other, they form an apparent area of contact. In the case above, two spheres held together under pressure show an apparent circular area of contact between them.

Figure IV-2 Deformation Under Pressure of Two Surfaces in Contact




Figure IV-2 – Contact Theory
All surfaces are rough on the microscopic scale, with lots of peaks and valleys. When two surfaces touch each other, contact only occurs at the highest peaks, called asperities, or A-spots. So, no matter what deformation is occurring on a macroscopic scale, on a microscopic level the contact is only occurring at the asperities. This means that the actual area of contact may be as low as 5% of the apparent contact area.

MATERION

©2020 Materion Brush Inc.

Contact (Normal) Force

Contact force, P, is the load generated between two surfaces in contact. The force is perpendicular to the interface of the two surfaces, hence its other name, normal force. Maintaining a constant normal force is a direct indicator of the ability of a spring contact to maintain electrical integrity. A sufficiently large spring force (normal force) establishes the gas-tight interface between contact surfaces thus preventing corrosive contaminants from penetrating or forming between interfaces causing electrical instability. Section IV-Material Properties discusses this critical property of connector design in greater depth.

Contact Geometry

High contact stress geometries aid in maximizing the effective contact area for a given load condition. This contact stress, generated by the localized deformation of the two surfaces in contact, is called the Hertz stress. These calculations were originally developed by Heinrich Hertz to describe the contact footprint and subsurface stresses in a bearing system. The predicted Hertz stresses were useful in determining whether the contact surfaces in the bearing would be subjected to cracking, pitting and spalling. In connector applications, it is not the subsurface stress, but the contact footprint that is of interest. For a given force load, a geometry that produces a smaller contact footprint will have higher contact pressure, producing more ability to wipe away or break through oxides or surface contaminants, resulting in a lower contact resistance.

Figure IV-3 Geometry and Hertzian Contact Stress




Figure IV-3 – Geometry and Hertzian Contact Stress
The sphere on flat and crossed cylinder configurations both share a small contact area (a theoretical point contact). The cylinder on flat configuration is a theoretical line contact, while flat on flat is a theoretical area contact. Smaller contact areas result in higher pressures and stresses at the contact interface, leading to localized deformation that allows the contact area to expand.

Preferred geometries in order of decreasing contact (Hertz) stress are sphere on flat, crossed cylinders, cylinder on flat and lastly flat on flat (Figures IV-3, IV-4, and IV-5). This is why many contact springs have spherical or cylindrical embossments on the contact surface. For a detailed discussion of Hertz stress, please refer to the following papers:


Kantner, E. A. and Hobgood, L. D., "Hertz Stress as an Indicator of Connector Reliability," *Connection Technology*, March, 1989 pp 14-22.

Fluss, H. S., "Hertzian Stress as a Predictor of Contact Reliability," *Connection Technology*, March, 1989 pp 14-22. December, 1990 pp 12-21


Mroczkowski, Robert, "Concerning Hertz Stress as a Connector Design Parameter," *Proceedings of the 24th Annual Connector and Interconnection Technology Symposium* October, 1991 pp 327-337

©2020 Materion Brush Inc.


Figure IV-4 Contact Stress Distribution




Cylinder on Flat



Sphere on Flat



Crossed Cylinders



Flat on Flat

Figure IV-4 – Contact Stress Distribution
This is a representation of the stresses in the contact areas as calculated by finite element analysis. In the images on the right, high stress areas are in red and low stress areas are in blue. On the left side, high stress areas are in blue and low stress are in red. The sphere on flat configuration in the upper right and the crossed cylinders on the bottom left show the highest contact stress (and most deformation), while the flat on flat configuration on the bottom right shows the least.

Figure IV-5 Effect of Contact Profile on Contact Pressure




Figure IV-5 – Effect of Contact Profile on Contact Pressure
There are ways to use the contact profile to locally increase the contact stress on connectors, usually by stamping embossments in the contact area. The configuration on the left approximates the cylinder on flat line contact, while the other two approximate the point contact of sphere on flat.

Insertion & Extraction Forces

The force required to mate and unmate two connectors is the insertion and extraction forces respectively. Do not confuse these forces with contact force. The insertion and extraction forces are proportional to the normal force and the coefficient of friction. Wear concerns, contact force, number of contact points, coefficient or friction, lead-in angle of the mating part and design requirements determine the allowable number of insertion cycles. Ergonomic issues during mating and assembly determine the total mating force. Connector mating forces of more than 50 to 75 N (11 to 17 lbs) often require mechanical aids, and are frequently specified by governments as the maximum permissible insertion force for manually mated connectors. Lubrication lowers the insertion force and inhibits oxidation and corrosion. Non-sulfur containing lubricants are a requirement. The high temperature stability of the lubricant also is a consideration. (Section VII-Materials for other Connector Components contains more information on connector lubricants.)

©2020 Materion Brush Inc.

Electrical Requirements

Connector Resistance

The contact resistance of the separable or non-separable interfaces and the bulk resistance of the contact spring comprise the total connector resistance.

Figure IV-6 Contact Resistance




Figure IV-6 Contact Resistance
Bulk resistance is the overall resistance of the metal in the contact. Constriction resistance occurs as the electrical current must squeeze through the asperities to cross the interface. (A smaller cross sectional area for the current to flow through means greater resistance.) Film resistance is created by thin layers of oxides and other contaminants that form on material surfaces. These have higher resistivity which requires more effort for the signal to travel through the film. The overall resistance is the bulk resistance in series with the interface resistance. The interface resistance is the sum of all the constriction and film resistances in parallel.

Contact Resistance

Contact resistance is the electrical resistance of the interface between the two surfaces in contact. It is influenced by normal force, geometry, physical properties, and corrosion resistance of the contacting surfaces. Contact resistance further breaks down into constriction resistance and film resistance (Figures IV-6 and IV-7).

Figure IV-7 Contact Resistance




Figure IV-7 Contact Resistance
These are the classic formulas derived by Ragnar Holm for calculating the various resistances. Mostly they are functions of the normal force and the hardness & resistivity of the contact surfaces. Higher forces and softer interface layers decrease the resistance, although softer interface layers may be prone to wear and other problems.

©2020 Materion Brush Inc.

Contact resistance is independent of contact size and is dominated by the constriction resistance of tiny areas of A-spots. The film resistance is due to thin layers (as low as 20 angstroms) of insulating material between the contacts, caused by oxidation of the contact material or other contamination. These thin films conduct electrons by means of the tunneling effect. Both constriction and film resistance depend on the normal force and hardness of the contacting materials. Figure IV-8 shows the relationship between contact force and contact resistance. As the normal force increases and the surfaces come closer together, the contact stress increases, further deforming the asperities in contact and enlarging the contact area. Additionally, progressively smaller asperities also come into contact, further increasing the number of contact points. The magnitude of the separable contact interface resistance is a few milliohms.

Figure IV-8 Increased Contact Area as Normal Force Increases




Figure IV-8 Increased Contact Area as Normal Force Increases
As two surfaces approach each other, initial contact is made at very few asperities. As the contact pressure increases and the surfaces are brought closer together, two things happen. First, the contact area of the asperities that are touching widens, reducing constriction resistance. Secondly, additional asperities come into contact, providing additional parallel paths for the current to flow along, further reducing the contact resistance.

Figure IV-9 Required Contact Force Calculation

Figure IV-9 shows the equation derived by Holm for determining the minimum required contact force, based on the properties of the plating and the maximum permissible contact resistance. However, it is much more common to specify a required normal force for each different type of plating, cladding, or other surface treatment.

$$F = \frac{\pi \cdot H \cdot \rho_{Plating}^2}{4 \cdot R_{Constriction}^2} + \frac{\rho_{Film} t \cdot H}{R_{Film}}$$

H = hardness
t = film thickness
ρ = resistivity
R = resistance

R_c < 1 mΩ (for stability)*
R_c = 3 mΩ (maximum allowed)**

* M. Peel
* R Holm
** J.H. Whitley & R. D. Malucci

Figure IV-9 Required Contact Force Calculation
J. H. Whitley and R. D. Malucci came up with this formula based on the work of Max Peel and Ragnar Holm, for describing the required minimum contact force as a function of the various resistances.

©2020 Materion Brush Inc.

Key Points about Connector Design and Reliability

1. Contact performance is determined by low and stable contact resistance.
2. Low contact resistance is provided by contact force.
3. Contact force is determined by connector design and material properties.
4. Sufficiently high and consistent contact force provides low, stable resistance, which ensures reliability. The designer must prevent loss of contact force and/or ensure adequate contact force at the end of the connector's life.
5. The interface material (plating or other coating) determines the required minimum contact force; the spring alloy provides and maintains that contact force.
6. The important spring properties for contact performance and reliability are: strength, stiffness, stress relaxation resistance, and electrical conductivity.

Figure IV-10 shows the effect of normal force on contact resistance, in this case, for a gold-on-gold contact system. Figure IV-11 illustrates the importance of not only providing sufficient normal force, but keeping it stable which is also critical to reliability.

Sources of Contact Resistance Instability

- Stress relaxation due to ambient temperature and ohmic heating
- Permanent set due to high deflection, shock / impact loads, creep of housing materials, thermal expansion
- Corrosion in any of many forms such as atmospheric, galvanic, pore, fretting, arcing
- Surface contamination from wear debris, dust, frictional polymerization, lubricant degradation, polymeric condensation, flash
- Plating failure due to wear, diffusion of base metal, formation of intermetallic phases, delamination, pore corrosion
- Intermittent contact from thermal expansion mismatch, environmental vibration, shock loading, etc.

Figure IV-10 Contact Resistance vs. Contact Force




Figure IV-10 Contact Resistance vs. Contact Force

The bulk resistance is the resistance of all the components in a connector system. It is the minimum possible resistance of the system, if there were perfect metallurgical contact at the interface, without any void space or insulating films between the two surfaces. At very low contact forces, just beyond open circuit, it is the resistance of the insulating films on the surface that dominate. When the contact force increases such films are wiped away and as the asperities begin to mate, constriction resistance dominates. At sufficiently high contact forces, constriction resistance is minimized, and it is physically impossible to bring the surfaces any closer together, the resistance is low and stable near the bulk resistance.

Figure IV-11 Contact Resistance and Stability




Figure IV-11 Contact Resistance and Stability

No two electrical contacts are exactly the same. There will always be manufacturing variations around the nominal specification. An electrical contact design that has an initial contact force normally distributed around point "A" would have some reliability problems. Some such contacts would show low resistance, some would show higher resistance, and some would be open circuit. Any small decrease in contact force would result in an increase in contact resistance and greatly increase the probability of failure. Meanwhile, another design with a contact force distributed around point "B" would be far more reliable. The initial contact resistance would be low and stable for all contacts, and small decreases in contact force would have very little effect on contact resistance.

©2020 Materion Brush Inc.

Power Properties

Bulk Resistance – The contact spring bulk resistance is dependent upon the conductivity (resistivity) of the base material and its geometry. The magnitude of the spring bulk resistance is typically a few to tens of milliohms. The bulk resistance does not change, unless the conductivity of the metal itself changes (either by temperature dependence or metallurgical transformation.)

Current Capacity (Ampacity) – This is the maximum current allowed for a given temperature rise. Higher conductivity base material allows greater current flow with lower temperature rise. The current capacity of a connector is dependent on the contact material, geometry and normal force.

More detailed information on power properties can be found in Section VIII – Higher Voltage, Current, and Power Considerations

Signal Properties

One of the functions of a connector is to maintain electrical contact without unacceptable signal distortion. Connector signal properties are important for low current, high frequency signals. A listing of a few signal properties appears below.

Attenuation – Reduction in strength of a signal due to resistance, parasitic coupling, radiated emissions, or reflection. It is typically measured in decibels.

Signal Integrity – The ability of a connector to transmit a signal with no more than the maximum acceptable amount of signal degradation. An ideal connector would be completely transparent to the signal passing through it.

Signal to Ground Ratio – The ratio of signal pins to ground pins in a connector. This ratio is useful in determining connector "noise."

Impedance – The ratio of voltage to current of an electrical signal propagating through a circuit component. It consists of energy lost as heat through resistance (proportional to current/voltage), as well as energy stored in electric fields by capacitance (proportional to changes in voltage) and in magnetic fields by inductance (proportional to changes in current).

Delay – The signal delay caused by the connector capacitance or the propagation time along the path. Reduced connector length reduces the propagation delay.

Insulation Resistance – The resistance to current flow through an insulator under an applied potential. The measured resistance value is in Mega ohms on the housing material or wire insulation.

Dielectric Strength (Withstanding Voltage) – The highest potential difference (voltage) that an insulating material of given thickness can withstand for a specified time without the occurrence of electrical breakdown through its bulk. The measured voltage value is on housing materials and wire insulation.

Insertion Loss – The attenuation of a signal due to the presence of an electrical connector, compared to a theoretical unbroken path among the circuit elements.

Scattering Parameters (S Parameters) – A measure of the effect that a connector has on the overall electrical circuit, by relating the signals reflected and transmitted by the connector to the original signal entering the connector. The S-Parameters can be calculated by a finite element model of the connector, and then input into circuit simulation software to determine how well the connector transmits the input signal without altering it.

More detailed information on signal properties and electromagnetic compatibility (EMC) can be found in Section IX – Electromagnetic Compatibility, Signal Integrity, and other High Frequency Considerations

System Requirements

Reliability

The reliability of a system is dependent on the failure rate of its components. Reliability can be measured as the proportion of items not failing from a group, or the probability that an item will function without failure over a stated time period starting at time zero. Failure rates define reliability. The failure rate is the rate at which devices from a given population can (or were found to) fail as a function of time (for example, %/1000 hours of operation).

Connectors can fail due to plug dependent mechanisms, wear-out mechanisms or corrosion mechanisms. In this case, failure is defined as a certain percentage of the test population exceeding a specified change in contact resistance (typically 10 milliohms). The total system life or power-on-hours (POH) and the on/off cycles or number of times that a product powers on and off are important factors determining system reliability. A wiping connector with multiple contact points improves a connector's reliability. Wipe is a requirement to break through oxide films and displace contaminants during insertion. Redundancy decreases the probability of contamination affecting all contact points simultaneously. Stress (environmental) tests predict the product's performance in the field under the anticipated operating conditions.

Cost

Cost analysis determines the overall cost of the connector versus an alternate solution or, the cost of a connector using various base metals, plating, and housing materials. The connector cost analysis also evaluates the various materials versus the performance of the material. Section XVII – Cost Effective Material Use contains additional comments on cost.

Package Envelope

The system determines the overall size allowed for the connector (length, width, height) in the package. As the volume available for connectors decreases, the grid or contact spacing per inch decreases, requiring the material to become thinner and stronger. The tolerances required on the connectors also tighten. Guidance features prevent misalignment and overstressing of the contacts during mating. Positive retention features in the housing prevent disconnection instead of relying on the contacts to provide all the retention.

MATERION

©2020 Materion Brush Inc.

Standard and Specifications

Customer and industry driven specifications or standards determine many of the functional requirements of a connector. In addition, they specify the performance tests for qualification of the connector. Some examples include:

- SAE/USCAR specifications such as SAE/USCAR-2 managed by the US Center for Automotive Research / Electrical Wiring Component Applications Partnership (EWCAP)
- IPC specifications such as J-STD-002 managed by IPC Association Connecting Electronics Industries
- MIL specs such as MIL-STD-202 managed by the US Department of Defense
- TIA standards such as TIA-568 managed by the Telecom Industry Alliance
- JEDEC Standards managed by JEDEC Global Standards for the Microelectronics Industry
- NEBS requirements managed by iconectiv (formerly Telcordia, formerly Bellcore)

Material Requirements

Several attributes are desirable in connector materials:

- Low contact and bulk electrical resistance to meet circuit requirements
- Matched impedance in high frequency circuits
- Corrosion/environmental resistance
- Low friction forces with good wear resistance for repeated reliable insertions
- Adequate spring characteristics
- Dimensional stability
- Low cost

Connector Base Metals

These typically are high performance copper alloys containing a combination of good electrical conductivity and good mechanical spring and forming properties. Proper selection of base materials considers the following:

- Conductivity – minimize bulk resistance
- Ductility – aid in forming the contact
- Yield strength – maximize beam deflections in the elastic range and withstand accidental overstressing
- Stress relaxation resistance – prevent load relaxation with time at constant strain and elevated temperatures
- Hardness – reduce wear of contact metallization
- Elastic modulus – provide adequate contact force and vibration resistance
- Fatigue strength – withstand repeated cycling without fracture

These properties are discussed in more detail in Section V – Connector Base Materials and Their Properties

Connector Interface Materials

This refers to material that is plated, clad, or coated by any other method to the surface of the base metal. This is a crucial consideration, since all electrical contact occurs in this layer. Some properties of interest are:

- Conductivity – minimize contact resistance
- Hardness – harder to resist wear, softer to reduce contact resistance
- Lubricity – reduce wear
- Corrosion/oxidation resistance – reduce chance of contamination of the contact interface

More information on this may be found in Section VI – Connector Interface Materials and Hybrid Solution Technologies

Connector Housing Materials

Housings ensure proper alignment of the pins and sockets, provide the mechanisms for mating the two halves of the connector, and seal the contact region against the environment. Some necessary attributes of these materials would be:

- Dimensional stability – avoid distortion, retain seals
- Electrical insulation – keep currents and signals within the connector body
- Corrosion resistance– do not degrade in the intended environment
- Moldability – for plastic housings
- Machinability – for metal housings
- Yield strength – withstand and correct misalignment when mating

The housing itself may have some additional requirements

- Keying to ensure proper alignment
- Locking features such as bayonets, tabs, or locking levers to ensure retention
- Audible click/tactile feedback to indicate when properly mated
- Full mating when hand-tight on threaded connectors
- In medical connectors, the ability to withstand disinfecting agents or sterilization techniques such as ethylene oxide exposure or autoclave heating

Connector Lubricants

Lubricants reduce insertion/mating force, improve wear resistance, protect against fretting corrosion and improve overall corrosion resistance of the contact interface. Proper choice of lubricant includes:

- Viscosity – optimize frictional behavior
- Wetting characteristics – keep the lubricant from spreading outside of the contact area

Connector Dielectric/Insulator Materials

These are most often found in coaxial, circular, and military connectors. They keep the contacts spaced and electrically isolated from each other.

- Electrical resistivity – prevent current from flowing between contacts
- Dielectric withstanding voltage – keep contacts electrically isolated, even under high voltage
- Dielectric constant – keep low to minimize the parasitic capacitance between contacts

Chapter VII- Materials for other connector components such as connector housing materials, dielectrics, lubricants, and epoxies discuss these in detail.

MATERION

Assembly of Contacts into Plastic Connector Housings

For plastic housings, there are two means of assembling the contacts into the housing. The first is to mold the housing separately, then use a machine to insert the contacts into the housing in a process called stitching. The second is to mold the housing in place around the contacts, in a process called insert molding. The advantages and disadvantages of each are as follows:

Stitched Connectors (Figure IV-12)

- Contacts & housing made separately
- Contacts inserted into pre-existing housing
- Allows for disposal/recycling of faulty housings/contacts
- Held in place by interference fit, as well as barbs and/or notches on side of contact
- Requires strength in plastic to prevent over-stressing during insertion
- May be a looser fit than insert molded

Figure IV-12 Stitched Connector




Figure IV-12 Stitched Connector
The contact is stamped and the housing is molded independently. The contacts are then inserted into the pre-existing housings, and are held in place by an interference fit between the housing and any barbs or tabs on the side of the contact.

Insert Molded Connectors (Figure IV-13)

- Contacts are made first
- Contacts placed in mold, plastic housing molded around it
- Requires precise positioning of contacts in mold during the injection process
- Low margin for molding error
- May provide a tighter fit than stitched connectors
- No mechanical stresses induced in the housing by the contact
- Becoming more cost effective as pitches decrease
- Helps protect interface between dissimilar metals from galvanic corrosion

Figure IV-13 Overmolded Connector




Figure IV-13 Overmolded Connector
The electrical contacts are stamped and left on the reel. The reel is fed through an injection molding machine, which will overmold the housing directly onto one or more contacts as required. The overmolded contacts are then ready for further processing.

MATERION

©2020 Materion Brush Inc.

Mechanical Attachment and Termination Processes

Most of the mechanical methods of attaching components to printed circuit boards or wire replace the solder process. Mechanical connections tend to have higher normal force requirements than separable connections.

Compression Mount Contacts (Figure IV-14)

This method is a separable contact system. Compression type contacts are Z-axis non-wiping connectors that contact two planar substrates. A continuously applied force (such as a spring, wire or elastomer rubber) maintains electrical contact between the electrical path in the connector and a pad on the printed circuit board. Planarity of the two substrates is a critical issue. The spring pressure is maintained by fastening the connector directly to the board, usually with screws.

Figure IV-14 Compression Mount Connector




Figure IV-14 Compression Mount Connector
This may be the simplest termination technique. A compression mount connector will have contacts protruding from the flat bottom surface, which mate with pads on the printed circuit board. The connector is held in place on the board by mechanical fasteners, which provide the load on the spring contacts.

Compliant Pin (Press-Fit) Figure IV-15

A mechanical connection between a compliant pin and plated-through-hole (PTH) is a means of decreasing the process steps in printed circuit assembly. The technology involves pushing a pin or post through a plated-through-hole. The compliant pin contains a section that deforms, conforming to the PTH (Figure 8). This process eliminates the solder process step as well as the pre and post cleaning treatments. A number of material properties are important for this application. The compliant energy of the pin section is important in predicting the reliability of the joint relating to the material's spring properties. The formability of the compliant contact section also is critical. In addition, stiffness is important when inserting the pins into PC boards to prevent buckling.

Figure IV-15 Compliant Pin Connector in Plated Through Hole




Figure IV-15 Compliant Pin Connector in Plated Through Hole
The compliant section is designed to flex and fit into the plated through hole. The compliant section will be compressed by and press outward onto the PTH to maintain electrical contact.

©2020 Materion Brush Inc.

Insulation Displacement (IDC) Figure IV-16

IDC is a method to mass terminate ribbon cable to contacts. Here the contact pierces the cable insulation and makes intimate electrical contact with the conductor in a ribbon cable (Figure IV-16). The yield strength of the material is critical to prevent overstressing during insertion of the conductor and insulation. Stress relaxation resistance over time is important since the normal force is the sole means of maintaining electrical contact. The hardness of the contact edges that penetrate the wire insulation also is a critical factor. Insulation displacement connectors offer a one-piece connector housing with preloaded terminals for high volume manufacturing processes.

Figure IV-16 Insulation Displacement Connector




Figure IV-16 Insulation Displacement Connector

The inside edges of the IDC contact are often coined to be harder and sharper than the rest of the contact spring. These sharp edges will pierce and strip the insulation from the wire as it is fed into the contact. Electrical contact is made as the wire is compressed between the two legs of the IDC. Often, multiple wires are mated into their respective contacts at the same time during one termination operation.

Crimps (Figure IV-17)

The crimp is a method to terminate an individual wire conductor to a contact. A combination of cold welding and spring force provides the electrical and mechanical integrity of crimps. The cold welding results from the deformation of the contact and conductors producing microwelds at the newly extruded film-free surfaces. Several criteria are critical for a gas tight crimp. These are formability and springback as well as strength of the material to deform the wire during crimping. The amount of conductor deformation is critical in producing an effective crimp (Figure IV-18). A second crimp over the conductor's insulation forms a strain relief. Note that the maximum tensile pullout strength of the crimp does not necessarily correlate with the best electrical performance.

Figure IV-17 Crimp Connection




Figure IV-17 Crimp Connection

The wire is laid into the terminal. An automated crimping tool folds the tabs up, over and down into the wire strand section, while the second set of tabs lock onto the insulation, holding the crimp in place. There should be both insulated wire and bare wire visible between the two crimp barrels, and the strands should not be fractured. The barrel should be completely closed around the wire strands, and no strands should be outside the crimp barrel.

Figure IV-18 Crimp Cross Section

Good Crimps (unlike those shown below)

- **Meet the specified crimp height & width**
- **Show deformation of all wire strands**
- **Show little, if any, voids between strands**
- **Show no fracturing of the wire strands**




Figure IV-18 Crimp Cross Section

A good crimp can be determined by looking at the cross section of the crimped area. If all the wires are inside the crimp barrel, and they all show deformation, this is a good indicator that cold welding has taken place in addition to mechanical deformation. Fractured wire strands might indicate a weak pull strength, and voids between the wires could provide sites for corrosion to occur. Worn crimp tooling may lead to incomplete closure of the crimp barrel, or non-uniform deformation of the wires inside (as seen above).

©2020 Materion Brush Inc.

Solder Processes and Surface Mount Technology (Figure IV-19)

A connector typically connects mechanically and electrically to a printed circuit board or other substrate via a solder process. Selection of the best solder process depends on the number, type and complexity of the joints. The following reasons demonstrate why rapid hearing and cooling is the recommendation for all cases:

- High temperature can cause oxidation of the copper alloy substrate
- Fluxes will degrade during prolonged heating
- Overheating may cause metallurgical changes in the copper alloy base metal and can warp the substrate (stress relaxation, heat deflection, instantaneous reduction of strength)
- Excessive heating causes intermetallic compound formation at the solder-substrate interface, leading to a loss in bond strength

The various types of solder processes include manual, wave, vapor phase reflow and infra-red reflow. The following list provides processes in order of increased process temperatures.

- **Manual soldering or hand soldering** uses a soldering iron in low volume operations where rapid heating rates are critical. Dip soldering of prefluxed assemblies requires immersion in a solder pot from a few seconds to several minutes.
- **Wave soldering** involves passing the circuit board across a wave of liquid solder, allowing the solder to wet the joint between the leads and through-hole or bonding pads. The technique usually involves processing steps to apply flux, preheat the board to minimize warpage during soldering, and remove excess solder. Often a solder mask is placed over areas of the PCB where contamination by solder is unwanted. Elevated temperature limits exposure times to a few seconds.
- **Intrusive reflow** uses screen-printed solder paste in the surface mount process to hold a limited number of odd-form through-hole components in place during reflow. The leads of the surface mount components insert into the solder paste, and through-hole leads insert through the paste to hold the component in place during reflow soldering.
- **Vapor phase reflow** uses the condensation of a vapor onto the PCB to heat the solder joint. Vapor phase soldering offers advantages for selective or inaccessible joining operations, since it provides precise temperature control in a contamination-free environment. Solder is a paste or pre-form, and the elevated temperature exposure time varies from 10-180 seconds.
- **IR (Infrared) reflow** consists of melting solder by infrared heat. Normally a circuit board having pre-positioned and tin-lead plated connectors is transported through an IR reflow furnace.

Figure IV-19 Surface Mount Technology (SMT)




Figure IV-19 Surface Mount Technology (SMT)
In surface mount technology (SMT), the components are placed on the board, and the solder is applied to the areas where bonding is to occur. The solder would then be reflowed by heat, resulting in bonding of the components to the board. The components may also be soldered to the board in a wave soldering process. Tin (Sn) plating on the components often helps the bonding process.

Compatibility

Temperature and Chemical In-Process – Connectors require compatibility with acids and weak bases, solvents and miscellaneous chemicals (oxidizing agents, water) that would be part of the soldering process.

Automated Handling – In a high-volume manufacturing environment, smaller connectors are packaged in standard tape-and-reel format, whereas longer connectors are packaged in tubes, trays or non-standard tapes. Robotic handling requires special locating features.

Pin-in-Hole or Surface Mount – Components attach to a printed circuit board either by inserting a pin in a plated-through-hole in the PC board or by soldering a lead to a pad using surface mount techniques. The surface mount techniques rely on solder for strength. Some connectors are not conducive to surface mount soldering because of their size, weight, required insertion force and lack of flat surfaces, which lend themselves to pickup by vacuum nozzles. The higher densities required of newer connectors have helped shrink their size and weight to help address this concern.

Regulatory Requirements

Detailed information on environmental compatibility, regulatory requirements, and proper precautions for working safely with beryllium-containing alloys can be found in Section XI – Environmental, Operational and Regulatory Considerations.

Further Reading

Holm, R. Electric Contacts, 4th edition, Springe-Verlag, New York, 1967

Mroczkowski, Robert. Electronic Connector Handbook, McGraw-Hill, 1998

Slade, Paul. Electrical Contacts: Principles and Applications, Marcel Dekker, Inc. 1999

Chapman, David, Copper in Electrical Contacts, Copper Development Association 2015

©2020 Materion Brush Inc.

Section V: Connector Base Materials and Properties of Interest

Design optimization is dependent upon selecting the correct material to achieve the required criteria. Table V-1 identifies the critical design requirements and the material properties that influence them.

Table V-1 - Design Requirements Versus Material Properties

Design Requirements	Material Properties
Adequate Normal Force	Modulus of Elasticity Contact Geometry (Dimensions and Tolerances)
Maximized Insertion Cycles or Durability	Resilience Fatigue Strength (R=0, Low Cycle) Contact Finish
Withstand Overload/Overdeflection (Maximized Design Stress)	Yield Strength Modulus of Elasticity
Current Carrying Capacity (Ampacity)	Electrical Conductivity Thermal Conductivity Contact Geometry (Dimensions and Tolerances) Stress Relaxation Resistance
Reliability	Stress Relaxation Resistance Fatigue Strength Contact Finish Modulus of Elasticity (for Vibration Resistance)
Minimized Cost	Density Contact Geometry (Dimensions and Tolerances)
Miniaturized Size	Yield Strength Electrical Conductivity Formability
Ease of Fabrication	Formability Machinability Solderability
Minimized Insertion Force (Ergonomic Concerns)	Contact Finish Stress Relaxation Resistance
Repeatability	Material Property Tolerances Contact Geometry (Dimensions and Tolerances)

Careful examination of the properties required for a particular design and the ranking of these properties in order of importance will assist the designer in selecting the material that has the required combination of properties.

MATERION

©2020 Materion Brush Inc.

Types of Properties (Table V-2)

Material properties are associated with a particular material, although they may be functions of temperature, pressure, electrical frequency, magnetic field strength, etc. They do not change when the material is used in a system with other materials. These properties are easily found on data sheets, in handbooks, on websites, etc.

System properties, on the other hand, are associated with systems of materials, and are not associated with individual materials. They can be measured for any given system, but if you make any changes to any of the variables in the system, these properties would change as well. You may be able to find some data on system properties, but they would only roughly apply to your design if you have a similar system (same materials, geometry, loading conditions, environmental conditions, etc.).

Table V-2 – Material Properties Versus System Properties

Material Properties	System Properties
Are known and/or measurable for each material, regardless of mating material or loading condition.	Modulus of Elasticity Contact Geometry (Dimensions and Tolerances)
• Physical (density, elastic modulus, Poisson's ratio, etc.) • Mechanical (yield strength, hardness, elongation, fatigue strength etc.) • Electrical (resistivity, dielectric strength, permittivity, etc.) • Thermal (thermal conductivity, heat deflection temperature, thermal expansion coefficient, stress relaxation resistance, etc.) • Magnetic (permeability, coercivity, remanence, Curie temperature, etc.) • Etc.	• Coefficient of Friction • Contact Resistance • Wear Rate • Loop Inductance • Current Carrying Capacity • Etc.

MATERION

©2020 Materion Brush Inc.

Copper Alloy Metallurgy

The chemical compositions and densities of selected copper alloys are shown in Table V-3

Table V-3 - Copper Alloy Composition and Density

UNS Designation	Trade Name	Alloy Description	Chemical Composition (wt %), Cu Balance	Density (lb/in³)	Density (g/cm³)	Rod / Strip Availability	Materion† Availability
			Materion Strip, Rod and Wire Products				
C17200*	25	Copper Beryllium	1.8 Be, 0.2 Co	0.302**	8.36**	R, S	Y
C17200*	190	Copper Beryllium	1.8 Be, 0.2 Co	0.302	8.36	S	Y
C17200*	290	Copper Beryllium	1.8 Be, 0.2 Co	0.302	8.36	S	
C17300*	M25	Copper Beryllium	1.8 Be, 0.2 C0, 0.2-0.6 Pb	0.302**	8.36**	R	
C17410*	174	Copper Beryllium	0.3 Be, 0.5 Co	0.318	8.80	S	Y
C17460*	Brush® 60	Copper Beryllium	1.2 Ni, 0.3 Be	0.318	8.80	S	Y
C17460*	Alloy 390®	Copper Beryllium	1.2 Ni, 0.3 Be	0.318	8.80	S	
C17500*	10	Copper Beryllium	2.6 Co, 0.5 Be	0.319***	8.83***	R	
C17500*	390 E	Copper Beryllium	2.6 Co, 0.5 Be	0.319	8.83	S	
C17510*	3	Copper Beryllium	1.7 Ni, 0.3 Be	0.319***	8.83***	R, S	Y
C19150*	Brush 1915®	Leaded Nickel Copper	1.0 Ni, 0.8 Pb, 0.25 P	0.320	8.88	R	
C19160*	1916	Leaded Nickel Copper	1.0 Ni, 1.0 Pb, 0.25 P	0.320	8.88	R	
C72700*	BrushForm® 96	Cu-Ni-Sn Spinodal	9.0 Ni, 6.0 Sn, 0.1 Mn	0.321	8.89	S	
C72900*	BrushForm® 158	Cu-Ni-Sn Spinodal	15.0 Ni, 8.0 Sn	0.323	8.95	S	Y
C72900*	ToughMet® 3	Cu-Ni-Sn Spinodal	15.0 Ni, 8.0 Sn	0.323	8.95	R	
N03360*	360	Nickel Beryllium	2.0 Be, 0.5 Ti, Ni Balance	0.294	8.14	S	

* = precipitation hardened (and/or hardenable) materials
** = density before age hardening = 0.298 lb/in³ (8.25 g/cm³)
*** = density before age hardening = 0.316 lb/in³ (8.75 g/cm³)
† = available as a base material in composite strip from Materion

Alloy Designation

In North America, every metallic alloy is given its own unique designation, known as the UNS number, per the ASTM E527/SAE J1086 joint standard. These specifications designate allowable composition ranges, and do not cover any kind of material properties. The UNS standards start with a letter designating the type of alloy (C for copper, N for nickel, A for aluminum, etc.) and is followed by a 5 digit number. In Europe, alloy designations are covered by EN 17666, and form the ISO standard of naming alloys. This designation consists of the element symbol of the primary element in the alloy, followed by the symbols for the remaining major alloying elements and their corresponding weight percent in descending order of weight percent. Thus all copper, brass and bronze alloys start with Cu. The JIS standard in Japan use a system similar to the UNS Number, but with only 4 digits. The UNS number for Alloy 25 copper beryllium (with approximately 98% Cu and 2% Be) is C17200. The corresponding EN/ISO designation is CuBe2 and the JIS number is C1720. These are the major alloy designation systems, although other systems are used in other locations around the world.

©2020 Materion Brush Inc.

Table V-3 - Copper Alloy Composition and Density							
UNS Designation	Trade Name	Alloy Description	Chemical Composition (wt %), Cu Balance	Density (lb/in³)	Density (g/cm³)	Rod / Strip Availability	Materion† Availability
Other Copper Alloys							
C14500		Tellurium Copper	0.5 Te	0.323	8.94	R	
C14530		Tellurium Copper	0.013 Te, 0.013 Sn	0.323	8.94	S	Y
C15100		ZHC Copper	0.15 Zr	0.323	8.94	S	Y
C18080*	Wieland- K88	High Copper Alloy	0.5 Cr,0.2 Ag, 0.1 Fe, 0.1 Ti	0.320	8.86	S	Y
C18600		Copper Chromium Zirconium	0.5 Fe, 0.3 Cr, 0.2 Ti, 0.2 Zr	0.321	8.89	S	
C18665	MSP1/STOL 78	High Copper	0.65 Mg, 0.05 P	0.318	8.80	S	
C18700		Free Machining Copper	1 Pb	0.323	8.94	R	
C19025	STOL 76®, NB 109	Cu-Ni-Sn	1.0 Ni, 0.9 Sn	0.322	8.91	S	Y
C19210	NB 109, XP10	Cu-Fe-P	0.1 Fe, 0.03 P	0.323	8.94	S	Y
C19400		Copper Iron	2.3 Fe, 0.03 P, 0.12 Zn	0.321	8.89	S	Y
C19700		Copper Iron	0.6 Fe, 0.2 P, 0.05 Mg	0.321	8.89	S	Y
C19900*		Copper Titanium	3.2 Ti	0.314	8.69	S	
C26000		Cartridge Brass	30 Zn	0.308	8.53	S	Y
C34000		Leaded Brass	34 Zn, 1 Pb	0.306	8.47	R	
C36000		Free-Cutting Brass	35.5 Zn, 3 Pb	0.307	8.50	R	
C42500		Tin Brass	9.5 Zn, 2 Sn	0.317	8.78	S	Y
C42520	Olin 4252	Tin Brass	10 Zn, 2 Sn, 0.1 Fe, 0.1 Ni	0.318	8.80	S	
C50715	KLF™-5	Phophor Bronze	2 Sn, 0.1 Fe, 0.03 P	0.320	8.86	S	
C51000		Phosphor Bronze A	5.0 Sn, 0.1P	0.320	8.86	R, S	Y
C52100		Phosphor Bronze C	8.0 Sn, 0.1 P	0.318	8.80	R, S	Y
C53400		Phosphor Bronze	4.5 Sn, 1.0 Pb, 0.2 P	0.320	8.91	R	
C53800	B05	Leaded Phosphor Bronze	13.5 Sn, 0.5 Pb	0.314	8.69	R	
C54400		Free-Cutting Phosphor Bronze	4 Pb, 4 Sn, 4 Zn	0.321	8.89	R	
C63000		Aluminum Bronze	10 Al, 5 Ni, 3 Fe	0.274	7.58	R	
C63800	Olin 638	Aluminum Brass	2.8 Al, 1.8 Si, 0.4 Co	0.299	8.28	R, S	Y
C64725*	MAX 251C/STOL 92	Copper Nickel Silicon	2 Ni, 0.6 Si, 0.6 Sn, 1 Zn	0.320	8.86	S	
C64727*	MAX 375	Copper Nickel Silicon	2.8 Ni, 0.65 Si, 0.5 Sn, 0.6 Zn	0.320	8.86	S	
C65400		Silicon Bronze	3.0 Si, 1.6 Sn, 0.05 Pb	0.309	8.55	R	
C65500		Silicon Bronze A	3.0 Si	0.308	8.53	S	Y
C68800	Olin 688	Aluminum Brass	22.7 Zn, 3.4 Al, 0.4 Co	0.296	8.19	S	Y
C69750	PS2	Leaded Silicon Bronze	16 Zn, 2 Si, 1 Pb	0.311	8.61	R	
C70250*		Cu-Ni-Si	3.0 Ni, 0.6 Si, 0.2 Mg	0.318	8.80	S	Y
C70260*		Cu-Ni-Si	2.0 Ni, 0.5 Si	0.320	8.86	S	Y
C70275	MAX 126	Cu-Ni-Sn-Si	1.0 Ni, 0.6 Sn, 0.5 Zn, 0.25 Si	0.322	8.90	S	
C72500		Cu-Ni-Sn	9.5 Ni, 2.3 Sn	0.321	8.89	R, S	Y
C76300	Wieland N37	Nickel Silver	18 Ni, 19 Zn, 1 Pb	0.314	8.70	R	
C77000		Nickel Silver	27 Zn, 18 Ni	0.314	8.69	S	Y
Other Non-Copper Based Alloys							
S30100	301 SS	Stainless Steel	17 Cr, 7 Ni, 2 Mn, 1 Si, Fe balance	0.290	8.03	S	Y

Wieland-K57 & Wieland-K88 are registered trademarks of Wieland-Werke AG.
KME Germany GmbH & Co.
Kobe Steel, Ltd.

©2020 Materion Brush Inc.

Strengthening Mechanisms

Structure plays an important role in the mechanical behavior of solids. Structure depends on chemical composition and processing. Most metals have a crystalline structure. Common structures are shown in Figure V-1. Every crystal has 2 kinds of defects, namely vacancies and dislocations. (Figure V-2) Vacancies are areas where atoms are missing from the regular crystalline structure. Dislocations are essentially interruptions in the order of the crystalline structure, arising from how the crystal originally formed and grew over time. (Figures V-3 and V-4) Dislocations can move when the metal is under stress, which allows the metal to permanently deform. (Figures V-5 through V-7) All strengthening mechanisms work by inhibiting the movement of dislocations to various degrees. Processing steps such as hot working, cold working, and heat treatment influence mechanical properties, and thus determine the strength of the material. Three strengthening mechanisms commonly found in copper alloys are solid solution hardening, work hardening and age hardening.

Figure V-1 Common Crystalline Structures of Metals




Figure V-1 Common Crystalline Structures of Metals
Most metals are structured in one of these ways. Copper and its alloys tend to be face centered cubic (FCC) in structure. Steel alloys tend to be body centered cubic (BCC) in structure. This leads to some important differences in the metallurgical behavior of copper based alloys and steel based alloys.

Figure V-2 Two Kinds of Defects in Crystals




Figure V-2 Two Kinds of Defects in Crystals
Vacancies are holes in the crystalline lattice where atoms are missing. Dislocations are misalignments in the crystalline structure, which come from the way the crystal originally nucleates and grows. There are two kinds of dislocations: edge dislocations and screw dislocations.

MATERION

©2020 Materion Brush Inc.

Figure V-3 Edge Dislocation in Simple Cubic Structure

Slightly offset top view to highlight full 3D structure

Isometric view (with internal structure hidden for clarity)




Figure V-3 Edge Dislocation in Simple Cubic Structure
A simple cubic structure is used here instead of face centered cubic here to make drawing clearer. This type of dislocation appears as an extra plane of atoms in the structure.

Figure V-4 Screw Dislocation in Simple Cubic Structure

Slightly offset side view to highlight structure

Isometric view, with internal structure hidden and each level uniquely shaded for clarity




Figure V-4 Screw Dislocation in Simple Cubic Structure
Again, a simple cubic structure is used here instead of face centered cubic here to make drawing clearer. This type of dislocation arises when a crystal grows in a spiral pattern from its initial nucleation site.

Figure V-5 Dislocation Movement




Figure V-5 Dislocation Movement
From the side, an edge dislocation looks like an extra plane of atoms squeezed into the crystal. When the metal is stressed, the atoms near the dislocation may switch their strongest bonds (represented schematically here with springs) to other atoms. The bonds to neighboring side atoms are not shown in order to emphasize the bonds that switch during dislocation movement. Only one plane of atoms is shown for clarity.

DRAFT

Figure V-6 Dislocation Movement

Low energy required to switch bonds without breaking





Figure V-6 Dislocation Movement
The stress required for the atoms to switch bonds is much less than that required to break the bonds. This means that under stress, dislocations are free to move, without fracturing the metal.

Figure V-7 Dislocations and Plastic Flow

Free dislocation movement creates permanent deformation.



Stopping dislocation movement means increasing strength.

Figure V-7 Dislocations and Plastic Flow
Dislocations mean atoms are free to slide across each other while under stress. This results in permanent deformation of the metal, or yielding. In order to increase the strength of the metal, a mechanism must be used to impede or prevent the movement of the dislocations.

MATERION

©2020 Materion Brush Inc.

Grain Size and Strength

When metals solidify from the liquid state during the casting process, crystals grow out in tree-like structures known as dendrites from the sides of the mold. (Figure V-8 and left side of Figure V-9)

Subsequent thermal and mechanical operations cause the metal to reorganize into a more ordered crystalline structure. (Right Side of Figure V-9)

Metals are rarely single crystals, but are composed of a number of grains, each with its own crystalline orientation. The grain boundaries, or areas at the interfaces between the grains, are highly disordered and stop the movement of dislocations. With smaller grains, the percentage of grain boundary increases and the dislocations cannot move as far, resulting in a modest increase in strength. (Figure V-10) This is known as Hall-Petch strengthening.

Figure V-8 Crystallization and Dendritic Growth




Figure V-8 Crystallization and Dendritic Growth
For a particular composition, the metallurgical phase with the highest melting temperature freezes first onto the wall of the mold, and dendritic crystals grow and branch from the nucleation site. The last part of the molten metal to freeze (which is typically a different phase or even composition than the first to freeze) falls between dendrites. This leads to multiple phases coexisting in the solid metal.

Figure V-9 Copper Alloy Microstructures





Figure V-9 Copper Alloy Microstructures
The as-cast dendritic structures on the left clearly show the two distinct phases and the perpendicular branching dendrites that form as the metal freezes during casting. The wrought microstructure is more uniform in composition, and the organization of the structure into multiple crystalline grains is clear. These images were metallographically etched to darken the grain boundaries and reveal the structure.

©2020 Materion Brush Inc.

Figure V-10 Grain Size and Strength

Grain Boundaries stop dislocations



Metals with smaller grains have more boundaries, which prevent dislocations from moving




Figure V-10 Grain Size and Strength
Having a finer grain structure means more grain boundaries to stop dislocations. This is referred to as Hall-Petch strengthening, although its effect is not as pronounced as other strengthening mechanisms. A greater benefit of refined grain size is improved formability.

MATERION


©2020 Materion Brush Inc.

Solid Solution Hardening (Figures V-11 through V-14)

The addition of other metallic elements into the base metal by alloying increases strength by impeding dislocation motion. The effectiveness of the addition depends on the percentage of the added element present and the size difference between the atoms. In a substitutional solution, base metal atoms are replaced by atoms of the alloying element. Most copper alloys, including copper beryllium, are substitutional solutions. In an interstitial solution, atoms of the alloying element fit into the spaces, or interstices, within the atoms of the base metal crystalline lattice. As an example, carbon atoms fit among the iron atoms in steel alloys.

Figure V-11 Solid Solution Hardening

Substitutional solid solution



Interstitial solid solution




Figure V-11 Solid Solution Hardening
In a substitutional solution, atoms of the alloying element (solute) replace atoms of the base metal (solvent) in the matrix. Copper beryllium and most copper alloys fall into this category, with Be atoms replacing Cu in the matrix. In interstitial solutions, the solute atoms are small enough to fit in the spaces between the solute atoms. Most steel alloys fall into this category, with the much smaller C atoms fitting between the Fe atoms.

DRAFT REVISION

Figure V-12 Solid Solution Hardening




Figure V-12 Solid Solution Hardening
Both kinds of solute atoms can interfere with the movement of dislocations by interfering with the regularity of the crystalline matrix.

MATERION

©2020 Materion Brush Inc.

Figure V-13 Alloying and Strength




Figure V-13 Alloying and Strength
The strength increases in proportion to the amount of alloying element added to the copper. However, the conductivity decreases in proportion to the amount of alloying element. Therefore, it is an advantage to use alloying elements that give high returns on strength at low concentrations. Zinc requires a high concentration to get a moderate increase in strength, and thus produces a large penalty in reduced conductivity. On the other end of the spectrum, tin and beryllium give rise to high strength at low concentrations. Copper beryllium is heat treatable, meaning it requires an addition of only 2% beryllium to achieve the highest strength copper alloy possible. The heat treatment also increases the conductivity, minimizing the strength-conductivity penalty.

Figure V-14 Alloying and Strength / Conductivity




Figure V-14 Alloying and Strength/Conductivity
Tin and Zinc elements provide the boundaries for the behavior of all other common alloying elements in copper. Zinc allows the alloy to keep moderate conductivity, although the strength is low. Tin provides a higher return on strength, but the alloying percentage must be kept low to maximize conductivity.

Since copper beryllium is age hardenable, it can achieve a very high strength with very little alloying additions, 0.5 to 2.0%. Since the alloying content is low, the conductivity is relatively high. This ability to be age hardened allows its strength to conductivity ratio to fall outside the envelopes outlined above, once it is heat treated.

©2020 Materion Brush Inc.

Work Hardening (Cold Work) (See Figure V-15)

Metalworking involves changing the shape of the metal, and deforming the crystalline structure. If this is done at a high enough temperature, the metal will reform a new crystalline structure, which remains ductile and low strength. This is known as **hot working**. If, however, the deformation is performed below the recrystallization temperature, then it is known as **cold working**. The cold worked crystalline structure will be highly distorted and will contain a large amount of strain energy. The strength increases in proportion to the deformation while the ductility proportionately decreases, as the dislocations pile up on each other and become less free to move. The grains tend to become elongated in the deformation direction and take on a preferred crystallographic orientation or "texture." The metal becomes stronger and less easy to deform. Ductility can be restored by **solution annealing** the material, or heating it at a temperature high enough to cause the structure to recrystallize. However, the strength will be reduced to its initial value. The properties of the metal can thus be tailored by carefully controlling the amount of cold work imparted after the most recent anneal. Typical cold working operations include rolling of strip or plate and drawing of wire, rod, or tube.

Figure V-15 Strain/Work Hardening

"Increase in hardness arising from plastic deformation below the recrystalization temperature"

% Reduction = [(t_o - t_r) /t_o] x 100

t_o = initial thickness
t_r = rolled thickness




Figure V-15 Strain/Work Hardening
Strain hardening is called cold working, to differentiate it from hot working. Hot working is done above the recrystallization temperature of the metal, so the metal recrystallizes as it is deformed into a uniform microstructure with low strength since the newly formed defects are free to move. Cold working elongates and thins the grains, which causes dislocations to pile up and interfere with each other, increasing strength. While it greatly strengthens the metal, there is a limit to how much it can be cold worked without solution annealing to recrystallize the structure. Thin strip may be rolled and solution annealed many times before it reaches final gauge.

Age (Precipitation) Hardening

Heat treatment increases the strength of heat treatable alloys and is more effective than cold work, grain size reduction or solid-solution hardening. The alloy is first solution annealed by heating into the single-phase region, held there long enough to dissolve all existing soluble precipitate particles and then rapidly quenched into the two-phase region. The rapidity of the quench prevents formation of equilibrium precipitates and thus produces a super-saturated solid solution. On aging at or above room temperature, fine scale transition structures form as the beryllium rich phase precipitates out of the copper alloy matrix. (Figure V-16)

The hardening, beryllium-rich phase has a higher density than the matrix and its formation at elevated temperature leads to a slight volume change during the aging cycle. The volume change is negative, which means that the density increases. For the high strength copper beryllium alloys (25, M25, 165), the volume change is about -0.6%. Correspondingly, the linear dimensional change is -0.2%. The high conductivity copper beryllium alloys (3, 10) have a negligible volume change during age hardening due to their low beryllium content.

Figure V-16 Precipitation Age Hardening

Strengthening by formation of coherent precipitate




Figure V-16 Precipitation Age Hardening
The formerly dispersed atoms of the alloying element cluster together in a new phase and place high strain on the crystalline matrix, improving strength. In the case of CuBe, it is a beryllium-rich phase.

©2020 Materion Brush Inc.

A variation of age hardening is spinodal hardening, as seen in the copper nickel tin alloys ToughMet® 2, ToughMet® 3, BrushForm® 158 strip, and BrushForm 96. The spinodal decomposition strengthening mechanism yields a rearrangement of atoms to form controlled compositional fluctuations instead of the discrete precipitates common to normal precipitation or age hardening. In other words, the initial single phase spontaneously transforms into two phases of different compositions but identical crystal structure. (Figures V-17 and V-18) Spinodal decomposition results in reduced volume change (and therefore less distortion) relative to precipitation hardening.

Figure V-17 Spinodal Decomposition

Spontaneous decomposition into two phases that are chemically different but identical in crystalline structure.






Figure V-17 Spinodal Decomposition
Spinodal decomposition, such as that which occurs during heat treatment of BrushForm® 158 strip and ToughMet 3 alloy, is strengthening by spontaneous decomposition on the nanostructural scale into alternating waves of hard and soft phases.

Figure V-18 TEM Images of Spinodal Nanostructures

Transmission electron micrograph images showing the spinodal structure in aged ToughMet 3 material.



High magnification



Even higher magnification

©2020 Materion Brush Inc.

Temper Designation (ASTM B 601)

Tempers are defined based on the metallurgical structure and properties of an alloy resulting from the aforementioned thermal and mechanical processing treatments. The strength of an alloy is adjustable within a wide range to meet part specifications. This variation in strength is temper. Specifically, the supplier obtains different tempers by either varying the amount of deformation in the strip from rolling or wire from the drawing process and/or by varying the processing parameters of heat treatable alloys. Table V-4 contains definitions of the various tempers available in copper alloy strip.

Heat Treatable Tempers

These tempers are strengthened by thermal treatment after stamping. Not all alloys are heat treatable. Solution annealing, cold working and precipitation age hardening of metal produces heat treated (HT type) tempers. As an example, cold working Alloy 25 strip to ½ H, stamping and then heat treating results in ½ HT properties. It is not possible, for example, to heat treat ¼ H temper to HT temper – only ¼ HT is possible. (See Figure V-19.) For additional information on heat treating copper beryllium, refer to Section XVI-Production.

Figure V-19 Effects of Work & Age Hardening

Final Strength is Function of Chemistry, Hot Work, Cold Work and Heat Treatment




Figure V-19 Effects of Work & Age Hardening
The increasing amounts of cold work in Alloy 25 A, ¼H, ½H, and H temper generate increased yield strength. However, full strength is not realized until the material is heat treated to precipitation harden it. Note that each cold rolled temper has a unique corresponding age hardened temper, and vice versa. This means that, for example, it is not possible to heat treat ¼H temper to HT temper.

MATERION

©2020 Materion Brush Inc.

Mill Hardened Tempers

These tempers are heat treated to various combinations of strength and formability by Materion before ever leaving the mill. Mill hard (HM type) tempers result from precisely controlled combinations of cold work and precipitation heat treatment. Mill hardened material requires no additional heat treatment after stamping.

Table V-4 - Strip and Wire Temper Designation Values

	Traditional Designation	ASTM Designation	Description	Cold Rolled Strip % Reduction in Thickness/Area	Cold Drawn Wire % Reduction in Diameter	Cold Drawn Wire % Reduction in Area	True Strain
Cold Worked Only	A	O	Annealed	0	0	0	0
	1/4 H	H01	1/4 Hard	11	11	21	0.232
	1/2 H	H02	1/2 Hard	21	21	37	0.463
	3/4 H	H03	3/4 Hard	29	29	50	0.694
	H	H04	Hard	37	37	61	0.926
	EH	H06	Extra Hard	50	50	75	1.390
	S	H08	Spring	61	61	84	1.860
	XS	H10	Extra Spring	69	69	90	2.320
Cold Worked - Age Hardenable	A	TB00	Solution Annealed				
	1/4 H	TD01	1/4 Hard				
	1/2 H	TD02	1/2 Hard				
	3/4 H	TD03	3/4 Hard				
	H	TD04	Hard				
	EH	TD08	Extra Hard				
Cold Worked and Age Hardened	AT	TF00, TX00	Heat Treated [Precipitation Age Hardened (TH tempers) or Spinodally Hardened (TS tempers)] - Standard Heat Treatment of Corresponding Age Hardenable Temper Following Cold Rolling/Drawing and Forming				
	1/4 HT	TH01, TS01					
	1/2 HT	TH02, TS02					
	3/4 HT	TH03, TS03					
	HT	TH04, TS04					
	EHT	TS08					
Mill Hardened	AM	TM00	Mill Hardened with proprietary amounts of cold work, and age hardened under various proprietary heat treatment cycles. No Additional Heat Treatment Necessary. Strip Products Only				
	1/4 HM	TM01					
	1/2 HM	TM02					
	3/4 HM	TM03					
	HM	TM04					
	SHM	TM05					
	XHM	TM06					
	XHMS	TM08					
	-	TM10					
	…	…					
	-	TM20					
	MH2	-	Mill Hardened to Provide Properties Not Available by Standard Age Hardening. Alloy 360 Nickel Beryllium Strip Only.				
	MH4	-					
	MH6	-					
	MH8	-					
	MH10	-					
	MH12	-					
	HTS	-	Customized Mill-Hardened Tempers (Customer-Specific)				
Age Hardened and Cold Drawn	TL02	TL02	Solution annealed, Heat Treated [Precipitation Age Hardened or Spinodally Hardened] - Then Cold Drawn (Redrawn Wire Only)				
	TL04	TL04					
	TL08	TL08					
	TL10	TL10					

©2020 Materion Brush Inc.

Mechanical Properties

Mechanical properties such as elastic modulus and yield strength are the basis for material selection in a variety of applications. In actual use, materials are seldom (if ever) subjected to a single, steady deformation without the presence of other adverse factors such as vibration, corrosive environment and elevated temperature. A thorough understanding of mechanical properties and tests employed to determine such properties, as well as effect of adverse conditions over long periods of time, is extremely important. For this reason, Materion offers Design & Technical Service to its customers. Section XIII – Design and Analysis lists additional information on the service. This service is available at no cost by contacting the toll-free number 1-800-375-4205.

Primary

A basic understanding of load, deflection, and stress starts with a simple uniaxial tensile test, shown in Figure V-20.

Figure V-20 Uniaxial Tensile Test

Final Strength is Function of Chemistry, Hot Work, Cold Work and Heat Treatment






Figure V-20 Uniaxial Tensile Test
During a tensile test, material with a prescribed length and cross section is gripped at both ends and slowly pulled apart. The test machine continuously measures the displacement of the material and the force required to generate the displacement. These numbers are then normalized into engineering strain and stress to generate a stress-strain curve.

MATERION

©2020 Materion Brush Inc.

Stress (Engineering)

Engineering stress (top of Figure V-21) in a simple tension test is the ratio of applied load to the original cross-sectional area. It is usually expressed in pounds per square inch (psi), kg/mm^2 or MPa (N/mm^2).


Strain (Engineering)

Engineering strain (bottom of Figure V-21) is a dimensionless measure of the deformation of the material. In a tensile test it is equal to ratio of the change in length of the test specimen to its original length.

$$Stress = \sigma = \frac{Force}{Area} = \frac{P}{A}$$

$$Strain = \varepsilon = \frac{Change\ in\ Length}{Original\ Length} = \frac{\Delta L}{L}$$

Figure V-21 Simple Tensile Load



$$Stress = \sigma = \frac{Force}{Area} = \frac{P}{A} \qquad Strain = \varepsilon = \frac{Change\ in\ Length}{Original\ Length} = \frac{\Delta L}{L}$$

Figure V-21 Simple Tensile Load
Engineering strain is simply the change in length of the specimen divided by its original length. Note that it is a non-denominational number, usually expressed in percent. Stress is the force divided by the cross sectional area, so its units are the same as pressure units. It is usually reported in MegaPascals (Mpa = N/mm^2), or 1000's of pounds per square inch (ksi).

Figure V-22 Engineering Stress-Strain Curve

Figure V-22 shows the plot of typical tensile test results. This is the Engineering Stress-Strain Curve, which characterizes the mechanical behavior of material in tension.




Figure V-22 Engineering Stress-Strain Curve
These are the key features of a stress-strain curve for a ductile metal with a single yield point, like CuBe. The 0.2% offset yield strength is a calculated value, and is not an intrinsic property of the metal. However, it is much easier to calculate this value than it is to measure the proportional or elastic limit. The yield strength may sometimes be referred to as the proof strength or proof stress ($R_{p0,2}$).

©2020 Materion Brush Inc.

Modulus of Elasticity (Young's Modulus)

Metal deformation is directly proportional to the imposed loads up to a certain point. Since stress is proportional to load and strain is proportional to deformation, this implies that stress is proportional to strain. Hooke's Law is the statement of that proportionality.

$$\frac{Stress}{Strain} = \frac{\sigma}{\varepsilon} = E$$

The constant, E, is called Young's modulus, modulus of elasticity, elastic modulus or tensile modulus and is a measure of a material's stiffness in tension. Young's modulus is typically expressed in terms of 10^6 psi, GPa or 10^3 kg/mm^2. The modulus is the slope of the initial linear portion of the stress-strain curve (line OA in Figure V-22). While a material obeys Hooke's Law, it is said to be elastic. The modulus is relatively insensitive to the material's temper. The normal force generated by a spring contact is directly dependent upon the elastic modulus.

Proportional Limit

The proportional limit is the greatest stress at which a material is capable of sustaining the applied load without deviating from the proportionality of stress to strain (point A in Figure V-22). It is typically expressed in psi, MPa, or kg/mm^2.

Spring Bend Limit

The spring bend limit is similar to the proportional limit. The only difference is that it is measured in bending, and not tension. This means it is closer to the loading that would actually be experienced by the contact spring. However, it varies depending on the method used to measure it (JIS H3103 or EN 12384). It is also directional. (The measured value is different depending on whether you test the specimen in the coil set up orientation or the coil set down orientation, or if you test it in the transverse or longitudinal direction.)

Ultimate Tensile Strength (R_m)

This is the maximum engineering stress that a material withstands when subjected to an applied load. It is shown in Figure 19 as point C in Figure V-22. Tensile strength is typically expressed in psi, MPa, or kg/mm^2. Dividing the highest load in the test by the original cross sectional area determines the value.

Elastic Limit

This is the point on the stress-strain curve beyond which the material permanently deforms after removing the load (point D in Figure V-22). Material that is loaded to a stress level less than the elastic limit will elastically return to its original shape when the load is removed. If the stress level exceeds the elastic limit, the material will plastically deform, and will not return to its original shape when the load is removed, although the elastic deformation will recover. This property is very time consuming to measure, so it is seldom reported. The yield strength is often quoted instead.

Secant Modulus

The ratio of stress to corresponding strain at any given point on the stress-strain curve is the secant modulus. In Figure V-22, the secant modulus at point P is the slope of line OP. For stress levels less than the elastic limit, the secant modulus is equal to the elastic modulus. Beyond the elastic limit, the secant modulus will be less than the elastic limit.

Tangent Modulus

This is defined as the slope of a line tangent to the stress-strain curve at any given point. In finite element analysis (FEA), the term tangent modulus usually refers to the average slope of the plastic portion of the stress-strain curve, from the yield strength to the tensile strength.

Yield Strength (Proof Strength)

Constructing a parallel line to OA in Figure V-22 (the elastic modulus) at a specified offset strain establishes the yield strength. The stress where the line intersects the stress-strain curve at point B is the yield strength at that particular offset. For spring alloys, the yield strength is usually stated at 0.2% offset. The value is typically expressed in units of psi, MPa or kg/mm^2.


Poisson's Ratio

The ratio of the lateral to longitudinal strain is Poisson's ratio, v (Figure V-23). It is a dimensionless constant used for stress and deflection analysis of structures such as beams, plates, shells and rotating discs. A typical value ranges between 0.29 – 0.35 for connector spring alloys. This ratio becomes important for a decreasing width to thickness ratio where plane stress conditions dominate. The ratio is slightly sensitive to processing since high levels of cold work provide preferred crystallographic texturing.

$$v = \frac{Lateral\ Strain}{Lateral\ Stress} \approx 0.3$$

©2020 Materion Brush Inc.

Figure V-23 Poisson's Ratio



$$\varepsilon_{Transverse} = \frac{w_2 - w_1}{w_1} \qquad \varepsilon_{Longitudinal} = \frac{L_2 - L_1}{L_1}$$

$$\nu = -\frac{\varepsilon_{Transverse}}{\varepsilon_{Longitudinal}} = \frac{\Delta w / w_1}{\Delta L / L_1}$$

Figure V-23 Poisson's Ratio
Poisson's ratio is the ratio of lateral to longitudinal strain when a sample is extended. (i.e., it is a measure of how much a material thins when it is stretched). Most materials have a positive Poisson's ratio between 0 (cork) and 0.5 (rubber). Most metals, including CuBe and CuNiSn have a ratio approximately equal to 0.3.

Bending Stress

When bending a piece of metal, one surface of the material stretches in tension while the opposite surface compresses (Figure V-24). It follows that there is a line or region of zero stress between the two surfaces, called the neutral axis. Make the following assumptions in simple bending theory:

1. The beam is initially straight, unstressed and symmetric.
2. The material of the beam is linearly elastic, homogeneous and isotropic.
3. The proportional limit is not exceeded.
4. Young's modulus for the material is the same in tension and compression.
5. All deflections are small, so that planar cross-sections remain planar before and after bending.

Figure V-24 Beam in Bending




Figure V-24 Beam in Bending
When a material is bent, the outer fibers (layers) on the convex side are in tensile stress and the outer fibers on the concave side are in compression. The plane in the material where the stress is zero is called the neutral axis. It is typically half way through the thickness, although it will shift toward the compressive side by varying degrees during the bending process.

©2020 Materion Brush Inc.

Bending Stress (Continued)

Using classical beam formulas and section properties, the following relationship can be derived:

Bending stress, $\sigma_b = \frac{6PL}{wt^2}$

Bending or flexural modulus, $E_B = \frac{4PL^3}{wt^3y}$

Where: P = normal force
L = beam length
w = beam width
t = beam thickness
y = deflection at load point

The reported flexural modulus is usually the initial modulus from the stress-strain curve in tension. When available, take the value from a 4-point bend test. (For multi-layered composite materials, the flexural modulus is not equal to the tensile modulus, but can still be relatively easily calculated from the elastic modulus and moment of inertia of each layer.)

The maximum stress occurs at the surface of the beam farthest from the neutral surface (axis) and is:

$$\sigma_{max} = \frac{Mc}{I} = \frac{M}{Z}$$

Where M = bending moment
c = distance from neutral axis to outer surface where max stress occurs
I = moment of inertia (see Section XIII-Design & Analysis)
Z = I/c = section modulus (see Section XIII-Design & Analysis)

For a rectangular cantilever beam with a concentrated load at one end, the maximum surface stress is (Figure V-25):

$$\sigma_{max} = \frac{3dEt}{2L^2}$$

Where d = deflection of the beam at the load
E = flexural modulus/modulus of elasticity
t = beam thickness
L = beam length

One of the methods to reduce maximum stress is to keep the strain energy in the beam constant while changing the beam profile. Some additional beam profiles include trapezoidal, tapered and torsion.

Figure V-25 Maximum Surface Stress




Figure V-25 Maximum Surface Stress
The maximum stresses in any beam will always be at the outer fiber. The maximum tensile stress will be on the elongated side (convex), the maximum compressive stress on the compressed (concave) side. In cantilever beams, the maximum stress is at the fixed end, tapering to zero at the point of loading (and beyond if the load is before the end of the beam).

MATERION

©2020 Materion Brush Inc.

Yielding

For design purposes, yielding can be said to occur when the design stress exceeds the material's yield strength. Design stress is typically maximum surface stress (simple loading) or Von Mises stress (complex loading conditions). The Von Mises yield criterion states that yielding occurs when the Von Mises stress, σ_V, exceeds the yield strength in tension. Finite Element Analysis stress results use Von Mises stresses. Von Mises stress is defined as:

$$\sigma_v = \sqrt{\frac{(\sigma_1 - \sigma_2)^2 + (\sigma_2 - \sigma_3)^2 + (\sigma_1 - \sigma_3)^2}{2}}$$

where σ_1, σ_2, σ_3 are principal stresses

The safety factor is a function of design stress and yield strength. The following equation denotes safety factor, F_S.

$F_s = \frac{YS}{DS}$, where YS is the yield strength and DS is the design stress. Alternatively, for highly cycled applications the appropriate fatigue strength (see passage on fatigue later in this section) may be substituted for the yield strength.

For many years, it had been customary to set the design stress equal to 75% of the yield strength, for a safety factor of 1.33. Since the elastic limit of a copper alloy is typically around 70-80% of the 0.2% offset yield strength, this design stress level guarded against yielding. With the current widespread availability and predictive capability of finite element analysis (FEA), it is now common to see safety factors approaching and even falling below unity, if a small amount of permanent set can be tolerated.

Table V-5 lists the critical material mechanical properties of copper alloy strip.

Table V-5 Strip Mechanical Properties

Alloy	Temper	Heat Treatment Required for Peak Properties	Modulus of Elasticity (10^6 psi)	Modulus of Elasticity (GPa)	Yield Strength 0.2% Offset (ksi)	Yield Strength 0.2% Offset (MPa)	Tensile Strength (ksi)	Tensile Strength (MPa)	Total Elongation (%) min.
Materion Copper Beryllium Strip Alloys									
25	A	3 hr at 600°F (315°C)	18	124	30 - 55	200 - 380	60 - 78	410 - 540	35
	1/4 H	2 hr at 600°F (315°C)			60 - 80	410 - 560	75 - 88	510 - 610-	20
	1/2 H	2 hr at 600°F (315°C)			75 - 95	510 - 660	85 - 100	580 - 690	12
	H	2 hr at 600°F (315°C)			90 - 115	620 - 800	100 - 120	680 - 830	2
	AT	Properties after Heat Treatment by User per Above Specifications	19	131	140 - 175	960 - 1210	165 - 195	1130 - 1350	3
	1/4 HT				150 - 185	1030 - 1280	175 - 205	1200 - 1420	3
	1/2 HT				160 - 195	1100 - 1350	185 - 215	1270 - 1490	1
	HT				165 - 205	1130 - 1410	190 - 220	1310 - 1520	1
190	AM	Mill Hardened	19	131	70 - 95	480 - 660	100 - 110	685 - 755	16
	1/4 HM				80 - 110	550 - 760	110 - 120	755 - 825	15
	1/2 HM				95 - 125	650 - 870	120 - 135	825 - 940	12
	HM				110 - 135	750 - 940	135 - 150	930 - 1035	9
	SHM				125 - 140	860 - 970	150 - 160	1035 - 1110	9
	XHM				135 - 170	930 - 1180	155 - 175	1060 - 1205	4
	XHMS				150 - 180	1030 - 1250	175 - 190	1205 - 1320	3
290	TM02	Mill Hardened	19	131	95 - 115	650 - 800	120 min.	820 min.	14
	TM03				110 - 125	760 - 860	135 min.	930 min.	12
	TM04				115 - 135	790 - 940	140 min.	960 min.	9
	TM06				135 - 155	930 - 1070	155 min.	1060 min.	6
	TM08				150 - 175	1060 - 1210	175 min.	1200 min.	3
3	AT	Mill Hardened	20	138	80 - 100	550 - 690	100 - 130	685 - 900	10
	HT				95 - 120	680 - 830	110 - 135	750 - 940	8
174	1/2 HT	Mill Hardened	20	138	80 - 100	550 - 695	95 - 115	655 - 790	10
	HT				100 - 120	685 - 830	110 - 130	750 - 900	7
Brush® 60	3/4 HT	Mill Hardened	20	138	95 - 115	655 - 795	115 - 135	795 - 930	11
	HT				105 - 125	720 - 860	120 - 140	825 - 965	10
390	HT	Mill Hardened	20	138	135 - 153	930 - 1055	138 - 158	950 - 1090	1
390E	EHT	Mill Hardened	20	138	138 min.	951 min.	143 min.	968 min.	2

©2020 Materion Brush Inc.

Table V-5 Strip Mechanical Properties (Continued)

Alloy	Temper	Heat Treatment Required for Peak Properties	Modulus of Elasticity (10^6 psi)	Modulus of Elasticity (GPa)	Yield Strength 0.2% Offset (ksi)	Yield Strength 0.2% Offset (MPa)	Tensile Strength (ksi)	Tensile Strength (MPa)	Total Elongation (%) min.
Materion Copper Nickel Tin Strip Alloys									
BrushForm® 158	A	3 hr at 700°F (370°C)	17.5 - 21	119 - 145	25 - 45	170 - 310	64 - 85	440 - 590	32
	1/4 H	3 hr at 700°F (370°C)			52 - 75	360 - 520	75 - 100	520 - 690	18
	1/2 H	3 hr at 650°F (345°C)			75 - 100	520 - 690	85 - 110	590 - 760	8
	H	3 hr at 650°F (345°C)			95 - 125	660 - 860	100 - 130	690 - 900	1
	EH	3 hr at 650°F (345°C)			115 - 135	790 - 930	122 - 145	840 - 1000	1
	AT	Properties after Heat Treatment by User per Above Specifications	17.5 - 21	119 - 145	100 - 130	690 - 900	120 - 150	830 - 1030	6
	1/4 HT				115 - 145	790 - 1000	130 - 160	900 - 1100	4
	1/2 HT				135 - 165	930 - 1140	145 - 175	1000 - 1210	3
	HT				155 - 185	1070 - 1280	165 - 195	1140 - 1340	2
	EHT				170 - 200	1170 - 1380	175 - 205	1205 - 1415	1
	TM00	Mill Hardened	17.5 - 21	119 - 145	75 - 95	520 - 660	95 - 115	660 - 790	22
	TM02				90 - 110	620 - 760	105 - 125	720 - 860	15
	TM04				105 - 125	720 - 860	115 - 135	790 - 930	10
	TM06				120 - 145	830 - 1000	130 - 150	900 - 1030	6
	TM08				140 - 170	970 - 1170	150 - 178	1030 - 1230	2
	TM10				165 - 195	1140 - 1345	175 - 210	1205 - 1450	1
	TM16				198 - 212	1365 - 1462	203 - 219	1400 - 1510	1
	TM18				195 min.	1344 min.	202 min.	1382 min.	1
BrushForm® 96	A	2 hr at 700°F (370°C)	18	124	37 typ.	255 typ.	60 typ.	414 typ.	30
	1/4 H	2 hr at 700°F (370°C)			53 typ.	365 typ.	75 typ.	517 typ.	16
	1/2 H	2 hr at 700°F (370°C)			67 typ.	462 typ.	85 typ.	586 typ.	8
	H	2 hr at 700°F (370°C)			88 typ.	607 typ.	100 typ.	689 typ.	3
	EH	-			92 typ.	634 typ.	110 typ.	92 typ.	-
	AT	Properties after Heat Treatment by User per Above Specifications	18	124	75 typ.	517 typ.	100 typ.	689 typ.	15
	1/4 HT				90 typ.	621 typ.	115 typ.	793 typ.	10
	1/2 HT				100 typ.	689 typ.	125 typ.	862 typ.	6
	HT				120 typ.	827 typ.	135 typ.	931 typ.	4
	TM00	Mill Hardened	18	124	60 typ.	414 typ.	98 typ.	676 typ.	16
	TM02				75 typ.	517 typ.	105 typ.	724 typ.	15
	TM04				90 typ.	621 typ.	110 typ.	758 typ.	8
	TM06				100 typ.	689 typ.	120 typ.	827 typ.	4
	TM08				110 typ.	758 typ.	130 typ.	896 typ.	-

MATERION

©2020 Materion Brush Inc.

Table V-5 Strip Mechanical Properties (Continued)

Alloy	Temper	Heat Treatment Required for Peak Properties	Modulus of Elasticity (10^6 psi)	Modulus of Elasticity (GPa)	Yield Strength 0.2% Offset (ksi)	Yield Strength 0.2% Offset (MPa)	Tensile Strength (ksi)	Tensile Strength (MPa)	Total Elongation (%) min.
Materion Nickel Beryllium Strip Alloys									
360	A	2.5 hr at 925°F (500°C)	28 - 30	193 - 207	40 - 70	280 - 480	95 - 130	660 - 900	30
	1/4 H	2.5 hr at 925°F (500°C)			65 - 125	450 - 860	110 - 150	760 - 1030	15
	1/2 H	1.5 hr at 925°F (500°C)			115 - 170	790 - 1170	130 - 175	900 - 1210	4
	H	1.5 hr at 925°F (500°C)			150 - 190	1030 - 1310	155 - 190	1070 - 1310	1
	AT	Properties after Heat Treatment by User per Above Specifications	28 - 30	193 - 207	150 min.	1030 min.	215 min.	1480 min.	12
	1/4 HT				175 min.	1210 min.	230 min.	1590 min.	10
	1/2 HT				200 min.	1380 min.	245 min.	1690 min.	9
	HT				230 min.	1590 min.	270 min.	1860 min.	8
	MH02	Mill Hardened	28 - 30	193 - 207	100 - 125	690 - 860	155 - 180	1070 - 1240	14
	MH04				120 - 155	830 - 1070	180 - 205	1240 - 1410	12
	MH06				150 - 175	1030 - 1210	200 - 225	1380 - 1550	10
	MH08				170 - 205	1170 - 1410	220 - 245	1520 - 1690	9
	MH10				200 - 225	1380 - 1550	240 - 270	1660 - 1860	8
	MH12				220 - 245	1520 - 1690	260 - 290	1790 - 2000	8
Properties of Other Copper Alloy Strip Materials									
C18080*	TM04	Mill Hardened	19.5	134	65 min.	448 min.	71 - 81	490 - 558	8 nom.
	TM08	Mill Hardened			85 nom.	586 no.	77 - 87	531 - 600	4 nom.
C18600	TM02	Mill Hardened	18.5	128	60 min.	414 min.	70 - 90	483 - 621	8
	TM04				70 min.	483 min.	75 - 95	517 - 655	6
	TM08				80 min.	552 min.	85 - 105	586 - 724	2
C18665	H	Mill Hardened	18	125	64 - 80	441 - 552	70 - 83	483 - 572	7
	EH				71 - 90	490 - 621	78 - 91	538 - 627	5
	S				78 min.	538 min.	86 min.	593 min.	-
C19025	1/2 H	Not Age Hardenable	18.8	130	66 nom.	455 nom.	63 - 76	434 - 524	9
	H	Not Age Hardenable			76 nom.	524 nom.	72 - 83	496 - 572	4
	XS	Not Age Hardenable			97 nom.	669 nom.	91 - 106	627 - 731	-
C19210	H	Not Age Hardenable	17.2	119	54 - 66	372 - 455	56 - 66	386 - 455	3
	XS				64 min.	441 min.	66 min.	455 min.	-
C19400	S	Not Age Hardenable	17.5	121	67 - 75	462 - 517	70 - 76	483 - 524	1
C19700	H	Not Age Hardenable	17.2	119	53 - 68	365 - 469	60 - 70	414 - 483	2
	XS				70 - 78	483 - 538	73 - 80	503 - 552	-
C19900*	TM02	Mill Hardened	18	125	99 - 128	683 - 883	114 - 142	786 - 979	15
	TM04				107 - 135	738 - 931	121 - 149	834 - 1027	8
	TM05				121 - 149	834 - 1027	128 - 157	883 - 1082	5
	TM06				128 - 157	883 - 1082	132 - 164	910 - 1130	3
C26000	H	Not Age Hardenable	16	110	67 - 78	462 - 538	71 - 81	490 - 558	6
	S				82 - 98	562 - 676	91 - 100	627 - 689	1
	XS				86 - 102	593 - 703	95 - 104	655 - 717	1

©2020 Materion Brush Inc.

Table V-5 Strip Mechanical Properties (Continued)

Alloy	Temper	Heat Treatment Required for Peak Properties	Modulus of Elasticity (10^6 psi)	Modulus of Elasticity (GPa)	Yield Strength 0.2% Offset (ksi)	Yield Strength 0.2% Offset (MPa)	Tensile Strength (ksi)	Tensile Strength (MPa)	Total Elongation (%) min.
Properties of Other Copper Alloy Strip Materials (Continued)									
C42500	H	Not Age Hardenable	16	110	66 - 79	455 - 545	70 - 82	483 - 565	6
	S				81 - 92	558 - 634	84 - 94	579 - 648	2
	XS				87 min.	600 min.	92 min.	634 min.	1
C50715	H	Not Age Hardenable	17	117	64 - 79	441 - 545	74 - 87	510 - 600	8
	EH				74 - 90	510 - 621	81 - 95	558 - 655	5
	SH				79 - 94	545 - 648	86 - 100	593 - 689	3
C51000	1/2 H	Not Age Hardenable	16	110	47 - 68	324 - 469	58 - 73	400 - 503	16
	H				74 - 88	510 - 607	76 - 91	524 - 627	4
	S				92 - 108	634 - 745	95 - 110	655 - 758	1
C52100	1/2 H	Not Age Hardenable	16	110	51 - 75	352 - 517	69 - 84	476 - 579	25
	H				78 - 95	538 - 655	85 - 100	586 - 689	12
	S				100 - 113	689 - 779	105 - 119	724 - 820	3
C64725	1/2 H	Mill Hardened	19	130	70 - 91	483 - 627	78 - 93	538 - 641	8
	H				78 - 100	548 - 689	87 - 102	600 - 703	5
	EH				84 - 107	579 - 738	93 - 107	641 - 738	3
	SH				94 min.	648 min.	102 min.	703 min.	-
C64727	H	Mill Hardened	19	132	115 nom.	792 nom.	120 nom.	827 nom.	7 nom.
	SH				131 nom.	902 nom.	133 nom.	920 nom.	2 nom.
C65400	1/2 H	Not Age Hardenable	17	117	66 - 92	455 - 634	86 - 101	593 - 696	11
	H				94 - 109	648 - 752	108 - 120	745 - 827	4
	S				112 - 123	772 - 848	124 - 133	855 - 917	2
	XS				118 - 131	814 - 903	131 - 140	814 - 965	1
C65500	H	Not Age Hardenable	15	103	58 nom.	400 nom.	94 nom.	648 nom.	8 nom.
	S				62 nom.	427 nom.	110 nom.	758 nom.	4 nom.
C68800	1/2 H	Not Age Hardenable	17	117	82 - 102	565 - 703	97 - 112	669 - 772	3
	H				95 - 108	655 - 745	106 - 120	731 - 827	2
	S				111 - 117	765 - 807	123 - 133	848 - 917	1
	XS				117 min.	807 min.	130 min.	896 min.	2 max.
C70250	TM02	Mill Hardened	19	131	85 - 119	586 - 820	95 - 120	655 - 827	7
	TM03				95 - 120	655 - 827	100 - 125	689 - 862	5
C70260*	TM00	Mill Hardened	19	131	75 min.	517 min.	85 - 95	586 - 655	15
	TM02				95 min.	655 min.	95 - 105	655 - 724	6
C72500	1/2 H	Not Age Hardenable	20	138	59 - 78	407 - 538	65 - 80	448 - 552	3
	H				73 - 88	503 - 607	75 - 90	517 - 621	1
	S				83 - 97	572 - 669	85 - 100	586 - 689	1
C77000	1/2 H	Not Age Hardenable	18	124	64 - 93	441 - 641	78 - 95	538 - 655	5
	H				90 - 108	621 - 745	92 - 109	634 - 752	3
	S				107 - 118	738 - 814	108 - 123	745 - 848	1 nom.
S30100	A	Not Age Hardenable	28	193	40 nom.	276 nom.	110 nom.	758 nom.	60 nom.
	1/2 H				110 min.	758 min.	150 min.	1034 min.	15
	H				140 min.	965 min.	185 min.	1275 min.	8

©2020 Materion Brush Inc.

Hardness

Hardness is the resistance of a material to plastic deformation (usually measured by indentation). Hardness testing monitors process operations such as cold working, solution annealing and age hardening. Tensile testing of stamped parts is impossible, so hardness tests provide one of the only means of verifying age hardening response. (The alternative would be to place a few tensile samples made from the input strip into the furnace with the parts.) Remember that a hardness test does not measure a well-defined mechanical property but provides a useful approximation. Commonly used hardness tests use varying loads, indenters and techniques for calculating a hardness value from the size or depth of the indentation. It is not surprising that there are no universal hardness-conversion relationships. Therefore, avoid converted values where possible. Diamond Pyramid (DPH) and Vickers hardness scales have the advantage that a continuous set of numbers covers the entire metallic hardness spectrum. This test allows direct hardness comparison of different gauge products (see Table V-6).

Table V-6 - Hardness Values for Strip

		Hardness						
		Vickers or Diamond	Rockwell	Rockwell Superficial		Brinell		Knoop
Alloy	Temper	Pyramid (DPH)	A, B or C	30T / 30 N	15T / 15 N	5000 kg	500 kg	500 g
Materion Performance Alloy Materials								
25	A	**90 - 144**	**B 45 - 78**	**30T 46 - 67**	15T 80 - 86	-	HBS 89 - 126	KHN 104 - 158
	1/4 H	**121 - 185**	**B 68 - 90**	**30T 62 - 75**	15T 83 - 90	-	HBS 107 - 157	KHN 134 - 201
	1/2 H	**176 - 216**	**B 88 - 96**	**30T 74 - 79**	15T 89 - 92	-	HBS 150 - 179	KHN 192 - 231
	H	**216 - 287**	**B 96 - 102**	**30T 79 - 83**	15T 92 - 94	-	HBS 179 - 220	KHN 231 - 296
	AT	**353 - 413**	**C 36 - 42**	**30N 56 - 62**	15N 78 - 81	HBS 331 - 393	-	KHN 361 - 427
	1/4 HT	**353 - 424**	**C 36 - 43**	**30N 56 - 63**	15N 78 - 82	HBS 331 - 404	-	KHN 361 - 440
	1/2 HT	**373 - 435**	**C 38 - 44**	**30N 58 - 63**	15N 79 - 82	HBS 351 - 415	-	KHN 383 - 452
	HT	**373 - 446**	**C 38 - 45**	**30N 58 - 65**	15N 79 - 83	HBS 351 - 426	-	KHN 383 - 465
190	AM	**210 - 251**	**B 95 - C 23**	**30N 37 - 44**	15N 66 - 71	HBS 210 - 244	HBS 225 - 259	KHN 225 - 264
	1/4 HM	**230 - 271**	**C 20 - 26**	**30N 41 - 47**	15N 69 - 73	HBS 227 - 259	-	KHN 243 - 281
	1/2 HM	**250 - 301**	**C 23 - 30**	**30N 44 - 51**	15N 71 - 75	HBS 243 - 284	-	KHN 263 - 309
	HM	**285 - 343**	**C 28 - 35**	**30N 48 - 55**	15N 74 - 78	HBS 271 - 322	-	KHN 294 - 351
	SHM	**309 - 363**	**C 31 - 37**	**30N 52 - 56**	15N 76 - 79	HBS 291 - 341	-	KHN 317 - 372
	XHM	**317 - 378**	**C 32 - 38**	**30N 52 - 58**	15N 76 - 80	HBS 298 - 356	-	KHN 324 - 388
	XHMS	**325 - 413**	**C 33 - 42**	**30N 53 - 62**	15N 77 - 81	HBS 305 - 393	-	KHN 322 - 427
290	TM00	**225 - 309**	**B 98 - C 31**	**30T 81 - 30N 52**	15N 68 - 76	HBS 223 - 291	-	KHN 239 - 317
	TM02	**255 - 339**	**C 25 - 34**	**30N 46 - 64**	15N 71 - 78	HBS 247 - 318	-	KHN 267 - 347
	TM04	**285 - 369**	**C 28 - 38**	**30N 48 - 58**	15N 74 - 79	HBS 271 - 347	-	KHN 294 - 379
	TM06	**317 - 393**	**C 32 - 40**	**30N 52 - 60**	15N 76 - 80	HBS 298 - 372	-	KHN 324 - 405
	TM08	**345 - 429**	**C 35 - 43**	**30N 55 - 62**	15N 78 - 82	HBS 324 - 409	-	KHN 353 - 445
3	AT	**195 - 275**	**B 92 - 100**	**30T 77 - 82**	15T 91 - 15N 73	HBS 196 - 263	HBS 164 - 257	KHN 211 - 285
	HT	**216 - 287**	**B 95 - 102**	**30T 79 - 83**	15N 67 - 74	HBS 215 - 272	HBS 231 - 280	KHN 231 - 296
174	1/2 HT	**180 - 230**	**B 89 - 98**	**30T 75 - 82**	15T 90 - 92	-	HBS 153 - 191	KHN 196 - 243
	HT	**210 - 278**	**B 95 - C 27**	**30T 79 - 30N 48**	15N 66 - 73	HBS 210 - 265	HBS 225 - 276	KHN 225 - 287

The data in the plain black text are conversions based on the appropriate table in ASTM E140 (where applicable) or Materion internal data. Numbers in bold text are published hardness ranges. Numbers in red text are out of range of the standard conversion charts and are for reference only, not for specification purposes.

©2020 Materion Brush Inc.

Table V-6 - Hardness Values for Strip (Continued)

		Hardness						
		Vickers or Diamond	Rockwell	Rockwell Superficial		Brinell		Knoop
Alloy	Temper	Pyramid (DPH)	A, B or C	30T / 30 N	15T / 15 N	5000 kg	500 kg	500 g
Materion Performance Alloy Materials								
Brush® 60	3/4 HT	**220 - 280**	B 96 - C 30	30T 81 - 30N 48	15N 67 - 73	HBS 219 - 267	HBS 234 - 270	KHN 234 - 289
	HT	**230 - 290**	B 98 - C 31	30T 82 - 30N 49	15N 69 - 74	HBS 227 - 275	-	KHN 243 - 298
390	HT	**280 - 340**	C 27 - 35	30N 47 - 55	15N 73 - 78	HBS 267 - 319	-	KHN 289 - 348
390E	EHT	**300 min.**	C 30 min.	30N 50 min.	15N 75 min.	HBS 283 min.	-	KHN 308 min.
BrushForm® 158	A	**100 - 150**	B 55 - 80	30T 53 - 70	15T 80 - 87	-	HBS 92 - 131	KHN 113 - 164
	1/4 H	**150 - 235**	B 80 - 99	30T 70 - 83	15T 87 - 93	-	HBS 131 - 196	KHN 164 - 247
	1/2 H	**190 - 275**	B 91 - C 27	30T 77 - 30N 48	15T 90 - 15N 73	HBS 191 - 263	HBS 160 - 257	KHN 206 - 285
	H	**220 - 300**	B 96 - C 30	30T 80 - 30N 50	15N 67 - 75	HBS 219 - 283	HBS 234 - 285	KHN 234 - 308
	EH	**265 - 325**	C 27 - 33	30 N 46 - 53	15N 72 - 77	HBS 225 - 305	-	KHN 276 - 332
	AT	**275 - 350**	C 26 - 36	30N 47 - 56	15N 73 - 78	HBS 263 - 328	-	KHN 285 - 358
	1/4 HT	**290 - 365**	C 38 - 38	30 N 49 - 57	15N 74 - 79	HBS 275 - 343	-	KHN 298 - 374
	1/2 HT	**315 - 390**	C 31 - 40	30N 51 - 60	15N 76 - 80	HBS 296 - 369	-	KHN 322 - 402
	HT	**335 - 410**	C 34 - 42	30N 54 - 61	15N 77 - 81	HBS 314 - 390	-	KHN 343 - 424
	EHT	**370 - 450**	C 37 - 45	30N 57 - 64	15N 79 - 83	HBS 348 - 430	-	KHN 380 - 469
	TM00	**190 - 290**	B 91 - C 29	30T 77 - 30N 50	15T 90 - 15N 74	HBS 192 - 275	HBS 160 - 296	KHN 206 - 298
	TM02	**215 - 315**	B 96 - C 32	30T 80 - 30N 52	15T 92 - 15N 76	HBS 214 - 296	HBS 178 - 394	KHN 230 - 322
	TM04	**245 - 345**	C 21 - 35	30N 42 - 55	15N 70 - 78	HBS 239 - 324	-	KHN 259 - 353
	TM06	**270 - 370**	C 25 - 38	30N 46 - 58	15N 73 - 79	HBS 259 - 348	-	KHN 280 - 380
	TM08	**305 - 405**	C 30 - 42	30N 50 - 61	15N 75 - 81	HBS 287 - 385	-	KHN 313 - 418
	TM10	**370 - 450**	C 37 - 45	30N 57 - 64	15N 79 - 81	HBS 348 - 385	-	KHN 380 - 469
	TM16	**375 - 450**	C 38 - 45	30N 58 - 64	15N 80 - 83	HBS 353 - 430	-	KHN 385 - 469
	TM18	**375 min.**	C 38 min.	30N 58 min.	15N 80 min.	HBS 353 min.	-	KHN 385 min.

MATERION

©2020 Materion Brush Inc.

Table V-6 - Hardness Values for Strip (Continued)

		Hardness						
		Vickers or Diamond	Rockwell	Rockwell Superficial		Brinell		Knoop
Alloy	Temper	Pyramid (DPH)	A, B or C	30T / 30 N	15T / 15 N	5000 kg	500 kg	500 g
Materion Performance Alloy Materials								
BrushForm® 96	A	**100 - 150**	B 55 - 80	30T 53 - 70	15T 80 - 87	-	HBS 92 - 131	KHN 113 - 164
	1/4 H	**125 min.**	B 70 min.	30T 63 min.	15T 83 min.	-	HBS 110 min.	KHN 138 min.
	1/2 H	**-**	-	-	-	-	-	-
	H	**175 - 275**	B 88 - C 27	30T 75 - 30N 48	15T 89 - 15N 73	HBS 175 - 263	HBS 150 - 257	KHN 191 - 285
	EH	**-**	-	-	-	-	-	-
	AT	**250 - 340**	C 23 - 35	30N 44 - 55	15N 71 - 78	HBS 243 - 319	-	KHN 263 - 348
	1/4 HT	**230 - 330**	C20 - 34	30N 41 - 54	15N 69 - 77	HBS 227 - 310	-	KHN 247 - 338
	1/2 HT	**280 - 330**	C 27 - 34	30N 48 - 54	15N 73 - 77	HBS 267 - 310	-	KHN 289 - 338
	HT	**300 - 370**	C 30 - 38	30N 50 - 58	15N 75 - 79	HBS 283 - 348	-	KHN 308 - 380
	TM00	**180 - 280**	B 89 - C 28	30T 75 - 30N 48	15T 90 - 15N 73	HBS 181 - 267	HBS 153 - 269	KHN 196 - 289
	TM02	**200 - 300**	B 93 - C 30	30T 78 - 30N 51	15T 91 - 15N 75	HBS 201 - 283	HBS 167 - 330	KHN 216 - 308
	TM04	**230 - 300**	B 98 - C 30	30T 81 - 30N 51	15T 92 - 15N 75	HBS 227 - 283	HBS 191 - 330	KHN 242 - 308
	TM06	**240 - 360**	C 21 - 37	30N 42 - 56	15N 70 - 79	HBS 235 - 338	-	KHN 255 - 369
	TM08	**260 - 380**	C 24 - 39	30N 45 - 58	15N 72 - 80	HBS 251 - 359	-	KHN 271 - 391
360	A	**106 - 200**	**A 39 - 57**	30T 53 - 76	15T 77.5 - 89.5	HBS 106 - 196	-	KHN 121 - 228
	1/4 H	**153 - 293**	**A 50 - 65**	30T 68 - 85	15T 85.5 - 94	HBS 151 - 282	-	KHN 174 - 334
	1/2 H	**160 - 383**	**A 51 - 70**	30T 69 - 30N 60	15T 86 - 15N 81	HBS 158 - 363	-	KHN 182 - 437
	H	**180 - 491**	**A 55 - 75**	30N 30 - 68	15N 64 - 85	HBS 177 - 459	-	KHN 205 - 560
	AT	**343 - 528**	C 35 - 52	30N 55 - 70	**15N 78 - 86**	HBS 322 - 478	-	KHN 351 - 558
	1/4 HT	**383 - 598**	C 39 - 57	30N 59 - 75	**15N 80 - 88**	HBS 362 - 433	-	KHN 394 - 634
	1/2 HT	**395 - 695**	C 40 - 60	30N 60 - 82	**15N 81 - 90**	HBS 374 - 506	-	KHN 407 - 731
	HT	**446 - 695**	C 45 -65	30N 64 - 82	**15N 83 - 90**	HBS 426 - 506	-	KHN 465 - 731
	MH02	**180 - 205**	B 89 - 94	30T 76 - 79	15T 90 - 91	-	HBS 153 - 171	KHN 196 - 221
	MH04	**200 - 320**	B 93 - C 32	30T 78 - 30N 53	15T 111 - 15N 76	HBS 201 - 300	HBS 167 - 420	KHN 216 - 327
	MH06	**300 - 375**	C 30 - 38	30N 50 - 58	15N 75 - 80	HBS 283 - 353	-	KHN 308 - 385
	MH08	**350 - 415**	C 36 - 42	30N 56 - 61	15N 78 - 82	HBS 328 - 395	-	KHN 358 - 430
	MH10	**395 - 470**	C 40 - 47	30N 60 - 66	15N 81 - 84	HBS 374 -448	-	KHN 407 - 492
	MH12	**430 - 490**	C 43 - 49	30N 64 - 67	15N 82 - 85	HBS 410 - 463	-	KHN 447 - 515

Publish Data in plain font are conversions using internal Materion data or the appropriate table in ASTM E140. Numbers in red are out of range of the standard hardness conversion charts.

©2020 Materion Brush Inc.

Table V-6 - Hardness Values for Strip (Continued)

Alloy	Temper	Hardness						
		Vickers or Diamond	Rockwell	Rockwell Superficial		Brinell		Knoop
		Pyramid (DPH)	A, B or C	30T / 30 N	15T / 15 N	5000 kg	500 kg	500 g
Other Alloy Materials								
C18080*	TM04	**140 - 170**	-	-	-	-	-	-
	TM08	**150 - 180**	-	-	-	-	-	-
C18600	TM02	-	-	-	-	-	-	-
	TM04	-	-	-	-	-	-	-
	TM08	-	-	-	-	-	-	-
C18665	H	**150 - 190**	-	-	-	-	-	-
	EH	**170 - 210**	-	-	-	-	-	-
	S	**180 min.**	-	-	-	-	-	-
C19025	1/2 H	**135 - 170**	-	-	-	-	-	-
	H	**155 - 185**	-	-	-	-	-	-
	XS	**190 min.**	-	-	-	-	-	-
C19210	H	**120 nom.**	-	-	-	-	-	-
	XS	-	-	-	-	-	-	-
C19400	S	**130 - 150**	**B 76 nom.**	-	-	-	-	-
C19700	H	**132 - 153**	**B 69 nom.**	-	-	-	-	-
	XS	**153 - 174**	**B 75 nom.**	-	-	-	-	-
C19900*	TM02	**270 - 320**	-	-	-	-	-	-
	TM04	**280 - 330**	-	-	-	-	-	-
	TM05	**300 - 350**	-	-	-	-	-	-
	TM06	**310 - 360**	-	-	-	-	-	-
C26000	H	**148 - 173**	**B 82 nom.**	-	-	-	-	-
	S	**178 - 203**	**B 91 nom.**	-	-	-	-	-
	XS	**184 - 209**	**B 93 nom.**	-	-	-	-	-
C42500	H	**153 - 190**	**B 85 nom.**	-	-	-	-	-
	S	**175 - 220**	**B 92 nom.**	-	-	-	-	-
	XS	**190 min.**	**B 92 min.**	-	-	-	-	-
C50715	H	-	-	-	-	-	-	-
	EH	-	-	-	-	-	-	-
	SH	-	-	-	-	-	-	-
C51000	1/2 H	**130 - 165**	**B 72 nom.**	-	-	-	-	-
	H	**175 - 205**	**B 88 nom.**	-	-	-	-	-
	S	**205 - 235**	**B 95 nom.**	-	-	-	-	-
C52100	1/2 H	**150 - 185**	-	-	-	-	-	-
	H	**190 - 220**	-	-	-	-	-	-
	S	**225 - 255**	-	-	-	-	-	-
C64725	1/2 H	**150 - 215**	-	-	-	-	-	-
	H	**165 - 230**	-	-	-	-	-	-
	EH	**180 - 240**	-	-	-	-	-	-
	SH	**200 min.**	-	-	-	-	-	-

MATERION

©2020 Materion Brush Inc.

Table V-6 - Hardness Values for Strip (Continued)

Alloy	Temper	Hardness						
		Vickers or Diamond	Rockwell	Rockwell Superficial		Brinell		Knoop
		Pyramid (DPH)	A, B or C	30T / 30 N	15T / 15 N	5000 kg	500 kg	500 g
Other Alloy Materials								
C64727	H	**246 nom.**	-	-	-	-	-	-
	SH	**263 nom.**	-	-	-	-	-	-
C65400	1/2 H	-	**B 92 nom.**	-	-	-	-	-
	H	-	**B 97 nom.**	-	-	-	-	-
	S	-	**B 100 nom.**	-	-	-	-	-
	XS	-	**B 101 nom.**	-	-	-	-	-
C65500	H	-	**B 93 typ.**	-	-	-	-	-
	S	-	**B 97 typ.**	-	-	-	-	-
C68800	1/2 H	**240 nom.**	**B 95 nom.**	-	-	-	-	-
	H	**258 nom.**	**B 97 nom.**	-	-	-	-	-
	S	**275 nom.**	**B 99 nom.**	-	-	-	-	-
	XS	**280 min.**	**B 99 min.**	-	-	-	-	-
C70250	TM02	**190 - 240**	-	-	-	-	-	-
	TM03	**200 - 250**	-	-	-	-	-	-
C70260*	TM00	**190 nom.**	-	-	-	-	-	-
	TM02	**210 nom.**	-	-	-	-	-	-
C72500	1/2 H	**132 - 180**	**B 80 nom.**	-	-	-	-	-
	H	**135 - 180**	**B 82 nom.**	-	-	-	-	-
	S	**164 - 218**	**B 90 nom.**	-	-	-	-	-
C77000	1/2 H	**154 - 198**	**B 86 nom.**	-	-	-	-	-
	H	**188 - 220**	**B 93 nom.**	-	-	-	-	-
	S	**228 - 250**	**B 98 nom.**	-	-	-	-	-
S30100	A	**170 nom.**	-	-	-	-	-	-
	1/2 H	**300 nom.**	-	-	-	-	-	-
	H	**390 nom.**	-	-	-	-	-	-

Published data are in bold font. Data in plain font are conversions using internal Materion data or the appropriate table in ASTM E140.
Numbers in red are out of range of the standard hardness conversion charts.

MATERION

©2020 Materion Brush Inc.

When performing hardness testing on strip or stamped parts, it is important to avoid some common mistakes (Figure V-26). Make certain that the particular test scale is appropriate for the size and hardness of the test specimen, and that the corresponding correct load and indenter are used. Ensure that the hardness tester is properly calibrated, and that the test piece is appropriately fixtured, if necessary. During the test, be sure to provide an adequate spacing between adjacent indentations as well as between the indentations and the edge of the test specimen. ASTM test specifications provide detailed guidelines on this (ASTM E10, E18, E92, E382, E140). Be certain to record enough measurements to average out local variations. Be aware that the hardness value may be higher on work hardened surfaces than within the base metal. Be certain to use the appropriate formulas to correct the hardness value measured on curved surfaces. For very small parts, microindentation hardness tests such as Vickers hardness or diamond pyramid hardness (DPH) tests should be used, and the specimen should be appropriately metallographically mounted (Figure V-27).

More detailed information on hardness testing is available in the Materion TechBrief "Hardness Testing Copper beryllium," as well as the Materion presentation "Avoiding the Pitfalls of Hardness Testing and Technical Tidbits issues #25 and #26."

Figure V-26 Hardness Testing Pitfalls

- **Indentations too close to each other**
- **Indentations too close to edge**
- **Load/Indenter combination too large (anvil effect)**
- **Stacking multiple test pieces**
- **Testing through plating layer**




Figure V-26 Hardness Testing Pitfalls
These are common pitfalls that lead to the generation of erroneous numbers in a hardness test. The material must be free to move, so that the indentation should be far from the strain hardening effects of edges or previous indentations. If the piece is too thin or the load is too large, the reading will be affected by the underlying material. Surface curvature will also affect the results, if it is not appropriately accounted for by the appropriate correction factors published in test standards.

Figure V-27 Samples Appropriately Mounted for Microindentation Hardness Testing



Figure V-27 Samples Appropriately Mounted for Microindentation Hardness Testing
Mounting in resin and testing into the cross section eliminates most of the pitfalls seen in the previous figure.

MATERION

©2020 Materion Brush Inc.

Secondary Properties (Time Related)

Stress Relaxation

Stress relaxation is the gradual decay of stress under constant strain at elevated temperatures. Elastic strain is slowly converted to plastic strain, so that the permanent set increases over time. This property is measured by applying a fixed strain or displacement to a sample and measuring either the decrease in normal force or the increase in permanent set over fixed time intervals. A series of data curves is then plotted to show the percentage of stress remaining as a function of time and temperature. Temperature is more important than time for stress relaxation. Higher temperature means more rapid relaxation. The temperature of an actual connector is the ambient temperature plus the heat generated in the connector. The connector material's electrical and thermal conductivity determines the maximum internally generated temperature rise under different circuit conditions. Alloys with higher conductivity, therefore, will reach a lower maximum temperature that is advantageous from a stress relaxation point of view.

Most connectors operate at temperatures less than one half of the absolute melting temperature. Therefore, non-diffusion controlled mechanisms, including dislocation gliding, flow of grain boundaries, diffusion of vacancies and twinning govern the stress relaxation process. Figure V-28 uses cantilever beam maximum surface stress to demonstrate stress relaxation conditions. The relationship between maximum surface stress and normal force dictates that stress relaxation decreases normal force (Figure V-29).

Test Procedures –

The standard procedure utilizes tapered cantilever beam-style test samples with cross sections of the approximate dimensions of the contact design. Figure V-30 shows a test sample loaded in a test fixture. The set screw on the bottom deflects the beam tip to a value calculated to coincide with the desired stress level, usually 75% of the yield strength. (Stressing alloys to a constant percentage of their individual yield strengths is preferable to a common numerical stress value for all alloys.)

Figure V-28 Stress Relaxation Conditions




Figure V-28 Stress Relaxation Conditions
While under constant deflection (no change over time), the stress will fall over time as elastic strain is converted to plastic strain (delayed permanent set.)

Figure V-29 Stress Relaxation vs. Normal Force




Figure V-29 Stress Relaxation vs. Normal Force
In a cantilever beam, the bending stress provides the normal force. During stress relaxation, the falling stress level reduces the normal force, increasing contact resistance and decreasing reliability.

Measurement of the permanent set of the beam occurs at various times after continuous exposure to elevated temperatures. The measured permanent set reflects a loss of spring force, or a relaxation of the initial stress, as a result of the time and temperature exposure. The percentage loss at a given temperature and time is relatively constant for any initial stress below the alloy's yield strength. This technique works well for strip 0.010" (0.25 mm) or greater in thickness. Thinner strip requires a different technique.

©2020 Materion Brush Inc.

Figure V-30 Standard Stress Relaxation Test Apparatus




Figure V-30 Standard Stress Relaxation Test Apparatus
The tapered beam specimen helps to ensure a more uniform stress down the length of the beam while it is in the furnace.

Figure V-31 Tensile Stress Relaxation Test Apparatus




Figure V-31 Tensile Stress Relaxation Test Apparatus
This setup is far more complex and time-consuming than the simple tapered cantilever beam test. Nonetheless, it is suited for thin gauge strip and foils, and has the advantage of a theoretically uniform stress state in the entire sample.

The dynamic tensile stress relaxation test (Figure V-31) is more complicated, but is well suited to thin gauge strip or wire where the limited size prevents the use of a tapered cantilever beam. The strip or wire is placed in the test fixture, and is loaded in tension until the load cell records the force load corresponding to the desired stress level. The test sample is then gently vibrated, and the voltage output of the piezoelectric sensor in the test fixture is monitored by a spectrum analyzer to determine the test sample's natural frequency of vibration. The test fixture is then exposed to the test temperature for the desired length of time, and the frequency is measured again. The natural frequency is dependent on the tension in the test sample, so stress relaxation manifests itself as a reduction in tension and a corresponding decrease in natural frequency over time.

The tapered cantilever beam and the dynamic tensile stress relaxation tests are not equivalent, however. The tapered cantilever beam sample is stressed in bending, so a stress gradient exists in the beam, from zero stress at the neutral axis to maximum stress at the upper and lower surface. Therefore, only the material near the outer surface experiences stress relaxation. The data generated by this test can be used to estimate the percent stress remaining in contacts that are loaded in bending. The dynamic tensile test sample is loaded in pure tension, so that the entire sample is uniformly stressed, and the entire sample relaxes. This data generated by this test is more suited for finite element analysis of stress relaxation, where it is desired to correlate relaxation with an absolute stress state.

©2020 Materion Brush Inc.

A Larson-Miller stress relaxation plot presents stress relaxation data enabling performance prediction over a range of times and temperatures. This plotting technique has fallen out of favor, although the calculations behind it are useful for calculating "equivalent" times and temperatures for accelerated stress relaxation testing, as long as the difference in temperature is not more than about 25°C (See Technical Tidbits issues 87, 88, 89 and 98). The remaining stress indicates the contact alloy's ability to retain a portion of its stress. The stress relaxation plot predicts the percentage of remaining stress after exposure to a given elevated temperature over a specific time interval. **Isothermal** plots (Figure V-32) show curves for individual materials at specific temperatures on a plot of percent stress remaining vs. time. **Isochronal** plots (Figure V-33) show curves for individual materials for specific exposure times on a plot of percent stress remaining vs. test temperature. Table V-7 provides data on the relaxation characteristics of spring alloys at 100°C, 150°C and 200°C. Additional stress relaxation curves are available in the Materion document "Atlas of Stress Relaxation Curves for Copper Beryllium and Selected Copper Alloy Spring Materials." In addition, stress relaxation curves and data for Materion's strip alloys are available from the Customer Technical Service Department.

Table V-7 - Stress Relaxation

Alloy	Temper	Percent Stress Remaining after 1000 Hours (Initial Stress = 75% of 0.2% Offset Yield Strength)			
		100°C (212°F)	150°C (302°F)	200°C (392°F)	250°C (482°F)
Materion Alloys					
25	AT	96	88	61	-
	1/4 HT	96	90	62	-
	1/2 HT	97	88	59	-
	HT	98	87	55	-
190	AM	97	61	5	-
	1/4 HM	97	69	20	-
	1/2 HM	97	66	26	-
	HM	98	74	28	-
	SHM	98	77	35	-
	XHM	98	86	52	-
	XHMS	98	84	47	-
290	TM02	97	90	59	-
	TM04	98	86	33	-
	TM06	99	93	68	-
3	HT	95	85	66	-
174	1/2 HT	94	82	64	-
	HT	95	85	77	-
Brush® 60	3/4 HT	96	85	65	-
	HT	96	89	75	-
390	HT	95	85	69	-
390E	EHT	94	84	64	-
BrushForm® 158	TM08	-	84	70	-
360	MH8	-	-	-	96
	MH10	-	-	-	96
Other Copper Alloys					
C26000	H	41	-	8	-
C19700	XH	83	65	38	-
C51000	S	95	52	16	-
C65400	S	72	-	-	-
C68800	S	52	23	9	-
C72500	S	89	-	40	-

Red = Estimated Data Point

MATERION

©2020 Materion Brush Inc.

Figure V-32 Isothermal Stress Relaxation Curves




Figure V-32 Isothermal Stress Relaxation Curves
Precipitation hardened alloys like CuBe and CuNiSn have much greater resistance to stress relaxation than alloys strengthened by cold work alone, such as brasses and bronzes. Isothermal plots compare the stress relaxation behavior of different materials over time at a constant temperature.

Figure V-33 Isochronal Stress Relaxation Curves




Figure V-33 Isochronal Stress Relaxation Curves
Isochronal plots compare the stress relaxation behavior of different materials at a specified time over different temperature ranges.

FEA modeling frequently requires the stress relaxation data as an empirical equation. One frequently used equation is of the form:

$$\% \text{ Remaining Stress} = A - B (\log \{t\})^2$$

Where A and B are constants independent of initial stress and time yet dependent upon alloy, temper and temperature while t is time in hours. Table V-8 is a summary of the parameters, A and B, for several high performance copper alloys.

MATERION

©2020 Materion Brush Inc.

Table V-8 - Stress Relaxation Equation Coefficients for Strip

Alloy & Temper	Test Temperature		Equation Coefficients	
	°F	°C	A	B
Materion Alloys				
25 1/4 HT	257	125	97.83	0.079
	302	150	96.61	0.139
	392	200	98.22	0.749
25 1/2 HT	257	125	98.33	0.091
	302	150	97.67	0.202
	392	200	94.36	0.756
190 1/2 HM	257	125	99.03	0.279
	302	150	97.04	0.630
	392	200	62.48	0.841
190 XHM	257	125	97.62	0.104
	302	150	97.47	0.242
	392	200	93.51	0.818
290 TM04	257	125	100.86	0.159
	302	150	97.77	0.233
	392	200	97.10	1.311
174 1/2 HT	257	125	94.49	0.186
	302	150	91.17	0.239
	392	200	79.18	0.260
174 HT	257	125	97.84	0.145
	302	150	94.78	0.193
	392	200	89.68	0.273
Other Copper Alloys				
C19700 EH	257	125	90.36	0.265
	302	150	83.77	0.360
	392	200	62.93	0.511
C51000 S	257	125	99.42	0.423
	302	150	94.02	0.849
	392	200	53.73	0.762

Fatigue

Fatigue is the phenomenon leading to fracture under repeated or fluctuating stresses with a maximum value less than the tensile strength of the material. During each loading cycle, microscopic imperfections can nucleate cracks, while existing cracks will slightly extend. Over many loading cycles, these cracks propagate until the material can no longer support the load causing the material to fracture. Figure V-34 defines the fatigue testing conditions for strip in bending. The stress ratio R is defined as the minimum stress divided by the maximum stress experienced in each cycle. **Fully reversed** bending occurs when the beam is bent in one direction to a given stress level and then bent in the opposite direction to the same stress level. Since the minimum stress in each cycle is the inverse of the maximum stress, the test condition is denoted as **R=-1**. **Unidirectional** bending, where the minimum stress in each cycle is zero, is therefore denoted as **R=0**.

For typical connector applications, the number of cycles is typically 1K-10K in one way bending (R=0). The package governs the deflection. For switch and relay applications, reverse bending (R=-1) is the fatigue mode. The **fatigue life** is the number of stress cycles prior to failure for a stated test condition. The **fatigue limit** is the maximum stress in each cycle that leads to fatigue failure in a specified number of cycles. Fatigue is a surface phenomenon affected by surface quality and edge condition. In order to improve the fatigue properties, it is advisable to remove surface and edge damage from stamping or other fabrication processes and redistribute surface strains.

Figure V-34 Flexural Fatigue Test Conditions




Figure V-34 Flexural Fatigue Test Conditions
The bending ratio (R) is defined as the minimum stress experienced during each cycle divided by the maximum stress. In unidirectional (R=0) bending, during each cycle the specimen is deflected to a peak stress level, and then is returned to the zero stress position before beginning the next cycle. In fully reversed bending (R=-1), the magnitudes of the positive and negative stresses are equal. In any bending condition, R will fall between 1 and -1.

©2020 Materion Brush Inc.

Fatigue curves can be generated using either strain life or stress life methods. Stress life techniques are easier to use, and are valid for high cycle, low stress regimes when all of the applied stress is elastic. Strain life methods are more complicated, but are more accurate at the high stress, low cycle regime. You should use strain life when some of the alternating stress is plastic. There is a 3rd approach to analyzing fatigue, known as the fracture mechanics method. These techniques are best suited for numerical simulation using finite element analysis, as it relates the change in crack length per cycle to the range of stress intensity at the crack tip.

The discussion that follows relates to stress life methods. For a more thorough discussion on fatigue and fatigue calculations, please see Materion Technical Tidbits issues 52 through 72.

Conditions such as stress cycle, surface condition and environmental conditions strongly influence fatigue test results and performance. Table V-9 displays the fatigue strength of several connector spring alloys at 10^8 cycles. Figure V-35 contains fatigue curves (Wöhler or S-N curves). To estimate fatigue life, determine the stress level and the stress state. The intersection of the curves with the stress level determines the expected number of cycles. Conversely, one can use the required number of cycles to estimate the maximum allowable design stress in the material. Where data is otherwise unavailable, the R=-1 fatigue strength can be assumed to be the arithmetic mean of the R=0 fatigue strength and the ultimate tensile strength. Bending fatigue curves for various Materion alloy strip materials, as well as rotating beam fatigue curves for rod are available from the Customer Technical Service Department.

Table V-9 - Fatigue Strength of Strip in Bending

Alloy	Temper	10^8 Cycle Fatigue Strength			
		R=-1 (Fully Reversed)		R=0 (Unidirectional)*	
		(ksi)	(MPa)	(ksi)	(MPa)
Materion Alloys					
25	A	30-35	207-241	45-57	310-393
	1/4 H	31-36	214-248	53-62	365-427
	1/2 H	32-38	221-262	59-69	407-476
	H	35-39	241-269	68-80	469-552
	AT	40-45	276-310	103-120	710-827
	1/4 HT	40-45	276-310	108-125	745-862
	1/2 HT	42-47	290-324	114-131	786-903
	HT	45-50	310-345	118-135	814-931
190	AM	40-45	276-310	70-78	482-537
	1/4 HM	41-47	283-324	76-84	524-579
	1/2 HM	42-48	290-331	81-92	558-634
	HM	45-52	310-359	90-101	621-696
	SHM	47-55	324-379	99-108	683-745
	XHM	50-57	345-393	103-116	710-800
	XHMS	50-60	345-414	113-125	779-862
290	TM00	40-45	276-310	70-83	482-572
	TM02	42-48	290-331	81-94	558-648
	TM04	44-50	303-345	92-105	634-724
	TM06	47-57	324-393	101-116	696-800
	TM08	50-60	345-414	113-128	779-883
3	AT	38-44	262-303	69-87	476-600
	HT	42-47	290-324	76-91	524-627
174	1/2 HT	45-50	310-345	70-83	482-572
	HT	45-50	310-345	78-90	537-621
Brush® 60	3/4 HT	46-47	317-324	81-91	558-627
	HT	42-45	290-310	81-93	558-641
390	HT	30-40	207-276	84-99	579-683
390E	EHT	45-50	310-345	70-85	482-586
BrushForm® 158	HT	40-45	276-310	70-80	482-552
Other Copper Alloys					
C26000	H	21	145	43	296
C19400	S	21	145	42	290
C51000	S	30	207	59	407
C52100	S	33	228	64	441
C65400	S	37	255	77	531
C68800	S	37	255	77	531
C72500	S	38	262	56	317

*R=0 data computed as arithmetic mean of R=-1 data and ultimate tensile strength

MATERION

©2020 Materion Brush Inc.

Figure V-35 S-N (Wöhler) Curves for Flexural Fatigue




Figure V-35 S-N (Wohler) Curves for Flexural Fatigue
An S-N curve is created by compiling the cycles to failure over a large number of stress levels. There is more scatter in low cycle data, but high cycle data takes longer to generate.

For stress states other than R=0 and R=-1, the analysis becomes more complicated. An example is a switch contact that is initially stressed to a preload condition during assembly. During cycling, the stress will rise to a maximum level before falling back to the preload condition, indicating an R value greater than zero but less than one. In this case, **Goodman** or **Gerber** diagrams should be used to calculate the allowable alternating stress.

Figure V-36 shows a standard **Goodman diagram**. The **mean stress** is the arithmetic mean of the maximum and minimum stress, while the alternating stress is the difference of the maximum and minimum stress. Given the mean stress (S_M), the ultimate tensile strength (UTS) of the material, and the R=-1 fatigue strength (S_F) for the desired number of cycles, the maximum allowable **alternating stress** value can be calculated as:

$$S_A = 2S_F\left(1 - {S_M}/{UTS}\right)$$

However, if the alternating stress level falls between the two dashed lines on Figure V-36, the design can be considered safe. The modified Goodman diagram in Figure V-37 accounts for the yielding as a potential failure mode, so the safe design envelope is adjusted accordingly. The Gerber diagram (Figure V-38) is less conservative than the Goodman diagram. Here, the maximum allowable stress is calculated as:

$$S_A = 2S_F\left(1 - \left({S_M}/{UTS}\right)^2\right)$$

Figure V-36 Goodman (Haigh) Diagram




Figure V-36 Goodman (Haigh) Diagram
This diagram is constructed using the fatigue strength at the desired number of cycles and the tensile strength. The mean stress is the arithmetic mean of the maximum and minimum stress, and the alternating stress is the difference of the two quantities. If the mean stress in the design is less than the allowable mean stress, there is a good chance the material will survive the desired number of cycles. Otherwise, the design will likely fail in fatigue before its desired end of life.

Figure V-37 Modified Goodman Diagram




Figure V-37 Modified Goodman Diagram
The modified Goodman diagram narrows the permissible operating envelope by adding yielding as a second failure mode.

©2020 Materion Brush Inc.

Figure V-38 Gerber Diagram




Figure V-38 Gerber Diagram
The Gerber diagram is similar to the Goodman diagram. Although it is more representative of actual material behavior than the Goodman diagram, it is also less conservative and increases risk.

Figure V-39 Cantilever Beam Normal Force




Figure V-39 Cantilever Beam Normal Force
The normal force of a cantilever beam in bending is directly proportional to the deflection, beam width, and elastic modulus of the material. It is proportional to the cube of the thickness, and inversely proportional to the length, so these two variables become more important.

Tertiary (Property Interdependence)

Normal force

Normal or contact force is the most important attribute of a contact system directly related to contact reliability. Normal force is the force generated by surfaces contacting each other and perpendicular to those surfaces. For a cantilever beam type connector the following formula represents the normal force: (Figure V-39)

$$\text{Normal Force, } P = \frac{dEwt^3}{4L^3}$$

Where: d = deflection of beam
E = modulus of elasticity
w = beam width
t = beam thickness
L = beam length

Normal force is also a function of maximum surface stress:

$$\text{Normal Force, } P = \frac{\sigma_{Max} wt^2}{6L}$$

Interrelationships between the contact system and its normal force are in Table V-10.

Table V-10 - Normal Force Interrelationships

Affected by Normal Force	Affects Normal Force
Friction Force (Insertion/Withdrawal)	Contact Spring Rate (Elastic Modulus, Contact Geometry)
Wear Characteristics	Contact Pre-load
Contact Spring Stresses	Contact Beam Deflection
Contact Housing Stresses	Permanent Set
Contact Resistance	Stress Relaxation
Vibration/Fretting Resistance	

The frictional force depends on the normal force via the coefficient of friction (Figure V-40). The frictional force is very sensitive to conditions at the interface. In order to obtain a useful measured test value for the coefficient of friction in your design, the test conditions (loading mode, surface roughness, normal force, lubrication, etc.) should closely match your design. (Figure V-41).

Insertion and extraction forces are predominantly frictional forces. Insertion force is dependent on the lead-in angle of the mating parts as well as the friction force (Figures V-42 and V-43). Note that the peak insertion force will always be greater than the extraction force.

$$\text{Friction Force, } F = \mu P$$

Where: F = friction force
μ = coefficient of friction
P = normal force

©2020 Materion Brush Inc.

Figure V-40 Friction Forces




Figure V-40 Friction Forces
Frictional forces are typically proportional to the normal force between the mating surface. The friction coefficient is a system property dependent on lubrication, contamination, surface curvature, surface roughness, the hardness of the surfaces, and many other variables. It is not an intrinsic property of any material, and depends on the particular situation.

Figure V-41 Friction Test Methods




Figure V-41 Friction Test Methods
Friction is tested by a few standard methods. In order to estimate the frictional coefficient of your application, you will need to find a test condition that approximates the loading condition. You should also match the surface condition and lubrication used in the test as closely as possible to those of the application.

Figure V-42 Insertion and Extraction Forces




Figure V-42 Insertion and Extraction Forces
During insertion, the force required to continue movement increases until the contacts are deflected to their maximum amount. Then, the force drops down to a steady state sliding condition. The withdrawal force will be approximately equal to the steady state insertion force, and its peak will be much less than the peak insertion force.

Figure V-43 Insertion Force Calculation

$$F_{Insertion} = N \cdot P_{Normal}\left(\frac{\sin\alpha + \mu \cdot \cos\alpha}{\cos\alpha - \mu \cdot \sin\alpha}\right)$$




Figure V-43 Insertion Force Calculation
This equation demonstrates why the insertion force increases far beyond the peak extraction force. The withdrawal force is entirely governed by frictional forces, while the insertion force also includes the force required to deflect the contacts on the female side.

©2020 Materion Brush Inc.

True Stress and Strain vs. Engineering Stress and Strain

Recall that engineering stress at given point in a tensile test is defined as the current load divided by the original area of the test specimen, and that the engineering strain is simply the current change in length divided by the original length. The engineering stress assumes that the cross sectional area of the test specimen does not change. However, at the ultimate tensile strength, the test specimen will begin to neck (locally decrease in cross section) prior to failure. (See Figure V-**44**) The engineering stress will show a decrease at this point, since the force required to further deform the metal drops as the minimum cross section continues to decrease until the sample fractures. However, the **true stress**, defined as the force divided by the current actual minimum cross sectional area, will continue to increase until the point of fracture. For the same reason, the true strain is defined as the integral along the length of all the instantaneous increases in length divided by the original length, which equates to the natural logarithm of the instantaneous length divided by the original length.

$$\text{Engineering Stress } \sigma_{Engineering} = \frac{P}{A_0}, \text{ True Stress } \sigma_{True} = \frac{P}{A_i}$$

$$\text{Engineering Strain } \varepsilon_{Engineering} = \frac{\Delta L}{L_0}, \text{ True Strain } \varepsilon_{True} = \int_{L_0}^{L_i} \frac{\partial L}{L} = \ln \frac{L_i}{L_0}$$

Where P = Force, A_0 = the original cross sectional area, A_i = the instantaneous cross sectional area, L_0 = the original length, L_i = the instantaneous length.

Figure V-44 Decrease of Cross Section During Necking




Figure V-44 Decrease of Cross Section During Necking
During uniform elongation, the entire test cross section decrease by the same amount according to Poisson's ratio. In ductile materials, once necking begins, all further reduction in cross section occurs at the neck, accelerating the failure. Brittle materials, on the other hand, will fail without necking.

The true stress is very difficult to measure directly, since the minimum cross sectional area of the tensile sample would have to be known at all times during the test. However, as long as the deformation is uniform, the stress is below the ultimate tensile strength, and there is no necking, the true stress and strain can be computed from the engineering stress and strain by the following formulas:

$$\varepsilon_{True} = \ln\left(\varepsilon_{Engineering} + 1\right)$$

and

$$\sigma_{True} = \sigma_{Engineering}\left(1 + \varepsilon_{Engineering}\right)$$

At small deflections, for a given contact configuration and a constant deflection (strain), the normal force (stress) of the contact is a function only of the modulus of elasticity.

At large deflections, above the yield strength, the rate of increase in normal force with deflection decreases. This leveling off in force occurs as a result of plastic deformation, or permanent set, along the flexed portion of the beam. After large deflections, the contact will not return to its initial unstressed position.

In the plastic strain region, above the yield strength, the stress-strain behavior is no longer linear (Figure V-45). In this region, where the alloy is subject to strain hardening, the following equation can be used to predict the true stress, σ, for known levels of strain.

$$\sigma = K\varepsilon^n$$

Where ε is the true plastic strain, K is a constant known as the **strain hardening coefficient**, and n is the **strain hardening exponent**. Figure V-45 shows how this approximation is a good fit for the true stress-strain curve in the plastic region. The figure also illustrates the difference between the true stress-strain curve and the engineering stress-strain curve.

A materials composition, its amount of cold reduction and its processing history influence the values of n and K. Table V-11 provides representative values of the strain hardening coefficients and exponents for copper beryllium alloys.

MATERION

©2020 Materion Brush Inc.

Figure V-45 Strain Hardening




Figure V-45 Strain Hardening
During plastic flow, the dislocations will pile up and interfere with each other, resulting in higher strength. If the material is unloaded after plastic deformation and then subsequently reloaded, the new yield strength will be greater than the original yield strength by the amount that the material work hardened.

Table V-11 - Strain Hardening Coefficient & Exponent

Alloy	Temper	Longitudinal			Transverse		
		n	K (ksi)	K (MPa)	n	K (ksi)	K (MPa)
Materion Alloys							
25	ADS	0.425	153	1057	-	-	-
	A	0.427	156	1077	0.447	154	1059
	1/4 H	0.213	138	952	0.206	133	917
	1/2 H	0.111	132	907	0.050	115	790
	H	0.018	121	832	0.047	144	993
	AT	0.081	243	1677	0.076	233	1603
	1/4 HT	0.057	231	1594	0.081	207	1424
	1/2 HT	0.064	249	1716	0.037	228	1570
	HT	0.032	225	1554	0.085	297	2046
190	AM	0.202	178	1227	-	-	-
	1/4 HM	0.120	165	1135	0.166	181	1251
	1/2 HM	0.119	184	1272	0.083	161	1107
	HM	0.087	191	1315	0.084	189	1307
	SHM	0.081	207	1424	-	-	-
	XHM	0.056	206	1417	0.054	210	1445
	XHMS	0.051	225	1554	0.030	212	1460
290	TM02	0.132	194	1340	0.182	217	1496
	TM03	-	-	-	-	-	-
	TM04	0.120	206	1421	0.094	193	1330
	TM06	0.092	231	1592	-	-	-
	TM08	-	-	-	-	-	-
3	AT	0.114	163	1123	-	-	-
	HT	0.096	168	1155	0.165	178	1231
174	1/2 HT	0.093	141	970	0.150	147	1014
	HT	0.065	154	1064	0.090	162	1119
Brush® 60	3/4 HT	0.090	164	1133	0.137	185	1274
	HT	0.087	170	1170	0.151	184	1267
390	HT	0.006	146	1010	0.038	162	1117
390E	EHT	0.042	176	1213	-	-	-

©2020 Materion Brush Inc.

Permanent set

Permanent set is the plastic deformation that remains after releasing the deformation producing stress (Figure V-46). It accrues cumulatively as a result of repeated deflections during component mating. Any permanent set from oblique insertions or insertions of oversized test probes reduces the amount of total deflection available for subsequent insertions of correctly aligned or undersized test probes. The lost normal force results in connector performance degradation. The material property of importance is yield strength. Toughness and resilience are functions of yield strength.

Figure V-46 Permanent Set




Figure V-46 Permanent Set
When a material is released from a load, the unloading curve will follow a path parallel to the elastic modulus. If the material has yielded, there will be some positive strain when the stress returns to zero. This is the plastic strain. The elastic strain is relieved during the unloading process.

The ability to withstand occasional stress above the yield stress without fracturing is desirable. The **toughness** of a material is its ability to absorb energy in the plastic range. Toughness is defined as the area under a stress-strain curve up to the maximum stress (Figures V-47 and V-48). This area is an indication of the work per unit volume done on the material without causing it to rupture. Toughness is a parameter that comprises both strength and ductility.

The following equation approximates toughness:

Toughness = (YS X US) + ½ (TS – YS) US

Where: YS = 0.2% offset yield strength
TS = ultimate tensile strength
US = uniform strain

Figure V-47 Toughness Definition




Figure V-47 Toughness Definition
Toughness is the area under the stress strain curve, which is the amount of energy absorbed by the material during deformation. Stress and strain are normalized force and deflection, and the area under a force deflection curve is the work done (energy used) by the force to get that deflection.

MATERION

©2020 Materion Brush Inc.

Figure V-48 Toughness Approximation




Figure V-48 Toughness Approximation
This is a reasonable approximation for toughness, since the shaded area above and to the left of the curve is typically insignificant compared to the shaded area below and to the right of the curve, and non-uniform elongation is typically much smaller than uniform elongation.

Resilience is the ability of a material to absorb energy when deformed elastically and to return it when unloaded. The total deflection that a connector can withstand without yielding is a function of the maximum elastic strain in the material's stress-strain curve. The elastic strain, or elastic resilience, is equal to the yield strength divided by the elastic modulus (Figure V-49).

$$\text{Resilience} = \frac{YS}{E}$$

Where YS = 0.2% offset yield strength
E = Modulus of elasticity

The measurement of **modulus of resilience**, U, is the strain energy per unit volume required to stress the material from zero stress to the yield stress. The following equation defines the modulus of resilience:

$$U_R = \frac{YS^2}{2E}$$

Where YS = 0.2% offset yield strength
E = Modulus of elasticity

These equations indicate that the ideal material for resisting energy loads in applications where the material must not undergo permanent distortion is one having a high yield stress and a low modulus of elasticity. Resilience and toughness approximate durability.

Figure V-49 Modulus of Resilience




Figure V-49 Modulus of Resilience
Similar to the modulus of toughness, the modulus of resilience is the maximum amount of energy absorbed by a material in the elastic region of the stress strain curve. It is a useful measure to compare materials to be used for springs in general and for electrical contacts in particular.

MATERION

©2020 Materion Brush Inc.

Plastic deformation increases yield strength in the direction of plastic flow and decreases in the other direction. The **Bauschinger effect** (Figure V-50) results in a loss of stress upon applied stress reversal. Since forming operations result in large plastic deformations, this effect is of primary importance. Loading of a contact against the forming direction will result in a reduction of normal force and produce permanent set at loads less than that allowed by the contact design. Deflection in the forming direction will show normal force and permanent set as predicted in design. This effect is a function of yield strength in that greater yield strength results in lower reverse loading stress loss. Stress relief can minimize the effect after forming, and age hardening will virtually eliminate it (See Technical Tidbits issue #4 for more information).

Figure V-50 Bauschinger Effect




Figure V-50 Bauschinger Effect
Due to residual forming stresses, strain hardening and mechanical hysteresis, the yield strength of a part loaded in bending is higher in the direction of forming, and lower back against the direction of forming. Materials age hardened after forming would be relieved of any residual forming stresses, so they would be immune to this effect.

Electrical and Thermal Properties

Coefficient of Thermal Expansion (CTE)

CTE is the fractional change in length of a material per degree of temperature change as compared to its length at a reference temperature, usually 0°C. Differences in CTE result in a thermal mismatch between two components. The thermal expansion coefficient of copper beryllium is independent of alloy content over the temperature use range. Table V-12 gives the thermal expansion coefficients of common alloys, as well as their respective thermal conductivity, electrical conductivity, and specific heat.

MATERION

©2020 Materion Brush Inc.

Table V-12 - Room Temperature Electrical and Thermal Properties								
Alloy	Temper	Conductivity	Thermal Conductivity		Specific Heat (Heat Capacity)		Coefficient of Thermal Expansion from Room Temperature to	
		(% IACS min.)	(BTU/ ft-hr-°F)	(W/m-°C)	(BTU/lb-°F)	(J/kg °C)	400°F (in/in/°F)	200°C (m/m/°C)
Materion Alloys								
25	Age Hardened	22	60	105	0.086	360	9.7 X 10^{-6}	17.5 X 10^{-6}
M25	Age Hardened	22	60	105	0.086	360	9.7 X 10^{-6}	17.5 X 10^{-6}
190, 290	All Tempers	17	60	105	0.086	360	9.7 X 10^{-6}	17.5 X 10^{-6}
3	AT	45	140	240	0.080	335	9.8 X 10^{-6}	17.6 X 10^{-6}
	HT	48						
174	1/2 HT	50	135	230	0.08	335	9.8 X 10^{-6}	17.6 X 10^{-6}
	HT	48						
Brush® 60	3/4 HT, HT	50	128	222	0.080	335	9.8 X 10^{-6}	17.6 X 10^{-6}
390	HT	44	128	222	0.080	335	9.8 X 10^{-6}	17.6 X 10^{-6}
390E	HT	42	120	208	0.080	335	9.8 X 10^{-6}	17.6 X 10^{-6}
BrushForm®158	Age Hardened	7 max.	17	29	0.090	377	9.1 x 10^{-6}	16.4 x 10^{-6}
	Mill Hardened	7 max.						
BrushForm® 96	Age Hardened	10	30	52	0.090	377	9.0 x 10^{-6}	16.2 x 10^{-6}
	Mill Hardened	10						
360	Age Hardened	6	28	48	0.011	461	8.0 x 10^{-6}	14.4 x 10^{-6}
	Mill Hardened	5						
1915	Age Hardened	50	120	210	0.092	385	9.8 X 10^{-6}	17.6 X 10^{-6}
1916	Age Hardened	50	120	210	0.092	385	9.8 X 10^{-6}	17.6 X 10^{-6}
ToughMet® 3	All Tempers	7 max.	17	29	0.090	377	9.1 x 10^{-6}	16.4 x 10^{-6}
Other Copper Alloys								
C26000	H	28	70	120	0.090	375	11.1 X 10^{-6}	20.0 X 10^{-6}
C19400	S	60	150	260	0.092	385	9.7 X 10^{-6}	17.5 X 10^{-6}
C51000	1/2 H, H, S	15	40	70	0.091	380	9.9 X 10^{-6}	17.8 X 10^{-6}
C52100	1/2 H, H, S	13	36	62	0.091	380	10.1 X 10^{-6}	18.2 X 10^{-6}
C65400	1/2 H, H, X, XS	7	21	36	0.091	380	9.7 X 10^{-6}	17.5 X 10^{-6}
C68800	1/2 H, H, S, XS	17	40	69	0.090	375	10.1 X 10^{-6}	18.2 X 10^{-6}
C72500	1/2 H, H, S	11	31	54	0.09	377	9.2 X 10^{-6}	16.6 X 10^{-6}
C70250	TM02	40	98	170	0.091	380	10.0 x 10^{-6}	18.0 x 10^{-6}
	TM03	35						

©2020 Materion Brush Inc.

Electrical Conductivity

Electrical conductivity, γ, is the reciprocal of the material's bulk resistivity. The material electrical resistivity, ρ, is the electrical resistance of a given cross sectional area of material per unit length.

$$R = \frac{\rho L}{A}$$

Where: R = resistance (ohm)
ρ = resistivity (ohm-in or ohm-cm)
A = cross sectional area (in^2 or cm^2)
L = length (in or cm)

A copper alloy's electrical conductivity is expressed in units of %IACS. %**IACS** is the acronym for Percentage of International Annealed Copper Standard. The pure copper standard of 6.79×10^{-7} ohm-in (1.72×10^{-6} ohm-cm) at 20°C equals a value of 100%.

Thermal Conductivity

Thermal conductivity, κ, is the ease with which a material dissipates heat through itself. Formally, thermal conductivity is the rate of heat flow per unit time in homogeneous materials under steady state conditions, per unit area, per unit temperature gradient in a direction perpendicular to that area. The following equation approximates κ for temperatures above room temperature:

$$\kappa = \frac{7.1 \times 10^{-6}}{\rho} + 1$$

Where: κ = thermal conductivity (W/cm°C)
ρ = resistivity at 20°C (ohm-cm)

Temperature Rise

Temperature rise is a function of the bulk resistance of the material. The material's resistivity and contact geometry (cross sectional area and length) define the bulk resistance. The contact temperature rise depends on thermal dissipation of heat generated internally which in turn depends on the thermal conductivity of the spring material, the magnitude of the electrical current flow, the heat sink capability of the adjacent material, or convection around the connector.

The maximum, steady state temperature rise of a contact beam, accounting for the effects of resistive heating and heat transfer can be predicted by the following equation (Figure V-51):

$$\Delta T = \frac{J^2 L^2}{2\gamma\kappa A^2}$$

Where:

ΔT = temperature rise (°F)
J = current (amps)
L = beam length (in)
A = cross-sectional area (in^2)
γ = electrical conductivity (amps/Volt-in)
κ = thermal conductivity (Volt-amps/in-°F)


The conductivities are the only two material properties influencing temperature rise in a connector. This equation provides a conservative estimate of temperature rise in that it makes no allowance for heat loss through convection or radiation. It assumes that the contacts on both sides of the interface are similar in size, and that they are connected to larger copper wires that function as heat sinks.

It is apparent that temperature rise is inversely related to the product of a material's electrical and thermal conductivities. It is important that a connector material not only minimize resistive (Joule) heating through electrical conductivity, but also dissipate the heat which is generated in the contact through the alloy's thermal conductivity.

MATERION

©2020 Materion Brush Inc.

Figure V-51 Temperature Rise Approximation



$$\Delta T = T_{Hot} - T_{Cold} = \frac{J^2 \cdot L^2}{2 \cdot \gamma \cdot \alpha \cdot A^2}$$

Figure V-51 Temperature Rise Approximation
In this case, of two identical parts in contact, the peak temperature would occur where the two parts come together. This model assumes that both ends are connected to heat sinks. (This is realistic, since most contacts are attached to high conductivity wires. This temperature rise equation is conservative, since it does not take into account heat transfer by either convection or radiation, although contacts in sealed connectors approximate this condition.

Both magnitude and stability of contact resistance are critical for power distribution requirements. Joule or resistive heating, which is proportional to connector resistance, results in increases in connector operating temperature. A specified temperature rise (typically 30°C) determines the current capacity or rating. Power may be carried in single dedicated contacts or through multiple parallel contacts. (See Section VIII – Higher Voltage, Current and Power Considerations for greater detail.)

Signal Properties

Signal distribution requirements center around maintaining the integrity of the signal waveform. Impedance, propagation delay, crosstalk and low level circuit resistance are critical circuit characteristics. Conventional copper strip material connectors are effective up to a 1GHz operating frequency when proper considerations are given to electrical design. (See Section IX – EMC, SI and other High Frequency Considerations for greater detail.)

Composite Base Metals

Sometimes, there is no single material that can meet all the needs of your design, due to property trade-offs. For example, you may need very high electrical conductivity, but also good strength. At other times, you may need different properties in different sections of your part, (such as high resilience and stress relaxation at the spring end of a contact, and high ductility at the crimp end). Materion specializes in combining different metals in different ways to achieve property combinations that are impossible in monolithic materials, through a number of specialty technologies. Materion can also combine multiple technologies on one strip to create hybrid materials to meet a wide range of requirements. (See Figures V-52 and V-53.)

Figure V-52 Hybrid Technical Material-Process Technologies




Figure VI-52 Hybrid Technical Material-Process Technologies
Materion has been cladding materials for over 50 years. The clad layers can be heavy gauge or foil, as shown in the middle. The clad material can be monolithic or patterned, as shown on the right side. Already-clad materials can be further rolled and clad to each other, and the process repeated until the final product has hundreds of layers, as shown on the lower left.

©2020 Materion Brush Inc.

Figure V-53 Hybrid Technical Material-Process Technologies




Figure VI-53 Hybrid Technical Material-Process Technologies
Materion also has several decades experience in high speed strip profiling, electroplating, electron beam welding, and zone annealing.

Electron Beam (EB) Welding (Figure V-54)

An electron beam produces a higher energy density in the weld zone than any other commercial technology, including lasers. The electrons are focused to a narrow spot, approximately 0.2 mm (0.008") diameter at the weld seam. The combination of an intense, concentrated heat source and a relatively fast strip speed through the beam results in an extremely fast melting and freezing rate. This very rapid cooling rate gives the EB weld a unique metallurgy that allows successful joining of dissimilar metals that might otherwise be deemed "unweldable."

Figure V-54 Electron Beam Welding Capability




Figure VI-54 Electron Beam Welding
EB welding can join many different metals or alloys side by side, except copper and aluminum. The strip on each side of the joint can have different properties or tempers. The weld can combine precious and non-precious metals, magnetic and non-magnetic alloys, high thermal expansion and low thermal expansion metals, high conductivity and low conductivity alloys, thin metal and thick metal, etc. The strips to be joined can even have different coatings as well.

MATERION

©2020 Materion Brush Inc.

Dovetail Clad® Strip Side by Side Cladding (Figure V-55)

Copper Aluminum Dovetail Clad Strip is a breakthrough technology for joining copper and aluminum side-by-side in long continuous master coils. These coils can easily be stamped and formed to create busbars or lead tabs, enabling high-volume, low-cost laser assembly especially fitted to automotive format lithium-ion battery packs. Cladding copper and aluminum side-by-side eliminates the metallurgical instability of laser welding copper to aluminum by facilitating same metal welding of busbars to terminals. (That is, the aluminum side of the Dovetail Clad Strip can be easily welded to the aluminum terminal, and the copper side can be easily welded to the copper terminal, without fear of corrosion.)

Figure V-55 Copper-Aluminum Dovetail Clad® Strip Side by Side Cladding




Figure VI-55 Copper-Aluminum Dovetail Clad® Strip Side by Side Cladding
The dovetail clad strip joint has excellent formability, as illustrated by the cross section on the upper right. The entire joint can be bent without fracturing either the copper or the aluminum, and without separation of the layers.

Dovetail Clad Strip Features:

- Superior mechanical, electrical, and thermal performance over ultrasonic or bolted attachments
- No resistance or thermal rise at dovetail joint
- Narrow joint widths
- Overall thickness range from 0.1mm to 2.0mm
- Overall widths up to 165mm

Our cladding process achieves an excellent metallurgical bond by combining extreme reductions in cross-sectional area and thermal diffusion to create a controlled formation of a “thin” intermetallic compound resulting in a robust copper-aluminum dovetail joint which matches the strength and fatigue toughness of the aluminum alloy.

©2020 Materion Brush Inc.

Strength with Conductivity Composite (Figure V-56)

By cladding a high strength material over a high conductivity material, you can get a material that features the best of both worlds. With the high strength material on the outside (where the high bending stress is), the composite material will show the formability, stress relaxation resistance, and fatigue strength of the high strength material. Meanwhile, the inside greatly enhances the overall conductivity of the composite, without significantly reducing flexural strength or bending modulus.

Figure V-56 Clad Composite Materials




Figure VI-56 Clad Composite Materials

High strength and high conductivity strip materials can be combined to produce a hybrid structure that provides unequaled strength at high conductivity, or unequaled conductivity at high strength. In the chart above, the lines are drawn through points representing different thicknesses of BrushForm® 158 strip CuNiSn strip clad on either side of C19210, starting at the upper left from 100% C19210, through 10% BrushForm 158 strip, 20% BrushForm 158 strip, all the way to 100% BrushForm 158 strip in the lower right. Note the clear separation from monolithic alloys, in a material that still has decent formability.

Contour Profiling (Figures V-57)

Contour profiling is used to change the cross section of the strip material, or to deburr the edges of slit strip. The profile can be shaped by a grinding, milling, or skiving process. Unlike coining, these processes do not change the properties of the base metal, and they impart far less residual stress as well. Materion's advanced profiling technology enables commercial production of preshaped high strength metals including austenitic, ferritic, or precipitation hardened stainless steel alloys. Formability can be greatly enhanced by reducing the thickness of the material in the bend zones, effectively increasing the R/t ratio. To obtain the most robust formability in an otherwise high strength material, you can have the profiled section zone annealed as well.

Figure V-57 Process Technologies: Profiled Machining




Figure VI-57 Process Technologies: Profiled Machining

Materion can achieve a large number of profiles, and is one of the few companies in the world that can profile stainless steel. If you can draw it, we can do it.

MATERION

©2020 Materion Brush Inc.

Aluminum as a Connector Base Metal


There is currently significant interest in the use of aluminum alloy wire harness materials to reduce weight and cost in automobiles. As a result, there are growing developments using precipitation hardened aluminum alloys as a base material for wire harness terminals. These electrical materials would enable 100% aluminum systems, eliminating the danger of galvanic corrosion that is present in mixed copper-aluminum systems. The 3rd most abundant element on earth, aluminum, offers vast availability, low costs, and reduced weight of electrical components.


The strength and conductivity of some aluminum alloys can exceed those of many brass and bronze alloys that are commonly used in electrical systems. Please contact Materion to learn more about aluminum alloy base metals and to follow further developments.

Figure V-58 Potential High Strength Aluminum Alloys for Connectors and Lead Frames

Potential Benefits of Aluminum Alloy Base Metals

- Reduce costs by switching from copper
- Same high reliability bond pads as "aluminum inlay"
- 30% the weight of copper alloys
- Excellent electrical conductivity
- Formable for reel-to-reel stamping





	Conductivity (%IACS)	Density (g/cm³)
AL6-TX	43%	2.70
AL2-TX	30%	2.78
C260 Brass	28%	8.53
C519 Bronze	15%	8.83

Properties for –TX can be tailored for your specific application requirements

Figure VI-58 High Strength Aluminum Alloys for Connectors and Lead Frames

A great deal of weight can be saved in automobiles by replacing copper wire harnesses with aluminum wire harnesses. Although the conductivity of aluminum is less than copper, requiring that the wires be made with larger diameters, the reduced density of the aluminum more than offsets the mass in the increased volume of the wires. Furthermore, the lower cost of aluminum makes the wire harness less expensive than it would be made out of copper. However, an aluminum wire harness requires aluminum alloy terminals. This is where high strength aluminum alloys may potentially be used.

©2020 Materion Brush Inc.

Section VI. Connector Interface Materials and Composite (Hybrid) Strip Technologies

The main purpose of interface materials is to minimize the contact resistance of that interface. These materials also provide protection of the copper alloy base metal against corrosion. They are selected for nobility (to resist environmental attack and adsorption of organic molecules), conductivity (to minimize contact resistance), hardness (to resist wear and reduce friction), lubricity (to minimize insertion force) and ductility (to maximize contact area and resist cracking or spalling). Gold, silver, platinum, palladium, tin and their alloys are common top layer choices. Nickel is the most common underlayer. A copper flash is usually put on as the bottom layer to improve adhesion of the upper layers. Aluminum and gold are often used for wire bonding surfaces. (See Figure VI-1).

Figure VI-1 Common Contact Surfaces



Figure VI-1 Common Contact Surfaces
Contact materials are chosen for their resistance to oxidation & corrosion, electrical properties, ease of application, hardness, and wear properties. Cost is usually an important factor as well.

The interface material determines the normal force requirements for the contact, as well as related design considerations such as insertion force and contact resistance. How these parameters change over time under the influence of temperature, moisture, and/or corrosion determines the overall reliability of the connector (Figure VI-2). In short, the choice of the material that is plated, clad, or otherwise deposited on the surface is a critical design consideration, certainly not an afterthought.

Figure VI-2 Contact Surface Stability

	Oxide Thickness (nm) for R>10 mΩ	Time for R>10 mΩ*
Au (gold)	-	-
Pd (palladium)	20	> 4 years
Sn (tin)	50	> 4 years
Ag (silver)	300	3 years
Ni (nickel)	3	25 days
Cu (copper)	7	< 15 days

***Battelle Class II Environment30°C, 10% Relative Humidity, 10 ppb H_2S, 10 ppb Cl_2, 10 ppb NO_2**

Figure VI-2 Contact Surface Stability
This chart shows how thick oxides have to grow on various surfaces before they start to interfere with contact resistance, as well as the time it takes for such films to grown in a relatively benign environment. Gold is the most corrosion-resistant surface and does not form such an oxide film. Silver, palladium, and tin have relatively long shelf lives of at least 3 years. Bare nickel and bare copper lose their effectiveness as contact surfaces in a matter of days, which is why they are impractical as contact surfaces (except in cases of damp circuits with relatively high voltage, high wipe, and high normal force.)

MATERION

©2020 Materion Brush Inc.

Potential Purposes of Surface Coating

- Provide a low resistance path for signal/current between the two halves of contact interface
- Prevent/minimize corrosion of contact surfaces
- Minimize wear of the interface
- Minimize insertion force
- Maintain solderability
- Provide a visually appealing surface
- Carry the signal in high frequency connectors
- Provide a soft, corrosion resistant pad for wire bonding

Key Coating Properties

- Electrical conductivity
- Hardness
- Wear resistance
- Corrosion resistance
- Frictional polymerization resistance
- Fretting corrosion resistance
- Arcing erosion resistance
- Friction/lubricity
- Porosity
- Solderability
- Galvanic compatibility
- Thickness
- Thermal expansion coefficient
- Stiffness (at light gauges)
- Thermal stability
- Appearance

Switching Levels

The electrical properties of the circuit help to determine the choice of plating (Figure VI-3). The voltage across the connector and the current flowing through it are the most important parameters, as they influence whether or not the current can flow through oxides or other surface contamination, and whether or not arcing damage is possible.

- Dry Circuit
  - 0 - 0.1 Amp/ 0 - 0.08 Volts
  - No arcing
  - Contact pairs are usually brought together without any voltage applied
  - Found in light duty connectors and instrument plugs
- Light Duty Circuit
  - 0 - 1 Amp/ 0 - 12 Volts
  - Found in telecom relays, instrument switches, and heavier duty connectors
- Medium Duty Circuit
  - 1 - 40 Amp/ 12 - 120 Volts
  - Arcing may happen depending upon voltage
  - Found in household appliances, relays, thermostats, protective controls, small lamps and automotive electrical accessories
- Heavy Duty Circuit
  - 40 - 1500 Amp/ 120 - 600 Volts
  - Significant arcing expected
  - Found in line starters, heater contactors, motor protectors, heavy duty relays and circuit breakers

MATERION

©2020 Materion Brush Inc.

Figure VI-3 Electrical Circuit Classification




Figure VI-3 Electrical Circuit Classification
The type of contact surface used varies with the type of electrical circuit. Signal contacts (low voltage and low current) are in the lower left quadrant. Plate or clad their contact surfaces with gold, tin, platinum, palladium, or their alloys. With higher current (although still low voltage), use silver and its alloys for superior resistance to arcing damage. Designers frequently use bare nickel or bare copper in damp circuits (higher voltage, lower current), where the voltage is strong enough to frit through the oxides on surface, but the current is low enough that arcing is not a concern. Use silver metal oxides for wet circuits (very high voltage and current) for both arcing and wear resistance.

MATERION

©2020 Materion Brush Inc.

Gold (Au) – Figure VI-4

Hard gold (cobalt or nickel hardened) is the most common precious metal overplate. Gold plates from acid cyanide solutions offer deposits ranging from soft to hard, with bright finishes providing excellent corrosion resistance and good electrical properties. Soft gold is 24 carat or 99.99 percent minimum purity. Soft gold solders easily, but has relatively poor wear properties. Industrial hard gold is 99-99.8 percent gold alloyed with cobalt or nickel as the hardening agent and is quite durable, with ductile deposits. However, hard gold has reduced solderability compared to soft gold. Gold overplate thicknesses of 0.25-0.8 microns (10-30 micro inches) provide good wear, friction, electrical, and corrosion properties.

Because it is usually applied in very thin layers, gold is susceptible to porosity. This means that a nickel underplate is usually required to prevent creep corrosion. A nickel underplate will also increase the durability and wear resistance of the overlying gold. If nickel cannot be used (for example, if passive intermodulation distortion or magnetism could be problems) then you can reduce the porosity by making the gold layer thicker.

Au Advantages

- Resists corrosion, oxidation, and polymer films
- Superior electrical performance
- Hard gold (Ni or Co added) is durable

Au Disadvantages

- Expensive
- Hard gold can have poor solderability
- Soft gold has wear problems

Au Use

- Dry circuit, ultra-low signals
- No wiping, low contact force
- Typical thickness = 0.25 - 1.3 microns (10 - 50 microinches)

Gold Flash: This is an extremely thin layer of gold on the surface (0.1 - 0.25 micrometers / 5-10 microinches) to improve corrosion resistance of surface while using a minimum amount of gold. The gold layer is usually too thin to be seen with the naked eye.

Gold Cap: This is similar to a gold flash but is usually thick enough to appear gold in color.

Diffused Gold: This is a gold flash applied to surface, then thermally aged to diffuse the gold down into the top layer of plating, which prevents the gold from being worn away.

Figure VI-4 Gold

- **Gold (Au)**
  - Most corrosion resistant surface
  - High cost
  - Low-moderate force: 20-100 grams
  - Low coefficient of friction: 0.1 - 0.3
  - Life:

soft gold	<10 cycles
hard gold	10's of cycles
hard gold with lubrication	100's of cycles

  - Nickel barrier required
  - Avoid gold-tin couples







Figure VI-4 Gold Plating

Gold is the most noble, most corrosion resistant surface. It does not oxidize readily. Because of its high price, it is used most often as a thin coating (flash) on the surface of a less expensive contact alloy to enhance the overall corrosion resistance. Diffused gold is a gold flash that is given a thermal treatment to allow the gold atoms to diffuse down into the surface of the underlying contact alloy, which improves the durability of the surface. A pure gold surface requires a nickel barrier layer underneath. Gold-coated contacts should never be mated to tin-plated contacts.

MATERION

Platinum (Pt), Palladium (Pd) and Their Alloys (Figure VI-5)

Platinum, palladium, palladium-nickel (Pd-Ni) and palladium-cobalt (Pd-Co) are usually overplated with a thin soft gold flash (<0.25 microns or 10 micro inches) and are comparable to gold in terms of corrosion resistance and contact resistance. Platinum, palladium and their alloys have good thermal stability and are harder/more durable than gold alloys, but are less solderable and more sensitive to general corrosion than gold. Their pricing tends to be much more volatile than gold, so they can sometimes be more expensive as well.

Platinum
Pt Advantages

- Excellent corrosion resistance
- High wear resistance
- Virtually immune from oxidation and the growth of tarnishing films

Pt Disadvantages

- Low electrical conductivity
- Catalyzes a reaction with organic compounds to form frictional polymer
- High cost

PT Use

- Dry circuit (low current/low voltage)
- Wipe of moderate normal force recommended

Palladium
Pd Advantages

- Comparable to gold in corrosion, contact and oxidation resistance
- High hardness and durability

Pd Disadvantages

- Can oxidize at high temperatures
- Catalyzes a reaction with organic compounds to form frictional polymer
- Requires gold flash
- High Cost

Pd Use

- Light and medium duty switching and electronic connectors
- Commonly alloyed with 20% Ni
- Typical thickness = 0.8 microns (30 microinches)

Figure VI-5 Platinum and Palladium

- **Platinum (Pt) & Palladium (Pd)**
  - Excellent corrosion resistance
  - Lower price than Au (particularly Pd)
  - Moderate force: 50-150 grams
  - Moderate coefficient of friction: 0.2-0.5
  - More durable than gold:

Pd & Pt	100's cycles	125º C max
PdNi	1000's cycles	100º C max
PdAg	100's cycles	200º C max

  - Thickness: 0.5 - 1.5 µm
  - Limited solderability
  - Gold flash (.05 µm) required for wear, fretting resistance
  - Can form frictional polymer



Figure VI-5 Platinum and Palladium Plating
Platinum and palladium are much harder than gold and are also more durable. These two metals are strong catalysts, and can form what is known as frictional polymer. This powdery surface contamination happens when organic vapors in the surrounding air react with each other (under the catalytic influence of the metal) and deposit on the surface. You can prevent this reaction by covering the platinum or palladium surface with a gold flash.

MATERION

©2020 Materion Brush Inc.

Silver (Ag) – Figure VI-6

Silver has the highest conductivity of all the electrical contact materials. It is typically electroplated over a nickel underplate or else staked/riveted onto the base metal as contact button (Figure VI-20). Silver is mainly used in higher voltage or higher current applications, and is generally suitable for use up to 200°C. It is often used in switching applications where electrical arcing may be a concern. Silver is alloyed with platinum, palladium, and/or gold to improve its hardness and wear resistance. It can tarnish easily in the presence of chlorine or sulfur, but has good oxidation resistance.

In clad silver contact materials properties such as hardness, coefficient of friction and nobility can be optimized for each application. An alloy such as AgCuNiZn (Materion's AVT contact), for instance, can offer improved wear properties over silver plating for high insertion cycle devices. This can provide high wear resistance and durability in high voltage/high current automotive applications such as charger connectors, switches and relays, and other high current connectors.

Ag Advantages

- Has the highest electrical conductivity and thermal conductivity
- Is resistant to surface oxidation
- Has good resistance to arc erosion

Ag Disadvantages


- Is prone to sulfide formation
- Has only moderate wear resistance
- Its current carrying capacity is limited by relatively low melting temperature
- Is susceptible to creep corrosion

Ag Use

- It is the most common higher current contact material
- For medium and heavy duty circuits
- Not used in light duty without wiping (due to sulfide formation)

Figure VI-6 Silver

- **Silver (Ag)**
  - Tarnishes easily
  - Alloyed with gold - corrosion resistance
  - Moderate force: 100-200 grams
  - Maximum temperature: 200ºC
  - Low contact resistance
  - High coefficient of friction: 0.5 - 0.8
  - Life: 100's cycles (with lubrication)
  - Provides very high conductivity
  - Uses
    - RF Connectors
    - Power Contacts (>1 Amp)
    - Fretting Resistance








Figure VI-6 Silver Plating

Silver is not quite as noble as the other precious metals, although it also does not readily oxidize. It usually tarnishes with sulfide and chloride films instead. It is often used in contact buttons staked onto the ends of spring contacts in switches or relays where arcing may be a concern.

MATERION

Tin (Sn) and Its Alloys - Figures VI-7 and VI-8

Electroplating and hot dipping are two means of applying this coating system. Electroplated tin may be either matte or bright, depending on whether or not brighteners are added to the plating bath. **Hot dipping** involves passing the strip through a molten tin bath, which immediately forms an intermetallic layer with the base metal. This in turn allows the tin to adhere to the surface. Two common methods for hot dip tinning are: hot dipping with mechanical wiping for coating thicknesses between 0.8 and 2.0 microns (30 and 80 micro-inches) and hot dipping with air knife finishing (**Hot Air Leveled Tin**) for tin coatings thicker than 1.5 microns (60 micro-inches). The thickness limit of electroplated tin coating is 1-3 microns (40-120 micro-inches). **Reflow tin** is electroplated tin that is reflow heated in a furnace after plating to smooth its surface and increase its grain size. The main advantages of hot dip tin (versus electroplated tin) are improved solderability, adhesion to strip, and bendability as well as lower production costs.

Sn Advantages

- Low cost
- Low melting temperature

Sn Disadvantages

- Tin plating is subject to whiskering
- Potential fretting corrosion problems
- Readily forms thin, brittle surface oxide
- Is not a durable plating
- Intermetallic compound formation and growth limits service life

Sn Use

- Dry circuit to medium duty switching
- With wiping and lubrication, 100 gm force (min)
- Typical thickness = 2.5 - 3.8 microns (100 - 150 microinches)

Figure VI-7 Tin

- **Tin (Sn)**
  - Soft, thick, surface oxide forms easily
  - Requires engagement length (wipe)
  - Requires high force: 100-400 grams
  - Has fretting problems with vibration
  - Lubrication recommended
  - Life : < 20 cycles
  - Maximum temperature: 100 - 150ºC
  - Thickness: 4 - 8 µm
  - High coefficient of friction: 0.4 - 0.8
  - Good solderability, crimpability
  - Nickel barrier recommended (to prevent whiskers & intermetallic formation






Figure VI-7 Tin Plating

Tin is the lowest cost coating material, therefore it is the one that is used most often in the automotive industry. It can be applied by hot dipping, electroplating, or cladding. It is readily solderable, particularly when alloyed with lead (Pb), antimony (Sb), silver (Ag), copper (Cu), or bismuth (Bi). Tin coated contacts should not be mated to gold coated contacts. Tin is usually not recommended for temperatures above 100°C, due to its tendency to form intermetallic layers. However, engineers have used it successfully in temperatures as high as 150°C in well-designed connectors.

MATERION

©2020 Materion Brush Inc.

Figure VI-8 Surface Characteristics of Tin Plating

	Bright	Matte
Hardness	√	
Ductility		√
Appearance	√	
Handling	√	
Durability	√	
Solderability		√
Low Coefficient of Friction	√	
Whisker Resistance		√
Cost		√

Figure VI-8 Surface Characteristics of Tin Plating
Tin can be applied as either matte tin or bright tin. While bright tin is more durable and has a more visually appealing surface, it is more susceptible to whisker growth than matte tin.

Electroplated tin plating is subject to "whiskering" that can lead to electrical shorting. See Figures VI-9 and VI-10.) Historically, a minimum of 7% weight percentage of lead (Pb) was added to the tin to prevent whiskering. However, the use Sn-Pb alloys risks non-compliance with the European RoHS (Restriction of Hazardous Substances) regulations. Newer Pb-free tin alloys have higher soldering temperatures but may be subject to whiskering.

Tin whiskers have been studied for several decades, without any real consensus on the exact mechanism that causes the whiskers, other than a common belief that residual stress in the deposited electroplate plays a major role. Some other possible influencing factors are surface roughness, the presence or absence of an underplate layer, surface topography of the tin or the base metal, the composition of the base metal, and the composition and thickness of the thin intermetallic layer that forms between the tin and the base metal or underplate. Without adding Pb to the Sn, the only known means of suppressing whisker formation is to reflow or hot air level the tin deposit to thermally stress relieve it.

Tin is also subject to fretting corrosion. (See "Fretting Corrosion" in Section X – Considerations for Harsh Environmental Conditions.) If using a tin coating, you should specify a minimum of 100 grams of contact force and lubricate the contact interface to prevent fretting. (See "Connector Lubricants" in Section VII – Materials for Other Connector Components.)

Figure VI-9 Tin Whiskers




Figure VI-9 Tin Whiskers
This is a scanning electron microscope (SEM) image of whiskers erupting from the surface of a tin-plated component. The whiskers reflect more electrons than the underlying surface, and thus appear brighter in the image.

Figure VI-10 Image Close-Up of Tin Whisker




Figure VI-10 Close-Up Image of Tin Whisker
In this close-up image, you can see how the whisker grows as a single crystal.

©2020 Materion Brush Inc.

Solder Coating (Figure VI-11)

The solder print-on process is designed for thin coatings, typically 0.0025 mm to 0.01 mm (0.0001" to 0.0004"). Since the solder is applied in the molten condition, this process is comparable to hot dip tinning. Materion can also electroplate thin solder coatings. The solder reflow process is designed for thick solder coatings, typically 0.125 mm to 0.63 mm (0.005" to 0.025"). Depending on the shape of the skiving tool different shapes are obtainable. Stripes or complete overlays can be clad on one or both sides. The base metal can be any material.

Figure VI-11 Solder Coating

- **Print-on (Thin Solder)**
- **Reflowed (Thick Solder)**
- **Solder Clad**
- **Electroplated**
- **Profiled**




Figure VI-11 Solder Coating

Solder coating is applied to any areas that are to be soldered (surface mount components, lead frames, etc.) Materion can apply thick or thin solder, can reflow it to eliminate whiskering, and can even profile it after reflowing.

MATERION

©2020 Materion Brush Inc.

Nickel (Ni) - Figure VI-12

The nickel underplate layer serves several purposes:

- Nickel acts as a barrier to copper diffusion through gold, which in turn allows usage of a thinner layer of gold.
- The nickel underplate reduces porosity through to the copper alloy base metal maintaining a corrosion-free surface.
- Nickel is harder than gold, therefore it increases the durability of gold by providing a hard substrate foundation improving wear characteristics.
- Precious metal plating baths are sufficiently acidic or alkaline that they dissolve small accounts of copper base metal prior to the initiation of plating. Since this does not occur with nickel, the nickel layer increases the lifetime of the precious metal plating solution.
- A nickel underlayer also helps to level the surface of the contact

Electroplated nickel can vary widely in its properties (Figure VI-13). Hardness, ductility, residual stress and tensile strength are functions of the plating bath. Three typical nickel plating bath solutions are sulfamate, fluoborate and pyrophosphate. Typical Ni underplate thickness is 1.25-2.5 microns (50-100 micro inches).

Ni Advantages

- Can reduce porosity through to the base metal which allows a thinner overplate layer
- Can provide a corrosion migration barrier and diffusion barrier
- Is harder than gold and increases the gold overplate's durability

Ni Disadvantages


- The oxide has to be removed
- A high stress Ni deposit (bright nickel) may cause premature fatigue failure or formability problems

Ni Use

- Underplating for precious metals
- Typical thickness = 1.25 - 2.5 microns (50 - 100 microinches)

Figure VI-12 Nickel

- **Nickel (Ni)**
  - Bare nickel forms a hard, dense surface oxide
  - Not advised for contact surfaces
    - Damp circuits, > 12 V & < 1 A
    - Contact force > 200 g
    - High wipe: > 1 mm
    - No vibration
    - Designed contact redundancy
    - Non-critical reliability



  - Common Uses
    - Barrier layer (2-4 µm) under Au, Pd, Sn
    - Increases wear resistance of surface
    - Decreases gold thickness required
    - Surface leveler



Figure VI-12 Nickel

Nickel is rarely used as a plating surface. It is most often used as a barrier layer underneath a more noble contact surface. Nickel underplates greatly enhance the hardness and wear resistance of the overlying surface. They also prevent:

- Diffusion of the base metal to the surface
- Creep of corrosion products from bare edges across the contact surface
- Growth of brittle intermetallic layers between tin surfaces and copper base metals
- Pores extending all the way from the surface of the outer plating layer to the base metal

MATERION

Figure VI-13 Nickel Plating Types

- Matte nickel provides better solderability
- Ductile (sulfamate) plating highly recommended
- Avoid electro-less nickel process (brittle)
- Brighteners tend to make it brittle
- Hardened nickel (Ni-P) has very low ductility




Figure VI-13 Nickel Plating Types

Electroless nickel and bright electroplated nickel are very hard and wear resistant, but can possess high residual tensile stress and can be brittle. This can create formability problems for pre-plated contacts, and can reduce the fatigue life of highly cycled contacts.

Figure VI-14 Copper

- **Copper**
  - Often used as first plating layer
    - Improves adhesion of later plating layers
  - Not recommended as a contact surface
    - Instantly forms oxides, chlorides, sulfides
    - Tarnish films grow quickly
    - Contact resistance failures within hours or days
  - When used as a contact surface
    - High wipe: > 1 mm
    - High contact force: 500 - 1000 g
    - High voltage: > 20 V
    - No vibration
    - Designed contact redundancy
    - Non-critical reliability



Figure VI-14 Copper

Copper is the least reliable of all contact interface materials, so it is almost never used as one, except in high voltage applications. It is most commonly used as a flash coating directly on the base metal. Additional plating layers will easily adhere to the surface of such a coating.

Aluminum (Al) - Figure VI-15

Aluminum (usually inlaid) is used on lead frames to make pads suitable for aluminum wire bonding. (For wire bonding with gold or copper wires, soft gold would normally be used instead.) Pure aluminum conductors may be used if the mating terminal is also aluminum, most often in power transmission. Aluminum conductors are often used in high voltage switches for power transmission in national electrical grids.

Figure VI-15 Aluminum

- **Aluminum**
  - Wire bonding surfaces on lead frames
  - Li-ion battery electrodes
  - High strength aluminum terminals




Figure VI-15 Aluminum


Aluminum is used as a contact interface for wire bonding pads. You may also use it on the crimp area of wire harness terminals, when crimping onto all aluminum wire harnesses. This prevents the non-ideal situation of having copper and aluminum mated together in a separable interface. (Differences in thermal expansion or a galvanic reaction in a copper-aluminum separable interface can quickly oxidize the surface and generate very high resistance at the interface. Mating copper and aluminum requires interfaces specifically designed for this purpose.)


Figure VI-16 Aluminum Inlay Wire Bond Lead Frames

Aluminum inlay for high reliability wire bond application

Advantages

- Superior reliability
- High temperature stability
- High vibration stability
- Robust and sustainable








Figure VI-16 Aluminum Inlay Wire Bond Lead Frames

This process is compatible with copper, stainless steel, and aluminum base metal alloys. Aluminum bonded to aluminum is one of the easiest and most reliable wire bonding solutions for automotive electronic applications. When also considering manufacturability and reliability issues, this proven material features the lowest "Total System" cost.

MATERION

©2020 Materion Brush Inc.

Other Alloys

Often coatings are made out of alloys of the above contact interface materials, in order to combine the benefits of the individual materials. See Table VI-1 for details. Examples include

- Palladium Nickel PdNi
- Palladium Silver PdAg
- Gold Silver AuAg
- Tin Silver AgSn
- Silver Nickel AgNi
- Silver Copper AgCu
- Gold Nickel AuNi
- Gold Silver Copper AuAgCu
- Etc.

iON Connector Materials (Figures VI-17 through VI-19)

iON Connector Materials are engineered alternatives to Electroplated contact finishes. These solutions improve temperature and wear performance while reducing exposure to the price volatility of expensive precious metals by using alloys of silver, palladium, and gold. The engineered metal systems used in iON connectors were developed with harsh conditions in mind; whether the objective is Gold Replacement (iON-GR), High Wear performance (iON-HW), or High Temperature stability (iON-HT), these materials outshine electroplated systems when performance matters.

Figure VI-17 iON Connectors For Harsh Environments

- **New connector materials for the most demanding environments**
  - Engineered alloys for superior performance in extreme environments
  - Enhanced vibration, temperature, and wear performance
  - Reduced precious metal cost




Figure VI-17 iON Connectors For Harsh Environments

iON connector materials were developed with extreme environments in mind. Whether your application is downhole, underhood, or out of this world, these engineered alloy contacts offer superior vibration, temperature, and cost performance over what is achievable with conventional electroplated materials. iON connectors are provided clad to any terminal or spring material, allowing for drop-in replacements to your challenging gold contact applications.


Figure VI-18 iON Connectors

Contact Finish	Description	Applications
iON - GR	A composite alloy system, predominantly silver and palladium, with a noble gold enriched contact surface	A common low cost replacement for hard gold electroplated connectors, with additional benefits of improved high temperature and high vibration stability
iON - HW	An ultra-hard wrought nickel-palladium base layer with a gold enriched surface	For maximum wear performance in applications with high vibration, sliding, or make-break contacts
iON - HT	A stable ternary alloy system of silver-palladium-gold providing high hardness, nobility, and supreme temperature stability	For ultra-high temperature applications with exposures to temperatures up to 350°C

Figure VI-18 iON Connectors

iON-GR is used as a reduced cost gold replacement, iON-HW is used for resistance under vibration and high wear conditions, and iON-HT is used for superior high temperature stability. The improved performance properties are derived from the alloyed microstructure of iON materials. Manufactured as an inlay clad to spring alloys in selective stripes, iON connectors are formed from bulk metals creating fully dense structures with large grain size. With overall contact layer thicknesses down to 0.5 µm, iON materials can be drop-in replacements to electroplated gold and palladium systems. Each iON material is specifically formulated for its application.

Figure VI-19 iON Connectors Cost Conscious Technology



Reduces cost fluctuations due to a PM market volatility

Figure VI-19 iON Connectors Cost Conscious Technology

iON connector materials also reduce exposure to volatile precious metal markets. Reducing precious metal costs by as much as 70%, these alloys protect your company against the next wild price spike, giving financial peace of mind in addition to performance you can trust.

©2020 Materion Brush Inc.

Contact Buttons (Figure VI-20) can be resistance welded or staked onto the end of a switch or relay contact. These are primarily used in higher voltage/high current applications where resistance to arcing damage is required. Typical materials are silver, silver tin oxide, and silver cadmium oxide.

Figure VI-20 Silver Contact Button on End of Rotary Switch Spring




Figure VI-20 Silver Contact Button on End of Rotary Switch Spring

The contact button may be pure silver for maximum conductivity. Often, the silver is alloyed with copper, platinum, palladium, or gold to improve its resistance to wear and arcing. If even more durability is required, use a powder metallurgy composite of silver, silver metal oxides (AgCdO, AgSnO, AgInO), molybdenum, graphite, or nickel.

Table VI-1 lists the minimum recommended normal force for each of these coating systems. Please note that these are guidelines only, and that a contact may be able to function perfectly well at contact forces lower than the recommended values if the environment is benign, the number of cycles is low, the coating is relatively thick or there is a good deal of wiping action during the connector mating process. However, thin plating, aggressive environments, a high number of expected cycles, fretting action in service, and low to no wiping during connector mating may necessitate a higher normal force than that specified in the table. Figure VI-21 provides the recommended maximum service temperatures for these materials.

MATERION

©2020 Materion Brush Inc.

Table VI-1 - Plating/Cladding Normal Force Requirements											
Coating Composition	Coating Method	Density		Minimum Recommended Normal Force			Electrical Conductivity	Resistivity	Knoop Hardness		Type of Contact
		lbs/in³	g/cm³	(g)	(N)	(oz)	% IACS	uohm-cm	Annealed	Spring	
Soft Gold (Au)	Plated	0.698	19.3	35	0.3	1.2	71	2.4	40	90	Signal
Hard Gold (AuCo or AuNi)	Plated	0.633	17.5	50	0.5	1.8	45	3.8	130	200	
Palladium (Pd)	Plated	0.434	12.0	50	0.5	1.8	16	10.7	200	300	
Palladium Nickel (80Pd20Ni)	Plated	0.405	11.2	50	0.5	1.8	9	19.0	200	500	
Soft Au	Clad	0.698	19.3	35	0.3	1.2	71	2.4	40	90	
75Au25Ag	Clad	0.577	16.0	50	0.5	1.8	17	10.0	50	110	
WE 1 (69Au25Ag6Pt)	Clad	0.580	16.1	50	0.5	1.8	10	15.4	80	140	
Palladium (Pd)	Clad	0.434	12.0	50	0.5	1.8	16	11.0	80	160	
Palladium Nickel (90Pd10Ni)	Clad	0.419	11.6	50	0.5	1.8	11	16.0	145	265	
Palladium Nickel (80Pd20Ni)	Clad	0.405	11.2	50	0.5	1.8	9	19.0	180	310	
Palladium Silver (60Pd40Ag)	Clad	0.410	11.3	100	1.0	3.5	4	43.0	120	210	
Palladium Silver (50Pd50Ag)	Clad	0.404	11.2	100	1.0	3.5	6	30.0	110	200	
Platinum (Pt)	Clad	0.775	21.5	50	0.5	1.8	15	11.5	75	140	
Au-Flashed PdNi	Clad	0.405	11.2	150	1.5	5.3	9	19.0	180	310	
Diffused Au PdNi	Clad	0.500	13.8	150	1.5	5.3	9	19.0	150	280	
Paliney 6*	Clad	0.390	10.8	50	0.5	1.8	6	25.8	290	370	
Paliney 7*	Clad	0.426	11.8	50	0.5	1.8	5	31.6	330	400	
72Ag28Cu	Clad	0.361	10.0	75	0.7	2.6	87	2.1	90	130	
90Ag10Cu	Clad	0.373	10.3	75	0.7	2.6	87	2.1	80	120	
Nickel (Ni)	Plated	0.322	8.9	200	2.0	7.1	18	9.6	150	700	Power
Silver (Ag)	Plated	0.379	10.5	100	1.0	3.5	101	1.7	40	185	
Silver (Ag)	Clad	0.379	10.5	100	1.0	3.5	101	1.7	40	90	
Tin (Sn)	Plated	0.208	5.8	150	1.5	5.3	14	12.3	30	100	
Silver Tin Oxide (92Ag 8SnO)	Clad	0.357	9.9	100	1.0	3.5	88	2.3	100	130	Power/ High Voltage Switching
Silver Cadmium Oxide (97.5Ag 2.5CdO)	Clad	0.368	10.2	100	1.0	3.5	85	2.2	95	130	
Silver Nickel (90Ag 10Ni)	Clad	0.372	10.3	100	1.0	3.5	87	2.1	70	105	

**Derringer-Ney, Inc.*

©2020 Materion Brush Inc.

Figure VI-21 Surface Coating Selection Based on Maximum Exposure Temperature

Contact Material	Maximum Exposure Temperature (°C)	Potential Failure Modes
Sn, SnPb Alloys	60	Softening, Intermetallic Growth
Plated PdNi	100	Oxidation
Plated GF PdNi, Au-Co	125	Oxidation, Diffusion, Blistering
Pd, PdAg, PdNi Alloys	200	Oxidation, Diffusion
Plated Au, DGR 156, WE#1/PdAg	200	Diffusion
WE#1	300	Diffusion
65Au21Pd14Ag	350	Diffusion

Figure VI-21 Surface Coating Selection Based on Maximum Exposure Temperature

The service temperature can influence which particular coating material is used. This chart shows the maximum recommended service temperatures for different options, and what the failure modes are likely to be if the recommendation is exceeded. (As stated earlier, engineers have used tin and tin alloy coatings successfully in temperatures as high as 100 to 150°C, so these are conservative estimates.)

Plating Porosity

Porosity is the presence of pores (small holes) in the plating that extend from the surface down to the underlying base metal. Porosity is dependent on the electroplating process parameters, plating thickness, and substrate defects. Pores may be sites at which corrosion can occur. Corrosion products or films arise from an interaction between the non-noble portions of the contact member and the environment, through pores in noble plating. These corrosion products may grow and creep across the contact surface, increasing contact resistance in a phenomenon called creep corrosion.

Electromigration

This is a phenomenon primarily seen in copper and silver surface coatings. Crystals can grow dendritically outward from the plating across a non-conducting surface (such as a printed circuit board) in the direction of an applied electric field. Such growth can create short circuits in the same way that tin whiskers can. Moisture or humidity can accelerate the growth by carrying dissolved ions across the non-conducting surface in the direction of the field.

Surface Coating Processes

The most common deposition processes are electroplating, electroless plating, hot dipping, and cladding.

Hot dipping (Figure VI-22) is the oldest method of metal coating. The process consists of dipping metal parts into a molten metal of different composition, which adheres to the surface of the part. Use this method only if the base metal to be coated forms an intermetallic alloy with the coating. In addition, the melting point of the coating must be considerably below that of the metal to be coated, for example, tin (232°C) on copper (1085°C). When you use hot dipped tin, it is important that you coat sufficiently thick so that the contact surface is pure tin and not the copper-tin intermetallic. The advantage of hot dipping is the relative simplicity and the high output rate. A drawback of the hot-dip method is that it is difficult to control the thickness of the coating. Hot dipped tin finishes are not susceptible to whiskering.

Advantages of hot dipping

- It has low cost.
- It has relative simplicity and a high output rate.
- Hot dipped tin finishes are not susceptible to whiskering.


Design limitations of hot dipping

- It is difficult to control the coating thickness and appearance.
- It is best for relatively simple shapes and flat surfaces.
- A thicker intermetallic layer leads to shorter service life.
- A high contact force is required to break the oxide layer at surface.
- There is no diffusion barrier between the tin and the copper.

MATERION

©2020 Materion Brush Inc.

Figure VI-22 Hot Dipping



Solder print-on, a variation of hot dipping

Figure VI-22 Hot Dipping

This process consists of dipping parts into molten metal, normally tin and its alloys. Use this method only if the metal to be coated forms an intermetallic alloy with the coating. The intermetallic allows the bond to form readily between the tin and the copper base metal.

Electroplating (Figure VI-23)

Overall and selective stripe electroplating is possible with finishes of tin, tin-lead alloys, nickel, copper, and precious metals. Electroplating can be easily combined with other technologies for enhancing the performance of the end product. By combining electroplating with in-house heat treatment, Materion is able to offer a truly ductile nickel coating. Materion can also reflow and shape electroplated tin to eliminate whiskering.

Figure VI-23 Electroplated Connectors




Figure VI-23 Electroplated Connectors

Materion can do continuous reel-to-reel plating of strip or stamped parts. Materion specializes in precise elective plating to maximize performance while minimizing costs and can also combine precious and non-precious metals. This technology is compatible with a wide-range of copper, stainless steel and aluminum alloys.

MATERION

Electroplating (Figures VI-24 and VI-25) is the deposition of an adherent metallic coating onto a conductive object placed into an electrolytic bath containing a solution of the metal plating salt. In electroplating, a direct (DC) current passes through the plating solution, using the terminal as the anode, which causes the transfer of metal ions onto the cathodic plating surface. Selective electroplating technology allows the deposition of plating only in the required functional area, by placing a temporary mask over areas that are not to be plated.

Figure VI-24 Electroplating




Figure VI-24 Electroplating

In electroplating, the metal strip is immersed in an electrolytic solution while connected to the negative end of a DC terminal. The positive end is connected to pieces of the desired plating metal immersed in the same solution. The action of the electric current in this electrolytic cell causes the contact metal source to dissolve into solution, then plate out onto the surface of the strip.

Figure VI-25 Gold Plating Process




Figure VI-25 Gold Plating Process

This is one example of a typical plating process. Whether pre-plating or post-plating, the surface to be plated must first be degreased and cleaned to remove contaminants (dirt, oil, etc.) and then activated by removing the surface oxides. These steps are absolutely critical, since without proper cleaning and activation, the plating will either not adhere or will have a great amount of porosity. The temperature and chemistry of the cleaning and plating baths must be carefully controlled. Do not allow scale or other contamination to build up in the baths, as this will negatively affect plating performance.

MATERION

©2020 Materion Brush Inc.

Advantages of electroplating

- Allows for the selective deposition only in the required functional areas
- Used to prevent tarnish or corrosion

Design Limitations of electroplating

- Allows for plating to be deposited on non-critical surfaces
- Need to avoid sharp edges, corners, etc., that would prevent uniform current density
- Need to avoid thin cross sections that could be distorted by internal stresses in the coating
- Often has a non-uniform deposit thickness

Electroless plating is metal deposition, usually in an aqueous medium, which proceeds by an exchange reaction between metal complexes in the solution and the particular coated metal. The reaction is autocatalytic and does not require externally applied electric current.

Advantages of electroless plating

- Electroless plating yields a more uniform thickness of metal
- No power source is needed
- Electroless deposits are less porous than electroplates

Design Limitations of electroless plating

- Has a slow deposition rate
- Is difficult to control bath chemistry
- Avoid features that would trap process chemicals, creating future corrosion concerns
- Avoid features that could trap air and prevent the plating from depositing or cause staining

Proper Plating Procedures

If you will be plating after heat treatment, you can get the best results by following a few simple guidelines:

- Be sure to degrease material before heat treatment and properly clean after.
- Appropriately clean or degrease mill hardened material prior to plating.
- Ensure that the tank is kept clean, with no noticeable dirt or scale on the sides or bottom.
- Use treated water in your plating baths, to avoid dissolved salts and minerals that are found in hard water, for example.
- Monitor the bath chemistry to ensure that it is kept within proper limits.

Cladding (Figure VI-26)

Cladding is a thin layer of a metal mechanically bonded to a base metal, usually by heating and rolling. There are two type of cladding: overlay cladding and stripe-inlay cladding. Overlay cladding (Figure VI-27) provides a layer or a stripe of the coating material on a metallic surface. Stripe-inlay cladding (Figure VI-28) imbeds a stripe or stripes of precious metal in a milled or skived groove in the base metal. In either case, the two materials are permanently bonded together by rolling under high pressure and temperature in a bonding mill. The top surface of an inlay is then flush with the base metal surface, and an overlay would rise above the surface. Clad surfaces are far less subject to porosity since the inlay metals are wrought and fully dense. The combination of precious metal and tin or solder cladding on the same strip metal may offer manufacturing advantages.

Figure VI-26 Clad Connectors – Performance Beyond Electroplating




Figure VI-26 Clad Connectors – Performance Beyond Electroplating

Cladding is used in harsh environments where high reliability is required, and plating won't work (such as in high temperature and/or high vibration applications). It can also be a potential cost savings over gold plated connectors.

Figure VI-27 Overlay Cladding Process




Figure VI-27 Overlay Cladding Processes

In overlay cladding, a strip or strips of metal is laid down on the base metal and mechanically bonded to the surface by rolling. This elongation breaks up the oxide films on the surfaces, allowing them to cold weld together, through oxide-free metal-to-metal contact. A subsequent thermal treatment can further increase the bond strength.

©2020 Materion Brush Inc.

Figure VI-28 Inlay Cladding Process




Figure VI-28 Inlay Cladding Process

In inlay cladding, the strip is laid down into a channel on the base metal. This channel can be made by skiving, milling, or grinding the base metal. The end result is a contact surface that is level with the surrounding base metal, which reduces the overall connector profile.

Clad metals are far less porous than electroplated materials, and have greater resistance to elevated temperature. Furthermore, metals that cannot be electroplated (such as aluminum) may be easily clad. Cladding permits further working of the strip material, so that it may be rolled, annealed, profiled, etc. after cladding. It allows for thick coatings that would be cost prohibitive to electroplate, and generally leaves the assembly ductile enough for stamping, forming, deep drawing, and bending without fear of fracture. Cladding easily accommodates multiple layers.

Clad surfaces also delay diffusion of base metal to the surface relative to plated surfaces. The bulk of diffusion occurs along the grain boundaries in the coating layers, as this is a lower energy path to the surface than through the grains themselves. Clad surfaces have elongated grains, which effectively increase the length over which base metal atoms must diffuse before they reach the surface. Clad surfaces can thus withstand higher temperatures and/or longer times at elevated temperature than the same surfaces in electroplated form, before changes in contact resistance occur. (Figure VI-29)


Advantages of cladding

- Cladding can join virtually any metal used in today's connector applications.
- It provides unique property combinations at specific locations on the strip.
- It simplifies part production.
- Claddings are much less subject to porosity since the inlay metals are wrought.

Design limitations of cladding

- It can only be done on relatively simple shapes, especially with flat surfaces

Figure VI-29 Clad vs. Electroplated Surfaces



Large grain size
Fully dense boundaries
Long diffusion path

Small grain size
Entrapped organics
Pores
Short diffusion path

Figure VI-29 Clad vs. Electroplated Surfaces

Most any contact alloy can be clad, while only a limited number of contact alloys can be electroplated. Clad surfaces feature a 10 times slower diffusion of the base metal to the contact surface than electroplated surfaces, since they are fully dense (non-porous), and feature elongated grains which increase the length of the diffusion path. Clad surfaces show electrical temperature stability up to 350°C, depending on the particular alloy system. They also have enhanced wear and vibration properties relative to electroplated surfaces.

MATERION

©2020 Materion Brush Inc.

Residual and Induced Stresses

Coatings applied by electroplating, vapor deposition, and electroless plating will contain a certain amount of internal residual stress. This stress is created as the coating grows in thickness. Additionally, thermal expansion differences between the coating and the substrate will create thermal stresses, especially if the coating is deposited at high temperatures and then cooled. (The thermal stresses will also cycle with temperature during normal service of the part.) Residual tensile stresses may lead to premature fatigue failure, while residual compressive stresses can improve resistance to this type of failure. Excessive tensile stress in the coating may also cause cracking. The residual stress in clad metal will be the same as that of the base metal.

Pre-plating vs. Post-plating

Mill hardened strip may be plated before or after stamping and forming operations. Heat treatable strip must be plated after heat treatment, to prevent diffusion of the base metal through the plating.

Pre-plating or cladding will leave the base metal exposed at edges of the part after stamping (Figure VI-30). Corrosion can occur at these bare edges. This can allow corrosion products to creep across the surface of the contact, disrupting the flow of current. Pre-plating will typically produce stamping scrap that has been coated with the plating material. It can be difficult to recover plating metal from this scrap. Depending on the thickness and ductility of the coating, the formability of the part may be substantially reduced, since a less ductile coating will fracture more easily than the base metal.

Figure VI-30 Effective Precious Metal Utilization





Figure VI-30 Effective Precious Metal Utilization

If you plate after forming, you only have gold plating where you need it. If you plate or clad first, then blank and form, some of the gold will be lost in the stamping scrap.

Post-plating requires that the part be stamped, and then coated selectively or overall. However, the edges of the part will be coated, so there will be no creep corrosion. If the part is to be in-line spot plated (in reel form), it must be blanked, spot plated, and then formed. This requires that the stamping and forming operations be done at separate times, with an intermediate coating operation (Figure VI-31).

Figure VI-31 Strip Coating Process Comparison



Concerns	Pre-Plate	Post-Plate	Clad
Are the edges bare? (Is creep corrosion a concern?)	Yes	No	Yes
Is plating lost on scrap?	Yes	No	Yes
Is porosity a concern?	Yes	Yes	No

Figure VI-31 Process Comparison

Pre-plated and clad strip will produce contacts with bare edges, while post-plating will not. Post-plating may at first appear to be the most expensive option, as it requires separate blanking and forming operations. However, since you are only putting plating on areas that are being used in service, it is the only method that does not produce coated scrap. (Note that rack or barrel plating of finished parts is also a form of post-plating, since it comes after stamping and forming. However, this is a batch process, not a reel to reel process, so the cost may be even higher.) You should perform a careful cost analysis before deciding which option is most economical for your design, factoring in reliability and cost of failure as well.

©2020 Materion Brush Inc.

It should also be noted that certain plating materials are available only as pre-plated, and others only as post-plated. Cladding is only done before stamping.

Here are some additional considerations for choosing a coating method:

- Bare Edges
  - Only post plating has coated edges. Preplated and clad metals will have bare edges.
  - However, it may not be an issue, since the plastic housing will slow creep corrosion down considerably, particularly if the housing is hermetically sealed.
- Formability Requirements
  - Rack or barrel plating of finished parts is only restricted by the formability of base metal.
  - Preplated parts or parts plated after blanking (but before forming) are restricted by the formability of both the base metal and the plating.
  - A clad coating is typically more formable than a plated coating.
- Strip Robustness
  - Residual plating stresses may cause distortion of thin gauge strip and foil. Clad surfaces do not contain these residual stresses.
- Coating thickness
  - Use clad coatings for thicker layers.
  - Use plated coatings for thinner layers.
- Precious Metal Utilization
  - You can optimize the die layout or progression, and you may use interdigitation of contact surfaces to minimize the amount of plated scrap lost (Figure VI-25).
  - If the layout is not optimized, you will need to separate the coated scrap from regular scrap and recover the precious metal from it.

Both Materion and Materion supply strip in both the bare and preplated conditions.

Figure VI-32 Optimized Precious Metal Usage




Figure VI-32 Optimized Precious Metal Usage

In this case, the contacts are interdigitized so that no precious metal is lost as scrap. The coating is only on the contact area, and the shape of the contact area is configured symmetrically to ensure that all of the coated material is used in the final contact. The only penalty is a little additional handling required to feed coils wound with opposite orientations into downstream molding and assembly operations.

Other Surface Treatments not applicable to Copper Alloys

People may be familiar with specialty surface treatments that work on steel, aluminum or other alloy systems, and they wonder if copper alloys can be subjected to similar treatments. Often, the answer is “No.” These processes will only work because of the unique metallurgy of steel or aluminum. The metallurgy of steel alloys is vastly different from copper, and aluminum alloy metallurgy is also vastly different from either steel or copper alloys.

That being said, the following processes are not physically possible on copper alloys:

- Conversion coatings (chromate coatings, phosphate coatings)
- Case hardening (carburizing, nitriding, carbonitriding)
- Passivating

Other processes such as black oxide coatings are physically possible, but it may take some trial and error to determine the exact process necessary.

©2020 Materion Brush Inc.

Technology Compatibility (Figure V-33)

While a wide variety of hybrid materials are possible, certain material combinations are not possible using every method. The attached chart shows which metal combinations are compatible with which technologies. Cladding allows the most possibilities, and electro-plating is the most limited.

Figure VI-33 Hybrid Material Compatibility




Figure VI-33 Hybrid Material Compatibility

Cladding is the most robust joining method and can be used to combine the greatest number of materials, including those that cannot be electroplated or EB welded. Only a relatively limited number of materials can be electroplated onto a surface, making this the most restricted method of producing hybrid materials.

MATERION

Section VII: Materials and Properties of Interest for Other Connector Components

Plastic or Elastomer Housing Materials (Figure VII-1)

Polymer based thermosets or thermoplastics isolate, locate and support contacts, enhance alignment and provide environmental protection for connectors. Choose a material compatible with connector processing such as soldering. The critical property of the resin during soldering is the Heat Deflection Temperature. Other desirable properties are dimensional stability, low warpage, moisture resistance, corrosion resistance and the ability to be molded in thin sections.

Figure VII-1 Multiple Connectors with Plastic Housings



Figure VII-1 Multiple Connectors with Plastic Housings

These are some of the more common connectors found this century.

Purpose of Polymer-Based Connector Housing

- Keep contacts/ground planes in position and ensure proper alignment during mating
- Shield contacts from environment - ensure water, dust, salt, corrosive agents, etc. are kept out of the connector housing and away from the contact interface.
- Keep contacts electrically insulated
- Provide easy mating/separation capability of connector
- Provide strain relief/flexibility at cable to connector joint

Some potential connector housing polymers and general properties (properties may vary based on content of fillers and other additives)

- Acrylonitrile Butadiene Styrene (ABS) – Good resilience and toughness
- Liquid Crystal Polymers (LCP) – Low shrinkage, good dimensional stability
- Polyethylene Terephthalate (PET) – Good stiffness and temperature resistance
- Polybutylene Terephthalate (PBT) – Low cost, average performance
- Polyetherimide (PEI) – High stiffness, water and temperature resistance
- Polycyclohexylene Terephthalate (PCT) – Low dielectric constant for high frequency connector use
- Polyphenylene Sulfide (PPS) – Easy to mold, high temperature & chemical resistance
- Polyamide (PA or Nylon) – High toughness
- Polyphthalamide (PPA) – High temperature resistance
- Polycarbonate (PC) – High stiffness and toughness, moisture resistance
- Polyphenylene oxide (PPO) – Very good electrical insulation
- Phenolic Resins – Good dimensional stability and heat resistance
- Perfluoroalkoxy Alkane (PFA) – High temperature resistance
- Polyether Ether Ketone (PEEK) – Good heat resistance and chemical resistance
- Natural and Synthetic Rubbers – Good moisture resistance

A question commonly asked is whether or not a particular resin is compatible with the base metal or plating material. In most cases, the base polymer (PA, PEEK, etc.) used in the resin will have no effect on the copper alloy or surface coating. However, resins contain more than just the base polymer. They usually contain any number of dies and colorants, fillers, flame retardants, lubricants, mold release agents, etc. There is always the possibility of some interaction between the additives which may cause outgassing or release of some kind of corrosive substance.

MATERION

©2020 Materion Brush Inc.

What can go wrong with the housing?

- **Dimensional change / warpage** – This could occur during molding, cooling, soldering or in service. It can be caused by mechanical stresses, shrinkage during or after solidification, thermal softening/creep of plastic, and swelling from water absorption.
- **Outgassing** - Can build up contaminants on contact surfaces
- **Loss of environmental seal** - Allows corrosive agents access to contacts
- **Additives attacking the base metal or plating.**

Key plastic properties

- Dimensional Stability
- Molding Characteristics
- Mechanical Properties
- Electrical Characteristics
- Thermal Properties
- Environmental Resistance Characteristics

Dimensional Stability – Stay within dimensional tolerances upon cooling and over the life of the connector under environmental conditions, as detailed below

Molding Characteristics

- **Melt temperature**
- **Viscosity/fluidity** - Be able to flow into very thin-walled sections of tight pitch connectors (e.g. I/O, backplane, mezzanine, etc.).
- **Filler content** - Add strength without compromising fluidity, wearing the mold, or outgassing corrosive by-products.
- **Shrinkage in mold** - Must be accounted for in mold design. Some resins may also continue to shrink after ejection from the mold. Contact your resin supplier to determine how much allowance must be made.
- **Warpage in mold or upon ejection** - Minimize the shape distortion in cooling by providing uniform cooling (i.e., avoid hot spots in the mold and molded part).
- **Outgassed by-products** - Avoid outgassing and corrosion of contact interface. These by-products could be from the base resin, pigments, flame retardants, fillers, stabilizers, or any other additive used to influence the properties and other characteristics of the plastic.
- **Micromolding capability** – Be able to maintain precise tolerances and alignment of contacts in extremely small connectors, with low post molding shrinkage and distortion.

Mechanical Properties

- **Tensile strength** - Withstand stresses induced by mating/unmating, stitching, molded-in stresses, etc. without breaking.
- **Impact strength/toughness** - Absorb energy from impact, overstressing due to misalignment during mating, etc. without failure.
- **Flexural modulus/stiffness** – High stiffness to minimize deflection/movement under stress to keep contacts aligned, or high flexibility for strain relief on cables and flexible housings.
- **Ductility** - Deform instead of fracture when overstressed.
- **Wear Resistance** - Withstand repeated cycling.

Electrical Characteristics

- **Electrical resistivity (Surface & Volume)** - Electrically insulate conductors. However, high surface resistivity allows for electrostatic build-up and possible electrostatic discharge (ESD).
- **Dielectric strength** - Withstand high voltage without allowing electric current to pass through (i.e., minimize electrical energy lost through plastic insulation).
- **Dielectric constant** – Use low dielectric constant (low-k) insulating material to minimize parasitic capacitance between adjacent traces.

Thermal properties

- **Continuous use temperature (UL Thermal Index)** - Withstand extended high temperatures in modern applications (e.g. automotive underhood).
- **Heat deflection temperature/heat deflection under load temperature (HDT/HDTUL)** - Withstand short-lived temperature increases without losing strength or permanently deforming.
- **Thermal expansion coefficient** - Minimize thermal expansion differential between components of connector.
- **Creep resistance** - Avoid slow permanent deformation under load and associated dimensional changes over time.

Environmental Resistance Characteristics

- **Flammability** - The plastic must be resistant to burning when exposed to flame, or quickly self-extinguish once ignited. This can be accomplished by mixing the resin with flame-retardant additives. (Note that brominated flame retardants are restricted by RoHS).
- **Chemical resistance** - Resist breakdown or environmental stress cracking in the presence of corrosive or solvent chemicals.
- **Hygroscopic resistance** - Resist water absorption and accompanying swelling.
- **Ability to withstand medical sterilization procedures** – Must be capable of withstanding multiple medical sterilization cycles, which are typically done using high pressure steam in an autoclave, or by exposure to ethylene oxide, nitrogen dioxide gas, or high intensity gamma radiation.

PREVIEW

©2020 Materion Brush Inc.

Figure VII-2 Circular Connector with Plastic Housing




Figure VII-2 Circular Connector with Plastic Housing

This plastic housing incorporates locking tabs and strain relief on the cable.

Metal Housing Materials (Figure VII-3)

In certain high-performance designs, plastic would be inadequate for the housing. Either it will not stand up to temperature and vibration (such as in aerospace connectors), or the housing will need to be electrically conductive to ground, bond, shield, or otherwise control EMI (such as in coaxial connectors). Often, the two halves of the connector interface are threaded so that the two sides can make more intimate contact.

Purpose of Metal-Based Connector Housing

- Keep contacts/ground planes in position and ensure proper alignment during mating
- Provide electromagnetic shielding of connector
- Provide 360° bond around edge of connector to control EMI
- Provide true ground for connectors (not signal return)
- Shield contacts from environment - ensure water, dust, salt, corrosive agents, etc. are kept out of the connector housing and away from the contact interface.
- Provide easy mating/separation capability of connector

Key properties of metal

- Easy Machinability
- Corrosion/Environmental Resistance
- Dimensional Stability
- Mechanical Properties

Common choices for metal housings include steel and free-machining brass, since the mating housing parts are typically large, they do not require as much strength as the smaller contacts.

Within these metal-housed connectors, the individual contacts will still need to be separated by a dielectric material, which could be glass or ceramic based (hermetically sealed, high temperature and/or military connectors) or polymer-based for most other applications. For polymer-based dielectrics, the same considerations that were discussed in the plastic housing section apply.

Figure VII-3 Connector with Metal Housing and Dielectric




Figure VII-3 Connector with Metal Housing and Dielectric

The dielectric provides electrical isolation between the contacts. The threaded metal housing provides EMI shielding through its bulk electrical conductivity and a 360 degree seal around the connection.

MATERION

©2020 Materion Brush Inc.

Connector Lubricants

In separable connectors, lubricants serve a number of important functions to help ensure a low and stable contact resistance.

Purpose of Connector Lubricants:

- Ensure low insertion force
- Protect against fretting and pore corrosion
- Flush debris and other contaminants away from the interface zone and help to prevent them from getting back in
- Protect against oxidation and other chemical fouling of the surface
- Remain stable over time, and when exposed to elevated temperature, oxygen, or other corrosive environmental agents

Polyphenol ethers (PPE's) are perhaps the most widely used lubricant types. Also, perfluoro polyethers (PFPE's), Poly alpha olefins (PAO's), and various synthetic lubricants are available. Various thickening agents (microcrystalline wax, silica, soap, clay, polymers such as PTFE, etc.) may be added to form greases with tailored properties.

Key Properties of Lubricants:

- Lubricity (reduce insertion force)
- Viscosity (provide wear resistance)
- Surface tension (wet the surface and limit lubricant migration)
- Maximum and minimum rated temperatures
- Chemical inertness in environment
- Non-corrosive to the contact surfaces, base metals, and housing materials
- Low volatility (remain on the surface/ do not evaporate)
- Thermal stability

Note that the first 3 properties are also functions of temperature. Please contact your lubricant supplier to ensure that the lubricant that you want to specify is suitable for the expected temperature range and environment of your application.

Dielectric/Insulator Materials

Dielectric materials are necessary to electrically separate contacts in order to provide signal integrity, while physically holding the contacts in place. In lower cost, commodity contacts these are usually made of plastic. In higher end, high reliability military/aerospace connectors these are usually ceramic or glass.

Purpose of dielectric materials

- Keep separate circuits electrically isolated, even as they pass through pins and sockets in the connector
- Hold sockets and pins in place

Key properties of dielectric materials

- **Volume resistivity** – This is the bulk resistivity of the material, usually measured in megaohm-cm. It is the resistance to current flowing per cubic centimeter of material.
- **Surface resistivity** – This is the resistance to leakage current flowing across the surface of the material, usually measured in megaohm. It is the resistance to current flowing per square centimeter of the material surface.
- **Creepage** – This is not a material property, but a circuit property. It is the shortest distance along an insulating surface between two conducting parts. This is the path that leakage current would take along the surface.
- **Dielectric strength (withstanding voltage/breakdown voltage)** – Under a high enough voltage, even electrical insulators can conduct current. The dielectric strength is the maximum voltage that can be placed across a dielectric material before it conducts current. In RF applications, the dielectric strength typically does not matter, since voltages are small. In high current or high power applications, it may become a consideration.

  For air, the breakdown voltage is about 3 MV/m. If the voltage to distance ratio between two contacts separated by air exceeds this limit (if the voltage is high enough and the contacts are close enough), an arc will form between them and the air will conduct current. See Section VIII – High Voltage, Current, and Power Considerations for more detail). Most solid insulators and dielectric materials have higher breakdown voltages, typically on the order of 10-50 MV/m.
- **Permeability** – This is the magnetic field equivalent of permittivity. It describes how a material **magnetizes** (orients itself on an atomic or molecular level) when a magnetic field is applied to it. The permeability of a material relative to the permeability of free space (Vacuum or air) is known as the **relative permittivity**. Free space permeability is $4\pi\times10^{-7}\ H/m = 4\pi\times10^{-7}\ V\cdot s/A\cdot m = 4\pi\times10^{-7}\ T\cdot m/A$.

  If the magnetic dipoles in the material orient themselves to oppose the external magnetic field, decreasing the overall field strength, then the relative permeability is less than 1 and material is said to be **diamagnetic**.

  If the dipoles orient themselves to reinforce the applied field, the material has a relative permeability greater than 1 and is said to be **paramagnetic**.

  If the relative permeability is exactly equal to 1, then the material is said to be magnetically transparent, and the material and the applied magnetic field have absolutely no effect on each other, and the magnetic field passes through the object unaffected.

  If the paramagnetic material retains the magnetism after the field is removed, it is said to be **ferromagnetic**. Permanent magnets are strongly ferromagnetic.

  It is important to note that permeability may be a function of the frequency of the applied signal.

©2020 Materion Brush Inc.

Magnetic Susceptibility – This is another means of expressing magnetic permeability. The volume magnetic susceptibility is found by the following relationship:

$$\chi_m = \mu_r - 1 \qquad \text{or} \qquad \mu_r = \chi_m + 1,$$

So, if the relative permeability is 1 (the material has no effect on the applied magnetic field, as in the case for air or vacuum, then the material has a magnetic susceptibility of 0. If the material is diamagnetic (permeability less than 1), then the susceptibility is negative. If it is paramagnetic or ferromagnetic (permeability greater than 1), then the susceptibility is positive).

Permittivity – This is a measure of how easily the atoms of a material **polarize** in response to an applied electric field, and is the electric field equivalent of permeability. Polarization occurs when the atoms within the material orient themselves with positive charges on one side and negative charges on the other, in a way that increases the overall electric field without changing the initial charge on either side of the dielectric material. The permittivity of a material relative to the permittivity of free space (Vacuum or air) is known as the **relative permittivity**, or **dielectric constant**. Free space permittivity is $8.85\times10^{-12}\ F/m = 8.85\times10^{-12}\ C/(N\cdot m^2)$. A high relative permittivity between two charged objects effectively increases the capacitance between them, relative to air or vacuum. Relative permittivity is always greater than or equal to one.

It is important to note that permittivity may also be a function of the frequency of the applied signal.

Dielectric constant (relative permittivity) – In addition to governing how much capacitance occurs between traces on either side of the dielectric, it also influences how quickly the signals will propagate down the line.

The speed at which a signal travels down a line, with a dielectric material between the signal and return paths, is given by the following equation:

$$v = \frac{1}{\sqrt{\varepsilon \cdot \mu}} = \frac{1}{\sqrt{(\varepsilon_0 \cdot \epsilon_r)\cdot(\mu_0 \cdot \mu_r)}}$$

Where:

v = transmission speed of signal

ε = permittivity of the dielectric medium

μ = permeability of the dielectric medium

ε_0= free space permittivity

ϵ_r= relative permittivity (dielectric constant) of the dielectric medium

μ_0= free space permeability

μ_r= relative permeability of the dielectric medium

The term in the first set of parentheses is the permittivity of the dielectric material, and the term in the second set is its magnetic permeability. If the dielectric material happens to be air or a vacuum, the relative permittivity (dielectric constant) and the relative permeability are both 1, then the transmission speed happens to be the speed of light in a vacuum.

The upshot is that the speed of a signal down a transmission line will always be slowed by the permeability and permittivity of the dielectric medium between the signal traces. However, dielectric and common insulating materials usually have a permeability either exactly equal to or approximately equal to 1, so the speed of the signal is almost entirely governed by the dielectric constant. This is why there has been a lot of interest recently in materials with low dielectric constants, also known as low-k materials. (They are called **low-k** because the dielectric constant is sometimes expressed as the Greek letter κ.) With a lower dielectric constant (lower permittivity), signals can travel faster along the circuit, improving overall circuit speed.

Electric Susceptibility - This is another means of expressing relative permittivity. The electric susceptibility (χ_e) is found by the following equation:

$$\chi_e = 1 - \varepsilon_r \qquad \text{or} \qquad \varepsilon_r = \chi_e + 1$$

So, if the relative permittivity is 1 (the material has no effect on the applied electric field, as in the case for air or vacuum, then the material has zero electric susceptibility. Unlike the case for magnetic susceptibility, there is no known material (as of the writing of this document) with negative electric susceptibility.

Loss Tangent (Dissipation Factor) – Mathematically, this is the tangent of the angle that the real and imaginary parts of the dielectric constant make with each other. This factor accounts for the **dielectric loss**. As the atomic structure aligns itself with the electric field, (charges in each atom lining up with the field), heat is generated by this internal motion. The energy to do this has to come from somewhere. In this case it is removed from the signal, reducing its power

MATERION

©2020 Materion Brush Inc.

Epoxies and Potting Compounds

These are often used to encapsulate packages or seal connectors against the elements. In connectors, they can be used where the connector housing meets the cable, in order to prevent water ingress at that point. In high end, hermetically sealed connectors, glass frit may be used instead of epoxies to seal the connector housings.

Epoxies and potting compounds

- Must not outgas any elements that may corrode the contacts
- Must keep the connector sealed (except for separable interface)
- Must keep water/air/corrosive elements out of connector housing
- Must not crack or pull away from housing

Key properties of epoxies

- Adhesion
- Corrosion resistance
- Thermal expansion coefficient
- Curing temperature
- Maximum exposure temperature
- Flammability

The epoxies must not pull away from the surfaces they are sealing, which requires good adhesion strength, as well as good ductility to tolerate any thermal expansion mismatch between the epoxy and the surfaces it is sealing. Furthermore, it should cure at a temperature low enough to not cause damage to the contacts, plating, or housing, without outgassing any harmful chemicals.

MATERION

©2020 Materion Brush Inc.

Section VIII. Higher Voltage, Current and Power Considerations



[Note, this chapter focuses on what are considered to be higher voltages for automotive and consumer electronics, with voltages on the order of tens to a few hundred V. This is not a discussion on connectors for high voltage transmission lines, typically measured in kV.]

For most of the 20th century, automobiles operated with a14 volt architecture in their electrical systems. This utilized a 14V alternator to charge a 12V battery, which supplied sufficient power to all of the car's electrical systems. At this voltage level, an auto mechanic who was unlucky enough to accidentally complete a circuit through his body would receive a nasty jolt, but would be unharmed.

In the latter years of the 20th century, the number of electrically powered features on cars continued to increase. It was realized that the 14V architecture would soon be insufficient to power all of an auto's electrical systems. In the 1990's, the idea of the 42V power net was floated. This would utilize three 12V batteries in series, with a 42V alternator to charge them. No new battery technology would need to be developed, and 42V was still less than the 60V level widely considered dangerous to human life.

While the merits of the 42V system were being debated, the automakers released gasoline-electric and diesel-electric vehicles. These were shortly followed by plug-in hybrid electric autos and then vehicles with all-electric power trains. Electrical systems operating at 100 – 600 V are now found on vehicles, well above the "safe" level of 60V.

Now, 48V architectures are becoming vogue for mild hybrid vehicles to power accessories during engine off periods. This uses a single 48V battery to power high voltage components and systems in conjunction with a standard 12V battery to power low voltage components.

Whether its 48V, 100V, or 600V, these high voltages present their own challenges to connector manufacturers.

Breakdown Voltage

Generally speaking, electrical current will flow easily through conductors and semiconductors, and will have a difficult time flowing through insulators. However, if the voltage is sufficiently large enough across an insulator and the gap between the charges is sufficiently small, an electric current will flow through the insulator.

Figure VIII – 1 Electric Charge and Current Moving Through Air



Corona Discharge



Lightning Strike



Electrical Arc

Figure VIII – 1 Electrical Charge and Current Moving Through Air

Corona discharge occurs when an item with a strong electrical potential (high voltage) ionizes the surrounding air, transferring charge to it. An electrical arc is current flowing between two electrically separated components with a high potential between them.

MATERION

©2020 Materion Brush Inc.

Electrical Arcing

Arcing is a phenomenon by which current can travel across a gap between electrically charged surfaces (such as the two contact surfaces on a separated electrical connector). It can occur in closing contacts as the two surfaces approach each other, before the two halves of the interface actually touch. It also can occur in opening contacts as the two contact surfaces separate from each other.

An electrical connector or switch must pass current across the contact interface when in the mated or closed position. This means that there is an electrical potential (voltage) across the contact interface. When a connector is unmated, or a switch is opened, the current may stop flowing, but the voltage still exists. This potential will only go away if the source voltage in the circuit is disconnected. Under the right circumstances, this voltage may induce an arc across the gap between the contact surfaces.

Arcs can only ignite when the electrical potential between the two contacts exceeds the minimum arc voltage, and the available current in the circuit exceeds minimum arc current. These are not absolute values, but depend on many factors such as the contact interface material, distance between the contacts, and the medium between the contacts. They also are functions of each other. If the source voltage in the circuit is increased, then the minimum arc current drops. If the available current in the circuit is increased, then the minimum arc voltage drops. However, if either the voltage or current drops beneath the minimum level, the arc will cease to burn. This does not preclude the possibility that the arc may reignite later. In DC circuits with inductive loads, the arc may extinguish and reignite several times. This is known as a showering arc.

Arcing can occur upon both the opening and the closing of a contact interface. In the closing case, the minimum arc voltage drops as the two contact surfaces approach each other. If the source voltage is too low, no arc will form, and the current will only start to flow once the surfaces are in contact with each other. With sufficient source voltage, a closure arc will occur when the minimum arc voltage drops below the source voltage.

A closure arc begins when electrons leave the cathode and jump across the contact gap to the anode. Along the way, the electrons will collide with and ionize gas molecules in the air. (The glow of the arc comes from the energized gas molecules.) As the electrons rain upon and heat the anode, it may release positive ions into the gap. These positive ions, along with those created in the intervening gas, will likewise bombard and heat the cathode. This heating may vaporize portions of the anode and/or cathode, resulting in wear. Together, the electrons, metal ions, gas ions, and vaporized metal form the arc column. A typical arc column is schematically (albeit simplistically) illustrated in Figure VI-2.

Figure VIII – 2 Closure Arc Process




Figure VIII – 2 Closure Arc Process

This provides a detailed description of how arcs form when the two halves of the connector interface are brought together under sufficient voltage to initiate electrical breakdown of the gap and the subsequent arc.

©2020 Materion Brush Inc.

Arcing can also occur when the two halves of the contact interface separate, breaking the current path in the circuit. This occurs when large current and voltage loads are interrupted, as are usually found in switches and relays. However, this can happen in other separable connectors, such as automotive wire harness terminals, if the circuit is not de-energized prior to separation of the connector.

Opening arcs can initiate in a different way. As discussed in section IV, any two surfaces in contact touch each other only at their high spots, or asperities. There is a certain amount of electrical resistance as the current is "squeezed" through these small numbers of paths across the interface. As the contacting surfaces begin to separate, the asperities decrease in both size and number. This forces a greater amount of current through each asperity and increases the electrical resistance. Resistive heating eventually will cause the last few paths to melt, resulting in a current-carrying molten metal bridge between the contacts. The bridge will vaporize at temperatures high enough to release electrons, initiating the arc.

Figure VIII – 3 Opening Arc Process




Figure VIII – 3 Opening Arc Process

This provides a detailed description of how arcs form when the two halves of the connector interface are separated. This this illustrates what is happening on the level of two asperities in contact.

One of the effects of arcing is the generation of electromagnetic interference. Any electrical noise in a device can be detrimental to its functionality. If arcing cannot be prevented, the interference can be minimized by shielding and filtering the affected circuits.

Metal transfer is another consequence of arcing. As mentioned earlier, electrons will pass from the cathode to the anode during an arc. In turn, the anode may release positive ions from its surface, which travel to the cathode. This would result in transfer of metal from the anode to the cathode. This is usually the case. However, in certain circumstances the direction of metal transfer may be reversed. The direction depends on the anode and cathode materials, and the length of the arc. (Shorter arcs will tend to show transfer from the cathode to the anode.) In AC circuits, the polarity of the contacts continuously changes, so the instantaneous direction of transfer depends on which of the contacts happened to be the anode and cathode at the moment of interruption. Over time, however, the net transfer in AC circuits will be approximately zero.

Welding may occur on contact closure. The heat created by the arcing may cause the contact surfaces to melt. If the contacts were to close on the molten metal, they may weld together. If the opening force is sufficient, the weld will be ruptured when the contacts are opened, resulting in some mechanical damage to the contact surfaces. If the opening force is insufficient, the contacts may not separate, and the separable interface will suddenly become a permanent bond. It also is important to note that welding can occur without arcing, since the sudden inrush of current upon making contact can be substantially higher than the steady state current, resulting in temporary melting of the interface. Silver tin oxide, silver cadmium oxide, and silver carbon composites have high melting temperatures and are less likely to weld than pure silver contact surfaces, which in turn are better than other surfaces such as gold, platinum, paladium, etc.

In switches, the energy of impact can damage the contact surfaces. Over many cycles, small fatigue cracks will appear and grow at the interface. This results in mechanical wear of the contact surfaces over time. The total erosion of the contact interface is a combination of material transfer, material vaporization, and mechanical damage from impact, fatigue, and separation of welded surfaces. As stated in *Electrical Contacts, Principles and Applications,* by Paul C. Slade, the amount of wear that occurs on each contact cycle depends on many factors including the current level, arcing time, size of the contact gap, the gasses present in the gap, opening and closing velocity, contact stress, the number of bounces on closure, movement of the arc on the contact surfaces, and the contact size, shape, and material.

The high energy of arcing will result in the formation of corrosion products such as oxides, chlorides, sulfides, nitrides, and carbon on the surface of the contacts. This will cause the electrical resistance of the contact interface to increase over time. Carbon deposits also are much more susceptible to arcing than standard contact materials. Arcs therefore will form more readily and last longer. This is referred to as **activation** of the contact surface.

©2020 Materion Brush Inc.

Contact bounce when a switch or relay closes has a significant effect as well. A closure arc begins the sequence, followed by an impact, then an opening arc as the contacts separate, and the cycle repeats until the bouncing subsides. In this case a single contact closure results in multiple arcs and impacts. In order to minimize the wear of the contacts, it is necessary to minimize the number and height of the bounces. This can be achieved by reducing the impact velocity, increasing the energy absorption upon impact, increasing the contact force, and reducing the inertia of the contact. A reduction in impact velocity implies a reduction in opening velocity, which will increase the duration of opening arcs. Soft contact materials will absorb more energy during impact, but are more susceptible to mechanical wear than hard contact materials. However, arcing will heat and soften the contact surfaces, which increases the amount of energy absorbed at impact and improves the damping rate of the bounces. Unfortunately, this may make the surfaces more susceptible to welding. Bouncing therefore can best be controlled by using small, strong, stiff contacts with low inertia and high contact force, and by using contact materials that are most resistant to arc formation and wear.

Another way to control the damage due to arcing is to minimize the arcing duration during contact opening. This can be accomplished by increasing the contact gap as quickly as possible. This may make the contact more likely to bounce when closing, but an arc of sufficient strength and duration can completely vaporize the contact! Therefore a balance must be found that minimizes the combined damage of opening arcs and contact bounce.

Arcing will become increasingly important as the automotive industry implements higher voltage architectures for electric and hybrid electric vehicles. These voltage levels are certain to create arcs. Therefore, contacts must be designed with arcing in mind. Care must be taken to optimize the contact opening and closing velocity, and to use the appropriate contact materials. The cost of plating will probably become a larger percentage of connector cost than the base metal. Therefore, it is best to select the materials which allow easy miniaturization of the connectors (high strength and good formability), and which are resistant to high current levels and heat (high conductivity, good stress relaxation resistance). High performance alloys like copper beryllium thus become much more cost effective in these cases.

Hot Plugging/Unplugging & Arcing Damage – When a “live” connector is mated or disconnected, an electrical arc will form on both closing and opening. With higher voltages, the damage caused by arcing becomes more significant. Small connectors under higher voltages and currents may even vaporize completely if they are not separated quickly enough. It is always best to de-energize circuits before mating and/or disengaging such connectors, but it is not always remembered or practical to do so. In this case, some kind of mechanical assist may be built in to the connector housing to increase the disengagement speed. Alternatively, a shunt path may be built into the circuit to divert the current, or an arc arrester may be incorporated into the connector housing.

Galvanic Corrosion – As connectors are driven by higher voltages, any stray voltage around the connector will also increase in magnitude, potentially impacting galvanic reactions. Such stray voltage accelerates galvanic corrosion, if it drives the current in the same direction as the galvanic reaction does.

Emergency Disconnection – In the case of automotive traffic accidents, the presence of high voltages poses a hazard to emergency first responders, who may have to cut trapped victims out of the wreckage. Emergency disconnects may be necessary to de-energize high voltage circuits so that the responders can safely do their job without the potential hazard of electrocution.

High voltage surges and transient currents – Automotive power busses are inherently noisy. Transient voltage suppression is built into many electronic circuits to protect them from such overvoltage. Connectors may still experience the full voltage of the transients, if the protection is only applied to the sensitive electronics on the PCB.

EOS - Electrical Overstress failures. (See Figure VIII-4.) With higher voltages and currents flowing through systems, the likelihood of an electrical overstress failure increases, if such current inadvertently flows where it is not intended to go.

Figure VIII – 4 Electrical Overstress Damage



Figure VIII – 4 Electrical Overstress Damage

Electrical overstress occurs any time that a circuit is forced to carry more than the maximum safe level of current. It can easily destroy components on the PCB or even the PCB itself.

©2020 Materion Brush Inc.

Section IX. Electromagnetic Compatibility, Signal Integrity, and other High Frequency Considerations



In an ideal world, electrical signals would travel from their source along the circuit, perform work at the load, and return to the source. The signals would only travel along their intended path, and would not leak onto unintended paths. Additionally the intended path would not be compromised by the presence of unwanted signals. However, we do not live in an ideal world, but in one governed by the laws of physics. Electrical circuits tend to pick up unwanted signals from other sources, a phenomenon known as **electromagnetic interference (EMI)**. This tendency increases as the frequency of the signal increases.

The trend in electronics has been and probably always will be toward faster processing speeds, requiring operations at ever higher frequencies. As such, it becomes critical to incorporate the principles of **electromagnetic compatibility (EMC)** and **signal integrity (SI)** into the design of all components of electronic circuits, including connectors.

It is also important to note that the electromagnetic compatibility is the function of the entire system, not just of the individual components. Even a perfectly designed connector cannot prevent EMI from occurring, if there are sources elsewhere in the circuit. In fact, a lot of solutions to ensure signal integrity and EMC must be designed into the circuit board itself. Examples include filtering, proper trace routing, proper use of ground planes, decoupling capacitors, shielding cans, etc. On the other hand, the signal integrity of a perfectly compliant board can be ruined by a non-compliant connector. It is your job as a connector designer to ensure that you follow the principles of SI and EMC to ensure that your connector is not a source of EMI.

Definitions

Electromagnetic Compatibility (EMC) – The ability of an electrical or electronic device to operate in its intended environment without being disturbed by or disturbing other equipment through conducted or radiated electrical signals.

Electromagnetic Interference (EMI) – An undesirable effect or disturbance in an electrical or electronic device due to the transmission or reception of unwanted electrical signals unintentionally conducted or radiated from another device.

Radio Frequency Interference (RFI) – Electromagnetic interference due to radiated signals in communication bands.

Intentional Electromagnetic Interference (IEMI) – Deliberate disruption of operations through the use of electromagnetic interference, radio frequency interference, or an electromagnetic pulse as a weapon in a targeted attack against a system.

Signal Integrity (SI) – A measure of electromagnetic compatibility in which the desired signal arrives at its intended destination with sufficient strength at or below an acceptable level of distortion, and with any unwanted noise signals below the threshold at which they would cause errors.

Emissions – Conducted or radiated energy generated and transmitted by an electrical or electronic device's operation. Unintended emissions create electromagnetic interference.

Immunity - A measure of how resistant a device is to the potential negative effects of external fields. A device's immunity would typically be tested in an anechoic chamber, or an open air (OATS) test.

©2020 Materion Brush Inc.

Susceptibility – This is a measure of how susceptible a device is to EMI from external fields and noise, and is the inverse of immunity.

Resistance - Electrical energy lost from the circuit as useful work done by the load on the circuit (desirable) as well as resistive heat dissipated the conductive elements in a circuit (undesirable).

Capacitance - Electrical energy stored in an electric field as charge (voltage or potential) between elements of an electrical circuit. It is a means of coupling between signal conductors, or between signal and ground. A change in the voltage (potential) between the two components generates a change in the electric field between them. This capacitive coupling induces a current in the victim line, creating electrical noise. Conductor spacing, material and design influence this.

Inductance – Energy stored in a magnetic field by and around current looping through an electrical circuit. A change in current generates a change in the magnetic field, which induces a voltage in nearby conducting circuit elements. This induced voltage, or inductive coupling, is one source of electrical noise.

Self-Inductance – The inductance per unit length of a conductor when current runs through it. The current stores energy in magnetic fields around the conductor, which may affect neighboring conductors.

Mutual Inductance – Inductance in a conductor from a current running through a neighboring conductor. The magnetic field generating by the neighboring conductor may create currents in the quiet wire, and vice versa.

Loop Inductance – The inductance of an entire circuit path, including all elements in the circuit.

Impedance - The ratio of voltage to current in a circuit element. Like resistance, impedance is measured in Ohms. Impedance consists of resistance (energy loss through joule heating), and energy storage from capacitive reactance (capacitance) and inductive reactance (inductance). Electrical currents and signals will always travel the path of minimum impedance, whether the path is desired or not. The impedance magnitude and mechanism depend on the frequency of the signal. In DC and low frequency AC signals, resistance dominates, and the current will tend to flow along the path of least resistance. At high frequencies, induction and capacitance dominate, and the current will tend to flow along the path of minimum loop inductance. Matched and uniform impedance along the entire signal path is desirable in high-speed circuits and transmission lines. Signals will be partially reflected by changes in impedance along the path.

$$Z = \sqrt{R^2 + \left(\omega L - \frac{1}{\omega C}\right)^2}$$

Where Z = Impedance, R= Resistance, L = Inductance, C= Capacitance, ω=driving frequency of the circuit.

Attenuation - The total amount measured in decibels by which power received is reduced relative to power transmitted after a device has been inserted in the electrical path. It consists of copper loss (resistance) in the conductors, dielectric losses (as a result of the dielectric having high but not infinite resistance therefore dissipating some energy), reflection losses (due to some of the signal being reflected at various discontinuities) and radiation losses (the line acts like an antenna and radiates electromagnetic energy at high frequency). Attenuation may be intentional (as in electromagnetic shielding) or unintentional (as in insertion loss or reflection loss).

Cross Talk (Coupled Noise) – Signals from one line unintentionally transferring to another line because of conduction or capacitive and/or inductive coupling.

Voltage Standing Wave Ratio – The ratio of the amplitude of a reflected signal to the amplitude of the transmitted signal as it enters a new circuit element. For perfect transmission, the ratio is 0 and for total reflection the ratio is 1 or -1.

Bandwidth – The range of frequencies through which the bulk of the of the signal energy passes, as defined by the frequency band where the spectral power of the signal remains above predetermined limits. Bandwidth provides an approximate measure of how fast data can be transmitted along the electrical path for a given coding technique.

Parasitics – Undesired inductive or capacitive coupling between two or more components of a circuit. This causes loss of signal strength, as well as cross talk on adjacent signal traces.

Rise Time – The approximate time it takes for a binary signal to switch states from fully off to fully on. It is usually defined as the time it takes for a signal to rise from 10% of its fully off value to 90% of its fully on value. It is typically on the order of tens to hundreds of picoseconds. Shorter rise times allow faster data transmission, but create more capacitive and inductive coupling.

Skin Effect – The tendency of a high frequency electrical signal to travel preferentially on the surface of a conductor, as opposed to spreading evenly through interior. As the frequency increases, a greater portion of the signal travels on the surface, and a smaller portion travels through the interior of the conductor.

Skin Depth – The depth into the surface of a conductor at which the strength of a high frequency signal is reduced to 1/e (37%) of its maximum strength.

Intermodulation Distortion – When modulation deliberately applied to an electrical signal on one path unintentionally

©2020 Materion Brush Inc.

appears on a neighboring path due to coupling, or as a result of a linear summation or difference of harmonics of signals at lower frequencies. For example, if a modulation "A" is a applied on a signal at a frequency of 275 MHz and modulation "B" is applied on a signal at a frequency of 300 MHz, then spurious signals with a modulation of A+B will appear at frequencies of 25, 50, 75, 200, 225, 250, 325, 350, 375, 500, 525, and 575 MHz (including 2nd through 7th order harmonics). The closer the intermodulation product is to the original frequencies, the stronger the signal.

Ground Bounce – Noise caused by a sudden difference in voltage between the reference voltage in a circuit and the ground voltage, usually during switching. This can result in spurious signals in the circuit.

Switching Noise – When multiple signals share the same return path, switching on one signal effectively changes the voltage between signal and return, which may generate noise, on any other circuit that shares the same return path.

Insertion Loss – The portion of a signal that does pass completely through a circuit element, usually measured in decibels. It is a measure of the power that passes through the element relative to what that power would be if the element were not there. Note, however, that the S-Parameter that is commonly referred to as insertion loss is actually a measure of what is transmitted, not what is lost.

Return Loss – Portion of a signal lost by reflection at an impedance discontinuity, such as a connector, usually measured in decibels.

Noise and Coupling Mechanisms

To have an electromagnetic compatibility problem, there needs to be a coupling mechanism for the undesired signal to travel from the source component to the victim component. (Figure IX-1) This coupling could happen by conduction (either by a direct conducting path between the components, or by an indirect conducting path (such as through a common ground). A second possibility is when the electrical fields, magnetic fields, and/or electromagnetic waves emitted by the desired signal in the source circuit generate undesired electrical currents in the victim circuit. Even the desired signal could be partially reflected by a discontinuity in the path, in which case part of the desired signal itself becomes the noise.

Figure IX-1 EMI Noise Sources (and Receptors)

To have an EMI problem, three elements are necessary:

1. Source
2. Coupling path
3. Receptor

Potential Sources & Receptors

- Motherboard & card traces
- Internal ribbon & cables
- External cables
- Improperly grounded/ bonded connectors
- Seams/gaps in enclosures



Figure IX-1 EMI Noise Sources (and Receptors)

For EMI to exist, it requires a coupling path between the source and victim. The path could be a direct conduction through physical contact, indirect conduction through ground, capacitive coupling through electric fields, inductive coupling through magnetic fields, or via electromagnetic radiation (RFI).

MATERION

©2020 Materion Brush Inc.

Reflection Noise

One method by which noise can occur is reflection of the signal at a junction between circuit elements. Different segments of the circuit may have different impedance, such as a signal passing from a high conductivity material to a low conductivity material (change in resistance), or by a change in distance from neighboring circuits (change in capacitance). Reflection caused by impedance mismatches can alter the original signals transmitted from one point to another, causing logic circuits to switch at incorrect times. Reflection losses increase with increasing frequency.

Reflection losses are typically measured by the **Reflection Coefficient (Γ)** or the **Voltage Standing Wave Ratio (VSWR)**. See Figures IX-2 and IX-3. The reflection coefficient is the ratio of the reflected signal voltage to the incident voltage. The VSWR is the ratio of the amplitude of the reflected signal voltage to the amplitude of the transmitted signal voltage. They are defined by the following equations, where Z_1 is the impedance of the transmission line before the discontinuity and Z_2 is the impedance after the discontinuity

$$\Gamma = \frac{V_{reflected}}{V_{incident}} = \frac{Z_2 - Z_1}{Z_2 + Z_2}$$

$$VSRW = \frac{|V_{Max}|}{|V_{Min}|} = \frac{1 + |\Gamma|}{1 - |\Gamma|}$$

$$V_{reflected} = \Gamma \cdot V_{incident}$$

$$V_{transmitted} = V_{incident} \cdot (1 + \Gamma)$$

For Perfect Transmission: VSWR = 0, **(Γ)** = 0

For Total Reflection: VSWR = 1, **(Γ)** = -1 or +1

(A negative reflection coefficient means that the voltage has opposite sign to the incident voltage. When the coefficient is 1, the reflected signal is in phase with the transmitted signal. When the coefficient is -1, the reflection is 180° out of phase with the transmission.)

Figure IX-2 No Impedance Mismatch




Figure IX-2 No Impedance Mismatch

Perfect transmission with no reflection loss occurs when there is matched impedance.

Figure IX-3 Reflection Loss at Impedance Discontinuity




Figure IX-3 Reflection Loss at Impedance Discontinuity

Reflection loss occurs at impedance discontinuity, in this case with a positive Γ.

Impedance Matching

The impedance of connectors or devices should match the impedance of the entire circuit as closely as possible to minimize reflectance loss. Using a high conductivity material for the contact element in a connector minimizes the change in resistance from the connector to the rest of the circuit. However, the capacitive reactance and inductive reactance are properties of the circuit geometry, and cannot be controlled by material selection.

©2020 Materion Brush Inc.

Coupled Noise (Cross-Talk)

Cross-talk (Figure IX-4) is essentially the leakage of a signal from the desired pathway onto an undesired pathway, thus becoming noise. The noise could reach the circuit by either direct or indirect conduction (usually at low frequencies), by inductive and/or capacitive coupling at higher frequencies or by electromagnetic radiation (more prevalent at radio frequencies). Cross talk has two effects:

1) Signal loss (attenuation) on the driven line

2) Contamination of the quiet line causing false triggering, overloaded circuits, and interference.

The most important measure of crosstalk is signal attenuation, which is measured in decibels (dB) and compared to the original signal strength. It can be measured as **near-end cross talk (NEXT)** or **far-end crosstalk (FEXT)**, depending on whether the measurement is taken near the signal source or at the load.

Cross talk can be controlled by proper grounding (to ensure that conductive coupling does not occur) and by shielding (to guard against capacitive coupling and RFI), and by proper circuit geometry (to minimize inductive coupling).

Ways to Reduce Crosstalk

- Surround signal/return pair with grounded high conductivity shield
  - – Minimizes emission of electromagnetic interference
  - – Blocks unwanted noise from outside the pair
- Use differential pairs
  - – Keeps magnetic field mostly between the two lines (incoming and outgoing) in the pair
  - – Same principle to reduce susceptibility as twisted pair wiring
  - – Allows noise to be filtered out automatically.

Figure IX-4 Cross Talk




Figure IX-4 Cross Talk

Coupling between adjacent signal lines happens through interaction between the source line and the victim line via electric field (mutual capacitance) or magnetic field (mutual inductance). This generates unwanted signals on the victim line, in the forward and backward directions.

MATERION

©2020 Materion Brush Inc.

Conducted EMI

EMC engineers distinguish between two types of current, namely differential mode and common mode.

Differential mode current (Figure IX-5) is what most lay people would think of when they hear electrical circuit. In this mode, the signal current leaves the source through the signal wire or trace, does work at the load, and returns along the return wire or trace. In electrical power terms, the current leaves the source through the phase line, does work at the load, and returns via the neutral line. In either case, the ground line never carries current, except in the case of diverting an overload or transient pulse. For signal currents, the return path may be termed ground, but as in power transmission, the true ground path does not carry current under normal circumstances. (On a PCB, the return path may be along the ground plane, but it is still considered return. Also, pins in a connector may serve as a both a signal return path and path to ground.) While the differential mode is where all desired currents and signals travel, unwanted EMI (noise) may also travel in differential mode

Figure IX-5 Differential Mode Current




Figure IX-5 Differential Mode Current

Differential mode current flows along the path starting from the source, passes through the load, and returns to the source. All intended signals travel this way, as does some noise.

Common Mode Current (Figure IX-6) virtually always carries noise, not the signal. (The exception was in telegraph systems, where there was no return line, and the return path was literally through the ground in the Earth's soil). In common mode, the induced current travels along either the signal (phase) line and or the return (neutral) line, does unintended work at the load, and completes the loop through the source through some unknown path through ground (known as a **ground loop**). Common mode currents can be eliminated by proper grounding (to avoid ground loops), or by the use of common mode filters in the circuit. Note that only one side of the circuit should be grounded to avoid the potential for ground loops. One ground is better than two, as this is one case where it is easily possible to have too much of a good thing.

Figure IX-6 Common Mode Current




Figure IX-6 Common Mode Current

Common mode current travels from the source through the load, and then finds its way back to the source through ground. Only unintended signals travel this path, but they can still cause unintended action at the load.

MATERION

A major source of conducted noise in circuits can come from **pulses, surges** and **transient currents**. Lightning strikes are an obvious example, causing a surge of damaging high current, if not diverted to earth through an electrical safety ground.

An **electrostatic discharge (ESD)**, occurs when a high potential electrostatic charge (i.e. static electricity) builds up on a person or object that subsequently comes into contact with an object having a lower electrostatic potential, resulting in a sudden movement of charge from the high potential object to the low potential object.

A **coronal mass ejection (CME)** is a natural outburst of charged particles from the sun. These particles can damage electronic equipment either through direct impact with susceptible circuitry or by generating numerous secondary particles once they hit the earth's magnetosphere.

An **electromagnetic pulse (EMP)** is a blast of electromagnetic radiation, typically resulting from a nuclear explosion that can completely overwhelm and destroy any electrical circuit or device in the vicinity. If a nuclear explosion occurs anywhere near you, then electromagnetic compatibility is probably the least of your worries. However, if you are designing connectors for military devices that might be involved in nuclear warfare, then you can protect against EMP's through the use of thick, rugged electromagnetic shielding on every component in said equipment.

Electrical fast transients (EFT)/Switching Noise

As discussed in Section VII, high voltage considerations, when circuits are opened and closed, arcing can occur between the two halves of the interface. For DC or low frequency AC circuits that are primarily resistive in nature, the arc will typically ignite, burn for a short period, and then quickly extinguish, resulting in a transient noise waveform of a single, sharp peak. For reactive circuits (circuits that have significant energy stored in electric and magnetic fields), the arc may experience a number of cycles of ignition, burning, and extinguishing as the stored energy gradually diminishes. This results in what is known as a showering arc, and the noise waveform is a series of sharp peaks.

Electric motors are particularly noisy, and tend to generate a great deal of electromagnetic and radio frequency interference. If you are old enough to remember watching analog broadcast television, you will remember how the operation of a nearby electric motor would distort the picture and sound.

EFT's can be controlled by properly grounding the circuits, and by adding high pass, low pass, or band pass filters to the circuits as necessary to remove noise.

Radiated Coupling Mechanisms

As electrical signals travel along the conducting paths, they generate electrical and magnetic fields around the conductors. If a straight section of the conducting path is sufficiently long relative to the wavelength of the signal (generally, about ¼ of the wavelength), the signal can propagate through surrounding space via electromagnetic waves radiating from the source. These radiated coupling mechanisms can induce unwanted voltage, current, or modulation in the victim line. This potential noise source is usually a concern when the frequency is above 30 MHz or so.

Electric Field Coupling (Mutual Capacitance)

Capacitance is the storing of energy in an electric field between two charged objects. In the case of circuit, the electric field extends from the signal line to the return line. A changing voltage in this circuit creates changes in the electric field between the signal and return lines. This changing electric field induces a current in any conducting circuits that lie within the field, shown schematically in Figure IX-7.

Figure IX-7 Mutual Capacitance




Figure IX-7 Mutual Capacitance

Unwanted current is induced in victim circuit by electrical field generated by changing voltage in the driven circuit.

©2020 Materion Brush Inc.

The simplest case of capacitance is the presence of an electric field between two charged plates. (See Figure IX-8). The capacitance (or amount of energy stored in the electric field) between the two plates depends on only two factors: the area of the surfaces facing each other and the distance between the two surfaces. The thicknesses of the plates and the amount of charge do not enter into the equation.

Figure IX-8 Capacitance Between 2 Charged Plates




Figure IX-8 Capacitance Between 2 Charged Plates

Mutual capacitance only depends on the area surface area of the two components, and the distance between them. As electrical contacts get smaller, it is important to reduce the area of the facing surface to minimize capacitive parasitic leaks.

The first implication of this is that capacitive coupling between adjacent contacts depends on the distance between them. As the contacts are spaced closer together, the capacitance increases. If they are farther apart, then the capacitance decreases. However, miniaturization dictates tighter contact spacing, which increases the tendency for capacitive coupling.

The second implication is that the geometry of adjacent contacts has a profound effect on the potential for capacitive coupling. As the area of the surfaces facing each other increases, the capacitive coupling increases. Therefore, if capacitive coupling is a concern, short contacts will show better performance than long connectors. If adjacent contacts made from strip are oriented with the top and bottom surfaces of the strip facing each other, then narrower widths and thicker gauges will show better performance than wider strip with thinner gauges. If they are oriented with the slit or stamped edges facing each other, then thinner gauges, where possible, would show better performance.

Capacitive coupling can also be reduced by the use of grounded electric field shielding between adjacent contacts. Proper grounding of the circuit components will also help to reduce the potential for stray capacitance between components.

Magnetic Field Coupling (Mutual Inductance)

Inductance is the storing of energy in a magnetic field within a current loop (circuit). The magnetic field extends in loops from the signal line to the return line. A change in the current flowing through the loop induces changes in the magnetic field. This changing magnetic field induces a current in any conducting circuits that lie within the field, shown schematically in Figure IX-9. The induced current will appear in a direction so that its magnetic field opposes the change in the magnetic field that created it. Therefore, the current direction depends on whether the field strength is increasing or decreasing.

Figure IX-9 Mutual Inductance




Figure IX-9 Mutual Inductance

Unwanted voltage is induced in victim circuit by a magnetic field which is generated by changing current in the driven circuit.

The magnitude of the inductive coupling depends only on the relative loop areas of the two circuits. A large loop area results in much greater coupling than small loop areas (Figures IX-10 and IX-11). The way to minimize inductive coupling is by minimizing the loop area of the current. On printed circuit boards, ensure that the signal line runs over an uninterrupted path on the ground plane below. This will allow the signal return to flow directly underneath the outgoing path, minimizing the distance between them.

©2020 Materion Brush Inc.

Figure IX-10 Mutual Inductance of a Pair of Circuits




Figure IX-10 Mutual Inductance of a Pair of Circuits

A magnetic field generated by a current loop in the source path can pass through adjacent current loops, which generates unwanted noise on the victim path.

Figure IX-11 Mutual Inductance of a Pair of Circuits




Figure IX-11 Mutual Inductance of a Pair of Circuits

To minimize the potential for mutual inductance, current loops should be kept as small as possible, with signal lines (and contacts) adjacent to or above return lines (and contacts).

Cross modulation

Cross modulation is when modulation applied to one signal appears on a nearby signal due to capacitive and inductive coupling. (Figure IX-12)

Figure IX-12 Cross Modulation




Figure IX-12 Cross Modulation

This occurs when modulation on one signal is unintentionally transferred via capactive or inductive coupling to a victim signal.

MATERION

©2020 Materion Brush Inc.

Intermodulation Distortion

Intermodulation causes high-bit error in digital systems and unacceptable levels of noise in analog systems. It occurs when 2 or more transmit signals of given frequencies, or higher order harmonics of those frequencies, interact to create a new unintended signal at different frequency.

Passive Intermodulation occurs when two or more signals flow through a region of nonlinear impedance (i.e., the ratio of voltage to current is nonlinear). Usually this happens when the signals pass through dissimilar metals or finishes (the metal difference may be inherent or it may be due to corrosion). Magnetic materials, such as nickel and steel, are known to be a prime cause of passive intermodulation generation. These materials inherently have a non-linear relationship between voltage and current due their high magnetic permeability. They should be carefully avoided on RF-carrying conductors or in regions of RF field distribution.

Intermodulation also happens when the materials experience increased temperature due to contact resistance, and when signals pass through discontinuities within a cable system. It can occur when electrical contacts get rust or other corrosion products on them, or if the electrical contacts are loose.

It can also occur when two broadcast signals are picked up by conductors (particularly iron-based) in the vicinity, and get mixed when passing through the rust on the surface. A classic example would be radio signals mixing in and being rebroadcast by neighboring rusty fences, nails, bolts, etc. This is why passive intermodulation is sometimes known as the **rusty bolt effect**.

Electrical contact surfaces give rise to two additional non-linear effects that can cause intermodulation:

- **Microscopic arcing** – Arcing is an inherently non-linear process, as it only occurs when the voltage exceeds the breakdown voltage of the gap.
- **Electron tunneling** – Even with a physical gap that is too large for electrons to cross, there is a quantum probability that they could appear on the other side of the gap. They can thus suddenly appear on the other side of the barrier without ever crossing the gap.

For two broadcast frequencies (f_1 and f_2), the frequencies at which intermodulation products occur are defined by the following equation.

$f_{IM}=m\times f_1+n\times f_2$, where m and n are ± 1, 2, 3, 4 …

Intermodulation products are defined by their order, which is defined as m + n. Even order intermodulation products typically occur outside the bandwidth of the generating frequencies, and would only be a concern if nearby equipment happens to be operating at one of those frequencies. Odd-order intermodulation products where m and n are of opposite sign and differ by 1 happen to fall near the generating frequencies, and may be picked up by the receiving equipment. The power of the intermodulation products tends to fall off with the order, so generally only the 3rd, 5th, and 7th order products can create problems, as shown in Figure IX-13.

Figure IX-13 Intermodulation




Figure IX-13 Intermodulation

There are multiple intermodulation products, located at frequencies that are sums and differences of multiples of the two original frequencies. Odd lower order intermodulation products contain more power than higher order products, and are close to the carrier frequencies, so these are more likely to cause interference.

Note that the heights of the lines in Figure IX-13 are arbitrary. The actual power (signal strength) in each intermodulation product depends on the power in each of the original frequencies, as well as the exact nature of the nonlinearity generating the IM products. Furthermore, the power in the higher order products tends to be spread out over a greater bandwidth than that of the original frequencies.

Electromagnetic Wave Radiation

Any path in a circuit with a straight conducting length greater than about 5% of the signal wavelength can radiate electromagnetic fields. Once the length of the straight section exceeds 25% of the wavelength, it will function relatively efficiently as a transmitting and as a receiving antenna. These electromagnetic (EM) waves, which propagate through air or vacuum with a characteristic impedance of free space (Z_0= 377 ohms), will induce currents and voltages in any conductors they come across. Shielding can be used to contain or suppress unintentionally broadcast EM waves at the source, and can also be used at the receiving end to prevent reception of the unintended signals. Filtering may also be used in the circuits to remove any such noise unintentionally picked up.

©2020 Materion Brush Inc.

PCB/System Design to Suppress EMI

On printed circuit boards try to keep the highest speed circuits within the smallest possible area, as close as possible to without entering the breakout area near the backplane or connectors when the signal leaves the board. This will reduce the possibility of high frequency signals traveling through traces that are long enough to function as broadcast antennas. Shield high frequency traces, when possible. Try to keep high frequency and low frequency circuits apart, using different ground planes, if possible.

Use shielding cans over high speed processors. Drawn cans may offer better protection than cans that are blanked out and folded, which might have gaps at the edges.

Minimize the potential for inductive coupling by minimizing the loop area. Keep your signal and return paths close together, and keep them approximately the same length on circuit boards, in cables, and in connectors. In connectors, the position and utilization of the contact pins influences the current loop area, and thus the amount of coupling.

Filtering

When shielding and board layout is not enough to suppress EMI, then you may need to add filters to the circuits. Filters pass signals within the desired frequency range and attenuate unwanted signals outside the desired frequency range. Examples include:

- **High Pass Filter** - removes low frequency noise
- **Low Pass Filter** - removes high frequency noise
- **Band Pass Filter** - removes noise at frequencies above and below the desired range
- **Band Reject Filter** - removes noise from a specific frequency range, good if there is a specific frequency that is known to be troublesome
- **Common Mode Filter** - attenuates CM current (always noise) and passes DM current (desired signal, some noise)
- **Differential Mode Filter** - attenuates unwanted DM signals

Cabling/Harnessing

For cables between systems, the current loops can be minimized with the use of twisted pair wires (Figure IX-14) or coaxial cable (Figure IX-15).

Twisted Pairs

When signal and return wires on the same circuit are twisted in pairs, the loop area is minimized, reducing the potential for mutual inductance. Furthermore, the orientation of the magnetic field changes continuously along the length of the cable, so the magnetic field as whole is not coherent.

Figure IX-14 Use of Twisted Pair Wiring to Reduce Inductance




Figure IX-14 Use of Twisted Pair Wiring to Reduce Inductance

When signal and return wires on the same circuit are twisted, the loop area is minimized, reducing the potential for mutual inductance.

Coaxial Cable

In coaxial cable, the return line completely surrounds signal line. Recall that the electric field passes linearly from the return line to the signal line while the magnetic field travels in loops from the signal path to the return path. In coaxial cables, the magnetic & electric fields are contained entirely within the cable, so there is no potential for induced EMI on nearby lines. This is confirmed by Figure IX-15, which shows a vector plot using a 2D field solver of the electrical (left) and magnetic (right) fields inside a coaxial cable. (Of course, a poorly designed connector at either end of the cable could still emit EMI, so it is important to properly ground, bond, and shield the connectors.

Figure IX-15 Coaxial Cable as a Means of Minimizing EMI




Figure IX-15 Coaxial Cable as a Means of Minimizing EMI

When the return line completely surrounds the signal line, the magnetic & electric fields are contained entirely within the cable, so there is no induced EMI on nearby lines.

MATERION

©2020 Materion Brush Inc.

Ribbon cable should be shielded to protect against stray electrical, magnetic, or electromagnetic fields. The connectors at the ends should be appropriately shielded, grounded, and/or bonded.

Any signal or power cable leaving the enclosure can function as an antenna (either broadcasting or receiving). The connector at the end of the cable must have a full 360 degree bond to the enclosure and to the cable shielding itself. A partial bond with a small gap around the periphery may allow EMI leakage.

If a long cable does pick up some unwanted high frequency EMI, ferrites or common mode choke filters may be used on the ends of the cable as low pass filters to block the EMI. (Figure IX-16).

Figure IX-16 Cabling




Figure IX-16 Cabling

Signal or power cables leaving the enclosure can function as antennas (both as broadcasting and receiving antennas). The connector at the end of the cable should have a full 360° bond to the enclosure. Also, you may use a ferrite or common mode choke filter on the cable to block unwanted EMI.

Controlling EMI at the Connectors

Bonding

Bonding creates a low impedance interface between two components (connector and cable, or connector and chassis) by fastening two surfaces together in intimate metal to metal contact. This makes a continuous grounded connection between the chassis and the cable shielding. The fastening may be done mechanically (through the use of threaded fasteners, crimps, etc.) or chemically by welding or brazing. The surfaces in contact should be clean and conductive, and dissimilar metals should be avoided to prevent passive intermodulation. When mechanically fastened, the surfaces should be kept together with adequate pressure to ensure no gaps.

Figure IX-17 shows some examples of connector configurations that exploit multiple solutions. The connector configurations are arranged from top to bottom in descending order of potential EMI problems.

Note that in all cases, the connectors are completely surrounded by a grounded shield (green), which makes 360 degree contact with the mating shell on the other side of the connector interface. Therefore, any performance difference among the connectors would be due to the internal configuration only.

Figure IX-17 Controlling Parasitic Coupling at the Connectors




Figure IX-17 Controlling Parasitic Coupling at the Connectors

Metallic (shielded) housings should be used to protect against magnetic and capacitive stray fields in all cases of potential interference (at low or high frequency).

©2020 Materion Brush Inc.

Pin Assignment in Connectors

In Figure IX-17, red dots represent signal pins and blue the return pins. It is possible to use one pin for signal return (top case), but there would be large current loops within the connector, with other signal lines inside these loops. This would increase the chance for unwanted magnetic field coupling between the pins in the connector.

In the second case from the top shows each signal pin is located next to its return pin. This reduces electric field and magnetic field coupling between each set of pins, although there is still some potential for capacitive coupling, particularly if the circuits are at different potentials to ground.

In the next case down, all the pins share one linear ground plane. This eliminates the problem of capacitive coupling in the case above, by ensuring that all the circuits share a common ground. However, there is still potential for magnetic field coupling.

In the second case from the bottom, each contact pair is separated from the next with shielding integrated into the connector housing. Therefore, the electric and magnetic fields around each pair are prevented from reaching their neighbor.

The bottom case uses the same approach as the second from the bottom, but includes a **differential pair** in the signal path. This feature eliminates common mode noise through a simple linear subtraction at the circuit board. Just before leaving the source circuit board, the signal is split in half, with half sent through one signal contact, while the other half is inverted (i.e. a mirror image) and sent through the second signal contact. At the other end of the connection, as the signals enter the circuit board, the inverted signal (and any inductive or EM noise it picked up along the way) is inverted again and is added to the first signal. In this case the two half signals add up to one full signal, and any potential noise is added to its inverse and is canceled out.

$$\left(\frac{Signal}{2} + Noise\right) - \left(\frac{-Signal}{2} + Noise\right) = Signal$$

Grounding (Earthing)

Most people are familiar with electrical safety grounds, which divert damaging excess current (such as a surge from a lightning strike) away from sensitive electronic systems or components (such as a house and the electronics and appliances within it). However, grounding has several different meanings in electronics, as shown in Figure IX-18. When used properly, grounding provides a common reference voltage for circuits, or provides a low impedance alternative path for unwanted noise signals and/or current (such as from electrostatic discharge).

Remember, that even though a ground plane may sometimes be used as a low impedance path for signal return, this is not a true ground function. Also, when grounding, be careful to avoid ground loops. You do not want to put in extraneous grounds that provide paths for common mode EMI currents.

Figure IX-18 Types of Grounding (Earthing)




Figure IX-18 Types of Grounding (Earthing)

Each type of grounding has a different purpose, and functions differently. You should never assume that any one type of grounding will handle the responsibilities of the other types.

Shielding

Shielding is used to reduce coupling due to electric fields, magnetic fields, or radiated electromagnetic (EM) fields. Proper shielding, grounding and bonding of connectors may eliminate the need for EMI filters on the circuit board. Remember that on connectors, shielding must extend 360° around the interface, or RFI may leak. Shielding is also used to seal any potential leakage points in a system where EM waves may otherwise escape. The type of shielding that is required depends on the coupling mechanism that is of concern.

©2020 Materion Brush Inc.

Distance and Coupling Mechanisms

Near Field Coupling

In near field coupling, the distance between the source and the receiver is less than wavelength of the signal. In these circumstances, most of the energy transferred from the source to the receiver is through electrical and magnetic fields.

In electric field coupling, energy from the source is stored in the electric field generated by the capacitance between the source and the receiver. The strength of the field falls off with the square of the distance between the source and receiver.

In magnetic coupling, the source energy is stored in the magnetic field generated by the inductance of the source, and may be transferred to the receiver. The strength of the magnetic field falls off even faster, falling at a rate equal to the cube of the distance between the source and receiver.

Since the strength of these fields fall off so rapidly, their effect becomes insignificant more than a distance of the wavelength of the signal. This is where the term near field coupling comes from.

Far Field Coupling

In far field coupling, the distance from source to the receiver is greater than wavelength of the signal. Here, most of the energy transferred from the source to the receiver is in the form of electromagnetic waves (radiated energy, as opposed to stored energy). The field strength of the electromagnetic waves falls off linearly with the distance between the source and the receiver, so the receiver can pick up the signal over much longer distances.

Electric Field Shielding

To protect against unwanted electric fields, surround the susceptible circuit with high conductivity metal. The metal should be thicker than its skin depth, and the shield should be connected to the ground of the protected circuit. This way, there should be no potential (voltage) between the shield and the ground, and no electric field will be generated outside the shield. The entire electric field should be contained within the shield, as in a coaxial cable with a grounded outer conductor.

Magnetic Field Shielding

To prevent the release or pickup of a stray magnetic field, you should surround the signal current with return current. In this case, the magnetic field would be completely contained between the return and signal paths, which would eliminate the need for shielding. However, this is not always possible, and sometimes shielding is necessary, especially when operating around strong magnetic fields. In this case, magnetic shielding may be necessary.

For a low frequency magnetic shield, surround susceptible circuit with high permeability metal like mu metal, which will divert the magnetic flux and keep it contained within the shield. For a high frequency magnetic shield, surround the circuit with high conductivity metal. A changing magnetic field creates eddy currents in the metal, which in turn generate magnetic fields opposing the field that created them.

EM Wave Shielding (Figure IX-19)

EM wave shielding uses conductive metal to close any gaps in an electronic enclosure. When used properly, it keeps unwanted radiated EMI out of the enclosure, and attenuates any waves attempting to leave the enclosure by reflecting and absorbing them.

Reflection is caused by a difference in impedance between the conducting metal and the 377 ohm free-space impedance. Remember that any change in impedance along a conducting path will result in partial reflection of the wave (signal). This is true whether the wave is current flowing along a copper trace on a circuit board, or an electromagnetic wave propagating through free space.

Absorption is caused by the wave generating eddy currents in the metal, or by internal reflections in the metal which remove power from the wave.

Figure IX-19 Electromagnetic Wave Shielding Theory




Figure IX-19 Electromagnetic Wave Shielding Theory

Part of the incident wave will be reflected back when it hits the shielding, thus taking power out of the wave. Furthermore, additional power is removed from the wave by internal reflections within the shielding (absorption). The signal that does finally make it through the shielding (transmitted wave) is thus highly attenuated (many orders of magnitude) lower than the incident wave.

©2020 Materion Brush Inc.

Shielding Theory

Shielding effectiveness (SE) is measured in decibels (dB), and is governed by the following equations:

SE(dB)= 10 log (P_1/P_2)

Or

SE(dB)= R (dB) + A (dB) + IR (dB) - Leakage Effects

Note: If A ≥10 (dB) then IR ≈ 0

R(dB) = Reflection losses P_1=Field Power without shield

A(dB) = Absorption losses P_2=Field Power with shield

IR(dB) = Internal reflection losses

Reflective Loss (R) is also measured in decibels (dB), and is governed by the following equations:

$$R(dB) = 20log_{10}\frac{Z_0}{4Z_s} = 20log_{10}\frac{\sqrt{\mu_0/\epsilon_0}}{\sqrt{2\pi f\mu_r\mu_0/\sigma}}$$

Z_0 = free space characteristic impedance

Z_S = impedance of shielding material

The higher the conductivity (σ) of the shielding material, the greater the reflection losses will be.

Absorption Loss (A), also measured in decibels, is described by the following equations:

$$A(dB) = 20log_{10}\left(e^{-t/\delta}\right) \approx 8.686\frac{t}{\delta}$$

t = thickness of the shielding material

δ = the skin depth of the shielding material

The skin depth, in this case, is the depth through which the strength of the signal has been reduced to 1/e (about 37%) of its original value. It is governed by the following equation:

$$\delta = \sqrt{\frac{1}{\mu\cdot\sigma\cdot\pi\cdot f}}$$

μ = the magnetic permeability of the shielding material

σ = the electrical conductivity of the shielding material

f = the frequency of the EM wave

The absorption loss in decibels is thus approximately 8.7 times the number of **skin depths**. At just under 12 skin depths thickness, the absorption loss exceeds 100 dB. Therefore, maximum shielding effectiveness is obtained by using high conductivity material several skin depths thick.

Internal Reflection Losses

If the thickness of the shield is more than a couple of skin depths, so much of the transmitting wave's power has been absorbed that any additional reflection is insignificant.

Shielding Integrity

If the source is completely surrounded by sufficiently thick metal with no gaps or openings, then all EM waves will be properly attenuated. However, if this were the case, then no signals of any kind could get into or out of the enclosure. In reality, every enclosure has openings that may emit EMI. Some typical leakage areas include:

- Seams
- Doors
- Cover Plates
- Vents
- I/O Ports
- Holes and Apertures
- Non-Bonded Connectors and Cables

Openings can be electromagnetically sealed through the use of shielding gaskets.

Figure IX-20 Gaps in Shielding Integrity




Figure IX-20 Gaps in Shielding Integrity

The critical dimensions are the metal thickness (t) and the largest dimension of each opening (d). The gaps should be kept as small as possible.

MATERION

©2020 Materion Brush Inc.

Leakage Through Apertures

The amount of leakage through apertures depends on the wavelength (l) of the EM wave, the size of the opening (d), and the thickness of the metal (t). See figure IX-21. For circular openings, the critical dimension would be the diameter of the opening. For rectangular openings, regardless of orientation, the critical dimension would be the length of the longest side.

If the largest dimension of the opening is less than 5% of the wavelength (d < l / 20), then the EM signal will be effectively shielded. However, if the largest dimension is greater than 50% of the wavelength (d > l / 2), then the opening will effectively radiate and propagate the EM wave outside the enclosure. At this size, the aperture can function as a wave-guide in thick barriers (where t > 3d) or as a dipole antenna (shielding effectiveness = 0) in thin barriers (where t < 3d). The waveguide has more intrinsic signal loss than a dipole antenna, so the thicker the barrier, the better. This is illustrated in the equations below:

For thin barriers (t < 3d) $$SE(dB) = 20\log_{10}\left(\frac{\lambda}{2d}\right)$$

For thick barriers (t > 3d) $$SE(dB) = 20\log_{10}\left(\frac{\lambda}{2d}\right) - 27.3\frac{t}{d}$$

Multiple Apertures

If there are multiple openings of different sizes, the hole that has the lowest shielding effectiveness will dominate the overall shielding effectiveness of the enclosure.

There may be cases when there are patterns of multiple instances of holes with the same geometry, as in a honeycomb or circular mesh screen used to cover ventilation holes. If there are n holes, and they are spaced less than half the wavelength (l / 2) apart, then the following equations apply:

For thin barriers (t < 3d) $$SE(dB) = 20\log_{10}\left(\frac{\lambda}{2d}\right) - 10\log_{10} n$$

For thick barriers (t > 3d) $$SE(dB) = 20\log_{10}\left(\frac{\lambda}{2d}\right) - 10\log_{10} n + 27.3\frac{t}{d}$$

To increase overall shielding effectiveness of the enclosure the following guidelines should be observed:

- Decrease aperture size (d), to preferably less than l/20 (most effective, but not always achievable, particularly at very high frequencies).
- Increase thickness of metal enclosure (not always practical).
- Reduce number of apertures in a pattern. (Not always easy, as in some cases it may be more effective to use a larger number of smaller size apertures).
- Shield the openings to prevent EM leakage.

Reducing Leakage with Shielding

In general, to reduce leakage of EMI in a system, you can use the following approaches:

- Add gaskets or fingerstock to cover as much of the potential gaps and seams as possible.

  Add more screws to reduce spacing between them, and reduce the chance of gaps between the gasket and the surface it is mounted on.
- Cover ventilation holes with conductive screens or fan filters
- Use smaller vent slots or a series of smaller holes, or a screen over a larger hole.
- Use a conductive, transparent window for display
- Use conductive greases or adhesives to seal gaps

There are four principle categories of shielding gaskets:

- Spring Fingers (Finger Stock)
  - Usually CuBe
  - Figure IX-21 Middle Row and Corners
- Wire Mesh Tubing
  - Usually CuBe or SnCuFe (Monel),
  - Sometimes with a hollow core (Figure IX-21 top Middle)
  - Sometimes with an elastomer core (Figure IX-21Bottom Middle)
- Metal Filled Conductive Elastomers

Figure IX-21 Metallic Electromagnetic Shielding Gasket Examples



Figure IX-21 Metallic Electromagnetic Shielding Gasket Examples

Most are stamped from strip, but some mesh gaskets are woven from wire. The shielding may or may not contain an elastomer core.

©2020 Materion Brush Inc.

Table IX-1 Summary of Methods to Control EMI			
Coupling Mechanism	**Where is it a Concern?**	**Field Strength**	**To Control**
Direct Conducting Path (Conductance)	Anywhere (even between circuits not obviously connected)	N/A	• Use appropriate grounding • Use noise filters in circuits
Magnetic Field (Mutual Inductance)	Near Field Only $d < \lambda$	$\propto 1/d^3$	• Minimize current loop area (twisted pair wiring, differential signaling, microstrip, physically close signal and return traces, etc.) • Surround signal line with return line (coaxial cable, stripline, etc.) • Shield with high permeability metal for low frequency noise • Shield with high conductivity metal for high frequency noise
Electrical Field (Capacitance)	Near Field Only $d < \lambda$	$\propto 1/d^2$	• Use proper grounding • Use grounded, high conductivity thick metal shielding.
Electromagnetic Waves (Radiated)	Both Near Field and Far Field (generated by high frequency signals traveling on any straight conducting path with length $> \lambda/20$)	$\propto 1/d$	• Use thick, high conductivity metal shielding, with minimal gaps • Appropriately bond connectors • Appropriately filter circuits

SI and EMC Measurements

A connector may have to be tested to see what effect it has on the overall system. The measurements may either be taken in the time domain, or in the frequency domain. In the time domain, the measurement devices compare the properties of the output signal to the input signal and how this relationship changes over time. In the frequency domain, the input signal sweeps through a range of different frequencies, and the output is measured over the frequency range. Measurements may be converted from the time domain to the frequency domain by a Fourier transform. Similarly, frequency domain measurements may be converted back to the time domain by an inverse Fourier transform.

In the Time Domain

Measurements in the time domain show how consistent the signal is over time. Typical instruments used include **oscilloscopes** and **Time Domain Reflectometers**. **Time Domain Reflectometry (TDR)** measures the reflected signal at the input and **Time Domain Transmissometry** measures the output signal. You can also measure rise time, jitter, and cross talk on these instruments.

Perhaps the most useful output of these instruments is an **eye diagram**, which shows the voltage vs. time behavior graphically. Successive periods of the signal are repeatedly overlaid on each other. How well the different signal traces overlap reveals a great deal about the behavior of the circuit. An example of a good-looking eye diagram is shown in Figure IX-22. In this case, the **voltage rails** (i.e. upper and lower limits – full on, and full off), have very little **droop** (difference from the intended value). There is very little **jitter** (drift in timing relative to the clock signal) in this example, since successive traces do not drift to the right or the left. The eye is wide open, both horizontally and vertically. This makes it easy to pick up the ones and zeros of a binary signal, since the voltage peaks are at a level of a true one or a true zero exactly when they are supposed to be.

Most systems would have a requirement that the eye must have a certain amount of both horizontal and vertical clearance. One typical figure of merit would be to place an **eye mask** outlining the area of minimum performance in the center of the eye diagram. If none of the traces overlap the eye mask, the system passes (Figure IX-22). If the traces do overlap the eye mask, the system fails (Figure IX-23). Jitter would cause the eye to close horizontally. Signal integrity issues, ground bounce, impedance mismatch, and other noise would cause the eye to close vertically (Figure IX-24). With a closed eye diagram, the peak voltages would not be near true one or true zero, and may not occur when they are supposed to occur relative to the clock signal, making it difficult for the circuit to pick up the ones and zeros.

MOTION

©2020 Materion Brush Inc.

Figure IX-22 Open Eye Diagram




Figure IX-22 Open Eye Diagram

If the traces are orderly and repeatable, then the eye mask fits between the traces, then this is a good indicator of signal integrity.

Figure IX-23 Closed Eye Diagram




Figure IX-23 Closed Eye Diagram

Here, the signal traces do not lie nicely on top of each other, and the eye mask covers some of the traces. This is an indicator of signal integrity problems.

Figure IX-24 Problems Indicated by Closed Eye Diagram




Figure IX-24 Problems Indicated by Closed Eye Diagram

The eye diagram gives a good indication of rail collapse and jitter in the signals.

In the Frequency Domain

Measurements in the frequency domain show which particular input frequencies would have trouble passing through the system. Since many circuit properties (inductance, impedance, etc.) depend on frequency, it would make sense that a circuit optimize for one frequency would show poor performance at other frequencies. Certain frequencies may also show resonant effects, where reflection or other losses become much higher than in neighboring frequencies on either side. Frequency domain measurements are made using **Vector Network Analyzers** (VNA's).

The figures of merit most commonly measured are **scattering parameters**, more commonly known as **S-parameters**. These measure the power of the signal exiting a device port relative to the signal entering the same or another device port. Each S-parameter is written as S_{AB}, where A is the output port and B is the input port. If the port numbers is the same, the S-parameter describes the amount of the signal reflected. If the port numbers are different, then the S-parameter is measuring signal transmission or cross talk. Every device has as many scattering parameters as the square of the number of ports.

Return loss (S_{11}, S_{22}, $S_{Input\ Input}$, etc.) – The ratio of the power reflected back to the input port relative to the power sent into the input port. So, for total reflection, the ratio is 1, and corresponds to 0 dB when plotted on an S-parameter versus frequency chart. As the measured value falls off to increasingly negative decibels, the performance improves. (Figure IX-25).

Figure IX-25 Return Loss S-Parameter




Figure IX-25 Return Loss S Parameter

This is a measure of the signal lost to reflection. The lower the loss, the better the performance is.

©2020 Materion Brush Inc.

Insertion loss (S_{12}, S_{21}, S_{io}, etc.) The ratio of the power transmitted to an output port to the power sent into the input port. For total transmission, the ratio is 1, corresponding to 0 dB. As the measured value falls off from 0 dB to increasingly negative dB, the performance worsens. Note that in this case the S-parameter plot is not actually a plot of what is lost, but is actually a plot of what is not lost.

The return loss S-parameters truly measure what is lost, while the insertion loss S-parameters measure transmission. Therefore, for return loss, 0 is bad, and very negative numbers are good. For insertion loss, 0 is good, and very negative numbers are bad. (See Figure IX-26).

Figure IX-26 Insertion Loss S-Parameters




Figure IX-26 Insertion Loss S-Parameters

This is actually a measure of transmission (what is not reflected) so a high insertion loss S-Parameter is desired.

Cross talk can also be seen in the S-parameters of multi-port networks. For example, Figure IX-27 shows the S parameters that you would get in 2 port and 4 port networks from a signal into port 1, intending to come out at port 2. S_{11} is the return loss, S_{21} is the insertion loss, S_{31} is the near end cross talk, and S_{41} is the far end cross talk. Ideally, S_{21} would be close to zero, while the other 3 would be negative and very large.

A two port network would have an additional 2 S-Parameters for signals going into port 2 intended for port 1. These would be S_{22} and S_{12}. If the device is symmetric, $S_{22} = S_{11}$ and $S_{21}=S_{12}$. The four port network would have twelve additional S-parameters. Namely, they are S_{12}, S_{22}, S_{32}, and S_{42} (for signals into port 2), S_{13}, S_{23}, S_{33}, and S_{43} (for signals into port 3), and S_{14}, S_{24}, S_{34} and S_{44} (for signals into port 4).

MATERION

©2020 Materion Brush Inc.

Figure IX-27 Two-Port and Four-Port Networks




Figure IX-27 Two-Port and Four-Port Networks

This diagram gives an indication of how the various S parameters are labeled, for a signal sent into port 1 with a desired exit at port 4.

Simulation

The last subject to talk about would be simulation. All circuit parameters (impedance, cross talk, S-parameters, reflection coefficients, etc.) can be estimated by an appropriate simulation program. Some examples are as follows.

2D Field Solvers - Computes electric, magnetic, and electrostatic potential fields; modal impedance, resistance, capacitance, and inductance; effective dielectric constants; and voltage waveforms associated with cross talk, attenuation, and return losses.

3D Field Solvers – Computes the impedance and scattering parameters (S Parameters) of a solid part versus frequency of the electronic signal passing through the part. The results are ready for input into SPICE simulators or other EDA tools for additional circuit analysis.

SPICE – Stands for Simulation Program with Integrated Circuit Emphasis. This is an open source circuit simulation program for computing the behavior of circuits and networks. You would use the program to build the system component by component, and you would input the relevant parameters of each component (S-parameters, inductance, resistance, etc.)

©2020 Materion Brush Inc.

Section X. Considerations for Harsh Environments



Environmental Considerations

During their normal operation, contacts are subject to mechanical stresses by design. Contacts experience additional environmental stresses including elevated temperatures and sudden high stress levels as well as exposure to corrosive substances. Elevated temperature conditions may result from ambient or resistive heating. Tensile properties are temperature dependent (approximately 10% reduction in strength for each 100°F or 50°C temperature rise). A number of factors contribute to a stress level above the design point. These are dependent upon the material and geometry, thermal level, residual stress and functional stress in a contact. Corrosion resistance can also be critical for exposure to some harsh environments.

Table X-1 shows some common operating environments for connectors.

Table X-1 - Operating Environments

Use Category	T min		T Max		Years of Service
	(°F)	(°C)	(°F)	(°C)	
Consumer Electronics	32	0	140	60	1 - 3
Computers	59	15	140	60	≈ 5
Telecom	-40	-40	185	85	7 - 20
Commercial Aircraft	-67	-55	203	95	≈ 20
Industrial & Automotive Passenger Compartment	-67	-55	203	95	≈ 10
Military Ground & Ship	-67	-55	203	95	≈ 5
Space LEO and GEO	-40	-40	185	85	5 - 20
Military Avionics	-67	-55	203	95	≈ 10
Automotive Underhood	-67	-55	392	200	≈ 10

What Can Make an Environment Harsh:

- High Temperature
- High Pressure
- Humidity
- Vibration
- Shock/Impact Loading
- Exposure to Corrosive Compounds

For example, connectors in fixed wing aircraft may be subjected to very high accelerations, and high temperatures. Helicopter connectors may not have quite the acceleration or temperature, but the vibrations are far more excessive. Automotive environments are subjected to high temperatures, vibration, and depending on where the part is located, corrosive exhaust gasses. Components used in oil and gas drilling see elevated temperatures, corrosive environments, and erosion from fluid flow. Consumer electronic devices can be subjected to impact loads from dropping and as well as exposure to any number of corrosive consumer products. Multiple-use medical devices must be sterilized between uses. Connectors that work well in any one of these environments can be destroyed by any of the other environments.

MATERION

©2020 Materion Brush Inc.

Environmental Requirements

Operating Class

The more common electronic applications are automotive (passenger compartment and underhood), consumer, medical, telecommunications, aircraft and space, military (avionics, weapon systems, communications), computer (mainframe, midrange, PC, workstation, supercomputer), process control (heavy industry, light industry), test and burn-in.

Subclasses

Each operating class defines ranges of the following additional parameters.

Psychrometric Class – Defines temperature and humidity ranges.

Gaseous Class – Defines concentration ranges for corrosive gases. The gases and gas families are: S_x (total reduced sulfur) that includes all of the sulfur in elemental sulfur vapor or in any sulfur compounds that are sulfiding gases (H_2S); Cl_x (acidic chlorine gases) that includes gaseous chlorine (Cl_2) and the chlorine contained in gaseous hydrogen chloride (HCl); SO_2 (sulfur dioxide); NO_2, (nitrogen dioxide); and O_3 (ozone) or total oxidant that includes ozone and defines all substances other than nitrogen dioxide that oxidize iodide ions to iodine under neutral pH conditions.

Particulate Class – Includes concentration ranges for atmospheric particulates.

Shipping and Storage Class – All products, regardless of their intended application, must be capable of withstanding exposure to the atmospheric environment during periods of shipment and storage prior to actual installation with no degradation. This typically includes thermal shock and condensation, but not rain. Excessively long storage times permit moisture, oxide, tarnishing or other films to form on some metal surfaces.

Vibration Class – This class includes operational, shipping and relocation vibration.

Shock Class – Requirements include impact to the product during shipping and handling.

See Section XV, Qualification, for more information on relevant tests, specifications, and standards.

Storage of Copper Beryllium

CuBe is an alloy containing more the 97% copper, so it will oxidize and tarnish over time, similar to pure copper. Other Materion alloys such as nickel beryllium and copper nickel tin have more native resistance to corrosion, but will also oxidize, albeit at a slower rate. Over time, these oxide layers will build up, degrading surface appearance, solderability, and platability. This surface contamination is easily removed by cleaning.

Materion's copper-based alloys are shipped with stain inhibitors such as benzo-triazole on the surface. Material shipped overseas is tightly wrapped in plastic with vapor corrosion inhibitors. These inhibitors will slow the oxidation and tarnish process down, but are not guaranteed for longer than 6 months. Furthermore, these coatings are very fragile, and are easy to wipe or scratch off the surface, leaving exposed metal.

If the material will not be used right away, it is best to store it in a clean, dry environment in order to maximize the useable shelf life. The relative humidity should be kept below 60% at all times, in order to prevent condensation. Furthermore, exposure to dust, chlorides, sulfides, amines, ammonia and acid fumes (such as nitric or sulfuric) should be limited by proper ventilation.

If the material arrives tightly packaged and much colder than the storage environment, allow the material to come to room temperature before opening. This will minimize the chances of water vapor condensing on the surface and causing staining.

For more detailed information, see Materion's Tech Brief Storage of Materion Copper-based Strip Products.

©2020 Materion Brush Inc.

Shock and Impact Loading

One of the worst environmental hazards faced by electronic components is simply the danger of being dropped. The forces generated by an impact load may be equal to many multiples of the component's own weight. Figure X-1 shows an example of this effect. If an infinitely rigid object with mass (m) were placed onto vertically oriented, ideal coil spring with a spring constant (K), and the system were allowed to come to equilibrium, the spring would compress to the point that generates a force equal to the weight of the object placed on it. By Hooke's law, the equilibrium or static deflection (d_{ST}) and force would be defined by the following equations:

$$d_{ST} = \frac{mg}{K} \quad , \quad F = mgd_{ST}$$

However, if the same object were dropped onto the same spring from a height (h), the maximum force and compression experienced by the spring would be defined by the following formulas (ignoring frictional damping):

$$F = mg\left(1+\sqrt{1+\frac{2\cdot h}{d_{ST}}}\right) \qquad \text{and} \qquad d = \frac{mg}{K}\left(1+\sqrt{1+\frac{2\cdot h}{d_{ST}}}\right).$$

The term within the parentheses is called the impact factor. Note that if the object were held on top of the uncompressed spring and suddenly let go (dropped from a height of zero), the maximum spring force and compression would both be double that of the equilibrium position. Therefore, the minimum possible impact force experienced by any ideal rigid dropped object is twice that of its own weight. As the drop height increases, the impact force will as well. (Figure X-2)

Taking this exercise further, the energy absorbed by the spring would be equal to the work done by the falling mass on the spring, which is force x deflection, or:

$$U = F\times d = mg\left(1+\sqrt{1+\frac{2\cdot h}{d_{ST}}}\right)\times\frac{mg}{K}\left(1+\sqrt{1+\frac{2\cdot h}{d_{ST}}}\right) = \frac{m^2g^2}{K}\left(1+\sqrt{1+\frac{2\cdot h}{d_{ST}}}\right)^2$$

In this case, the impact factor for the energy absorbed is the square of the impact factor for either the deflection or force case.

When an electronic device is dropped, the force of impact will travel through all of its internal components, potentially overstressing them. Some of the kinetic energy of the falling object at the time of impact will be converted to sound, and the rest will deform the device and its various components. For example, a pin suddenly subjected to an axial compression due to impact will absorb an amount of energy defined by the following formula:

$$U = \frac{\sigma^2 AL}{2E}$$

Where σ = the stress generated by the deformation

A = the cross sectional area of the pin

L = the length of the pin

E = the elastic modulus

The maximum amount of energy that this component can absorb without yielding is given by the following formula:

$$U_{Max} = \frac{\sigma_{Yield}^2}{2E}AL = U_R V$$

The energy absorbing capacity of a component is thus equal to the modulus of resilience (U_R) multiplied by the volume of the component. Materials with a high modulus of resilience, therefore, are desirable for withstanding impact loading, particularly when the miniaturization of devices and components mean that the component volumes must also decrease.

MATERION

©2020 Materion Brush Inc.

Figure X-1 Forces Generated by Impact




Figure X-1 Forces Generated by Impact

For a suddenly applied load on an ideal spring, the maximum deflection, force, and strain energy absorbed by the spring are at least twice that of their static equilibrium values. Any additional height on the drop only adds to the multiplying impact factor. The first three underlying assumptions are that the mass is infinitely rigid, so it does not deform under load, that the spring remains elastic and does not permanently deform, and that the spring has no internal frictional damping (ideal spring). Any such behavior would reduce the deflection, force, and elastic energy absorbed. The fourth underlying assumption is that the entire body of the spring is under uniform stress and strain at all times. In reality, they will be higher at the point of impact, moving through the spring at the speed of sound in the metal, so the stress is at first concentrated at the point of impact.

Figure X-2 Dropped Height vs. Static Load




Figure X-2 Dropped Height vs. Static Load

The impact factor increases with the dropped height. The curve will flatten out when the height reaches the distance needed for the object to achieve terminal velocity.

High Acceleration

Note that the equations for impact factor contain an acceleration term, g. In the examples above in the shock and impact section, the suddenly applied loads were all due to gravity, with an acceleration of 1 g. For a suddenly applied acceleration of objects previously in equilibrium, the height term (h) becomes 0, and the equations reduce to the following:

$$F = mg\left(1+\sqrt{1+\frac{2\cdot h}{d_{ST}}}\right) = mg\left(1+\sqrt{1}(1+0)\right) = 2mg$$

$$d = \frac{mg}{K}\left(1+\sqrt{1+\frac{2\cdot h}{d_{ST}}}\right) = \frac{mg}{K}\left(1+\sqrt{1}(1+0)\right) = 2\frac{mg}{K}$$

$$U = F \times d = 2mg \cdot 2\frac{mg}{K} = 4\frac{m^2 g^2}{K}$$

The physical meaning of the above equations apply to the same ideal spring, compressed to equilibrium position by the applied weight, under the same assumptions, when the base of the spring is suddenly accelerated upwards by an arbitrary acceleration in g's. If the mass and spring constant are assumed to be constant, the multiplication factor for force and deflection is equal to twice the acceleration in g's, while the factor for the increase in energy that must be absorbed is proportional to 4 times the square of the acceleration in g's. (Figures X-3 through X-5)

Figure X-3 Sudden Acceleration vs Static Load




Figure X-3 Sudden Acceleration vs Static Load

At 5 g's, the force and deflection experienced are each 10 times that of the static load. At only 7 g's, the part needs to absorb almost 100 times more energy than it would under static deflection.

©2020 Materion Brush Inc.

Figure X-4 Combination of Impact and Acceleration on Force and Deflection




Figure X-4 Combination of Impact and Acceleration on Force and Deflection

Even a modest height increases the impact factor at a given acceleration. Increasing the acceleration has more effect than increasing the drop height.

Figure X-5 Combination of Impact and Acceleration on Energy Absorbed




Figure X-5 Combination of Impact and Acceleration on Energy Absorbed

The impact factor for energy absorbed increases much more rapidly than that for the force and deflection. At 1 g, however, the impact factors for all 3 parameters are identical.

Vibration

Mechanical vibrations are a primary cause of the micromotion responsible for fretting corrosion. Additionally, if the vibrations have enough amplitude, they can result in intermittent electrical contact or even contact disengagement. Higher contact forces and stiffer materials help to prevent separation of the surfaces, and minimize changes in resistance of the contact interface. (Figure X-6)

Shock and vibration resistance is increasingly becoming a concern in automotive connector applications. Efforts to increase fuel efficiency by reducing vehicle weight decreases the mass necessary to damp out vibrations and impacts transmitted from the road through the suspension system. Contact sizes are also decreasing as more electronics are routed through the same connectors.

Figure X-6 Vibration

- **Natural frequency of a cantilever beam:**

$$f = \frac{t}{2 \cdot L^2}\left(\frac{E}{\rho}\right)^{1/2}$$

- **Minimum force to prevent sliding due to shock or vibration (G is acceleration in g's):**

$$F = \frac{3\rho wtL}{8\mu}G$$

Figure X-6 Vibration

From the top equation, you can see that materials with a higher elastic modulus and/or a lower density (higher specific stiffness) are more resistant to vibration (less chance of experiencing damaging vibrations at the resonant frequency). From the bottom equation, you can see that a higher contact force means less chance of vibrating loose.

MATERION

©2020 Materion Brush Inc.

Elevated Temperature Exposure

Material properties change at high temperatures. (Figure X-7) Most materials will see a decrease in yield strength as the temperature increases. Copper alloys will also show a reduction in ductility, negatively impacting fatigue strength, and potentially increasing notch sensitivity. Electrical conductivity will decrease, although thermal conductivity will increase. Copper beryllium retains a higher percentage of its room temperature strength than non-heat treatable copper alloys like brasses and bronzes.

Figure X-7 High Temperature Stability





Figure X-7 High Temperature Stability

CuBe Alloy 25 retains most of its room temperature properties through 200°C. CuNiSn BrushForm® 158 strip alloy retains properties through approximately 250 to 300°C. NiBe can survive temperatures over 400°C.

There are several other potential negative effects of elevated temperature. The first is the potential for creep and stress relaxation, which decrease the contact force and increase the contact resistance over time. Materials with high resistance to stress relaxation are required for high temperature applications. (Figures X-8 and X-9)

The second potential effect is that of a temporary temperature excursion dropping the yield strength of the contact base metal below the applied stress level, resulting in unexpected yielding. This could occur in processes such as wave or reflow soldering, when parts that work perfectly well at room temperature may come out of the reflow oven permanently deformed and out of tolerance.

Figure X-8 Stress Relaxation Resistance – Percent Stress Remaining




Initial Stress = 75% of the 0.2% Offset Yield Strength

Figure X-8 Stress Relaxation Resistance – Percent Stress Remaining

The precipitation hardened alloys like CuBe and CuNiSn show much greater resistance to stress relaxation than those hardened by cold work alone, such as brasses and bronzes. The age hardened materials show a much greater amount of stress retained over time.

Figure X-9 Stress Relaxation Resistance – Actual Stress Remaining



Initial Stress = 75% of the 0.2% Offset Yield Strength

Figure X-9 Stress Relaxation Resistance – Actual Stress Remaining

The advantage of the high strength alloys becomes clear when the stress is not normalized to percent remaining. Since they have higher yield strengths, loading to an initial stress level of 75% of the yield strength results in a much higher initial stress, and a much higher actual stress retained over time. This makes these alloys ideal for high power, high temperature, high reliability, and/or miniature contacts where very high stress is required to generate adequate contact force, and where retention of contact force would challenge most materials.

DRAFT

Corrosion and Corrosion Mechanisms

People will rarely find pure metals in nature. They will usually be found in their natural states as ores (compounds of the metal and some other nonmetal like oxygen, sulfur or chlorine). The only exceptions are precious metals, such as gold, silver and platinum. In fact, it is their resistance to combining with other chemicals that make them so valuable and sought after.

Significant energy and processing is required to convert ores into usable metal, such as iron oxide into iron and steel alloys, or copper sulfide into copper and copper alloys. Given time, most pure metals will corrode (recombine with corrosive agents in the environment like oxygen, chlorine, sulfur, fluorine, etc.), in an attempt to return to their natural state. Since these corrosion products interfere with the passage of electrical current across a contact interface, contact surfaces are usually coated to prevent (or at least minimize) the formation of corrosion products.

Most everyone, regardless of technical background, understands what corrosion is on an intuitive level. However, here are some good definitions from the world of materials science:

Corrosion is "deterioration caused by chemical or electrochemical reaction of the metal with its environment." – *ASM Metals Handbook - Desk Edition*

"Corrosion is a natural process that tries to reverse the chemical action of the refining process." – Donald J. Wulpi, Understanding how Components Fail

"Corrosion is nature's way of transforming metal into 'ores'," – Giles F. Carter and Donald E. Paul, *Materials Science and Engineering.*

Traditionally, the oil & gas, military, automotive, aerospace & industrial markets demanded corrosion resistance. However, corrosion resistance is becoming increasingly important for consumer electronics. (Figure X-10) The reasons for this are that the plating/surface treatment is typically very thin, and many connectors have bare edges due to the use of preplating. Wearable technology also has closer contact with consumer skin.

Figure X-10 Drivers and Consequences of Corrosion in Consumer Electronics




Figure X-10 Drivers and Consequences of Corrosion in Connectors.

Consumer electronics devices in general and wearable electronic devices in particular are more at risk for the items on this list. "Consumer fluids" include sweat, spilled beverages, etc.

There are many corrosion mechanisms, including but not limited to:

- General Corrosion
- Pore Corrosion
- Creep Corrosion/Corrosion Migration
- Galvanic Corrosion
- Fretting Corrosion
- Hydrogen Embrittlement/Hydrogen Assisted Cracking/Hydrogen Induced Cracking
- Stress-Corrosion Cracking (SCC)/ Season Cracking
- Sulfide-Stress Cracking (SSC)
- Crevice Corrosion
- Pitting Corrosion
- Erosion Corrosion
- Selective Leaching/ Dealloying
- Corrosion Fatigue
- Liquid Metal Embrittlement
- Microbiologically Influenced Corrosion
- Stray Current Corrosion

MATERION

©2020 Materion Brush Inc.

General Corrosion

General corrosion is the slow, uniform attack of an entire surface. Steel rusting away in a shipyard and the green copper chloride coloring of the Statue of Liberty are perfect illustrations of this type of corrosion. Of all corrosion mechanisms, it is the least prone to catastrophic failure, as the onset is slow and highly visible. (Figures X-11 and X-12)

Figure X-11 General Corrosion



Figure X-11 General Corrosion

This is the most familiar form of corrosion, leading to a general, uniform attack on the base metal, as seen on this galvanized steel fence post.

Figure X-12 Corrosion Products on Copper Coins



Figure X-12 Corrosion Products on Copper Coins

Here are a number of US pennies with varying degrees of surface oxidation and other corrosion products. Those in the picture with heavy corrosion product were retrieved from a decorative outdoor water fountain treated with bleach (NaClO) to prevent mosquito breeding. Over time, copper will tarnish in reaction to atmospheric oxygen, gradually turning from near pink to orange to red to brown to black as the oxide layer thickens. A green corrosion product on the surface indicates copper chloride or copper carbonate. Blue is associated with copper sulfide. The white color on some of the coins above is a salt deposit, in this case it is likely sodium carbonate.

To reduce the potential for general corrosion, you can use a coating or treatment on the surface to reduce the potential for corrosion. Sometimes, it may be most economical to just let the part corrode and replace it when it is no longer useful. If you do wish to prevent or mitigate general corrosion, one of the following surface treatments may work:

- Passivation – in stainless steel alloys, treating the surface with acid to remove easily corroded iron, leaving behind a passive layer of chromium and nickel oxides.
- Painting or powder coating
- Plating or cladding with another more corrosion resistant metal
- Sacrificial coating – such as galvanizing steel with a coating of zinc. (See galvanic corrosion for more details.)

Pore Corrosion

A pore is a small discontinuity in the contact finish that exposes the underlying base metal to chemical attack from which corrosion growth occurs (Figure X-13). Pores generally originate during the plating process due to improper plating solution control, surface cleanliness or roughness issues. (ASTM has several standard porosity tests.) The number of pores tends to decrease as the plating thickness increases. (Figure X-14) Pores may not initially affect contact resistance, but if corrosion product spreads across the surface, the contact resistance will increase. Pore corrosion may be slowed or eliminated with the use of a nickel underplate below the top plating layer (Figure X-15).

Ways to reduce pore corrosion:

- Increase plating metal thickness
- Use underplating of less porous metal

Figure X-13 SEM Image of Pore Corrosion




Figure X-13 SEM Image of Pore Corrosion

This cross section through pore corrosion shows how corrosive substances can pass through small holes in the plating and attack the underlying base metal.

©2020 Materion Brush Inc.

Figure X-14 Pore Corrosion

• **Porosity decreases as thickness increases**




Figure X-14 Pore Corrosion

- Porosity also depends on:
- Surface Roughness
- Surface Cleanliness
- Plating Material
- Plating Bath Chemistry
- Current
- Dwell Time

Figure X-15 Pore Corrosion/ Corrosion Migration Schematics




Figure X-15 Pore Corrosion/Corrosion Migration Schematics

A nickel underplate (of sufficient thickness) effectively seals the pores against corrosion, and protects the surfaces to some degree from corrosion products that would otherwise creep across the plated surface from the bare edges.

Creep Corrosion/Corrosion Migration

Corrosion migration refers to the movement of corrosion products into the contact area from sites away from the contact interface. Such sites include contact edges and defects in the contact finish. Corrosion migration is of concern predominantly in environments in which sulfur and chlorine are present. The use of a nickel underplate may again slow or eliminate the migration of corrosion products from the bare edge over the surface of the plating (Figure X-15).

A further use of a nickel underplate layer is to prevent diffusion of the base metal to the surface of the contact, where it would result in corrosion under the influence of temperature and humidity (Figure X-16).

Figure X-16 Nickel Underplate for Diffusion Control




Figure X-16 Nickel Underplate for Diffusion Control

A nickel underplate greatly increases the time it takes for copper atoms to diffuse onto the surface of the gold, and for the gold to diffuse down into the copper. Left unchecked, diffusion would leave the surface unprotected.

MATERION

©2020 Materion Brush Inc.

Galvanic Corrosion

Every metal has its own **electrode potential** when in contact with a liquid. The electrode potential is a measure of how readily a metal is oxidized (dissolves positive ions into solution and becomes negatively charged) or reduced (allows dissolved ions to plate out onto its surface and becomes positively charged) by such contact. Galvanic Corrosion is an electrochemical process that arises from contact of an electrolyte with two or more conductive surfaces that have different electrode potentials, and that happen to be electrically connected via a conducting path. (Figure X-17)

Figure X-17 Galvanic Corrosion




Figure X-17 Galvanic Corrosion

Note, the anode and cathode do not need to be in direct contact with each other. Galvanic corrosion may occur as long as the electrolyte contacts both materials and there is a continuous electrically conductive path between the anode and cathode.

One of these metals will have a stronger oxidizing electrode potential than the other, and becomes the **anode**. The one with a weaker oxidizing electrode potential (or stronger reducing potential) becomes the **cathode**. The anode will dissolve into the electrolyte solution, and pass electrons through the conducting path to the cathode, where they will combine with ions precipitating out of solution onto the cathode's surface. Figure X-18 shows a simple galvanic series in seawater, indicating which metal in a couple is likely to corrode.

Figure X-18 Galvanic Series in Seawater




Figure X-18 Galvanic Series in Seawater

In the a galvanic couple, the more anodic material will corrode while the more cathodic material will remain intact. The farther apart the metals are on the galvanic series, the faster the corrosion will be. This also means that if the base metal is protected by a much more noble plating material, corrosion will occur very rapidly at any points where the base metal may be exposed due to cracks, scratches, or wear of the plating. A material may be galvanically protected by fastening it to a sacrificial part made of a more anodic material.

©2020 Materion Brush Inc.

The worst setup for galvanic corrosion would be to have a large cathode (noble metal) coupled to a small anode (active metal). This leads to extremely rapid, highly localized corrosion of the anode material. This could quickly lead to failure by overstress, fatigue, corrosion fatigue, etc.

The large cathode, small anode coupling could happen unintentionally, if a highly active metal is plated or otherwise coated with a noble, corrosion resistant metal. As long as the coating is sufficiently thick and continuous on the entire surface, the whole system will have the corrosion resistance of the noble material. However, any scratch or defect in the coating that exposes the underlying anodic metal will lead to rapid corrosion of the active metal in the area of the defect.

A large anode (active metal) coupled to a small cathode (noble metal) is much better. This leads to general corrosion of the entire anodic surface, at an extremely slow rate. Galvanized steel is simply steel coated with a thin layer of highly active zinc. Any scratch or defect in the zinc plating will have very little effect on the overall corrosion rate of the zinc surface.

Using the galvanic series chart (Table X-2).

The table shows a more detailed galvanic series in seawater, although it is pieced together from several resources. Note that any galvanic series depends on the composition of the electrolytic liquid, but also on the reference electrodes used to measure the electrode potential. The most common electrolyte is synthetic seawater, and the most common electrodes are standard hydrogen electrodes (SHE) or saturated calomel electrodes (SCE). In this case Table X clearly spells out volts vs. SCE for the electrode potential.

The potential difference between any two materials governs what kind of environment the couple can function in without fear of failure. The following information is based on multiple references, including the Standard Electrode Potentials (Metals) Handbook, 9th edition. In severe environments, any different metals coupled together should have a potential difference of about 0.1 V or less. In mild environments, this can be expanded to approximately 0.2 Volts of potential difference. In controlled environments, about 0.5 V difference can be tolerated.


To reduce the potential for galvanic corrosion:

- Prevent electrical current flow by physical separation or by insulating the dissimilar metals from each other.
- Try to eliminate the electrolyte.
- Use similar metals or metals that are as close as possible in the galvanic series.
- Connect the couple to an even more anodic material within the electrolyte.
- Apply an external current of equal and opposite magnitude to that generated by the galvanic pair. Known as impressed current cathodic protection, it is difficult to achieve in practice, but has seen some commercial success, notably in protecting bridges from corrosion by road salt.
- Use a large anode and a small cathode to take advantage of the area effect.

MATERION

©2020 Materion Brush Inc.

Table XI-2 - Galvanic Series in Seawater, Volts vs. Saturated Calumel Electrode (SCE)



Stray Current Corrosion

This refers to any corrosion due to unintended current flow from the metal through an electrolyte back to the current source. Any time current travels from a metal to an electrolyte, ions will dissolve into the electrolytic solution.

MATERION

Fretting Corrosion

Fretting refers to the small motions, hundredths to tenths of a millimeter, which occur randomly due to small amplitude vibrations, mechanical disturbances or thermal expansion mismatches. Fretting corrosion appears as pits or grooves in the metal surface, typically filled with corrosion products. Tin (Sn) is particularly vulnerable. When tin oxidizes, it forms a particularly hard, electrically insulating protective layer on the surface that would otherwise limit further corrosion of the tin. Initially, this oxide film does not affect contact resistance since mating of the connector disrupts the oxide by the following mechanism. First, the thin, hard and brittle tin oxide fractures under the application of the normal force. Next, the soft, ductile underlying metallic tin gives way to enlarge the cracks in the oxide, and then fresh metallic tin extrudes through the cracks to establish the desired metal to metal interface (Figure X-19). This mechanism explains the usefulness of tin finishes despite the presence of the electrically insulating oxide layer.

Unfortunately, the oxide-forming tendencies of tin remain active, and if the contact interface moves due to vibration or thermal cycling, then oxide will re-form on the freshly exposed surfaces. As this cycle repeats, the continued disruption and re-oxidation of the surface layer results in a build-up of tin oxide particles on the surface (Figure X-20). This degradation mechanism, known as fretting corrosion, causes a continual increase in contact resistance until the circuit opens. High normal forces help to prevent micro-motion of the contacts, minimizing fretting. Lubricants will help to protect the surface from oxidation and may flush away accumulated debris, minimizing fretting corrosion.

Figure X-19 Tin-Tin Interface




Figure X-19 Tin-Tin Interface

As tin-plated contacts mate, the hard oxide on the surface of the softer tin is broken up, allowing fresh tin to extrude through to the interface and make good electrical contact.

Figure X-20 Fretting Corrosion




Figure X-20 Fretting Corrosion

After the initial contact is made, thermal expansion or mechanical vibration may cause the contact point to shift, causing the underlying exposed tin to reoxidize, while fresh tin is exposed at the new point of contact. This cycle repeats until the oxide is thick enough that the contact can no longer break through the oxides, and the contact resistance dramatically increases. Eventually, the resistance may drop again, if the tin is completely oxidized and subsequently worn away, exposing the underlying copper.

Fretting definitions:

- **Fretting** – small amplitude (micro) motion
- **Fretting wear** – mechanical erosion from abrasion during fretting
- **Fretting corrosion** – oxidation of the threading wear debris
- **Fretting failure** – gradual increase in contact resistance to unacceptable levels

Requirements for fretting:

- Repeated relative motion between two surfaces
- Deformation of surface due to load and motion
- Oxygen and/or moisture must be present
- Soft coatings with hard, brittle oxide films

MATERION

©2020 Materion Brush Inc.

During fretting corrosion, the contact resistance will steadily increase and become unstable (Figure X-21). Eventually, if the motion continues, the plating layer will be entirely scraped away, and the interface will be bare copper on copper. (Figure X-22) The contact resistance will then fall to a stable, although relatively high value (Figure X-23.) Fretting corrosion can be minimized with high contact forces (hence the 150 gram minimum for tin-plated surfaces) and the use of lubricants to keep exposed surfaces from oxidizing and to clear away the built-up tin oxide (Figure X-24). A stiff material with a high elastic modulus will be less likely to move under mechanical vibration or shock, and will have an advantage over a more flexible material.

Figure X-21 Contact Resistance Increase from Fretting




Figure X-21 Contact Resistance Increase from Fretting

Over time, the contact resistance increases from negligible to significant, as the oxide builds up on the surface. This is demonstrated by the results of this fretting corrosion test.

Figure X-22 Wear Scar Showing Base Metal Through Plating




Figure X-22 Wear Scar Showing Base Metal Through Plating

This is a wear scar in the plated surface, subjected to repeated micromotion, showing how the underlying base metal eventually gets exposed. (Technically, this image was taken from a tribology test, and not a fretting corrosion test, but the base metal exposure looks the same.)

Figure X-23 Contact Resistance Stabilization from Copper to Copper Contact after Complete Wear-through of Tin




Figure X-23 Contact Resistance Stabilization from Copper to Copper Contact after Complete Wear-through of Tin

Once the plating layer and all of its oxides are worn through, and the underlying copper base metal is exposed, the contact resistance drops again and stabilizes, albeit at a higher value than seen in the initial plated surface.

Figure X-24 Lubricants Protect Against Fretting Corrosion




Figure X-24 Lubricants Protect Against Fretting Corrosion

Lubrication provides protection against fretting corrosion. While full lubrication is best, even partial lubrication (such as with mineral oil) is better than none. Many chemical companies have designed lubricants specifically for use in electronic connectors, which provide the fully lubricated condition.

©2020 Materion Brush Inc.

Hydrogen Embrittlement/Hydrogen Assisted Cracking/Hydrogen Induced Cracking

Hydrogen atoms are small enough to diffuse into and fit within the interstitial spaces of steel alloys. This results in reduced ductility, toughness, and fatigue strength in steel alloys, leading to early failure at stresses that would normally not be a problem for the material. Exposure to hydrogen in the environment, particularly in the form of H_2S gas, is a leading cause of embrittlement in steel materials. Copper alloys are not susceptible to hydrogen embrittlement, since their face centered cubic (FCC) structure does not provide enough interstitial space for hydrogen to become entrapped, unlike the susceptible body centered cubic steel alloys.

Stress Corrosion Cracking (SCC)/Season Cracking (Figure X-25)

This refers to the sudden failure of a metal in the presence of a specific corrosive atmospheric environment at a static tensile stress below the normal fracture stress. The fracture occurs much more rapidly than for corrosion alone, and at a much lower tensile stress than a mechanical overload alone. For stressed copper alloys, SCC occurs if 3 atmospheric components are available:

- ammonia/ammonium hydroxide (potentially from fertilizer used in agricultural areas)
- high humidity
- oxygen

Depending on the type of alloy, steels may be susceptible to stress corrosion cracking in chlorides, nitrates, hydroxides and carbonates. Nickel alloys may be susceptible in steam, while Al and Ti alloys will have difficulty with chlorides, bromides, and iodides.

High-copper alloys such as CuBe and CuNiSn generally show the highest resistance to SCC from ammonia.

You can reduce the potential for SCC by reducing the tensile stress or the corrosiveness of the environment, or by using materials more resistant to stress corrosion cracking in the intended use environment.

Figure X-25 Stress Corrosion Cracking (SCC) Testing




Figure X-25 Stress Corrosion Cracking (SCC) Testing

For SCC testing, the sample is machined and then loaded in high stress (bent into C-ring in a fixture or by 4 point bending). The sample is immersed in liquid for the prescribed time. The test determines if a given material would be able to survive for long times under stress with chloride ions in the environment. Copper alloys are typically tested in ammonia, whereas nickel and steel alloys are typically tested in boiling MgCl (per ASTM G36).

MATERION

©2020 Materion Brush Inc.

Sulfide Stress Cracking (SSC)

Sulfide stress cracking is similar to stress corrosion cracking, in that the failure occurs when a material under tension is exposed to hydrogen sulfide, particularly in the form of dissolved H_2S often found in downhole environments while drilling for oil and gas. This usually afflicts steel alloys, and is a form of hydrogen embrittlement. Harder (higher tensile strength) steel is most susceptible, so the NACE MR0175/ ISO 15156 specification puts upper limits on the hardness of steel alloys that may be used in oil and gas drilling. Copper alloys are not susceptible, and thus have no hardness restriction.

Chloride Stress Cracking (CSC)

Chloride stress cracking is a form of stress corrosion cracking, usually caused by exposure to chloride-containing solutions and compounds found in downhole drilling.

Crevice Corrosion (Figure X-26)

When two surfaces are in very close proximity in an electrolyte, but do not touch each other, it is possible for crevice corrosion to occur. It is also possible for the two surfaces to hold an electrolyte between them, even if the surroundings are dry. Within the crevice, the liquid stagnates, and there is a potential for reduced oxygen levels, increased impurity levels (including corrosion-inducing ions), and lower pH. This creates anodic conditions inside the crevice, and if the surrounding material is more cathodic, then corrosion will occur rapidly within the crevice.

Figure X-26 Crevice Corrosion




Figure X-26 Crevice Corrosion

Crevice corrosion can occur when water or some other electrolyte gets into small spaces between components. Even if there is good flow of the solution outside the crevice, the electrolyte will be stagnant inside the crevice due to the bouindary layer effect. This can lead to a buildup of corrosion product and reduced oxygen levels in the liquid, which in turn makes the solution more acidic, accelerating further corrosion. While the overall surface of the part may show no signs of corrosion at all, the surface area hidden within in the crevice may experience rapid corrosion and failure. Steel and nickel alloys are particularly vulnerable to this form of corrosion. Resistance to crevice corrosion is typically tested in stagnant salt water (less severe) or in ferric chloride (more severe). During the test, a critical temperature is determined above which crevice or pitting corrosion can occur. Having a higher critical temperature means that the material will be more resistant to corrosion in general service.

MATERION

©2020 Materion Brush Inc.

Pitting is particularly a concern with chrome-plated passivated stainless steel alloys, or with active alloys coated with a more noble material. If the corrosion resistant surface is breached, rapid attack may occur on the underlying metal when exposed to corrosive agents, similar to pore corrosion. As with to crevice corrosion, as the pits grow, the conditions within the pit tend to favor an increased corrosion rate, so pits can grow much larger than the overlying holes. Usually pitting can be controlled by choosing materials with sufficient pitting resistance for the intended environment.

Figure X-27 Pitting Corrosion of Cr-Plated Steel Garage Door Handle



Figure X-27 Pitting Corrosion of Cr-Plated Steel Garage Door Handle

In pitting corrosion, small holes or cracks in the plating or passivated surface layer allow the underlying base metal to be attacked by the environment. A classic case is shown above, where a steel garage door handle shows pitting corrosion through the overlying chromium plating.

The tendency for pitting corrosion to occur is measured using **polarization curves**, per ASTM G61 or ASTM G100. A metallic sample is immersed in a liquid electrolyte, and an applied potential is swept from a low value to a high value, and back again. The tester monitors the change in current density with the change in voltage. As the voltage rises, active corrosion (either pitting or crevice) begins at the **critical pitting potential (CPP)**, or **breakdown potential**, which is visible as a sharp increase in current density (indicating chemical reaction) for little extra applied voltage. For materials that repassivate as the voltage drops, the repassivation potential is where the active corrosion stops (sharp decrease in current density with a slight decrease in voltage). Therefore, the tendency to pit is indicated by hysteresis the current density vs. potential chart. At potentials above the CPP, pits will form and grow, and/or crevice corrosion will occur. After testing is completed, the number and size of pits are measured, and a corrosion rate is statistically determined. Note that the CPP depends on the specific electrolyte used.

You may be familiar with the term **pitting resistance equivalence number**, or **PREN**, for stainless steels. This number is calculated based on the weight percentage of Cr, Mo, Nb, W, and N in the steel's composition, with a higher number indicating greater resistance to pitting. While this technique works well for stainless steels, it is not applicable to copper, nickel, or any other alloys.

Erosion Corrosion

While pitting corrosion and crevice corrosion occur due to stagnation of a surrounding electrolyte, erosion corrosion occurs when the surrounding fluid is moving. The name erosion-corrosion is self-explanatory, as the failure occurs much more rapidly than either by erosion or corrosion alone. Corrosion accelerates the rate of erosion (by weakening the material), and vice versa (by exposing new surface).

Corrosion Fatigue

As with erosion-corrosion, this is accelerated fatigue failure at lower stresses and/or shorter times than would occur without corrosive agents present. Corrosion weakens the crack tips and provides new failure initiation sites. Meanwhile, fatigue crack propegation exposes more crack surface to the effects of corrosion.

Selective Leaching/Dealloying

This is selective removal of one alloying element within a metal, in a corrosive environment leaving behind a weakened metal, or a porous structure. This is not a concern with copper alloys other than brass. Examples of dealloying include:

- Dezincification of brass – brass with more than 15% zinc may lose zinc over time, resulting in a leaner, redder, weaker brass alloy.
- Decarburization of steel – removal of carbon from steel, essentially the opposite of case hardening.
- Graphitic corrosion of cast iron – iron is selectively removed from cast iron, leaving behind a porous, brittle structure of graphite. Often seen in old cast iron pipes.

©2020 Materion Brush Inc.

Liquid Metal Embrittlement (LME)

Another self-explanatory name, as it references the tendency of a solid metal to lose ductility, strength, or toughness when in contact with another metal in liquid form. This usually happens when atoms of one of the metals has a strong affinity for one or more of the atoms in the other metal. LME may occur in the following pairs of incompatible metals:

- Liquid Hg attacks Al, Cu, Ti, Zn and their alloys
- Liquid Li attacks Cu, its alloys, and steel alloys
- Liquid Zn attacks Al, its alloys and steel alloys
- Liquid Pb attacks steel alloys
- Etc.

Microbiologically Influenced Corrosion

This may occur when films of bacteria or other microorganisms form on surface of a metal. These organisms can cause corrosion either directly by excreting corrosive byproducts, or indirectly through changing the local chemistry and cathode/anode ratios. It most often occurs in Fe, steel, and Al alloys. This is less of a concern with copper alloys, since they are naturally resistant to biofouling, and may show some anti-bacterial properties as well.

Corrosion Accelerators

- Elevated temperature
- Aqueous environments
- Highly acidic or alkaline environments
- Presence of salts in environment (Chlorides, fluorides, sulfates, nitrates, carbonates, hydroxides, etc)
- Contact with electrochemically dissimilar metals
- Low oxygen in environment
- Stray electrical currents
- Erosive environments
- Biological by-products from bacteria, mold, fungi, algae, animals, etc.

Corrosion Control:

- Choose the correct metals for the environment
- Reduce relative humidity where possible
- Filter out dust particles
- Isolate metals from environment
- Use protective coatings
- Use lubrication

Examples of Harsh Environments

HPHT Environments and Corrosion Resistance for Sour Service.

High pressure, high temperature environments (such as those found down hole in oil and gas exploration and completion) are particularly demanding on connectors. In addition to the temperature and pressure, downhole environments are also corrosive (with potential exposure to chlorides, hydrogen sulfide, and carbon dioxide), subject to heavy shock, vibration, and impact loading, as well as cyclical stress loads. The connectors must function routinely at 150°C – 200°C, with 225°C and even 250°C in the foreseeable future. They may also experience pressure from 69 to 138 MPa (10,000 - 20,000 psi). Figure X-27 shows how various connector materials retain strength at elevated temperatures.

Figure X-28 Temperature Stability for HPHT Environments




Figure X-28 Temperature Stability for HPHT Environments

Copper beryllium retains its room temperature strength through about 200-250 °C. Stainless steel and nickel alloys, particularly NiBe retain strength through much greater temperatures.

©2020 Materion Brush Inc.

The National Association of Corrosion Engineers (NACE) has defined standard test environments for materials to see if they would perform adequately downhole, as shown in the table below. Copper beryllium can be used in some downhole environments, and copper nickel tin alloys can be used in even harsher environments (Figure X-28). See Materion Tech Brief "Compliance of Copper Beryllium and ToughMet® 3 Copper-Nickel-Tin Alloys to NACE MR0175/ISO 15156" for more information on this subject.

Table XI-2 – Standard NACE Test Environments

	NACE Environment				
	Level I	**Level II**	**Level IV**	**Level V**	**Level VII**
Temperature °F (C)	23	23	90	150	205
H_2S Partial Pressure in psi (MPa)	0	Saturated	0.43 (0.003)	101 (0.7)	508 (3.5)
CO_2 Partial Pressure in psi (MPa)	0		101 (0.7)	203 (1.4)	508 (3.5)
Acetic Acid (%)	0	0.5			
NaCl (%)	5	5	15	15	25

Figure X-29 Corrosion Rates in Sour Environments




Figure X-29 Corrosion Rates in Sour Environments

Nickel based alloys show the highest resistance to corrosion in sour downhole drilling and completion environments. Copper beryllium shows decent performance through NACE level IV, and ToughMet® 3 (BF158) shows promise through NACE level V.

MATERION

©2020 Materion Brush Inc.

Reliability in Severe Automotive Underhood Environments

There were more than 60 million vehicles recalled in the U.S. during 2014 for various reasons, setting an all-time record. This was followed by 51 million recalls in 2015. Vehicle reliability and the costs of poor quality (such as death and injury, lawsuits, court costs, government fines, warranty claims, and brand damage) are on the forefront of everyone's mind throughout the automotive supply chain.

At the same time, vehicles are continuing the trend of becoming more electrical than mechanical. Vehicles have multiple electronic systems, many more sensors, and multiple electronic control units overseeing them all. All of these are linked together through the electrical connectors in the wiring harness. It is these separable connections that are most vulnerable to environmental conditions, and where failure is most likely to occur.

Each connector must pass electrical current and/or electronic signals through without distorting them. Any such distortion could result in incorrect operation or failure of the myriad devices in a car. To prevent signal distortion, the contact resistance must be kept low and stable over the life of the connector. This requires mechanical stability in the connector, as well as strength, stiffness, formability, conductivity, and stress relaxation resistance in the base metal, along with adequate hardness and lubricity in the plating.

Materion has been serving the automotive electronics market for decades. Copper beryllium has long been the alloy of choice in critical electrical connectors, providing unparalleled reliability in difficult, corrosive and high temperature environments, like those found under the hood of today's cars and light trucks.

Materion provide materials that support

- Miniaturization
- Light weighting
- Increasing electrification/electronics density
- Greater power
- Higher temperatures
- More severe vibration
- Larger impact & shock loads
- Lower insertion force
- Stability
- Reliability
- Lower total cost

MATERION

©2020 Materion Brush Inc.

Miniaturization – When contacts are made smaller, the only way to maintain good contact force is to increase the stress in the material during normal operation. Copper beryllium has the high strength required to withstand this additional stress, and the conductivity required to pass high current through a smaller cross sectional area without overheating or falling victim to thermal runaway. Copper beryllium also has the formability required to form small contacts in tight spaces, without sacrificing strength.

Light Weighting – As cars are made smaller and lighter, there will be less mass above the suspension system in the car, meaning a that a greater amount of shock loads and vibration from the road/tire interface will find its way into the cabin and under the hood, requiring higher strength to resist them. Smaller, lighter wires and cables with smaller connectors can run hotter, given the elevated temperature strength and stress relaxation resistance of copper beryllium.

Increasing Electrification/Electronics Density – As more electrical and electronic devices are included in cars, more circuits will be required to connect and power these devices, and each connector will see a greater number of circuits.

Greater Power – As more electronic devices are placed in cars, a greater amount of power will be required to drive them. This requires some combination of higher voltage (potentially increasing the potential for galvanic corrosion and electrical arcing on contact connection and disconnection) and/or higher current (requiring higher conductivity to minimize temperature rise through resistive heating and greater stress relaxation resistance in materials to withstand the higher temperatures generated). Furthermore, start-stop technology in engines may repeatedly generate high voltage (dozens of volts) surges and transients in the electrical system.

Higher Temperatures – Copper beryllium retains a high percentage of its room temperature strength at elevated temperatures, and has excellent resistance to stress relaxation. Because it will not lose as much force over time as lower performance materials, it can be designed with a lower initial contact force, promoting miniaturization and lowering insertion force.

More Severe Vibration – Copper beryllium provides the stiffness and contact force required to prevent intermittent contact and minimize fretting corrosion due to vibration.

Larger Impact & Shock Loads – Copper beryllium has the resilience and toughness required to absorb suddenly applied high forces without permanent deformation.

Lower Insertion Force – Since they retain force so well under extreme conditions, contacts made with copper beryllium can be designed with a lower initial contact force, more closely matched to the end of life contact force. This reduces insertion force per contact, allowing more contacts to be placed into a connector without increasing the required mating force beyond ergonomic limits.

Stability – Copper beryllium's high elevated temperature strength and resistance to stress relaxation means that the contact force changes very little over time. This means that the contact resistance starts low and remains stable over the life of the connector.

Reliability – Copper beryllium has the greatest resistance to loss of contact force over time, even in miniaturized designs carrying high current at elevated temperatures and under heavy vibration. Electronic signals and electrical power will pass through the connector without unacceptable distortion whether the car is 1 day old or 10 years old.

Lower Cost – High performance alloys can contribute to lower overall cost in two ways. One is through miniaturization. Contacts and connectors can be made smaller with high performance alloys. This means that there is less metal to buy per a given number of contacts, as well as less surface area to plate, and less plastic to mold around the connector. All of this results in cost savings that are not reflected in the purchase price in terms of dollars per pound, but that show up elsewhere on the balance sheet.

The second cost savings contribution comes with the increased reliability afforded by high performance alloys. This results in fewer failures, reducing the costs of poor quality. These potential hidden savings that come with the use of higher performance materials will never appear as a line item on a purchase order, just as the potential hidden costs of cheaper materials will never appear on the purchase order. It is up to the engineer to realize that such costs and savings are real, and will most likely make their presence known on the books in the quality or legal departments.

©2020 Materion Brush Inc.

Medical Devices and Sterilization

Medical devices must be sterilized between uses. This involves subjecting the device to temperature, humidity and/or chemical conditions that are lethal to pathogens. In addition to attacking viruses, bacteria, prions, mold, spores and fungi, the sterilization process can be detrimental to materials as well. Some common sterilization procedures include:

- Steam cleaning in an autoclave – high temperature, high humidity environment may accelerate oxidation of the surface
- Ethylene oxide, hydrogen peroxide, or ozone exposure
- Nitrogen dioxide exposure – NO_2 may cause some corrosion of copper alloys under certain pressure, temperature and relative humidity conditions
- Gamma or electron beam irradiation
- UV, microwave, or high intensity light irradiation

Consumer Electronics and Wearable Electronics

Wearable devices often contain sensors or connectors that may come into contact with human skin or bodily fluids, as well as fluids from sugary, acidic beverages or salty, oily snacks. Wearable devices also come into contact with skin oils, sweat, soap, hand sanitizers, moisturizers, etc. See Section XV- Qualification for more detailed information on corrosion resistance to specific substances that consumer-worn applications are likely to contact.

MATERION

©2020 Materion Brush Inc.

Section XI. Regulatory, Environmental, Health and Safety Considerations

Copper beryllium (CuBe), in solid form and as contained in finished products, presents no special health risks. Most manufacturing operations conducted properly on well-maintained equipment are capable of safely processing copper beryllium containing materials. However, like many industrial materials, copper beryllium may present a health risk if handled improperly. The inhalation of dust, mist or fume containing beryllium can cause a serious lung condition in some individuals. The degree of hazard varies, depending on the form of the product, how it is processed and handled, as well as the amount of beryllium in the product. Read the product specific Safety Data Sheet (SDS) for additional environmental, health, and safety information before working with copper beryllium alloys.



Product Regulations

Electronic products must conform to environmental regulations regarding the hazardous material content and end-of-life recyclability. The European Union directive on the Restriction of the use of Certain Hazardous Substances in electrical and electronic equipment **(RoHS)** restricts the use of lead (Pb), cadmium (Cd), mercury (Hg), hexavalent chromium (Cr^{6+}), two brominated flame retardants (PBB and PBDE) and four Phthalates (DBP, BBP, DEHP and DIBP) in most electrical and electronic components. It is important to note RoHS does exempt certain applications from these requirements including up to 4% lead in copper alloys added for machinability. Therefore, all copper beryllium alloys are all **fully compliant** with the both the original RoHS directive (2002/95/EC), as well as the RoHS recast of 2012 (2011/65/EU) and 2015 Amendments (2015/863/EU).

Furthermore, copper beryllium alloys are not banned or restricted in any way by the European Union , **Waste Electrical and Electronic Equipment (WEEE) or End-of-Life Vehicles (ELV)** directives. In addition, copper beryllium alloys are not banned, restricted or otherwise limited by the International Electrotechnical Commission (IEC) standard on Material Declaration for Products of and for the Electrotechnical Industry (IEC 62474).

MATERION

©2020 Materion Brush Inc.

REACH (Registration, Evaluation, and Authorization of CHemicals) Compliance

Most substances produced by Materion (except casting ingot) are considered articles and do not require registration.

- Be, BeO are registered through Harlan Laboratories UK
- Cu, Al, Ni are registered through Umwelt Consult GmbH

The REACH registration numbers are as followed:

- Aluminum metal: 01-2119529243-45-0056
- Beryllium metal: 01-2119487146-32-0000
- Beryllium oxide: 01-2119487134-37-0000
- Copper metal: 01-2119480154-42-0080
- Nickel metal: 01-2119438727-29-0049

The CLP Notification C&L submission number is:

- Cobalt metal: JD180154-53

Defense Federal Acquisition Regulation Supplement (DFARS)

Often suppliers in the United States need to know if their material is compliant to **DFARS (Defense Federal Acquisition Regulation Supplement)**, specifically supplement sections 252.225-7008 and 252.225-7009 (formerly section 252.225-7014). Materion Performance Alloy's strip and rod materials including copper beryllium, copper nickel tin, nickel beryllium, and leaded nickel copper are all melted and fully produced in the United States, so these alloys are all DFARS-compliant.

Materion Conflict Minerals Policy

As a global leader in high performance engineered materials, Materion Corporation is committed to conducting business so as to protect people and the environment. As required by the Conflict Minerals provisions of the Dodd-Frank Wall Street Reform and Consumer Protection Act, HR 4173, Section 1502 ("Conflict Minerals Act"), Materion Corporation will work with our suppliers and take appropriate actions to ensure that our products do not contain conflict minerals that directly or indirectly finance or benefit armed groups in the Democratic Republic of the Congo (DRC) or an adjoining country. These actions will include conducting reasonable country of origin inquiries and, as necessary, obtaining reliable certificates of origin for all materials that might possibly originate in the DRC areas or an adjoining country.

For additional information on compliance to RoHS, WEEE, ELV, IEC 62474, REACH, DFARS, or Conflict Minerals regulations, please contact Materion's Product Stewardship Department at 800.862.4118 in the US & Canada, or 216.486.4200 internationally.

MATERION

©2020 Materion Brush Inc.

A note on Lead-Free (Pb-Free) Materials

There is some confusion about what Pb-free really means. Lead (Pb) is naturally found in copper ores, and copper refiners remove as much as possible. Thus, most copper alloy composition specifications note a maximum Pb amount of 0.6%. In reality, the Pb amount will probably be much lower than this. It is impossible to guarantee absolutely zero atoms of Pb or any other element in a material. So, as long as no Pb is intentionally added to a copper alloy, it is effectively Pb-free. In particular, note that copper alloys with up to 4% Pb are also RoHS-compliant, so every material produced by Materion is RoHS-compliant.

Copper Beryllium Scrap

- Is not classified as a hazardous waste under federal law.
- Is an inert, insoluble material not subject to environmental decomposition
- Can be safely disposed of in accordance with state and local laws
- Is a valuable resource. Materion will purchase segregated beryllium-containing scrap (call 1-800-BUY-BECU). Materion also can provide information for other outlets

Obligations

OSHA requires that hazard information be provided in accordance with the Hazard Communication Standard (29 CFR 1910.1200).

Requirements include:

- Safety Data Sheets (SDS's)
- Warning Labels

Materion endorses the requirement to provide downstream customers with information regarding the safe handling of alloys containing beryllium

Health and Safety

Copper beryllium in solid form and as finished parts, presents no special health risks:

- It is not a fire hazard
- It is not radioactive
- It is not explosive
- It does not off-gas toxic fumes

Potential for exposure to beryllium-containing particulate should be determined by conducting a workplace exposure characterization which includes air sampling in the worker's breathing zone, work area and throughout the department. Use an industrial hygienist or other qualified professional to establish the frequency and type of air sampling necessary. Develop and implement a sampling approach that identifies the extent of potential exposure variation and provides statistical confidence in the results. Make air sample results available to workers.

Facilities handling beryllium-containing materials in ways which generate particulate are encouraged to use engineering and work practice controls, including personal protective equipment, to control potential worker exposure. Use exposure controls to keep beryllium work areas clean and keep beryllium particulate out of the lungs, off the skin, off of clothing, in the work process, in the work area and on the plant site. It remains the best practice to maintain levels of all forms of beryllium exposure as low as reasonably achievable, and continue to work to improve exposure control practices and procedures.

Specific EH&S Concerns with Beryllium and Beryllium-Containing Materials

Breathing fine airborne particles containing beryllium may cause chronic beryllium disease (CBD). Risks from processes that produce fine particles can be controlled with appropriate protective equipment and simple, proven and readily available engineering controls. Accidental implantation in the skin may result in sensitization to beryllium, so it is important to provide skin protection to prevent contact with particulate or solutions.

Safely Processing Copper Beryllium

The key to safely processing copper beryllium is understanding the likelihood of generating particles as well as the size of the particles (such as machining chips) produced in each operation. In most cases, machining chips generated are too large to become airborne and a respirable particle. Where only large chips or no particulate are generated there is a very low inhalation concern:

MATERION

©2020 Materion Brush Inc.

Table XI-1 – Operations with Low Inhalation Concerns

SOURCES OF EXPOSURE

The following table provides a summary of those copper beryllium processes that typically present low inhalation concern (green).

Low Inhalation Concern Operations			
Adhesive Bonding	Drawing	Milling	Shipping
Age Hardening (<950°F)	Drilling	Packaging	Sizing
Assembly	Dry Tumbling	Painting	Skiving
Bending	Electroless Plating	Physical Testing	Slitting
Blanking	Electroplating	Piercing	Stamping
Bonding	Extrusion	Pilger	Straightening
Boring	Filing by Hand	Plating	Stretch Bend Leveling
Broaching	Gun Drilling	Pressing	Stretcher Leveling
CNC Machining	Hand Solvent Cleaning	Radiography/X-ray	Tapping
Cold Forging	Handling	Reaming	Tensile Testing
Cold Heading	Heading	Ring Forging	Thread Rolling
Cold Pilger	Heat Treating (inert	Ring Rolling	Trepanning
Cold Rolling	atmosphere)	Roll Bonding	Tumbling
Cutting	Inspection	Rotary forging	Turning
Deburring (non-grinding)	Machining	Sawing (tooth blade)	Ultrasonic Cleaning
Deep Hole Drilling	Metallography	Shearing	Ultrasonic Testing
			Upsetting

Notes:

1) Operations in the "Low Inhalation Concern" category represent operations that typically release non-respirable (>10 micrometer) particles, are not expected to generate significant ultra-fine particulate, and/or are not expected to result in exposures in excess of the Occupational Safety and Health Administration (OSHA) Permissible Exposure Limit (PEL).
2) This list is not all-inclusive and variation can exist within specific processes. To verify the adequacy of engineering and work practice controls, conduct an exposure characterization of all copper beryllium processing operations.
3) Age hardening, as included in this table, is a heat treatment process conducted at <950°F.
4) When evaluating operations, consideration must be given to potential exposures from activities in support of these operations such as setup, preparation, cleanup and maintenance.

MATERION

Some other manufacturing operations typically do generate fine particles and are therefore a likely inhalation concern. You need to take additional precautions with these operations:

Table XI-2 – Operations with Likely Inhalation Concerns

The following table provides a summary of those copper beryllium processes that may present a likely inhalation hazard (yellow).

Likely Inhalation Hazard Operations			
Abrasive Blasting	Dross Handling	Laser Cutting	Sanding
Abrasive Processing	Electrical Chemical Machining (ECM)	Laser Machining	Scrap Management (Clean)
Abrasive Sawing	Electrical Discharge Machining (EDM)	Laser Scribing	Sectioning
Annealing	Electron Beam Welding (EBW)	Laser Marking	Slab Milling
Brazing	Forging	Laser Welding	Soldering
Bright Cleaning	Grinding	Laundering	Solution Management
Brushing	Heat Treating (in air)	Melting	Spot Welding
Buffing	High Speed Machining (>10,000 rpm)	Photo-Etching	Sputtering
Burnishing	Honing	Pickling	Swaging
Casting	Hot Forging	Point and Chamfer	Torch cutting (i.e., oxy-acetylene)
Centerless Grinding	Hot Rolling	Polishing	Water-jet Cutting
Chemical Cleaning	Investment Casting	Process Ventilation	Welding (ARC, TIG, MIG, etc.)
Chemical Etching	Lapping	Maintenance	Wire Electrical Discharge Machining (WEDM)
Chemical Milling		Resistance Welding	
Coolant Management		Roller Burnishing	
Deburring (grinding)		Sand Blasting	
Destructive Testing		Sand Casting	

Notes:

1) Operations in the "Likely Inhalation Hazard" category represent those operations which may release respirable (<10 micrometer) particles, may generate ultra-fine particulate, may generate beryllium oxide and/or may result in exposures in excess of the OSHA PEL.
2) This list is not all-inclusive and variation can exist within specific processes. Determine, then verify, the adequacy of engineering and work practice controls by conducting an exposure characterization of all copper beryllium processing operations.
3) Effective ventilation, work practices and personal protective equipment use can control a "Likely Inhalation Hazard".
4) When evaluating operations, consideration must be given to potential exposures from activities in support of these operations such as setup, preparation, cleanup and maintenance.
5) High temperature annealing (>1000°F) conducted in air can generate a loose beryllium-containing oxide scale that can flake off during processing and become airborne. Annealing in an inert or reducing atmosphere can minimize the formation of surface metal oxides.
6) Pickling, as included in this table, involves the use of strong acid and/or caustic solutions to remove metal oxides from the surface of beryllium-containing alloys. Other chemical cleaning or surface preparation operations should be characterized to determine potential exposure risk.
7) The use of the term "may generate ultra-fine particulate" to categorize the hazard of particular operations addresses the hypothesis that exposure to a large number of beryllium-containing particles with low mass and an aerodynamic diameter of 1 micrometer or less increases the risk of developing CBD.

MATERION

©2020 Materion Brush Inc.

The Beryllium Worker Protection Model (BWPM) is a comprehensive process implemented by Materion. It introduces a corporate management process encouraging users to err on the side of safety. The current prevention focus is to:

- Keep the working environment clean and shipshape
- Keep particulate containing beryllium:
  - Off the skin
  - Out of lungs
  - Off the clothing
  - In the work process
  - In the work area
  - On the plant site

The best way to implement your own safety process is to:

- Follow the Beryllium Worker Protection Model
- Understand the concerns inherent in your particular operation
- Take necessary precautions as prescribed in SDS and Safety Facts Sheet
  - Use ventilation & engineering controls
  - Conduct proper work practices to minimize particulate contact with skin, hair, or clothing
  - Use approved respiratory protection/personal protective equipment
- Conduct workplace exposure characterization if necessary

Workplace Exposure Characterization

- Conduct air sampling by a qualified Industrial Hygienist
- Develop and utilize a sampling strategy which identifies the extent of exposure variation and provides statistical confidence in the results
- Make air sample results available to employees
- The exposure assessment should include the evaluation of secondary exposure pathways such as housekeeping, particulate migration and/or solution control

Exposure Controls

- Ventilation & Engineering Controls - Use whenever possible as the method of controlling exposure to airborne particulate
- Work Practices - Develop work practices that prevent particulate from coming in contact with worker skin, hair or personal clothing
- Respiratory Protection - When airborne exposures exceed or have the potential to exceed the occupational limits, approved respirators must be used as specified by an Industrial Hygienist

To ensure that you have the latest information, please visit the Environmental, Health and Safety section of the Materion website.

To assist users of beryllium-containing materials, Materion has developed an “Interactive Guide to Working Safety with Beryllium and Beryllium-containing Materials” (Interactive Guide) to provide employers and employees with specific information on the elements of the Beryllium Worker Protection Model. The Interactive Guide is available on the web at www.berylliumsafety.com. The Interactive Guide provides an important foundation for the safe handling of beryllium and beryllium-containing materials in the workplace. Information about the Interactive Guide can be obtained through our website, www.materion.com, by contacting the Materion Brush Inc. Product Safety Hotline at (800) 862-4118, or by contacting a Materion Brush Inc. Sales Representative.

©2020 Materion Brush Inc.

Occupational Standards

The Occupational Safety and Health Administration (OSHA)

On 9 January, 2017, OSHA issued a new Beryllium Standard for General Industry (29 CFR § 1910.1024). The Beryllium Standard includes Permissible Exposure Limits (PEL) of 0.2 micrograms per cubic meter (0.2 µg/m^3) as an 8-hour Time Weighted Average (TWA) and 2.0 µg/m^3 as a Short-Term Exposure Limit (STEL) determined over a 15-minute sampling period which are the occupational exposure limits that Materion has been recommending for more than a decade. The standard also includes ancillary requirements prompted by exposures at or above an Action Level (AL) of 0.1 µg/m^3 or other specified situations.

Materion supports having a Beryllium Standard and believes having a Beryllium Standard should provide a measure of certainty and predictability about the safe use and handling of beryllium and beryllium-containing materials which will help create jobs, ensure the continuity of future beryllium supplies and improve the safety of all those who work with beryllium-containing materials.

Most companies processing beryllium and beryllium-containing materials that have adopted and applied the Materion Beryllium Worker Protection Model should not be impacted to any great extent and will likely only need to create the documentation of your program and potentially some signage as required by the standard.

The provisions of the new standard go into effect May 2018 and contain:

- Scope and Application
- Definitions
- Permissible Exposure Limits
- Exposure Assessment
- Beryllium Work Areas
- Methods of Compliance
- Respiratory Protection
- Personal Protective Clothing and Equipment
- Hygiene Areas and Practices (*see note below on showers and change rooms)
- Housekeeping
- Medical Surveillance
- Medical Removal
- Communication of Hazards
- Recordkeeping

Timeline of the new OSHA standard:

- On January 9, 2017, OSHA issued the final Beryllium Standard.
- The Effective Date of the final Standard was March 10, 2017 but was changed to March 21, 2017 by Executive Order.
- All obligations will commence and become enforceable as noted above, except:
  - Showers and change room, if required, must be provided by March 11, 2019, and,
  - Required engineering controls must be installed by March 10, 2020.

Companies processing beryllium and beryllium-containing materials who may be affected need not be concerned as Materion will assist these customers by providing vital information and tools to make compliance with the Beryllium Standard simple and straightforward.

Materion has an Information Hotline available for customers to call to obtain information on the proposed Beryllium Standard. The telephone number is 1-800-862-4118. For additional information on the new OSHA standard, please see the following:

- **FAQ 114** - Frequently Asked Questions about OSHA and the Beryllium Standard on the Materion website
- **Guide for Compliance with the OSHA Standard** – This online guide provides employers with information on the Standard and allows employers to determine if the Standard is applicable to their operations. Following this determination, the guide would assist in determining which sections apply to their operation and provide prescriptive guidance and assistance to comply with the applicable sections.
- **www.berylliumsafety.com**

EH&S Tools

The following additional tools are available from Materion to address any questions you may have regarding regulatory issues and working safely with copper beryllium

Safety Data Sheets (SDS), also known as Material Safety Data Sheets (MSDS) or Product Information Sheets – These documents provide environmental, health and safety information regarding materials produced by Materion. The SDSs are in the Globally Harmonized System of Classification and Labelling of Chemicals (GHS) recommended format.

MATERION

©2020 Materion Brush Inc.

Process-Specific Control Summaries

These documents have been developed to communicate the results of case studies performed on specific operations where copper beryllium (CuBe) alloys are processed and to provide the reader with information on exposure and exposure control options such as work practice, administrative and engineering controls. Those of interest to connector manufacturers include:

- PSCS 101 – Precision Stamping of Copper Beryllium
  Case Study: all sampling results were far below the OSHA PEL
  The highest result (0.038 mg/m^3) was over 5 times less than the OSHA PEL
  The vast majority of samples were 40 times less than the OSHA PEL
- PSCS 103 – Computer Numerically Controlled (CNC) Lathe Turning of Copper Beryllium

FAQ's about Beryllium and Beryllium-containing Materials

These documents provide answers to frequently asked questions about safe handling, environmental regulations, and recycling. Some relevant examples are:

- FAQ 100 – Frequently Asked Questions about the Banning or Restricting of Copper Beryllium in Products
- FAQ 101 – Frequently Asked Questions About Copper Beryllium and Recycling
- FAQ 102 – Frequently Asked Questions About Airborne Beryllium Levels and Exposure Assessment
- FAQ 103 – Frequently Asked Questions About Beryllium and Housekeeping
- FAQ 104 – Frequently Asked Questions About Beryllium and Cancer
- FAQ 105 – Frequently Asked Questions About The Beryllium Blood Lymphocyte Proliferation Test (BeBLPT)
- FAQ 106 – Frequently Asked Questions About the Material Declaration of Copper Beryllium in Products
- FAQ 107 – Frequently Asked Questions About Exposure Limits from ACGIH
- FAQ 108 – Frequently Asked Questions About Skin Contact and Copper Beryllium
- FAQ 109 – Frequently Asked Questions About the California Permissible Exposure Limit for Beryllium
- FAQ 110 – Frequently Asked Questions About Beryllium and Chronic Beryllium Disease
- FAQ 111 – Frequently Asked Questions About REACH and Beryllium Alloys
- FAQ 112 – Frequently Asked Questions About Recycling Of Electrical And Electronics Equipment Containing Copper Beryllium Alloys
- FAQ 113 – Frequently Asked Questions About The Occupational Exposure Limit For Beryllium In France
- FAQ 114 – Frequently Asked Questions About OSHA and The Beryllium Standard

MATERION

©2020 Materion Brush Inc.

Safety Facts

These documents provide both product and process specific environmental, health and safety information regarding materials produced by Materion. The Safety Facts present specific information from the Safety Data Sheets (SDS) in a "user friendly" format and language. Some that would be of interest to connector manufacturers include:

- SF105 – Processing Copper Beryllium Alloys
- SF103 – Safety Practices for Stamping Copper Beryllium Alloys
- SF101 – Safety Practices for Machining Copper Beryllium Alloys
- SF104 – Safety Practices for the Chemical Processing of Small Copper Beryllium Alloy Parts
- SF5 – Safety Practices for Electrical Discharge Machining Copper Beryllium
- SF6 – Safety Practices for Heat Treating Copper Beryllium Parts
- SF14 – Safety Practices for Handling and Disposal of Electronic Components Containing Copper Beryllium

Interactive Guide to Working Safely with Beryllium (Figure XI-1)

This interactive guide featured on the Materion website was created to provide employers and employees throughout the supply chain with guidance to working safely with beryllium and beryllium-containing materials.



www.berylliumsafety.com

Figure XI-1 Interactive Guide to Working Safely with Beryllium

This is a screenshot of the home page of the online Interactive Guide to Working Safely with Beryllium.

Beryllium Consultant Network

The network consists of professional Industrial Hygienists who have either attended an industrial hygiene training seminar on beryllium or have previous experience in controlling occupational exposure to beryllium. These consultants provide services independent of Materion. Materion will assist the network consultants by providing them periodic updates through refresher courses and written correspondence. Please contact your sales representative if you have any questions.

©2020 Materion Brush Inc.

Materion EH&S Policy

The Materion business management system requires the design, manufacture and distribution of our products be accomplished through a continuous improvement process that is committed to protecting the environment and providing for the safety and health of employees, customers, visitors and the general public. This commitment to people and the environment is a value that cannot be compromised. No job we do or service we perform is so urgent that we cannot take the time to perform each aspect of the job in a safe and environmentally responsible manner. The Materion business management system commits each employee to comply with all applicable legal requirements, follow established procedures, prevent pollution, conserve energy, minimize waste and promote recycling. Executive management ensures the sustainability of this policy as part of its annual business planning and review process and the line organization has functional ownership in order to drive employee involvement at all levels toward the achievement of documented, clearly defined and measurable goals and objectives. This policy is shared with employees, the public, our vendors and customers.

Materion EH&S Principles

The following environmental, health and safety principles are ingrained into every aspect of our operations and our daily work.

Each employee is committed to be a proactive steward of the environment, work safely and promote the safe use of our products. The goal of our safety culture is the elimination of accidents, injuries, health impacts and environmental harms at work and to encourage safety at home, not just as an objective, but as the way we conduct daily business. Emissions to air, water and earth are properly controlled for the protection of people and to prevent pollution of the environment.

We believe that incidents, injuries and illnesses are preventable. We utilize a disciplined environmental, health and safety management system to protect people and the environment. We seek to identify the environmental aspects of our activities, products and services to determine if they can result in significant health, safety or environmental impacts.

Management is responsible for integrating these environmental, health and safety principles into daily work activities and for diligently responding to employee, community and customer concerns. The line organization has functional ownership and drives employee involvement at all levels.

Each employee is responsible for maintaining an awareness of work practices and preventing conditions that may result in an unsafe situation or harm the environment. It is the responsibility of each employee to promptly notify management of any unsafe or harmful condition. Procedural compliance and the use of safe work methods and practices are expected at all times.

We conduct business in compliance with applicable environmental, health and safety laws, regulations and Materion standards.

We work to continually improve our environmental, health and safety performance and consider the expectations of interested parties by incorporating environmental, health and safety considerations and objectives into business plans and decisions, research and development and product stewardship. Our culture drives continuous improvement by establishing measurable targets and goals.

We utilize measurements and accountabilities for monitoring and documenting performance towards goals, overseeing improvements and maintaining the effectiveness of our environmental, health and safety systems.

We identify and prepare for unexpected emergencies and do not become complacent to everyday risks and challenges.

Additional Information

Read the SDS specific to the products in use at your facility for more detailed environmental, health and safety guidance. SDSs can be obtained by contacting the Materion Brush Inc. Product Safety Hotline at (800) 862-4118 or website at www.materion.com.

Additional information can also be obtained by contacting a Materion Brush Inc. Sales Representative or:

Product Stewardship Department
Materion Brush Inc.
6070 Parkland Boulevard
Mayfield Heights, Ohio 44124
(800) 862-4118

DRAFT

©2020 Materion Brush Inc.

Section XII. Miniaturization



Moore's Law

Before co-founding Intel in 1968, Gordon E. Moore (then Director of R&D at Fairchild Semiconductor) published an article in the April 19th, 1965 edition of *Electronics* magazine. This article, entitled "Cramming More Components onto Integrated Circuits", detailed his observation that the number of components produced at minimum cost on a semiconductor integrated circuit doubled every year. He further predicted that this trend would continue until at least 1975.

In the second paragraph of this article, Mr. Moore accurately predicted the coming of home computers, computer-controlled autos, personal portable communications equipment, and electronic wristwatches. Such hot trends as notebook computers, tablets, smart phones, smart watches and other wearable electronics, cars with ADAS, etc. all fall into one or more of these prediction categories.

In 1975, Gordon Moore revised his observation to note that the number of components on an integrated circuit doubles every two years. This trend, since renamed Moore's Law, has continued for over 40 years. The semiconductor industry itself has used it as a goal and has pushed itself to keep up with this self-fulfilling prophesy of miniaturization and increased functionality.

Miniaturization

(The following is reprinted verbatim from Materion Technical Tidbits Issue # 3 Miniaturization.)

Smaller component size has become the main design criterion in the consumer electronics market. Designers are constantly looking for ways to reduce the size and weight of their products without sacrificing performance. After all, when was the last time a cellular phone or notebook computer was advertised as being "bigger and heavier than ever before?"

The purpose of an electronic connector is to transmit an electrical current or signal from one component to another with as little alteration of the signal as possible. The ideal connector is one that is transparent to the signal it is carrying (similar to light passing through a clear window). No matter how many times the connection may be engaged or disengaged, the signal quality should remain the same. Over time, an improperly designed connector may lose transparency (much like a window becoming dirty over time will limit the amount of light passing through).

As a signal passes through a connector, it experiences electrical resistance. This causes some of the power in the signal to be converted to thermal energy by resistive heating. If the resistance is great enough, the signal will be completely blocked. Additionally, a large temperature rise in some higher current applications may have several negative effects. Therefore, it is important to keep the resistance to a minimum.

The total resistance of a contact has two components: Bulk resistance and contact resistance. Bulk resistance is a constant associated with the particular material comprising the contact, and is determined by the conductivity of the metal. Contact resistance is variable and is driven by the interface between two separable contacts. Bulk resistance can be minimized by using a material with high conductivity. Contact resistance can be minimized by maintaining a high normal force between the two contact interfaces. Therefore, contacts are designed to provide the highest practical force.

MATERION

©2020 Materion Brush Inc.

Contact force is a function of contact geometry and stress. Higher stress means greater force. On the other hand, smaller size means that less contact force is generated. Therefore, as the size of a part decreases, the design stress will have to increase to maintain the same level of normal force. This relationship drives the need for higher yield strength materials which are able to withstand higher stresses. Therefore, high yield strength materials allow a greater decrease in the size and weight of components.

Fatigue resistance is important if a connector is to be engaged and disengaged many times. Higher stress levels will result in fewer mating cycles before failure. The material with the highest fatigue strength for the required number of cycles is the material of choice.

If an engaged contact is exposed to elevated temperatures, it may experience stress relaxation. This gradual decrease in remaining stress over time results in a reduced contact force, which in turn increases the contact resistance. This occurs because the apparent contact area decreases, and because there is less force available to push through naturally forming tarnishes or corrosion films. Stress relaxation increases over time, with a rate dependent upon the temperature and the contact's initial stress level. (Similarly, looking out a window at cold weather will do nothing to reduce a person's stress, whereas the appearance of sunshine and warmth may relax a person's stress.) Therefore, it is important to choose a material with good stress relaxation resistance, and to minimize the temperature rise in order to preserve a good contact force.

In power transmission applications, current carrying capacity is related to the amount (mass) of metal in a wire or current-carrying contact. To carry more current, a thicker wire is required. For example, washing machines and electric stoves require much thicker power cords than electric toothbrushes or electric carving knives. As connector size decreases, the current carrying capacity is reduced as well. At the same time, the temperature will rise to a higher level, since there will be less surface area to carry away heat (by convection). Additionally, the bulk resistance will increase with temperature. This forces designers to use higher conductivity materials to make up for the loss in mass of the contact in order to minimize the resistance and temperature rise.

As products get smaller, limitations in the available design space also come into play. To compensate for a reduction in available space, bend radii are made smaller. This has two effects. First, a tighter bend radius will concentrate stress at the bend (obvious to anyone who has driven around a tight curve on a highway at rush hour). The greater stress concentration necessitates the use of a stronger material. Second, the material must have greater formability to withstand a tighter bend without fracturing. As higher strength and formability are not necessarily compatible, the best combination of the two must be selected.

Performance requirements dictate the relative importance of material characteristics in product design. Miniaturization changes the impact of each of the material characteristics discussed above. When designing smaller components, the optimal material will be the one that provides the best combination of yield strength, conductivity, fatigue strength, stress relaxation resistance, and formability given the design requirements. Proper alloy selection will pay big dividends in reduced product failure, warranty costs, and customer satisfaction.

PREVIEW

©2020 Materion Brush Inc.

Miniaturization Trends

Figures XII-1 and XII-2 show the evolution of computers and mobile phones over time, ultimately converging as smart phone technology. Each generation was successively smaller, faster, and could do much more, in accordance with Moore's law. This is progressing even further with the advent of wearable technology.

Figure X-1 Computer Evolution & Miniaturization Trends




Figure XII-1 Computer Evolution & Miniaturization Trends

Each successive generation became smaller and featured much more computing power.

Figure XII-2 Mobile Phone Evolution & Miniaturization Trends



Figure XII-2 Mobile Phone Evolution & Miniaturization Trends

Each successive generation became smaller and included more features.

Miniaturization is not limited to traditional consumer electronics. Automobiles can now almost be considered consumer electronics devices. Cars now have far more electronics for infotainment, Advanced Driver Assistance Systems (ADAS), more advanced driver interfaces, autonomous and semi-autonomous capability, and connectivity than ever before. This is coupled with a necessary increase in the number of sensors and electronic control units to process all the data, which has resulted in a greatly increased number of circuits in the car. To accommodate more circuits in each connector, the terminals need to be reduced in size.

This has resulted in the shrinkage of USCAR standard terminal sizes, as shown in Figure XII-3. Greatly increased current and power demands have also created demand for larger terminals, such as the 9.5 mm.

Figure XII-3 USCAR Standard Terminal Sizes




Figure XII-3 USCAR Standard Terminal Sizes

The size of the picture is scaled appropriately. USCAR added newer, smaller standard terminal sizes over time to help with miniaturization. A larger size was added to handle more power, as 48 V systems will be coming soon on gasoline and diesel cars.

MATERION

©2020 Materion Brush Inc.

Miniaturization Exercise

The industry trend of miniaturization drives smaller centerline spacing, tighter tolerances and lower profile connectors (Table XII-1). In addition, more features are being placed into every electronic device, requiring greater power to run them. Computer processor operating and test temperatures continue to increase. These evolutions in form and features drive designers to use stronger and more reliable materials in their designs, even though modern analysis tools allow for lower factors of safety.

Table XII-1 - Size and Feature Evolution

Connector Application	Product Evolution			
Computer Processor Sockets				
Typical Contact Pitch	1.0 mm	0.8 mm	0.65 mm	0.5 mm
	0.4 mm…			
Typical Operating Temperature	60°C	70°C	85°C	90°C…
Processor frequency	0.2 GHz	0.8 GHz	2.4 GHz	5.2 GHz…
Mobile Phones/Personal Digital Assistants				
Device Features	Analog Voice	Digital Voice	Text Messaging	Music Playing
	e-Mail	Game Playing	Photography	Web Browsing
	Wi-Fi Access	Social Media	Streaming Content	Payments/Financial Transactions
	Voice Recognition	Health/Wellness Monitoring…		
Automotive Electronics				
Safety	Headlights/Taillights	Turn Signals	Windshield Wipers	Rear Window Defoggers
	Seat Belts	Disc Brakes	Power Brakes and Steering	Crumple Zones
	Air Bags	Anti-lock Brakes	Electronic Stability Control	Daytime Running Lights
	Lane Departure Warning	Power Adjustable Mirrors	Auto-dimming Mirrors	Tire Pressure Monitors
	Back-up Cameras	Parking Assist	Steering by Wire	Braking by Wire
	Cross Traffic Detection	Blind Spot Detection	Adaptive Cruise Control	Night Vision
	Pedestrian Detection	Active Lane Keeping	Collision Avoidance	360° Surround View…
Comfort & Convenience	Cigarette Lighters	Power Windows	Power Locks	Power Adjustable Seats
	Electronic Cruise Control	GPS Navigation	Heated Seats	Voice Recognition
	Head-up Display	Self-Parking	Semi-Autonomous Vehicles	Fully Autonomous Vehicles…
Entertainment	AM Radio	FM Radio	8-Track Players	Cassette Players
	CD Players	DVD Players	Satellite Radio	MP3 Player Jacks
	Smart Phone Pairing	Wi-Fi Hot Spots…		
Environmental Compliance	Unleaded Gasoline	Catalytic Converters	Oxygen Sensors	High Efficiency Internal Combustion
	Emissions Monitoring	Hybrid Electric Vehicles	Battery Electric Vehicles	Fuel Cell Vehicles…
Automotive Box Terminal				
USCAR Standard Terminal Size	6.35 mm	2.8 mm	1.5 mm	0.64 mm…
Approximate Strip Thickness	0.25 mm (0.010")	0.20 mm (0.008")	0.175 mm (0.007")	0.15 mm (0.006")…

©2020 Materion Brush Inc.

The miniaturization of a standard cantilever beam type contact to half its existing size is an example of the benefits of using copper beryllium to design smaller contacts (Figure XII-4).

Figure XII-4 Miniaturization




Figure XII-4 Miniaturization

If all dimensions and the deflection are cut in half, the stress remains the same. However, the normal force is reduced by 75%. Therefore, in order to provide adequate normal force in a miniaturized design, one or more of the dimensions and/or the deflection must be changed to increase the stress and maintain the normal force. Smaller geometry thus requires higher strength material to withstand the higher stress necessary to maintain normal force, and potentially increased conductivity to carry the current without excessive temperature rise.

MATERION

©2020 Materion Brush Inc.

The current design parameters are:

- Contact material = phosphor bronze A C51000 (spring temper)
- Modulus of elasticity, E=16 x 10^6 psi (11,300 kg/mm^2)
- Yield strength, YS = 100,000 psi (70.3kg/mm^2)
- Beam length, L = 0.150 inches (3.8mm)
- Beam width, w = 0.040 inches (1.0mm)
- Beam thickness, t = 0.010 inches (0.25mm)
- Deflection, d = 0.007 inches (0.18mm)

The normal force was calculated using the following equation:

$$Normal\ Force, P = \frac{dEwt^3}{4L^3}$$

The normal force was found to be 150 grams (1.47 N). This design point achieves a reliable connection for this fictitious application. The next parameter to determine is the design stress. The following equation calculates design stress:

$$\sigma_{Max} = \frac{3dEt}{2L^2}$$

The design stress is 75,000 psi (52.7kg/mm^2) which is below the 0.2% yield strength of 100,000 psi (70.3 kg/mm^2) and is therefore acceptable.

The new design will be half the size of the original design and the new design parameters are:

- Contact material = phosphor bronze A C51000 (spring temper)
- Modulus of elasticity, E = 16 x 10^6 psi (11,300 kg/mm^2)
- Yield strength, YS = 100,000 psi (70.3 kg/mm^2)
- Beam length, L = 0.075 inches (1.9mm)
- Beam width, w = 0.020 inches (0.5mm)
- Beam thickness, t = 0.008 inches (0.2mm)
- Deflection, d = 0.0035 inches (0.09mm)

Here the normal force is constant as required for a reliable connection and the other dimensions downsize accordingly. The design stress using the formula previously mentioned with the changed dimensions is 120,000 psi (84.4 kg/mm^2). The design stress now exceeds the yield strength of the material and is unacceptable. The high design stress requires a material with higher yield strength. The new material chosen is Alloy 25 (C17200) with ½ HT temper.

The critical design parameters for this alloy are:

- Contact material = copper beryllium Alloy 25 (C17200) – ½ HT temper
- Modulus of elasticity, E = 19 x 10^6 psi (13,500 kg/mm^2)
- Yield strength, YS = 180,000 psi (126.6 kg/mm^2)
- Beam length, L = 0.075 inches (1.9mm)
- Beam width, w = 0.020 inches (0.5mm)
- Beam thickness, t = 0.008 inches (0.2mm)
- Deflection, d = 0.0035 inches (0.09mm)

The recalculated design stress using copper beryllium is 140,000 psi (98.9 kg/mm^2) which is well below the 180,000 psi (126.6 kg/mm^2) yield strength of the material. The normal force is now 183 grams (1795 N). To further emphasize the economy of copper beryllium, a thickness reduction to 0.0075 inches (0.2mm) lowers the normal force back to the design point of 150 grams (1471 N). This thickness reduction lowers the design stress to 133,000 psi (93.5 kg/mm^2).

DRAFT REVISION

Section XIII: Design & Analysis

Connectors and interconnection systems are required to transport data and power signals in electrical and electronic systems. Poorly designed connections can ruin otherwise well designed systems. The integrity of the entire system depends on the performance of the individual conductors, terminals, connectors, sockets, etc.

Methods

Computer Aided Design (CAD)

Connector designs today are frequently constructed as three-dimensional (3D) mathematical solid models with mass properties instead of two-dimensional (2D) drawings due to the availability of computer aided design software packages.

The main reasons for the move to solid models is that solid modeling packages can serve as a means of portraying parts for study by cross-functional concurrent engineering teams. Providing data for analysis tools, numerically controlled machining, and additive manufacturing (3D printing) are three such uses.

Design for Manufacturability

The need for higher volume production, enhanced interchangeability, and cost reduction has led to the development of what has become known as statistical tolerance analysis. The primary aim of such analysis is the computation and subsequent analysis of the mathematical probabilities related to the likelihood of exceeding manufacturing specifications. The underlying concepts of statistical analysis are being integrated with the notion of designing for manufacturability. The basic thrust of this philosophy relates to the simultaneous optimization of customer satisfaction and production costs. This implies a marriage between engineering tolerances and manufacturing capability. By jointly studying assembly tolerances and manufacturing performance from a statistical point of view, an organization can enjoy higher manufacturing yields and lower cost.

Figure XIII-1 Arithmetic Worst Case Tolerance Analysis Example




Figure XIII-1 Arithmetic Worst Case Tolerance Analysis Example
The arithmetic worst case is found by simply adding up the extreme values of the tolerances. For example, the worst case (maximum possible) gap would be the maximum permissible width of the space on part E1, coupled with the minimum possible widths on parts P1 through P4. In this example, the arithmetic worst case for a maximum gap is 0.031, (194% of nominal) while the worst case for a minimum gap would be 0.001 (6.25% of nominal). If a tighter tolerance on the gap is required, the only way to improve it would be to improve the tolerances on each of the individual components.

Figure XIII-2 Contact Load Error Due to Thickness Tolerance




Figure XIII-2 Contact Load Error Due to Thickness Tolerance
Since contact force in a cantilever beam is a cubic function of material thickness, any small variation in thickness will have a much larger effect on contact force. The green line represents the expected variation in contact force for spring materials made with standard ASTM B248 thickness tolerances. At thinner gauges, the variation is greater than +/- 60%. ASTM B248 provides a special tighter tolerance, which reduces the variation. Materion standard tolerances reduce the variation even further.

©2020 Materion Brush Inc.

Tolerance Analysis

Tolerance analyses are tools to achieve the goal of higher product quality by minimizing the impact of tolerance build-up during assembly and mating. Several types of analyses are available:

- **Arithmetic Worst Case (AWC)** is simple linear addition and subtraction of tolerances, each at their worst case condition. This method produces an overly conservative design and does not take into account the statistical probability of an interference fit. The analysis considers the linear extremes of design specifications without regard to process capability. Worse case analysis applies best when the number of parts in an assembly is less than four (Figure XIII-1).
- **Root Sum of Squares (RSS)** is less conservative than AWC tolerance analysis. RSS assumes that the print tolerance equals +/-3 standard deviation (σ) limits and that the part nominal equals the print nominal. This analysis exploits the manufacturing probability that a part is not always at its minimum or maximum value. It does not take into account process mean shifts (tool wear) and assumes the process is always centered.
- **Dynamic Root Sum of Squares (DRSS)** is less conservative than RSS analysis. This method factors in the process mean shift by adding the actual process capability index (C_{pk}) into the equation. Whenever process capability at the component level decreases, the likelihood of assembly decreases. This method inflates the assembly standard deviation, but has little impact on the overall assembly mean (random process mean shift).
- **Static Root Sum of Squares (SRSS)** postulates sustained mean shift conditions of each component in the assembly.

Dimensional Tolerances

In addition to assembly tolerances, tight thickness tolerance is essential to the manufacture of precision stamped strip metal springs since contact or normal force varies as a cubic function of thickness. The normal force equation illustrates this. Figure XIII-2 demonstrates the potential normal force error for different tolerance levels. Tables XIII-1 through XIII-6 provide strip, wire and rod dimensional tolerances in US Imperial and SI Units. Tighter tolerances than those listed also can be achieved. Contact Materion with your specific requests.

Parametric FEA

Parametric FEA allows the user to vary parameters such as dimensions, loads, and material properties within set limits, to study the effects of tolerances on the outcome. Typically, a maximum, a minimum, and a nominal value for all important parameters would be necessary to determine the worst case outcome and to identify the potential failure modes and sites.

Structural Analysis

In the design and analysis of any connector, a systematic approach is desirable. Engineers new to connector design often neglect the effects of stress caused by assembly, handling, shipping, processing, temperature and other environmental changes. The simple analysis techniques presented here assist the design engineer in developing new designs, by demonstrating how to handle anticipated loading while keeping stress and strain within acceptable limits. This section applies simplified classical stress and deflection equations to connector designs. Increased complexity designs requiring very accurate results require more exact classical methods or computerized finite element analyses.

Table XIII-1- Strip Dimensional Tolerances - US Imperial Units

Strip Thickness (inches) Over	Including	Materion Standard Tolerance (+/- inches)
	0.0020	0.00010
0.0020	0.0040	0.00015
0.0040	0.0060	0.00020
0.0060	0.0090	0.00025
0.0090	0.0130	0.00030
0.0130	0.0260	0.00040
0.0260	0.0370	0.00600
0.0370	0.0500	0.00800
0.0500	0.0750	0.00100

Table XIII-2 - Strip Dimensional Tolerances - Metric/SI Units

Strip Thickness (mm) Over	Including	Materion Standard Tolerance (+/- mm)
	0.05	0.003
0.05	0.10	0.004
0.10	0.20	0.006
0.20	0.30	0.008
0.30	0.70	0.001
0.70	1.00	0.016
1.00	1.30	0.020
1.30	2.00	0.025
0.0500	0.0750	0.00100

continued on next page

©2020 Materion Brush Inc.

Table XIII-3- Wire Dimensional Tolerances - US Imperial Units			
		Materion Standard Tolerance	
Wire Diameter (inches)		Cold Drawn (+/- inches)	Annealed (+/- inches)
0.030	0.0080	0.0003	0.0010
0.080	0.1250	0.0004	0.0020
0.125	0.2500	0.0006	0.0020
0.250	0.3125	0.0007	0.0020
0.313	0.4060	0.0010	0.0020
0.406	0.5000	0.0010	0.0020

*Note: Out of Round tolerance is 50% of the diameter tolerance

Table XIII-3- Wire Dimensional Tolerances - Metric/SI Units			
		Materion Standard Tolerance	
Wire Diameter (mm)		Cold Drawn (+/- mm)	Annealed (+/- mm)
0.80	1.5	0.01	0.03
1.50	2.0	0.01	0.03
2.00	3.8	0.02	0.05
3.80	12.0	0.03	0.05

*Note: Out of Round tolerance is 50% of the diameter tolerance

Table XIII-5 - Rod Dimensional Tolerances - US Imperial Units			
Cold Drawn or Annealed Rod Diameter (inches) Over Including		Materion Standard Diameter Tolerance (+/- inches)	Materion Standard Out of Round Tolerance (+/- inches)
0.0300	0.0080	0.0003	0.0003
0.0800	0.1250	0.0004	0.0004
0.1250	0.2500	0.0006	0.0004
0.2500	0.3125	0.0007	0.0007
0.3125	0.375	0.001	0.001
0.375	0.500	0.002	-
0.500	1.00	0.003	-
1.00	2.00	0.004	-
2.00	3.00	0.2% of Size	-

Table XIII-5 - Rod Dimensional Tolerances - Metric/SI Units			
Cold Drawn or Annealed Rod Diameter (mm) Over Including		Materion Standard Diameter Tolerance (+/- mm)	Materion Standard Out of Round Tolerance (+/- mm)
0.76	2.00	0.008	0.008
2.0	3.2	0.010	0.010
3.2	6.4	0.015	0.010
6.4	7.9	0.018	0.018
7.9	9.5	0.025	0.025
9.5	12.0	0.05	-
12.0	25.0	0.08	-
25.0	50.0	0.10	-
50.0	75.0	0.2% of size	-

Spring Types (Figures XIII-2 through XIII-7)

Cantilever Beam – This a spring which is held fixed on one end and is free to deflect on the other. This kind of spring is loaded in bending. The majority of spring contacts in electrical and electronic connectors fall into this category.

Torsion Beam (Louvered Contact) – This is a spring which is held fixed on one or both ends, with the span free to rotate under load. This design features a long wiping action on insertion and high contact stress. This kind of spring is loaded in torsion.

Simply Supported Beam (Arch Beam or Leaf Spring) – This is a spring which is held fixed on one end with the other end free to move in only one direction. The loading is applied between the supports, and causes the beam to bend. This design is 8 times stiffer than a cantilever beam of similar dimensions, and is often seen in automotive terminals and power connectors.

Figure XIII-3 Spring Types - Beams




Figure XIII-3 Spring Types – Beams
The three types of beams are cantilever, torsion, and simply supported. Most electrical contacts, switches, relays, etc. fall into one of these 3 categories.

©2020 Materion Brush Inc.

Conical Spring (Belleville Washer) – These springs show a nonlinear relationship between deflection and contact force. They can be stacked in nesting or anti-nesting configurations to provide a wide variety of force-deflection characteristics. During snap-through, they may show a negative spring constant.

Compression and Extension Springs – These springs are made of coiled wire, usually spiraled into a cylindrical shape, and are familiar to virtually all people. In electrical connectors, these are generally used as back-up springs to other spring contacts, or as battery contacts in electronic devices. This kind of spring is loaded in torsional stress.

Bellows and Diaphragms – Repeated folds on the surfaces of these spring types provide predictable and precise response to pressure and force changes, making these ideal for high accuracy pressure and force gauges.

Torsion Spring – These are made of wire coiled into a flat spiral. The stress-state in these springs under load is bending. These are typically not seen in electrical/electronic connectors.

Figure XIII-4 Spring Types – Spring Washers




Figure XIII-4 Spring Types – Spring Washers
The three basic types of spring washers are curved, conical (Belleville washers), and wave springs. All 3 types can be stacked in parallel (center row), and all but the curved washer can be stacked in series (which may require spot welding) as seen in the bottom row. Parallel stacking increases the spring rate (more force per unit deflection), and series stacking increases the resilience (more deflection per unit force). Series and parallel stacking can be combined to provide an unlimited (except by stack height) combination of force/deflection combinations. Belleville washers have unusual nonlinear spring rates. See Technical Tidbits Issue #80 for more information on Belleville washer stiffness.

Figure XIII-5 Spring Types – Coil Springs




Figure XIII-5 Spring Types – Coil Springs
The ends of coil springs can be open, flat, or ground. They can be loaded in extension or compression. Pitch and diameter can be either constant or variable. When these springs are compressed or extended, the wire is actually loaded in torsion.

©2020 Materion Brush Inc.

For additional information (such as force-deflection and stress-deflection equations) on these and other spring types, please refer to Technical Tidbits Issues number 75 through 84. A quick summary is as follows:

- **Cantilever beam –** simple, allows one-piece designs, has good spring rate, highest temperature rise
- **Arch (simply supported) beam –** stiffer than cantilever beam, more linear than torsion beam, lowest temperature rise
- **Torsion beam –** stiffest design, has a high insertion force, and better durability
- **Coil spring –** large deflection & low stress, but very low spring rate; may be nested to increase spring rate, most often used in electronics as a backup spring

Figure XIII-6 Spring Types – Bellows and Diaphragms




Figure XIII-6 Spring Types – Bellows and Diaphragms
The cutaway views on the bottom show the corrugations (in the bellows) and convolutions in the diaphragms that spread stress and strain over the entire surface, allowing for very precise and predictable pressure deflection (or force-deflection) behavior.

Figure XIII-7 Miscellaneous Spring Types




Figure XIII-7 Miscellaneous Spring Types
While torsion springs are macroscopically loaded in torsion, the wire itself is actually loaded in bending. C -rings and garter springs clamp radially around an object and compress inwards, or press radially outward when fit into a groove on the inside of a curved surface. Volute springs are compression springs in which friction between the wraps increases the stiffness. Spiral springs converts linear motion to stored torque, and vice versa. Spiral springs can be used as clock springs to store and gradually release energy such as in wind-up toys and watches. Constant force springs are spiral springs designed to provide constant force vs deflection behavior.

Loads

The first step in analyzing any part is to determine the part loading. These loads generally fall into two categories:

Directly Applied Loads – These are loads applied to defined areas of the part, either concentrated at a point, line or boundary, or distributed over an area. Service conditions determine the magnitude and direction of such loads.

Strain Induced Loads – Frequently, loading is a result of deflection. The actual load results from the structural reaction of the part to the applied strain. Unlike directly applied loads, strain induced loads depend on the modulus of elasticity of the material.

Support Conditions

For the part to remain in equilibrium, there must be equal forces acting in the opposite direction to the applied forces during loading. The balancing forces take the form of reactions at the supports. Several support conditions are demonstrated in Figure XIII-8:

Free (Unsupported) – The edge of the body is totally free to translate (move in a straight line) or rotate in any direction.

Guided – This is similar to a free end except that the edge is prevented from rotating. It is only allowed to translate.

Simply Supported – The transverse displacement in one direction is restricted.

Held (Pinned) – This is similar to simply supported except that only rotations are allowed.

Fixed (Clamped) – All displacements and rotations are prevented, such as in an end support firmly embedded in a fixed wall.

Figure XIII-8 Support Conditions




Figure XIII-8 Support Conditions
These are the six possibilities for support conditions in 2 dimensional simulation. There are two translational degrees of freedom (DoF), and one rotational. In 3D analysis, there are two additional rotational DoF's, and one additional translational DoF.

MATERION

©2020 Materion Brush Inc.

When analyzing a particular design using classical mathematical equations, the accuracy of the result depends on the assumptions used during the calculations.

Simplifications and Assumptions:

1. The part under load can be broken down into one or more simple structures, beams and/or plates for analysis.
2. The material being analyzed may be considered to be linearly elastic, homogeneous and isotropic.
3. The equations assume that the load is a single concentrated or distributed static load, gradually applied for a short period of time and then removed. However, the same equations can be used to analyze relaxation and fatigue loads, using the appropriate modulus.
4. The part being analyzed has no residual stress.
5. The equations apply to regions that are remote both from the point of application of the load and from any stress riser such as a shoulder, hole or change in dimension of the part.

The equations may be used at shoulders, holes or other sudden dimensional changes as long as appropriate stress concentration factors are used.

Section properties for some common cross-sections (Figure XIII-9):

Rectangular:

$$Area, A = b \cdot h$$

$$1st\ Moment\ of\ Inertia, I = \frac{b \cdot h^3}{12}$$

$$Section\ Modulus, Z = \frac{b \cdot h^2}{6}$$

$$Polar\ Moment\ of\ Inertia, J = \frac{b \cdot h \cdot (b^2 + h^2)}{12}$$

Circular:

$$Area, A = \frac{\pi \cdot d^2}{4}$$

$$1st\ Moment\ of\ Inertia, I = \frac{\pi \cdot d^4}{64}$$

$$Section\ Modulus, Z = \frac{\pi \cdot d^3}{32}$$

$$Polar\ Moment\ of\ Inertia, J = \frac{\pi \cdot d^4}{32}$$

Maximum stress and deflection equations for selected beams

Cantilevered beam (one end fixed), concentrated load at free end:

(At support) $Stress, \sigma = \frac{FL}{Z}$

(At load) $Deflection, y = \frac{FL^3}{3EI}$

Cantilevered beam (one end fixed), uniformly distributed load:

(At support) $Stress, \sigma = \frac{FL}{2Z}$

(At free end) $Deflection, y = \frac{FL^3}{8EI}$

Simply supported beam, concentrated load at center:

(At support) $Stress, \sigma = \frac{FL}{4Z}$

(At load) $Deflection, y = \frac{FL^3}{48EI}$

Torsion beam (one end fixed), concentrated torque at free end:

(At support) $Torsional\ Stress, \tau = \frac{Tr}{J}$

(At load) $Rotation, \theta = \frac{TL}{GJ}$

Figure XIII-9 Common Cross-Section Properties




Figure XIII-9 Common Cross-Section Properties

The beam cross section helps to determine the stiffness behavior of the beam. More specifically, the stiffness in tension depends on the cross sectional area (A), the stiffness in bending depends on the 1st moment of inertia (I), and the stiffness in torsion depends on polar (second) moment of inertia (J), which are all properties of the cross section. The neutral axis would typically pass through the centroid of the cross section. The variable c is the distance between any point and the neutral axis.

Figure XIII-10 Embossing to Increase Stiffness




Figure XIII-10 Embossing to Increase Stiffness

By putting an embossment in the beam, you can greatly increase the stiffness without having to change the width or thickness of the input material. In this example, the two cantilever beams shown above have the same thickness and overall width, and are given the same deflection at the end. The beam with the embossment has a higher stress and much higher contact force than the beam with the rectangular cross section. Such an embossment can be carried into the contact zone, to further increase the contact pressure. (See Figure IV-5)

©2020 Materion Brush Inc.

You are not limited to simple, regular cross sections when you stamp materials. You have the freedom to change the stiffness by adding hems, folds, embossments, slots, etc. Figure XIII-10 shows one such example, where you can use an embossment to increase the stiffness. Figure XIII-11 shows how you can use the different types of beams to achieve similar results.

As shown, handbook solutions are available for simple structures and loading conditions. Additional cantilever beam equation transforms are located in the Appendix. Complicated shapes or complex loading conditions require a more accurate method than standard beam equations. Finite Element Analysis is one such method.

Figure XIII-11 Maximum Stress and Deflection Example




Figure XIII-11 Maximum Stress and Deflection Example
Simply supported beams are much stiffer than cantilever beams, and require about 16 times as much force to achieve the same deflection. (Alternatively, you could say that simply supported beams provide 16 times more force for a given deflection than cantilever beams.)

Simulation

There are multiple types of computer simulation, as follows:

- FEA (Finite Element Analysis) – predicts mechanical stresses, strains, displacements, forces, pressures, temperatures, electric current flow, heat transfer, etc.
- CFD (Computational Fluid Dynamics) – predicts fluid flow around and through solid objects, including convective heat transfer
- BEM (Boundary Element Method) – predicts the interaction of electrical and magnetic fields with nearby objects
- SPICE (Simulation Program with Integrated Circuit Emphasis) – predicts the behaviors of electrical circuits and circuit elements
- And many, many more…

Figures XIII-12 and XIII-13 highlight the benefits of simulation, while the latter also provides some caveats. For more information, see the Whitepaper "Why Engineering Simulation is Critical to Your Smart Products Success in the Internet of Things, available from ANSYS.

Figure XIII-12 Why Simulate




Figure XIII-12 Why Simulate
The left side of the figure indicates a design cycle without simulation. The relative cost of each step is indicated by the number dollar signs. If the built part does not work after testing, it must be redesigned. There may be several passes through this loop until the design is perfected, with each step being fairly costly. The right side of the figure indicates a design cycle with simulation. If the simulation does not indicate that the part will work, it must still be redesigned. However, this loop only passes through low cost steps. If the analysis is done properly, the expensive build and test phases would only need to be done once. If the analysis is not done properly, there will be at least one more loop through the expensive part of the cycle, which underscores the importance of accurate simulations.

MATERION

©2020 Materion Brush Inc.

Finite Element Analysis (FEA) is a computer-based technique for analyzing the mechanical, thermal, or electrical behavior of a structure or component. The inputs and results may be either static or time-dependent. FEA can be used to find potential design problems before a physical prototype of the part is made, since it is much easier and cheaper to make changes in an electronic model than to make changes in physical tooling. Used properly, FEA will minimize the number of prototype models and tooling changes. However, the finite element method is only a model of reality whose accuracy depends on the skill of the modeler and the accuracy of the loads and boundary conditions. The computed results are based on interpolations that only approximate reality. It is still advisable to create and test prototypes to verify the design. Some common forms of FEA are as follows:

- Mechanical (Stress)
- Electromagnetic (High/Low Frequency)
- Thermal (Heat Transfer)
- Dynamic (Frequency Response, Vibration)
- Fluid Dynamics
- Fatigue
- Design Optimization
- Multiphysics (Combination of two or more of the above)

Mechanical FEA finds stresses, deformations, and reaction forces in a structure due to applied forces, pressures, or deflections. The finite element method divides a complicated structure into many small elements with easily defined stress and deflection characteristics based on a series of differential equations. FEA programs assemble the differential equations governing each of the individual elements into global matrices, and then solve the system of thousands of simultaneous equations. FEA uses the following steps:

1) Geometry Development – The first step in Finite Element Analysis is the creation of a geometric model. The modeler typically uses a front-end CAD program to create three-dimensional (3D) representation of the product geometry as previously described. The meshing process later breaks the structure into simple standardized shapes or elements with a common coordinate grid system (Figures XIII-14 & XIII-15). The coordinate points, called nodes, are locations in the model that provide output data. Strains, displacements and stresses are transmitted between elements through common nodes. Element selection is a function of product geometry and loading conditions. The element selected affects the results as each element has characteristic properties. A model can use more than one type of element. The list below contains some of the element types and their properties:

- 2D elements = all forces and displacements act in a single plane
- Axisymmetric elements (2D) = node displacements in radial and axial directions – model is taken as a cross-sectional slice of an object with rotational symmetry
- 3D elements = forces and displacements in all three dimensions or complex geometry
- Specialty elements = shell, plate and beam

Figure XIII-16 shows some common element types.

Figure XIII-13 Simulation

Benefits

- Almost anyone can do it
- Produces convincing graphics
- Can increase your confidence of reliability

Disadvantages

- Almost anyone can do it
- Produces convincing graphics
- Can increase your confidence of reliability

Figure XIII-13 Simulation
Yes, the advantages and disadvantages are intentionally identical. With easier to use CAD and FEA programs, almost anyone can do it. This means it no longer requires an engineer with a PhD to do the analysis. This opens simulation to all companies and engineers. The downside of this is that is difficult to determine if the person who ran the simulation was properly trained to do so. If you are trying to sell your design, the graphical outputs can be very convincing. This is good if the simulation was done properly, and will help to get a good design built and used. However, if the simulation was done improperly, the graphics could easily convince someone to build or use a flawed design. A good simulation gives you the confidence to go ahead and build that prototype for test, as it will most likely work. However, a bad simulation can also give you false confidence to proceed with a bad design.

Figure XIII-14 Finite Element Model




Figure XIII-14 Finite Element Model
The most important consideration for getting accurate simulation results is inputting accurate and appropriate loads and boundary (support) conditions. If these do not match reality, the results of the simulation will not match reality.

DRAFT

2) Material Property Assignment – Modulus of elasticity and Poisson's ratio define material the properties for each element in linear elastic mechanical analysis. A stress-strain curve represents the material properties for a non-linear material condition (elastic-plastic). Section IV-Connector Base Metals and Their Properties defines one such curve.

3) Mesh Generation – Based on the element types selected, automatic mesh generation subdivides the geometry into a finite number of elements. The element density within each segment of the product geometry is either specified by the analyst or automatically determined. The nodes and elements defining the geometry of the structure comprise a mesh. A finer mesh size will improve accuracy, although it also will increase computation time. Elements can be either high order or low order. Higher order elements improve accuracy by using additional nodes in each element (Figure XIII-16), although they also increase computation time. The finite element program calculates nodal stiffness properties for each element and arranges them into matrices. The appropriate matrix transformation generates a global stiffness matrix from the existing element matrices. Figure XIII-17 shows the same part modeled and meshed using a number of different element types.

4) Boundary Conditions – The appropriate boundary conditions apply constraints to the model (fixed, simply supported, etc.)

5) Load Application – Forces, pressures, temperatures, etc. are applied to the model. Together, the loads and boundary conditions describe the interaction of the part with its environment.

6) Run Analysis – The program processes the equation matrices with applied loads and boundary conditions to calculate displacements, strain, natural frequencies or other outputs requested by the user. The simulation generates a stress distribution across the entire model. To minimize computational errors, the high stress regions also should have the highest element density and each individual element should have a small stress gradient across itself. Various adaptive methods find the critical regions in the model and make the necessary mesh refinement to reduce the error for the next iteration before reaching convergence.

Static analyses such as deflection, stress and strain under a constant set of applied loads are the most common types of analysis. The material is usually assumed to be linear and elastic, but the analysis of non-linear behavior such as plastic deformation, creep and large deflections is possible. Nonlinear analysis is increasingly common, especially as more parts are designed with stresses close to or exceeding the yield strength.

Since FEA is highly sensitive to the geometric accuracy of the model as well as its loads and boundary conditions, it will typically predict relative changes in deflection and stress better than absolute deflection and stress. Therefore the proportional difference of two structures is usually more accurate that the absolute results.

Figure XIII-15 Finite Element Mesh




Figure XIII-15 Finite Element Mesh
The complicated part is divided into many smaller, simply shaped elements. The elements intersect at points called nodes, where information is passed from element to element. A finer mesh will generally be more accurate. Inaccuracies in the solution can come from poorly shaped elements, or from sharp corners.

Figure XIII-16 Element Types




Figure XIII-16 Element Types
These are the basic types of elements, used in 2D (triangle and plane) and 3D (shell, solid, tetrahedral) analyses. Lower order elements use linear interpolation of calculated results (such as stress, strain, heat flux, electric field strength, etc.) throughout the element volume, while higher order elements use polynomial interpolation.

©2020 Materion Brush Inc.

7) Results – Results usually include an output file and graphical displays of the results images (Figure XIII-18).

Typical connector FEA results include:

- Deflected contact shapes during and after mating
- Beam and contact stresses
- Interferences
- Normal forces
- Mating force vs. deflection curve
- Thermal effects
- Behavior under shock and vibration

8) Check Results – Compare results to estimated values using hand calculations to see if results are of proper order of magnitude and approximately where they should be. If not, double-check model geometry, loading, and boundary conditions. Make corrections as necessary and re-run the analysis.

9) Data Correlation – Collect experimental data to correlate the FEA model results and to formulate a baseline.

10) Design Optimization – After comparing the baseline results, modify the design as appropriate and repeat the modeling process. This iterative process is design optimization. Design optimization combines the engineering requirements, geometric parameters, CAD model and performance goals into a computer simulation to achieve the optimum design.

Figure XIII-17 Element Type Examples




Figure XIII-17 Element Type Examples
This is an example of the same part meshed with different elements, in each case using the minimum number of elements required to obtain the same (accurate) results. 2D and shell elements dramatically reduce the number of nodes and elements, and thus the computational time and resources. These should be used whenever appropriate in order to minimize the analysis time.

Figure XIII-18 Finite Element Model Example




Figure XIII-18 Finite Element Model Example
This is an example of a static structural analysis using shell elements, where a part representing a cantilever beam is fixed around the circular hole, and deflected by a point load at the free end. Potential results include deformed shape, displacement, stress, and strain at each point in the analysis, as well as permanent set after load removal.

©2020 Materion Brush Inc.

Figure XIII-19 FEA Stress-Strain Behaviors




Figure XIII-19 FEA Stress-Strain Behaviors
The blue line above indicates the average stress-strain curve of a number of samples of the same material, temper, and thickness. The red line indicates linear stress-strain (force-deflection) material behavior. Since linear analyses converge to solution faster than non-linear, use this as a first step to see if further analysis with nonlinear properties is necessary. If the stresses are less than about 75% of the yield strength, the linear material properties would be adequate. If not, you should run the analysis again with nonlinear material behavior. If the amount of plastic strain is small, and the stress-strain curve has two distinct regions, a bi-linear curve (green line) may be used. However, with today's readily available computing power, it is just as easy to enter the entire stress-strain curve. The dashed lines show the six-sigma variation on the averages curve, which is another potential source of deviation between the model and reality.

Figure XIII-20 Variation of Material Properties vs. Material Model Used




Figure XIII-20 Variation of Material Properties vs. Material Model Used
Most tensile tests measure the engineering stress-strain curve (blue line). Most FEA software packages prefer to simulate with the true stress-strain curves. Luckily, since thin gauge strip and small diameter wire have very little non-uniform elongation before fracture, the true curves are easily calculated from the engineering curves, accurate almost all the way to failure. This chart also shows how a bilinear approximation using the elastic modulus and the tangent modulus can miss significant stress-strain behavior, particularly if the curves deviate significantly from linear behavior.

Caveats for Finite Element Analysis

The accuracy of the analysis depends on the geometric accuracy of the model, the assumptions used during the modeling process, as well as how the loads and boundary conditions are applied. There are many sources of error and variation from reality in any given model. Some common sources are listed below.

- Oversimplification of model
- Element type/size
- Nonlinearities
- Definition of boundary/initial conditions
- Frictional effects
- Material property variation
- Stiffness singularities
- Dimensional tolerances
- Edge condition/cross-section uniformity
- Residual stresses
- Forming history

Oversimplification of the Model – The more complicated a model is, the longer it will take to run and the greater amount of disk space it requires. There is a trade-off between accuracy and run time. In simple 2D models this is rarely an issue, since these can run in just a few minutes time. Complicated 3D models can take hours or days to run, assuming that there is enough RAM and disk space available on the host computer. One way to solve this issue is to simplify the model by taking advantage of symmetry and modeling only a portion. At other times, features that are small relative to the rest of the model can be removed from the model in order to decrease the run time. However, if such a feature is a severe stress riser in reality or if it plays a critical function, then the analysis will completely miss this important factor.

Element Type and Size – As stated earlier, smaller elements and higher order elements improve the accuracy of the model at the expense of computation time. However, the element type can play a role as well. Three-node triangular and 4-node tetrahedral elements are very stiff, and can give inaccurate results. It is better to use 4-node quadrilateral elements in 2D analysis, and hexahedral or 10-node tetrahedral elements in 3D analysis.

WATERTION

©2020 Materion Brush Inc.

Nonlinearities - Traditional Finite Element Analysis programs analyze linear problems, assuming linear elastic material behavior, small displacements relative to the overall dimensions, and constant boundary conditions. Another requirement when assuming linearity is reversibility of the process modeled. While this condition is usually satisfied in load deformation analysis, the whole premise of contact stamping is to impart permanent and irreversible deformation to the work piece. The nonlinearities encountered in contact stamping fall into three major categories:

- **Material:** Materials may show elasto-plastic (yielding or strain hardening) behavior, strain rate sensitivity, and anisotropic behavior due to rolling. (See Figures XIII-19 and XIII-20)
- **Geometry:** The part may undergo large rotations and deformations, so small angle approximations no longer hold. All connectors will fall under this category, so the large displacement option in the analysis program must be turned on.
- **Boundary Conditions:** Some nonlinearity is due to constantly changing contact between the part being modeled and its environment, or the part may make contact with another part of itself. This results in rapidly changing stiffness (Figure XIII-21).

Definition of Boundary/Initial Conditions – There can be significant differences in the analysis results based on subtle differences in the way that the boundary conditions are applied. An example is shown in Figure XIII-22, where two identical cantilever beams are given the same deflection. In one, the fixed end is completely constrained, with no possibility of movement. In the other beam, the fixed end is embedded in a flexible wall, with a small amount of movement allowed. The former case is the boundary condition that normally would be assumed for an analysis, while the latter may better represent a contact molded into a flexible housing or inserted into a flexible PCB. Note the significant difference in contact force and stress distribution.

Figure XIII-21 Effect of Changing Contact on Stiffness




Figure XIII-21 Effect of Changing Contact on Stiffness
Contact makes an analysis highly nonlinear, as it changes the stiffness drastically (due to changes in support conditions). In the example above, the force deflection curve remains almost perfectly linear until the point where second contact is made, at which point it becomes nonlinear.

A second example is shown in Figure XIII-23, where a curved cantilever beam contact (such as a battery or a SIM card contact) rests on a PCB or housing. In the case on the left, the entire bottom of the contact is considered to be rigidly fixed to the PCB or housing. With the example on the right, only the far left end is considered rigidly fixed to the underlying surface, while the remainder of the bottom of the contact merely rests on the surface. Again there is a significant difference in contact force and permanent set. This illustrates the importance of exactly determining where and how the contact is attached to the surrounding components.

Figure XIII-22 Rigid vs. Flexible Boundary Conditions




Figure XIII-22 Rigid vs. Flexible Boundary Conditions
The contact on the left side is modeled with completely rigid behavior on the back end, while the contact on the right has some flexibility built in (which may more accurately represent how an electrical contact would be retained by a plastic housing or dielectric material). The contact force in the perfectly rigid contact is much higher than that of the contact that has a little more “slop” built into the model.

Figure XIII-23 Rigidly Fixed to Surface, or Merely Resting on It




Figure XIII-23 Rigidly Fixed to Surface, or Merely Resting on It
This example could represent a contact that is resting on a PCB. The left edge indicates a condition reflective of having the entire bottom surface soldered to the board. The right side shows a condition where it is only soldered at the back end, while the bulk of the beam is merely resting on the surface. The right case is much less stiff than the left case, showing lower contact force and no permanent set. This further indicates the need to get all of the boundary conditions correct in the model, if you want to get simulation results that accurately reflect reality.

©2020 Materion Brush Inc.

Figure XIII-24 Direct Deflection vs Contact Deflection





Figure XIII-24 Direct Deflection vs Contact Deflection
A deflection can be applied directly to a node, or 2nd object can be used to deflect the first. The latter case is more indicative of reality, where a battery, SIM card, mating contact blade, switch actuator, etc. would actually deflect the spring contact. The big difference is that on the right side, the point of contact slides along the beam (reflective of reality) while on the left side it remains constant. This is why point displacements should be avoided, if at all possible.

Figure XIII-25 Effect of Friction



Model with Sliding Contact – Dependence of Results on Friction Coefficient

Figure XIII-25 Effect of Friction
This repeats the example shown on the right side of Figure XIII-24. In this example, the model is run with different coefficients of friction between the contact surface and the spring contact. This shows that both the contact force and the permanent set depend on the frictional behavior. Therefore, it is important to use an appropriate friction coefficient in your analysis.

Figure XIII-24 shows a third example, this time illustrating the significance of how the loading is applied. In the contact on the left, the deflection of the contact is modeled by prescribing the displacement of the topmost node. In the contact on the left, a surface representing the mating component is used to deflect the contact by the required amount. The initial point of contact is the topmost node, which is actually deflected *more than the nominal displacement*. The contact on the right more accurately represents the real-world situation, although the former case is sometimes used in analysis as a shortcut.

Frictional Effects – For contact problems, the coefficient of friction at the interface must be specified. Figure XIII-25 shows results for the same contact shown in the right side of Figure XIII-24, as a function of the coefficient of friction. In reality, the friction coefficient of the interface will vary as a function of the hardness and roughness of the contact surfaces, as well as the presence of lubrication and even the amount of contact force. A value of 0.3 is typically used to represent gold-on-gold contact. Friction is a factor that the designer has little control over, so the value used in the analysis should be reported with the results, if applicable.

Material Property Variation – The material properties specified in FEA may be the nominal values, or some average value of production material. However, there always will be slight property variations within the specification range for a given alloy and temper. The properties usually will be very consistent within a slit coil, although there may be variation from slit-cut to slit cut, and from heat to heat. (Figure XIII-26 and XIII-27).

©2020 Materion Brush Inc.

Figure XIII-26 Variation of Material Properties




Figure XIII-26 Variation of Material Properties
Since all material properties experience some sort of natural variation, it is important that your model take this into account. If you run the analysis using only nominal material properties, there will be a certain margin of error. However, you can also run it with the +3 sigma and -3 sigma standard deviations, in order to account for the six sigma variation in materials. This will give you a best case and worst case boundaries for performance vs. material condition. Geometric variation is another story. It would take a little more work to determine what the best case and worst case would be for the sum of all the individual geometric tolerances. Materion will provide you with the appropriate stress-strain curves, with standard deviations listed, for your simulation work.

Figure XIII-27 Distribution of Material Properties




Figure XIII-27 Distribution of Material Properties
Since all materials will show variation in material properties, it is always best to design to the specification minimum of the material, or specify the minimum required when ordering. Actual material will most likely be normally distributed around the specification center, but there could be outliers that might not meet a very tight safety factor, but would still be within specification.

MATERION

Types of Properties

Material Properties are known and measurable by standard test methods for each material.

Examples include:

- Physical properties are generally not temper dependent (i.e., they do not change significantly with processing). Examples include density, elastic modulus, Poisson's ratio, etc.
- Mechanical properties do change significantly with the temper (how the material was processed). Examples include yield strength, tensile strength, fatigue strength, impact strength, ductility, strain hardening coefficient and strain hardening exponent, etc.
- Electrical and magnetic properties include electrical conductivity, permittivity, permeability, Curie temperature, etc.
- Thermal properties include thermal conductivity, specific heat, thermal expansion coefficient, etc.
- etc.

Material properties may be functions of the following:

- Temperature (Strength, Conductivity, Specific Heat, Toughness – See Figure XIII-28)
- Strain Rate (Strength, Toughness)
- Electric Field Strength (Permittivity)
- Magnetic Field Strength (Permeability)
- Pressure (Melting/Freezing Temperature)
- Frequency (Dielectric Constant)
- Time (Stress Relaxation)

Figure XIII-28 Material Variation with Temperature




Figure XIII-28 Material Variation with Temperature
Many properties are temperature dependent. If your simulation includes temperature rise or operation at elevated temperatures, please ensure that your model reflects the expected changes in material properties. In copper alloys, yield strength, tensile strength, fatigue strength, elastic modulus, and electrical conductivity all fall with temperature. On the other hand, thermal conductivity rises with temperature.

Figure XIII-29 Appropriate Direction for Stress Strain Curves in Analysis




Figure XIII-29 Appropriate Direction for Stress Strain Curves in Analysis
Use the stress strain curve that matches the direction of the beam length, whether it is a cantilevered, simply supported, or louvered beam. For parts machined out of rod or wire, the beams are almost always oriented down the length of the rod, so axial (longitudinal) direction stress-strain curves are appropriate. (This is fortunate, since it is impossible to measure stress-strain curves in any other direction in wire or small diameter rod.) In strip, transverse beam orientation almost always optimizes the layout for minimal scrap, so most stamping dies are laid out with the springs oriented in the transverse direction. Unfortunately, ASTM requires certification of properties in the longitudinal direction only, so transverse properties need to be measured as a special order, if not already available.

©2020 Materion Brush Inc.

System Properties come from the combination of material properties, the applied loading conditions, and the specific environmental conditions. Examples include coefficient of friction, contact resistance, etc. The components of system properties have complex and confounding interactions with each other.

System properties may be functions of

- Contact Force (Friction, Contact Resistance)
- Surface Roughness (Friction, Dielectric Constant)
- Velocity (Friction)
- Surface Coatings and Contamination (Contact Resistance, Friction)
- Environmental Conditions (Contact Resistance, Friction)
- Time (Contact Resistance)
- Distance (Capacitance)
- Length (Resistance, Inductance)
- Surface Area (Capacitance)
- Hardness (Wear, Friction, Contact Resistance)
- Temperature (Contact Resistance)

Anisotropy - Longitudinal vs. Transverse Direction Properties – Use the material properties for the direction in which the 1st principal tensile and compressive stresses are oriented. (i.e., down the length of the beam for arch, cantilever, and torsion beams). If the beams are laid out in the transverse direction (as is most often the case, then the transverse direction material properties should be used.) Otherwise, use the longitudinal direction properties. For small diameter rod and wire, it is not possible to perform tensile testing in any orientation other than longitudinal. Therefore, those properties must be used by default. See Figure XIII-29 for clarification.

Heat treated high performance alloys typically have low anisotropy compared to alloys strengthened by cold work alone, especially in the higher strength tempers.

Stiffness Singularities – As stated earlier, the finite element analysis solver arrives at a solution by solving thousands of simultaneous equations in matrix form. Certain situations arrive where the stiffness matrix can become ill-conditioned or even singular, respectively affecting the accuracy of the results or resulting in an aborted analysis. These usually occur during abrupt changes in equilibrium conditions, such as those encountered in a snap switch (Figure XIII-30) or in a long slender column on the verge of buckling. Stiffness singularities also may arise from insufficiently constrained models. Sometimes a part may not be completely fixed in reality, such as one may find in an LGA contact loosely molded into the interposer. In such a case, soft springs may be inserted into the model for stability (Figure XIII-31).

Figure XIII-30 Snap Action Stiffness Singularities




Figure XIII-30Snap Action Stiffness Singularities
Snapping is a sudden switch from one equilibrium position to another based on a small change in boundary condition. This abrupt transition may lead to stiffness singularities, which would prevent the simulation from converging to solution. In this case, the analysis would best be run with displacement or arc length control, instead of force control. Note that this is not the same as applied force or applied deflection. In force control, equilibrium forces are monitored to determine if a time step has converged to solution. In displacement control, displacements are monitored. Forces and/or displacements may be used as loads under any kind of analysis control.

Figure XIII-31 Soft Springs to Eliminate Stiffness Singularities




Figure XIII-31 Soft Springs to Eliminate Stiffness Singularities
The floating contact in the center has no connection to mechanical ground, so the stiffness matrix used to solve the finite element analysis would be singular, and the analysis would not converge to a solution. By fixing the contact to ground via very soft springs (1-dimensional beam elements with very low stiffness and prescribed cross section), the FEA program will find an appropriate solution. The springs' contribution to the overall stiffness of the contact will be insignificant, since it is several orders of magnitude lower than the contact itself (and several orders of magnitude lower than the permissible error in the solution).

©2020 Materion Brush Inc.

Dimensional Tolerances – It is virtually certain that no part will come out of the fabrication process exactly matching the nominal dimensions on the print. For example, bend angles may not be exact due to springback, heat treatment distortion, or residual processing stresses in the base metal. One way to account for this would be to run parametric FEA, where the dimensions, loads, and material properties can be input as a defined set of discrete values, instead of a single value. Typically minimum, maximum, and nominal values are used. The analysis will solve all cases simultaneously. This will allow the determination of the worst-case stack-up of tolerances.

Edge Condition/Cross-Section Uniformity – CAD models usually feature smooth bends, straight smooth surfaces, and uniform cross sections. Actual stamped parts will show bends that thin and stretch in the die (Figure XIII-32), and will have burrs and non-uniform cross sections from blanking (Figure XIII-33). They may also show brushing lines on the surface from the pickling process, and orange peel on the outer bend surfaces. Other forming methods will also show differences in the shape of the edges vs. the perfect geometry of the model. Chemically etched samples will show an inverted hourglass shape, while laser cut or EDM'ed parts will have a softer recast layer on the very edge. (Figures XIII-34 through XIII-38 show the condition of the edges of parts fabricated by various methods.)

Unfavorable Tolerance Stack-ups– Another potential problem with simulation is shown in Figure XIII-39. If the worst case set of properties and geometry is not considered, the design may fail, even if the nominal design run under the nominal set of properties does not indicate any potential problem. If you do not have adequate data to check for a worst-case situation, it is better to increase the safety factor to ensure that you don't suddenly start hitting a rash of failures on a previously successful design, just because the tolerances are drifting within the normal range.

Use of Handbook or Software Library Data – Be sure that when you input the material properties, obtain them directly from your supplier. (Materion will provide you with detailed stress-strain curves and other material properties needed to run your analysis.) Most data found in engineering handbooks or in material libraries built into CAD or FEA packages will not be accurate. Usually, they will report one set of properties for copper beryllium, despite the fact that there are over 40 unique tempers, each with its own unique set of properties. Odds are good that the properties listed for generic copper beryllium will not match those of the particular alloy and temper that you are using. (See Figure XIII-40).

Figure XIII-32 Uniformity of Cross Sections

Ideal vs Theoretical X-Section




Cross-Section Assumed for Model | **Cross-Section of Actual Stamped Part**

Figure XIII-32 Uniformity of Cross Sections
Model CAD models are created assuming uniform bends and cross sections. In reality stamped materials will thin stretch in the die, and the cross section may become more trapezoidal than rectangular as the outer bend surface narrows to accommodate the strain of elongating.

Figure XIII-33 Perfect Model Geometry vs. Reality

Natural Stress Risers

- **Increase stress in surrounding areas**
- **Burrs, scratches, tooling marks, fatigue cracks etc.**



Shape Assumed for Model | **Actual Stamped Part**

Figure XIII-33 Perfect Model Geometry vs. Reality
Again, the model usually assumes perfect geometry, but the stamping and forming process will induce residual stress, and may also create stress risers such as burrs, fractured edges, tooling marks, etc. that locally increase the stress far beyond what the model will predict.

PREVIEW

©2020 Materion Brush Inc.

Figure XIII-34 Edge Condition of Various Forming Processes




Figure XIII-34 Edge Condition of Various Forming Process

These are schematic representations of the edge condition of a stamped contact. CAD models used in FEA will usually assume perfectly rectangular edges. Blanked or pierced edges will have the expected rollover, shear and fracture zones as well as burrs. In addition, the edge will be work hardened somewhat. For EDM'ed or laser cut edges, there will be a heat affected zone (HAZ) along the edge that is softer, from either being dramatically overaged, solution annealed, or melted and resolidified. Photochemically machined (photoetched) edges may be slightly tapered or hourglassed in shape. Waterjet cut edges would be closest to a perfect rectangle, with no HAZ or work hardened edge, and will typically be straight (although they will have some amount of roughness).

Figure XIII-35 Stamped Edge




Figure XIII-35 Stamped Edge

This SEM image shows the typical shape of a stamped (blanked or pierced) edge. In this picture, the fracture zone at is at the top, and the rollover zone is at the bottom. The red arrow shows the direction that the punch traveled through the strip.

Figure XIII-36 Photochemically Machined Edge




Figure XIII-36 Photochemically Machined Edge

This SEM image shows the hourglass-shaped edge typical of etched contacts. Note the lack of stamping burrs, rollover, or fracture zones on the edges.

Figure XIII-37 EDM'ed (Spark Eroded) Surface




Figure XIII-37 EDM'ed Surface

This SEM image shows the cratered surface of an edge that was cut by EDM (spark erosion).

©2020 Materion Brush Inc.

Figure XIII-38 Laser Cut Surface




Figure XIII-38 Laser Cut Surface
This is an SEM image of a laser cut surface. The edges are fairly smooth, and you can see the track marks left by successive bursts of the laser. Again there are no burrs, rollover, or fracture zones on the edge.

Figure XIII-39 Potential Problem with Property Distributions




Figure XIII-39 Potential Problem with Property Distributions
The specification minimum would be set where virtually all material would be guaranteed to pass. If a part is designed to be stamped with a bend that has an R/t ratio is less than the specification limit, metal that happens to have a formability that falls within the distribution on the left side of the orange line can be formed successfully, while metal on the right side would likely crack during forming, even though there is nothing at all wrong with the metal.

Residual Stresses – The base metal strip may have residual stresses in it from rolling, slitting or leveling. This can be compounded by the residual stresses from the blanking and forming processes. Rod and wire may contain residual stresses from drawing, coiling or straightening, and the parts machined from it will have residual machining stresses. When a finite element analysis is run, it is usually assumed that the part is starting form a stress-free state.

Forming History – In order to account for the residual stresses due to the forming history of a connector spring contact, redefine the FEA boundary conditions after forming as follows:

- Input boundary conditions for forming
- Use stress-strain curve as material input and then "form" the "part"
- Elastically remove the forming "tooling" and allow stresses to redistribute
- Redefine the boundary conditions for the "part" model
- Deflect the FEA "part" and assess the performance

One MUST use nonlinear code that can suitably remesh when forming displacements are large enough to create an error due to shifting of the node coordinate system. The explicit method takes a large number of steps to represent the severe nonlinearities by many small linearized increments. In addition, use an elastic-plastic material model that includes work hardening for the forming step.

Results Interpretation for Fatigue – If running a structural analysis, one would typically use the 1st principal maximum tensile stress as a comparison to S-N curves. However, the caveat is that the location of peak tensile stress may not be the location where the combination of load history and strains cause fatigue failure to originate. For example, there may be a point that has a lower peak tensile strength but a much greater differential between maximum and minimum stress on each cycle. Therefore, the alternating stress would cause the failure to begin at the latter point. The best results would be obtained by using an FEA package explicitly designed for fatigue analysis.

©2020 Materion Brush Inc.

Figure XIII-40 CuBe Strip Alloys




Figure XIII-40 CuBe Strip Alloys

If you are looking up properties in engineering handbooks or are using a built-in material library in your simulation software, you must be careful to ensure that you are simulating with the actual properties of the material that you intend to use. Most engineered materials come in a variety of tempers, which determines the exact combination of properties you are likely to find. However, many built-in material libraries will only have one temper, and it many not be one that is commonly used. In the example above, each individual dot represents a unique temper of CuBe strip alloy, each with its own unique set of properties. For Alloy 25, the value that is usually found in handbooks or CAD/FEA software libraries is hard temper, before heat treatment (the circled red dot above). However, almost all springs would use this material after it has been heat treated, which would be the green dot circled above. In this case, the use of handbook or library property values would result in a grossly inaccurate model. If you are running a simulation, please contact Materion (or the supplier of whatever material you are simulating) to ensure that you are actually simulating with the right property set.

Electrical Analysis

The increase of integrated circuit speeds to greater than 50 MHz requires electrical analysis or modeling. Above those frequencies, the potential for electromagnetic interference (EMI) effects increase in interconnects, requiring verification with analysis tools.

Similar to mechanical Finite Element Modeling, electrical modeling uses a Boundary Element Method (BEM) field solver to determine resistance and per meter capacitance and inductance of the contact geometry, as well as scattering parameters (S-parameters) of the connector. The time domain solvers (SPICE-Simulation Program with Integrated Circuit Emphasis) use the BEM results to determine the interconnecting media's effect on signal integrity. These include propagation delay, ringing and reflections and crosstalk effects. The analysis requires the electrical length of the conductor and the wavelength of the fastest signal. Inputs also include conductor width, thickness, dielectric height and constant.

MATERION

©2020 Materion Brush Inc.

Design Review

Prior to the prototyping stage, design reviews ensure that the original requirements of the connector are achievable. An available resource is Materion's Alloy Technical Services Department, which provides the services listed on the next page.

Table XIII-7 - Summary of How to Reach Design Goals

Design Goal	How to Achieve	Required Material Properties	Potential Geometry Changes
Maximize Spring Rate	Increase Stiffness	Increased Elastic Modulus	Shorter Beam Length, Greater Beam Width, Greater Beam Thickness
Maximize Peak Force	Increase Stiffness and Resilience	Increased Elastic Modulus Increased Yield Strength	Greater Beam Width
Maximize Stroke/Deflection	Increase Resilience	Increased Resilience: Higher Ratio of Yield Strength to Elastic Modulus	Greater Beam Length, Reduced Beam Thickness
Maximize Energy Absorption/Survive Drops & Shock Loads	Increase Resilience	Increased Modulus of Resilience: Higher Ratio of Square of Yield Strength to Elastic Modulus	Greater Beam Length, Greater Beam Width, Greater Beam Thickness
Maximize Number of Operating Cycles	Increase Fatigue Strength, Decrease Stress	Increased Fatigue Strength	Greater Beam Length, Reduced Beam Thickness, Eliminate Stress Risers
Maximize Current Carrying Capacity/Reduce Temperature Rise	Decrease Electrical Resistance	Increased Electrical & Thermal Conductivity	Shorter Beam Length, Increased Beam Cross Section
Maximize Operating Time at Elevated Temperatures	Increase Thermal Stability, Decrease Temperature Rise	Increased Electrical & Thermal Conductivity, Increased Stress Relaxation Resistance	Shorter Beam Length, Increased Beam Cross Section
Minimize Vibration Amplitude	Increase Stiffness	Increased Elastic Modulus	Shorter Beam Length, Greater Beam Width, Greater Beam Thickness

MATERION

©2020 Materion Brush Inc.

Materion Value-Added Services

Alloy Selection – With more than 200 strip metals listed by the Copper Development Association (CDA), paring those down to a handful with the proper attributes is useful to connector design engineers.

Design Assistance – Materion has the resources to perform simple stress calculations as a second opinion as well as in-house capability to perform more complex Finite Element Modeling. Materion also can provide a number of spreadsheet-based calculators or the necessary input data for FEA.

Fabrication/Processing Assistance – Materion has application-specific technical specialists to assist the customer with any problems they might encounter in processing (stamping, heat treating, machining, cleaning, etc.) its materials.

Literature – Current literature is available for each product

Technical Library – Technical library with electronic database systems

Educational Seminars – In-house, tailorable design seminars

Custom Fabrication – Capabilities and engineering facility in Elmore plant

Failure Analysis – Both the Elmore and Reading laboratories are available to perform routine evaluations and failure analysis on the materials.

Worldwide Network – Materion maintains a worldwide network to guarantee on time delivery of base metal that consists of the following:

- Service Centers (material stocking)
  - North America – Michigan, Illinois
  - Asia – Singapore
  - Europe – Germany
- Additional Sales Offices
  - Asia – Hong Kong, Shanghai, Seoul, Taipei, Tokyo
  - India – Pune
  - Europe – UK
- Independent distributors
- Authorized agents

Reprocessor Relationships – Through our relationship with alloy reprocessors we can provide a direct link to special customer needs. The list below describes alloy reprocessors:

- Re-rollers (foil thickness <0.003 inches {0.08})
- Wire re-drawers (wire diameter <0.050 inches {1.27mm})
- Tubing re-drawers (tube diameter <0.75 inches {19.05mm})

Industry Contacts – In addition to reprocessor relationships, numerous industry contacts are available for other services. These include:

- Prototyping
- Plating
- Stamping
- Machining
- Welding & brazing
- Spring design
- Forging
- Extrusions (small and large)
- Photochemical machining (etching), laser cutting, EDM'ing, etc.
- Heat treating
- Casting
- Flexible circuitry/lamination

Toll Free Customer Service – Call 1-800-375-4205 in the US & Canada to speak with the technical service staff. The number for the rest of the world is +1-216-692-3108. You may also submit other inquiries through the contact us section of the Materion website at https://materion.com/Businesses/Performance-Alloys/About/ContactUs.aspx.

MATERION

©2020 Materion Brush Inc.

Section XIV: Prototype & Verification

Stamping is a high speed, high volume, low cost process that requires a relatively high initial cost and long lead time for tooling. With shortened development cycles, the need for rapid prototyping and verification is an important requirement. The following section discusses a few prototyping methods commonly used for CuBe, NiBe, and CuNiSn, or other strip alloys.

EDM-Electrical Discharge Machining/ Spark Erosion

Prototype contact quantities may be fabricated using EDM. Two types of EDM are conventional (ram) and traveling wire (TW) (Figure XIV-1). Conventional EDM used on thick material utilizes a copper or graphite electrode configured as the cavity desired in the workpiece. The area of the workpiece, the type of materials and the machining conditions determine machining speeds. All EDM applications require a dielectric fluid to act as a spark conductor, a coolant and a flushing medium that carries away swarf. For conventional EDM, the most common dielectric fluid used is light petroleum based oil.

Figure XIV-1 Electrical Discharge Machining / Spark Erosion




Figure XIV-1 Electrical Discharge Machining/Spark Erosion
EDM'ing can be used to cut out thin or thick material, with relatively straight edges. The edges, however, may be heat affected, and will have a cratered appearance that will not lend itself well to applications requiring resistance to fatigue.

Traveling-Wire (TW) EDM as used on strip or foil utilizes the same principles as conventional EDM, with the fundamental difference that straight sided cuts require a wire electrode. For TW-EDM, brass and copper wire electrodes are the most common. Wire diameters range from 0.002 to 0.012 inches (0.05 to 0.30 mm). Dielectric cooling of the electrode and workpiece usually employs deionized water.

For both conventional and traveling wire EDM, the machining rates of copper beryllium are typically 20% lower than those of tool steels, due to its higher electrical conductivity. The edge condition of the EDM material is dependent upon the conductivity of the material. Rough edges may reduce the fatigue life of the parts relative to other cutting technologies. Some EDM'ed edges can be "burned" or annealed which may alter the performance of the sample versus a stamped sample. This is important for prototype samples with small width to thickness (w/t) ratios.

The Electrical Discharge Machining (EDM) process generates fine particulate which can be a hazard if inhaled. The machining action takes place in a dielectric fluid which serves to control the spark, cool the work and flush the machining swarf from the machining area. The particulate accumulates in a sump for eventual disposal. The dielectric fluid should be filtered to minimize build-up in the solution.

While most of the swarf is contained in the dielectric fluid, a small fraction may become airborne if the operation of the EDM equipment produces a fine mist. In this case, ventilation must be provided above the fluid to ensure capture of the mist.

Disposal of fine scrap or sludge must be done carefully. While the dust is considered non-hazardous for landfill disposal, it must be packaged and handled in a manner that prevents it from becoming airborne during collection and disposal. Particulate from the sump presents minimal hazard if it is kept wet during removal and disposal. Do not allow particulate to be handled dry as this increases the risk of airborne generation. Ventilation must be provided if the particulate is handled in a manner that causes airborne generation. Where adequate ventilation is not possible, respiratory protection must be provided.

Additional information is available in the Materion TechBrief "Electrical Discharge Machining Copper Beryllium", and in the Safety Facts Sheet "Safe Practices for Electrical Discharge Machining Copper Beryllium."

- Produces a narrow kerf (cut width) allows efficient nesting of parts
- High accuracy cut with no burrs
- Macroscopically smooth surface (but microscopically cratered)
- Allows for tapered edges
- Allows for stacking of parts
- Much slower process than laser or waterjet

©2020 Materion Brush Inc.

- Cannot pierce holes
- Effects on base metal
  - Creates “recast” layer + heat affected zone (In CuBe alloys this layer will normally be softer than the base material, essentially an annealed layer)
  - Thickness of heat affected zone typically 0.001" (0.025 mm)

Photo Chemical Machining (PCM) / Etching (Figures XIV-2 and XIV-3)

The copper alloy etching process is done either as a continuous reel-to-reel process on coils or on batches of flat sheet. The material is first coated on both sides with photo resist film that is hot roll laminated in either dry or liquid form. The type of incoming material determines the pre-clean and activation step performed before lamination. Following lamination, an ultraviolet (UV) light source exposes the photo resist through the desired pattern using a precision pattern glass or film artwork. The finished pattern develops such that areas to be retained as metal are coated with resist and areas to be etched are free of resist. After developing the photo resist, the material then runs past a series of nozzles spraying etchant, typically cupric chloride ($CuCl_2$) or ferric chloride ($FeCl_3$). The final process step is to strip the protective photo resist from the finished part. The etching rates are dependent upon the isotropy of the etched materials.

Figure XIV-2 Photochemical Machining (Photoetching) – Part 1




Figure XIV-2 Photochemical Machining (Photoetching) – Part 1
In photochemical machining, a mask of photoresist is applied to the surface, leaving areas to be etched away unprotected. The areas with the cured photoresist on top remain intact, while the etchant removes metal from the exposed areas.

Figure XIV-3 Photochemical Machining (Photoetching) – Part 2




Figure XIV-3 Photochemical Machining (Photoetching) – Part 2
Different hole profiles are possible in photoetching by varying the etch time, the size of the exposed areas on either side of the strip, and even by using temporary, removable masks in part of the process.

The photoetching process leaves a clean, smooth edge and can produce much finer features than is possible with stamping or EDM’ing, particularly in foil gauges. It does not add residual stress to the base metal, unlike slitting or stamping. However, distortion can occur if there is residual stress in the base metal. This could happen if the material is slit, trimmed, or leveled prior to the photoetching process.

For copper beryllium or copper nickel tin alloys, etch with $CuCl_2$, $FeCl_3$. For nickel beryllium $FeCl_3$ should be used.

- Chemically etch away unwanted strip using a photographically prepared mask which protects the metal that is to remain after etching
- Etchant is typically ferric chloride or cupric chloride
- Low tooling and set-up costs
- Best for parts less than 0.015" thick
- Parts can be oriented in strip the same direction as the production parts
- Can be done on individual cut to length sheets, or in a reel to reel process to maximize productivity
- Effects on base Metal
  - Burr and stress free edges with no heat-affected zone.
  - Edges may be slightly tapered, or hourglass-shaped if etched from both sides

For more information on photochemical machining see “The Fundamentals of Photochemical Machining (PCM) for Engineers and College and University Students” by Emeritus Professor David Allen BSc, PhD, DSc. This publication is available on the Photochemical Machining Institute website www.pcmi.org.

©2020 Materion Brush Inc.

Laser Cutting (Figure XIV-4)

This is where a laser is used to cut the outline of the flat blank out of flat coil stock.

Figure XIV-4 Laser Cutting

3.40 mm long by 0.345 mm wide




Figure XIV-4 Laser Cutting
Lasers can be used to cut out prototype parts at very high resolution. There may be a heat-affected zone at the edge.

Copper alloys are generally more difficult to laser cut than other metals, because of their high surface reflectivity (which reflects some of the beam power) and high thermal conductivity (which makes it difficult to melt a small zone). Copper alloys generally require higher power lasers for cutting, although fabricators have successfully cut CuBe with laser power as low as 400 W.

Laser cutting would leave minimal burr on the side of the part, but it will produce a small heat affected zone at the edge of the material, resulting in soft edges. Local exhaust ventilation would be required to contain any fumes generated from cutting CuBe (or any other metal, for that matter.)

- Metal removed by melting/vaporizing
- Can be used to pierce holes
- Faster than wire EDM and waterjet cutting
- Rougher surface than EDM and waterjet
- Surface reflectivity can be a problem, as laser will be partially reflected instead of absorbed
- Generates fumes – requires proper ventilation
- Effects on Base Metal

  - Cut edge will be oxidized

  - Produces larger heat affected zone than wire EDM

At 400W power, the laser cutting units would typically be housed in a totally enclosed cabinet which would have interlocks on the doors/covers to prevent opening when the laser is operating. This is a required safety feature to prevent injury from the laser. The cabinet should also be equipped with inlets so that the cabinet could be ventilated to remove any dust or fumes generated by the laser cutting operation. Materion would recommend that the laser cutting machine be equipped with a ventilation system that provides an enclosure air change rate of 30 times per minute. The actual air volume and flow rate would need to be calculated based on the size of the laser cutting machine cabinet.

Water Jet Cutting

In water jet cutting (Figure XIV-5), a stream of focused, high pressure water mixed with abrasive ceramic particles is used to cut through the metal to create the flat blank. Unlike EDM or laser cutting, it does not leave a heat-affected edge. Unlike shearing or blanking, it does not work harden the cut edge, and leaves a very small burr. +/- 0.002" (0.05 mm) typical tolerance. The edges are usually straight and smooth.

Figure XIV-5 Water Jet Cutting




Figure XIV-5 Water Jet Cutting
Waterjet cutting can be used on relatively thick material, to cut parts with straight, stress-free edges.

©2020 Materion Brush Inc.

Water Jet Cutting

- Uses high pressure water (> 50 ksi / 344 MPa) & mixed with abrasive medium (typically garnet) to cut strip
- Metal removed by compressive erosion
- Faster process than wire EDM
- Process is clean, normally does not produce dust or chips.
- Strip can be stacked or nested
- Can be used to pierce holes
- Wider kerf than wire EDM or laser cutting
- Kerf tends to widen over time
- Rougher cut surface than wire EDM
- Effects on base Metal
  - No heat affected zone (HAZ)
  - Normally produces a clean cut edge
  - no burrs or damage

Milling (Router Cutting)

This kind of machining typically would be used for thicker sheets of material, and is not appropriate for thin gauge strip, unless multiple layers are firmly stacked.

- Much large kerf than EDM, waterjet, or laser cutting
- Effects on base Metal
  - No heat affected zone (HAZ)
  - Rough cut edges, with some burrs
  - Cut edges will be work hardened, and slightly harder than the base metal

Material Directionality

Parts that have been machined by EDM, laser cutting, photoetching, or water jet cutting still must be formed into the final shape. This is where property directionality becomes critical. Most strip material will form better in one direction than another. *Therefore, it is critical that the prototype parts be laid out on the sheet in the same orientation that will be used for the stamped production parts* (Figure XIV-6). Failure to do so may result in a case where the prototype parts performed flawlessly, but all of the production parts cracked during the stamping process. Less obvious, but equally damaging failures can be due to anisotropy in tensile, fatigue or stress relaxation properties, resulting in inadequate performance of the production parts relative to the prototype parts.

Figure XIV-6 Prototyping vs. Production Potential Directionality Issue




Figure XIV-6 Prototyping vs. Production Potential Directionality Issue

It is entirely possible to make prototype parts out of strip that has a different orientation than the production geometry. If the material is not perfectly isotropic, this could result in a situation where the prototype part forms perfectly, but the production part cracks during the stamping process. Always ensure that the prototype parts are oriented in the direction that the production parts will be oriented, even if it does not optimize the layout for prototyping.

Rapid Prototyping / Additive Manufacturing (3D Printing) Methods

None of these methods are currently used to fabricate electrical contacts using high performance alloys. Currently, metal printing can only be done using metal powders.

However, these methods could conceivably be used fabricate small volumes of plastic or metal housings for prototype connectors.

Additive manufacturing does allow for the design of parts with internal cavities, which is advantageous for reducing weight (as long as the internal cavities do not create stress rises which jeopardize the part). Even the composition of the material itself may be varied from location to location throughout the part, resulting in tailorable property gradients. However, additively manufactured parts cannot be strengthened by hot working or cold working. Heat treating an additively manufactured part may result in distortion. One possible solution would be to additively manufacture to near net shape, heat treat, and then finish machine.

All additive production processes start with a 3D CAD model. The software would then separate the part into its individual component layers, and would save this information in an STL file or other file capable of being read by 3D Printers and other additive manufacturing equipment.

©2020 Materion Brush Inc.

Stereo Lithography (SLA)

Stereo lithography (Figure XIV-7) is a Computer Aided Prototyping (CAP) process that allows a designer to quickly construct a three-dimensional model designed and stored on a CAD system. The process automatically builds complex plastic parts by successively printing cross sections of photo polymer (liquid plastic) on top of each other.

A light source is used to cure the plastic while tracing the pattern of each layer. When each layer is done, the stage drops further into the resin bath by one layer thickness, so that the next layer can be printed directly on top of the previous one. The process proceeds by joining all of the thin layers to form a whole part. With this technology, the parts grow out of a vat of liquid plastic. When all layers are done, the part is removed from the bath.

One drawback with this method is that all points in the part must be supported by solid plastic underneath, making downward projections and some overhanging geometry impossible, without subsequent subtractive processes to remove temporary supports.

The method of fabrication is extremely powerful for quickly reducing design ideas to physical form and for making prototypes. This parts are strictly non-functional in representing the mechanical properties of stamped contacts.

Figure XIV-7 Stereo Lithography




Figure XIV-7 Stereo Lithography
This is the original additive manufacturing technology. The laser or focused UV light source traces out each layer in the liquid polymer bath, causing it to cure into a solid at that point. After each layer is done, the stage drops, allowing the liquid to cover the surface again. The curing process is repeated layer by layer until the part is complete. Unlike a powder process, the liquid resin cannot hold up unsupported geometry.

Selective Laser Sintering (SLS) and Direct Metal Laser Sintering (DMLS)

Selective laser sintering (Figure XIV-8) is similar to stereo lithography. Instead of printing plastic by curing liquid resin layer by layer, this process uses a laser to selectively melt/sinter together each layer in a bed of powdered material, layer by layer, into the final shape. As in Stereo Lithography, once each layer is finished, the stage drops, so that the next layer can be printed directly on top of the previous one. When all layers are done, the part is removed from the powder bed, and excess powder is removed and recycled for fabricating the next part. Overhanging geometry and downward projections are possible with these methods, since the powder bed itself provides support for the solid layers above.

While Stereo Lithography is restricted to plastic, Selective Laser Sintering can also be used with other metallic and ceramic materials. DMLS exclusively refers to making metal parts, while SLS is the general term for this process on all materials.

Figure XIV-8 Additive Manufacturing by Powder Process




Figure XIV-8 Additive Manufacturing by Powder Process
A laser or electron beam selectively melts each layer on the surface of the powder bed, allowing it to resolidify. Once each layer is done, the stage drops, and additional powder is added to cover the surface. Unlike liquid beds, the powder bed can also support solid material layers above it, so this method can be used to make unsupported geometry, as in the image above. SLS, DMLS, SLM, and EBM are all powder processes.

©2020 Materion Brush Inc.

Selective Laser Melting (SLM)

This is similar if not identical to Selective Laser Sintering. Depending on who you ask, SLS and SLM are either distinct processes or the same process by different names. Theoretically, Selective Laser Melting may use a higher power laser that more completely melts the powder, allowing it to solidify with less porosity than with the Selective Laser Sintering process. At the time of this writing, only pure metals and very few select alloys can be manufactured by the SLM process, while DMLS can be used with just about any metal or alloy.

Electron Beam Melting (EBM)

This is similar to Selective Laser Melting except that an electron beam is used to fuse the powder instead of a laser.

Fused Deposition Modeling (FDM)

Fused deposition modeling (Figure XIV-9) is a 3D printing process, in which a printing head melts a plastic filament and extrudes the liquid resin through a nozzle, which then immediately hardens back into solid plastic. The printing head traces out each layer, before moving up and doing the layer immediately above.

Figure XIV-9 Fused Deposition Modeling




Figure XIV-9 Fused Deposition Modeling
FDM uses a filament of some kind of polymer resin. It is melted at the print head and allowed to solidify in place during the printing process.

Jet Printing/ Plastic Jet Printing/ Color Jet Printing

This is similar to 2D inkjet printing, except that liquid resin is jetted out of the printer nozzles to print each layer of the part. The advantage of 3D jet printing over Fused Deposition Modeling is that multiple colors or even different plastic resins may be used.

Laminated Object Manufacturing / Layered Object Manufacturing (LOM)

This method (Figure XIV-10 and 11) is really a combination of additive and subtractive manufacturing techniques. A series of thin layers of the same or different materials are bound together and built up into a laminated bulk form. The finished product may then be machined out of the solid laminated structure, or the individual layers may be cut to shape before bonding. The advantage here is that each layer can have different properties, either by using different materials, using different amounts of cold work or heat treatments, or just simply using different orientations with respect to the materials' grain directions.

Figure XIV-10 Laminated Object Manufacturing – Part 1




Figure XIV-10 Laminated Object Manufacturing – Part 1
Each layer can be fabricated by blanking, photochemical machining, EDM, laser cutting, etc. Different materials can be used in each layer to make a composite part, with properties unachievable in monolithic material.

MATERION

Figure XIV-11 Laminated Object Manufacturing – Part 2




Figure XIV-11 Laminated Object Manufacturing – Part 2
Each successive layer is bonded to the underlying layer. Each layer can use a different material, or a different orientation, or a different temper, etc.

Photoelectroforming

The photoelectroforming process (sometimes known by the German acronym LIGA) process, is a method of additive manufacturing by electroplating success layers of the desired material onto a substrate. The finished part is then removed from the substrate. In this method, the part strength is limited to what can be achieved in the electroplating (and possibly sequential heat treatment) process.

Design Evaluation

Design evaluation is a tool to evaluate design alternatives, proposed improvements, cost reduction proposals or determine cause of field problems. The evaluation proceeds prior to qualification to compare connectors and assures the design is adequate to offer a reasonable probability of acceptable performance during qualification testing. A design evaluation consists of the tests in Table XIV-1.

Table XIV-1 - Design Evaluation

Evaluation	Quantity Measured
Construction Analysis	Contact Force Insertion/Extraction Force Plating Adhesion Plating Porosity
Metrology	Contact Spacing Housing Dimensions Contact Dimensions Plating Thickness Contact Geometry
Electrical Characterization	Contact Resistance Current Rating or Capacity Dielectric Strength
Assembly Compatibility	Process Thermal Resistance Insulation Resistance Solvent Resistance
Safety Approval	UL Flammability

Test Methods & Data

As mentioned in Section XIII – Design & Analysis, FEA models require material property inputs as well as experimental data for correlation. The following data is available in spreadsheet form from Materion's Customer Technical Service Department.

FEA Data – Stress-strain curves to rupture (paired data) for each of the following alloys and tempers in both the transverse and longitudinal rolling directions are available:

25	A, 1/4H, 1/2 H, H, AT, 1/4HT, 1/2HT, HT
190	AM*, 1/4HM,1/2HM, HM, SHM*, XHM, XHMS
290	TM02, TM04, TM06*
165	1/4H, 1/2H, AT*, 1/4HT*, 1/2HT, AM*, 1/4HM*, 1/2HM*, HM*, XHM*
3	H*, AT*, HT
174	1/2 HT, HT
Brush® 60 strip	3/4 HT, HT
390	HT
390E	EHT
BrushForm® 47 strip	HT*
BrushForm® 65 strip	HT*
BrushForm® 158 strip	TM04*, TM06*, TM08*, TM10*, TM16*, TM18
360	1/4 H, 1/2 H, 1/2 HT

*** = Longitudinal direction data only**

Please contact Materion for other alloys and tempers.

Every strip coil manufactured by Materion is tensile tested as part of the material certification process. The test software stores each individual stress-strain curve, which is then used to create average stress-strain curves for each alloy and temper produced. Table XIV-2 provides a sample of the paired data available. Here the tensile specimen is 0.008 X 0.250 inches (0.20 X 6.35mm). Each stress-strain curve is plotted with standard deviation and average property results tabulated.

©2020 Materion Brush Inc.

Table XIV-2 - Paired Data for Alloy 25 1/2 HT			
Alloy 25 1/2 HT Longitudinal	**Strain (microinch/inch)**	**Stress (psi)**	**Modulus (106 psi)**
1	0	0	
2	808	10,726	13.27
3	1,616	28,966	17.92
4	2,424	45,944	18.95
5	3,232	61,800	19.12
6	4,040	77,063	19.07
7	4,848	92,078	18.99
8	5,657	107,033	18.92
9	6,465	121,849	18.85
10	7,273	135,468	18.63
11	7,374	137,125	18.60
12	7,475	138,830	18.57
13	7,576	140,495	18.55
14	7,677	142,167	18.52
15	7,778	143,831	18.49
16	7,879	145,447	18.46
17	7,980	147,144	18.44
18	8,081	148,549	18.38
19	8,182	149,980	18.33
20	8,283	151,431	18.28
21	8,384	152,881	18.24
22	8,485	154,312	18.19
23	8,586	155,766	18.14
24	8,687	157,126	18.09
25	8,788	158,427	18.03
26	8,889	159,638	17.96
27	8,990	160,847	17.89
28	9,091	162,050	17.83
29	9,192	163,167	17.75
30	9,293	164,328	17.68
31	9,394	165,368	17.60
32	9,495	166,392	17.52
33	9,596	167,420	17.45
34	9,697	168,379	17.36
35	9,798	169,250	17.27
36	9,899	170,072	17.18
37	10,000	170,927	17.09
38	12,513	183,921	14.70
39	15,026	189,204	12.59
40	17,538	191,779	10.93
41	20,051	192,979	9.62
42	22,564	173,094	7.67

Table XIV-3 lists the test methods used to obtain various types of data. Additional detailed information on tensile and hardness testing is available in the Materion TechBriefs “Tensile Testing Copper Beryllium” and “Hardness Testing Copper Beryllium.”

Table XIV-3 - Test Methods	
Test Required	**Test Method**
Tensile Test Properties	ASTM E 8
Hardness (Vickers or DPH)	ASTM E 384
Grain Size	ASTM E 112
Electrical Resistivity	ASTM E 193
Formability	ASTM E 290
Stress Relaxation	ASTM E 328 Part C-3
Fatigue	ASTM B 593
Solderability	MIL STD 202 Method 208

©2020 Materion Brush Inc.

Section XV: Qualification

Connector specifications define the recommended stress tests and requirements for connector qualification. This also includes recommended sample sizes for the tests. A specification's purpose is to set a standard for initial qualification of connectors, to define tests for re-qualification or periodic stress testing of on-going production, and to assess variations in connectors due to changes in design or assembly processes. The electronics industry, automotive industry and the military have documented specifications for connectors used in their applications.

General Requirements

The general requirements of a connector determine the appropriate environmental qualifications tests. Packaging and cleanliness requirements are to protect the connector from mechanical damage and contamination during shipping and handling. The operating environment consists of corrosive gas, particulate and psychrometric (temperature & humidity) conditions. Section X – Considerations for Harsh Environments describe these. Shipping and storage conditions are the conditions prior to installation.

Figure XV-1 Stress Test Method




Figure XV-1 Stress Test Method.
This is how connectors are commonly tested. The contact resistance is measured before, during, and after the stress test cycles. These cycles may involve multiple insertions, elevated temperature exposure, temperature cycling, exposure to corrosive substances, etc.

Environmental Tests

Environmental tests usually consist of accelerated conditions to simulate the lifetime of a connector and/or system. The test results are a measure of the reliability of the system. The criterion to measure whether or not a connector is reliable is a specified change in contact resistance. A 4 wire probe method measures the contact resistance while negating the effects of bulk resistance in the measurement. Before, during and after aging, the greatest change in resistance (CR) shall be determined for each contact with respect to its initial, acceptable contact resistance reading. A statistical method analyzes the resistance data to determine the connector failure rate or reliability. (Figure XV-1)

In addition to this requirement, connectors must meet a specified minimum number of insertion cycles. Connector test vehicles emulate the actual connector function. The assembly processes for the test vehicles should be representative of the application manufacturing processes. Environmental stress tests are thermal cycling, thermal aging, gaseous testing, temperature and humidity testing, dust sensitivity and vibration and shock testing.

Thermal Cycling

This test provides a short term simulation of the long term effects of temperature cycling. The Coffin-Manson relationship for metal fatigue determines the number of cycles required at test temperatures to equate to the number of anticipated cycles at field temperatures. The test consists of a simulated shipping environment followed by an operational environment. The key material properties are thermal mismatch or CTE (Coefficient of Thermal Expansion).

Typical conditions:

Shipping = 5 thermal cycles from -40°C to +65°C (-40°F to 150°F)

Operational = 100 thermal cycles from 0°C to 75°C (32°F to 170°F)

Thermal Aging

This test provides a short term simulation of the long term effects of exposure to elevated temperatures. The key material properties are dry oxidation of base materials and thermal stress relaxation.

Typical conditions:

- 700 hours at 100°C (212°F)

INTERNAL

©2020 Materion Brush Inc.

Gaseous Testing

The purpose of gaseous testing is to provide a short term simulation of exposed contact base metal corrosion. Gold finishes degrade through the ingress of corrosion products from various sources. The Battelle Memorial Institute's Mixed Flowing Gas (MFG) test is an example of this test type. Corrosion migration and pore corrosion are the two degradation mechanisms. The gaseous test involves exposing contacts to corrosive gases during a thermal cycling or aging. The key material properties are plating integrity (degradation) and shielding effects of the housing. Two relevant test standards are ASTM B845 and EIA 364-65

Typical conditions:

- 4, 10, or 21 days at 25-30°C, 70-75% relative humidity, with gas concentrations in the part per billion ranges (H_2S, SO_2, NO_2, and Cl_2).
- Some thermal cycling may also be done as well.

Even if the plating is largely unaffected, there may be some corrosion underneath the plating if it has pores or cracks. (Figure XV-2)

Temperature and Humidity Testing

The purpose of this test is to provide a short term simulation of the long term effects of high temperature and humidity. Humidity affects galvanic corrosion. Key material properties are oxidation rate of the plating and base materials. Note that all copper alloys will tarnish to some degree under these conditions.

Typical conditions:

- 300 hours at 50°C (122°F) and 80% relative humidity
- 1000 hours at 85°C and 85% relative humidity.

Figure XV-2 SEM Image of Pore Corrosion




Figure XV-2 SEM Image of Pore Corrosion
In this SEM image, the base metal is visible in the bottom half of the image. There are visible voids (black) underneath the cracks in the plating that have been filled in with the epoxy mounting agent. The bottoms of the voids are filled with corrosion product, and there may be some additional corrosion product in the grain boundaries, indicating significant attack of the base metal underneath the mostly intact plating.

Dust Sensitivity Test

This test tracks the response of connectors exposed to increasing amounts of dust to determine the point at which performance declines. Performance is monitored through the change in contact resistance or the number of open circuits that occur. The key design variables are normal force and wipe. Some relevant test specifications include EIA 364-50, EIA 364-91, and MIL-STD-810 test method 510.5.

Typical conditions:

- Dust application in milligrams/square inch

Vibration and Shock Test

Connector vibration and shock testing are performed at the next level assembly since the input level is very dependent on the mounting structure. The four vibration input types are random, sine-on-random, sine dwells and sine sweep. Operational and shipping conditions are dependent on the levels and packaging of the product. The plane and amplitude of expected shock and vibration affect connector design. A resonantly vibrating member can destroy electrical continuity causing intermittent failures. Vibration tests determine contact resonance at their natural frequencies. A drop table simulates impact during shipping. Here a shock load determines the level that will cause the contacts to separate. Shock load is defined by g-level and duration.

©2020 Materion Brush Inc.

Standards and Specifications for Qualification Testing

Once your connector design is finalized and assembled, it will most likely have to pass qualification testing by one or more of the following list of standards. This list is not exhaustive, and your customers may have their own proprietary test standards that your design will need to pass. Please remember that these standards and specifications cover finished components or systems, and raw materials by definition cannot be certified to them.

No laboratory testing can perfectly simulate all of the possible variables in environmental conditions that your component will be expected to experience. However, by passing the qualification testing, you should be able to have reasonable confidence in your designs, assuming that you use proper engineering judgment.

Automotive (SAE/USCAR)

These automotive industry specifications cover the design verification testing of electrical terminals, connectors and components that constitute the connection systems in vehicle electrical system applications. In addition to thermal shock, temperature/humidity cycling and high temperature exposure, the specifications include salt fog, soap shower, fluid resistance and immersion tests. Connectors and crimps are also tested for mechanical and electrical performance after exposure to the above conditions.

Military (MIL)

The most commonly used military specification for connectors is **MIL-STD-1344A** "Test Methods for Electrical Connectors." There are three test classes: environmental (1000 class), mechanical (2000 class) and electrical (3000 class). All Departments and Agencies of the US Department of Defense approve of this military standard. MIL-STD-1344A is the basis for many of the methods in both the electronics and automotive specifications.

MIL-STD-810G "Environmental Engineering Considerations and Laboratory Tests" establishes a standard for tailoring and carrying out appropriate testing to simulate the service of components in their intended environments as accurately as possible. It also contains a listing of the expected environmental conditions in various locations.

MIL-STD-461G "Requirements for the Control of Electromagnetic Interference Characteristics of Subsystems and equipment" establishes requirements for ensuring electromagnetic compatibility of electrical or electronic equipment used in military systems. It provides a number of test methods to measure and verify proper control of electromagnetic interference and other noise in such systems. Test methods are established for conducted emissions and susceptibility, radiated emissions and susceptibility, and defines where such tests are applicable.

Telecommunications Industry Association (TIA)

ANSI/TIA-1096-A," Telecommunications Telephone Terminal Equipment Connector Requirements for Connection of Terminal Equipment to the Telephone Network" outlines geometric, mechanical, material and performance testing requirements for plugs and jacks (such as RJ45) used in telecommunications.

Electronic Components Industry Association (ECIA)

The **EIA 364** and **EIA 448 series** standards are overseen and published by the ECIA. The EIA 364 series of more than 100 standards covers test procedures for connectors and sockets. The EIA 448 Series covers test methods for electromechanical switches and components.

Institute of Printed Circuits (IPC)

The IPC publishes a number of standards on printed circuit boards, solder materials, and mounting of components to the PCB.

IPC J-STD-001, "Requirements for Soldered Electrical and Electronic Assemblies", covers materials and design of components that are intended to be soldered to the PCB.

IPC J-STD-002, "Solderability Tests for Component Leads, Terminations, Lugs, Terminals and Wires" outlines procedures for establishing solderability of various components.

Underwriters Laboratories (UL)

Underwriters Laboratories is an organization that evaluates and certifies the safety of finished products intended for consumer use.

Connector Sealing (Ingress Protection) Specifications

IEC 60529 "Degrees of protection provided by enclosures (IP Code)" defines designations, requirements, and test procedures for degrees of protection offered by enclosures around electronic devices. This applies to protection of people outside the enclosure from hazardous energy or moving parts, as well as protection of the internal electronics against solid or liquid ingress. Part are rated depending on what degree of protection they offer with a designation of the characters IP followed by two digits. The first digit ranges from 0 (no protection against solid foreign objects), up to 6 (dust tight), with the number increasing inversely to the maximum size of solid objects that may enter. The second digit ranges from 0 (no protection against water) to higher numbers, including 6 for protection from high pressure water sprays, increasing to 8 for protection from water in full immersion greater than 1 m in depth.

©2020 Materion Brush Inc.

Table XV-1 – IEC 60529 Ingress Protection Ratings			
Solid Protection		Liquid Protection	
0	No protection	0	No protection
1	Protected from large objects > 50 mm diameter (such as hands)	1	Protected from dripping water (such as light rain).
2	Protected from objects > 12.5 mm diameter (such as fingers)	2	Protected from dripping water (such as light rain) when inclined up to 15 degrees
3	Protected from objects > 2.5 mm diameter (such as tools and wires)	3	Protected from lightly spraying water.
4	Protected from objects > 1.0 mm diameter (such as small insects, fine wires and precision tools)	4	Protected from splashing water.
5	Protected from most dust	5	Protected from moderate pressure water sprays (such as in car washes).
6	Totally protected from all dust, dust-tight interface	6	Protection from high pressure water jets.
		7	Protection from short-term immersion in water.
For detailed test conditions, please consult IEC EN 60529.		8	Protection from continuous immersion in water, suitable for underwater use.
		9	Protection from high pressure, high temperature water jets.

IEC 60529 Ingress protection standard

Reliability Standards

IEEE 1413, IEEE 1413.1 IEEE 1332, IEEE 1624

IEEE 1413-2010 – "IEEE Standard Framework for Reliability Prediction of Hardware", IEEE 1413.1-2002 – "IEEE Guide for Selecting and Using Reliability Predictions Based on IEEE 1413", IEEE 1332-2012 – "IEEE Standard Reliability Program for the Development and Production of Electronic Products", and IEEE 1624-2008 – "IEEE Standard for Organizational Reliability Capability" are all sponsored by the IEEE Reliability Society. The first two cover how to gather and evaluate data for reliability prediction and how to evaluate such predictions. The third covers how to establish a reliability program within or between companies. These three standards are published by the reliability assessment working group (1413). The last standard on how to define and assess a company's reliability capability is published by the reliability prediction working group (1624).

ANSI/GEIA-STD0009

This standard is titled "Reliability Program Standard for Systems Design, Development, and Manufacturing". It establishes a methodology for vendors and customers to work together in teams to create and follow a reliability plan. The use ensures that all customer requirements are clearly communicated to and followed by the vendor, and establishes measuring and monitoring procedures for ensuring that the reliability requirements are met.

Corrosion Testing for Consumer Electronics

Traditionally Military, Automotive & Industrial markets demanded corrosion resistance. However, corrosion resistance is becoming increasingly important for consumer electronics.

- Reducing warranty claims (particularly for more expensive items)
- Demonstrating product differentiation and improving brand reputation (to increase market share/profits)
- Staying ahead of the competition
- Designing for reliability in harsh consumer environments
- Coping with evolving use cases
- Plating/surface treatment is typically very thin
- Microscopic defects or damage can expose substrate material (Figure V-2)
- Electronic devices (particularly wearable electronics) may have closer contact with consumer skin
- Consumers desire an aesthetically pleasing appearance of visible electronic components
- Minor surface alterations can affect performance
- There is a growing demand for waterproof designs

Surface corrosion can be caused by:

- High humidity
- Higher salt concentration
- Environmental pollution (SOx, NOx)
- Increased contact with "consumer" fluids
- Incompatible solder, flux, mask materials
- Galvanic mismatch between materials

The consequences of corrosion can be severe:

- Discoloration
- Shorts
- Intermittent connectivity
- Loose contacts
- Skin reaction
- Complete failure

DRAFT

Independent Corrosion Test Study and Results

Materion commissioned a study of corrosion resistance of copper alloys commonly used for contacts and connectors in consumer electronic devices. (Figure XV-3) Duplicate samples were used in all tests. All samples were polished with 600 grit prior to testing. Testing was conducted by independent, third party laboratory:

DNV GL (Det Norske Veritas USA)
5777 Frantz Road, Dublin, Ohio 43017
Telephone: +1 614 761-1214
Website: www.dnvusa.com

Figure XV-3 Corrosion Testing at Det Norske Veritas USA




Figure XV-3 Corrosion Testing at Det Norske Veritas USA
The results published below came from testing carried out at an independent laboratory.

The following alloys were tested:

Table XV-2 – Alloys Studied in Corrosion Tests

Alloy	UNS Number	Nominal Chemical Composition
Alloy 190	C17200	Cu-2Be
BrushForm® 158	C72900	Cu-15Ni-8Sn
Alloy 174	C17410	Cu-0.5Co-0.3Be
521 Phosphor Bronze	C52100	Cu-8Sn
NKC286 Corson Alloy	C64728	Cu-2.8Ni-0.6Si-0.5Sn-0.4Zn
7025 Corson Alloy	C70250	Cu-3Ni-0.65Si-0.15Mg
C1990	C19900	Cu-3Ti
NKT 322 Gigalloy*	-	Cu-3.2Ti-0.2Fe

**JX Nippon Mining & Metals*

Short Term Exposure Test Procedure:

1. Inspect and photograph polished samples.
2. Soak samples in solution for two hours.
3. Remove samples from solution and dry with N_2 gas.
4. Place samples in chamber at 65°C and 90% relative humidity, and hold for 6 hours.
5. Inspect and photograph samples. Make note of physical damage or corrosion.
6. Dry samples for two hours in chamber at 65°C and 25-30% relative humidity.
7. Inspect and photograph samples. Make note of physical damage or corrosion.

Humidity Test

- Hold in chamber for 120 hours in 90% relative humidity at 35°C.
- Results are shown in Figure V-4.

Figure XV-4 120 Hour Humidity Test – 90% RH, 35°C



***for each alloy the picture on left is polished sample before testing and picture on the right is after testing**

Figure XV-4 120 Hour Humidity Test – 90% RH, 35°C
Upon exposure to high temperatures and humidity, the BF158 alloy darkens uniformly but does not show any splotchy discoloration.

©2020 Materion Brush Inc.


Salted Cola

- Pour 70 ml of salt (NaCl) into 300 ml of cola at ambient temperature (between 19 and 25°C). Stir until salt is absorbed into the cola.
- Add 750 ml more of cola into salt solution to dilute further. Stir until all liquid is combined.
- Immerse samples in solution per short term test procedure outlined above.
- Results are shown in Figure XV-5

Artificial Human Perspiration

- ISO 3160 Artificial Eccrine Perspiration from Pickering Laboratories (Sweat Corrosion Resistance for Alloys)
- Immerse samples in solution per short term test procedure outlined above. Results are shown in Figure V-6.

Figure XV-5 Salted Cola Test




***for each alloy the picture on left is polished sample before testing and picture on the right is after testing**

Figure XV-5 Salted Cola Test

This test measures corrosion resistance in a mixture of table salt (NaCl) and a sugary cola beverage. This test gauges corrosion resistance to substances that people might spill on their consumer electronic devices. BrushForm 158 strip shows the least amount of surface contamination.

Figure XV-6 Artificial Perspiration Test



***for each alloy the picture on left is polished sample before testing and picture on the right is after testing**

Figure XV-6 Artificial Perspiration Test


This test measures corrosion resistance against another substance that might come into contact with consumer electronics. BrushForm 158 strip again shows the least change in surface appearance, followed by copper beryllium.

MATERION

Phosphate Buffered Saline

- Dulbecco's Phosphate Buffered Saline from Sigma-Aldrich (ASTM F2129)
- Immerse samples in solution per short term test procedure outlined above.
- Results are shown in Figure XV-7.

Figure XV-7 Phosphate Buffered Saline Test



Copper Nickel Tin (BrushForm® 158 strip) | **Copper Beryllium (Alloy 190)** | **Copper Beryllium (Alloy 17410)**

Titanium Copper (NKT 322) | **Titanium Copper (NKT C1990)**

Phosphor Bronze "C" (Alloy 521) | **Copper Nickel Silicon (Alloy 7025)** | **Copper Nickel Silicon (NKC 286)**

***for each alloy the picture on left is polished sample before testing and picture on the right is after testing**

Figure XV-7 Phosphate Buffered Saline Test
This test measures corrosion resistance against substances designed to mimic bodily fluids like blood, such as may be found in medical/ hospital environments. BrushForm 158 strip again showed the least change in surface appearance.

Short Term Exposures Testing Summary

- BrushForm® 158 strip showed the least change in surface appearance after testing in humidity only or in salted coke, artificial perspiration and phosphate buffered saline solutions.
- CuTi alloys, followed by phosphor bronze and CuNiSi alloys showed the greatest degradation in surface appearance.

Salt Fog Testing Procedure

1. Weigh and photograph polished samples
2. Conduct test per ASTM B117: Standard Practice for Operating Salt Spray (Fog) Apparatus for 1000 hours.
3. Examine visually after 500 and 720 hours, and return samples to chamber
4. After 1000 hours, weigh and photograph samples post-test with scale.
5. Conduct one cleaning cycle per ASTM G1.
6. Weigh and photograph cleaned samples. Shown in Figure XV-8
7. Calculate corrosion rates (Shown Below in Table XV-3)


Table XV-3 - 1000 Hour Salt Fog Tests - Quantitative Results

DNV Alloy Letter - Sample #	Alloy	Alloy Type	Composition	1000 Hour Mass Loss	Corrosion Rate	
			(weight percent)	(grams)	(mils per year)	(µm per year)
Alloy E - Sample #13	BrushForm® 158	CuNiSn	Cu-15Ni-8Sn	0.1334	0.9	23
Alloy D - Sample #4	190	CuBe	Cu-2Be	0.2009	1.4	36
Alloy F - Sample #14	174	CuBe	Cu-0.5Co-0.3Be	0.2250	1.5	38
Alloy A - Sample #1	NKC 286	Corson	Cu-2.8Ni-0.6Si-0.5Sn-0.4Zn	0.1339	1.7	43
Alloy H - Sample #16	7025	Corson	Cu-3Ni-0.65Si-0.15Mg	0.2952	2.0	51
Alloy C - Sample #3	NKT 322	CuTi	Cu-3.2Ti-0.2Fe	0.3369	2.3	58
Alloy B - Sample #10	C1990	CuTi	Cu-3Ti	0.3598	2.5	64
Alloy G - Sample #7	521	Phosphor Bronze	Cu-8Sn	0.3884	2.6	66

MATERION

©2020 Materion Brush Inc.

Figure XV-8 1000 hour Salt Fog Test



***for each alloy the picture on left is polished sample before testing and picture on the right is after testing**

Figure XV-8 1000 hour Salt Fog Test

This is a common test done for automotive connectors. BF158 showed the least discoloration, while copper titanium showed the most.

Salt Fog Testing Summary

- Visually, CuTi alloys showed the highest surface corrosion products within the first 500 hours. BrushForm® 158 strip showed the least surface corrosion products even after 1,000 hours.
- BrushForm® 158 strip showed the lowest corrosion rate of 0.9 mpy (0.022 mm/year) after 1,000 hours.
- Corrosion rate of CuTi Alloys was significantly higher, between 2.3 to 2.5 mpy (0.058 to 0.064 mm/year) after 1,000 hours.
- Phosphor Bronze C521 showed the highest corrosion rate of 2.6 mpy (0.066 mm/year) after 1,000 hours.

MATERION

Section XVI - Production

CAD systems are wonderful tools for designing parts quickly. Simulation tools such as Finite Element Analysis can also help to verify that the designs will work as intended. However, it is easy, if the CAD engineer is not careful, to design parts that cannot be fabricated easily, or at all (Figure XVI-1). It is important for the designer to understand how parts are actually made, so that he or she can avoid any potential pitfalls that would make parts impossible or extremely costly to produce. This section provides a brief overview of stamping operations used on strip (and to a lesser extent on wire), as well as machining operations typically done on rod or wire.

Figure XVI-1 Impossible Parts

- **Parts created easily and quickly in CAD**
- **Impossible to fabricate with conventional stamping or machining operations**




Figure XVI-1 Impossible Parts
The stamped part on the bottom left has a spring that is longer than the detent it came out of. The beveled edges on the front curl all the way around the opening, including the corners. Both of these features are impossible with conventional stamping. The screw machined part on the bottom right has an inside bore that decreases in width down the barrel (difficult and expensive to do.) The ends of the tines are curled around an undercut, which would be impossible with conventional machining. Technically, both parts could easily be made with additive manufacturing techniques, but not with high performance connector materials. Of course, the well-known Penrose triangle optical illusion on the upper right is impossible to make as anything other than a 2D sketch using any technology. However, it clearly illustrates the point that virtually anything can be drawn in CAD, even if it is completely impossible to fabricate.

Copper alloy strip production consists of casting billet, hot rolling and cold rolling to final gage and then slitting to the required width. At various intervals in the cold rolling process, the mill provides thermal treatments to solution anneal the metal after reduction, in order to recrystallize and soften the material for further reduction. At later stages of processing, the precipitation age hardening treatments provide the proper temper, strength and formability. Stress relief thermal treatments after slitting reduce residual stresses. The metal surface requires cleaning at various stages of the processing. Benzotriazole (BTA) coats the strip to preserve the final finish.

Stamping uses a reel-to-reel production line that features a high speed precision press capable of speeds up to and exceeding 1000 strokes per minute. (One or more finished part is produced during each stroke). See Figures XVI-2 and XVI-3. A press typically utilizes a progressive stamping die that usually contains tungsten carbide or steel punches and dies. The strip is usually pierced on both edges as it is fed into the tool. These holes locate the strip precisely as it advances one unit length with each stroke of the press. At each station of the tool, multiple blanking, bending, piercing, etc., contributes to the final configuration of the product. Plating can also be done as a reel-to-reel operation. Assembly into plastic housings requires sectioning the plated strip into specified lengths.

You should be sure to keep the punches and dies sharp to keep the edges of the stamped parts in good condition. The stripper plate should apply enough clamping force on the strip to keep it from slipping in the die, so that all parts come out consistent in thickness and dimensions.

Alternatively, a multi-slide tool may be used to form parts from strip (or wire). They are typically capable of more complex forming operations than progressive dies, easily making bends greater than 90°. While progressive dies direct the punches down onto the dies, multislide tools direct multiple punches, one at a time, at the strip from different directions, usually horizontally. Multislide tools generate less scrap than progressive dies since no carrier strip is needed. However, they typically produce fewer parts per hour, since each part produced requires multiple strokes of the mulitislide). Multislide tools typically cannot provide the same press force (tonnage) as presses used in progressive die stamping, so this may limit operations requiring high forces such as deep drawing, and coining. Since only loose parts are produced, further reel to reel operations would not be possible, although barrel plating and vibratory feeding of loose parts into assembly machines is still possible.

©2020 Materion Brush Inc.

Figure XVI-2 Typical Progressive Die Section




Figure XVI-2 Typical Progressive Die Section
This shows the layout of a typical progressive die, in cross section at a single die stage. Other stages occurring before this stage would be behind this cross section, additional stages after this one would be in front of the page. The upper die assembly rides down the guide pins to deliver work to the material to be stamped. Punches will pierce, blank, lance, or otherwise cut the strip. Dies will bend, form, or draw the strip as required. Since the combination of the loads from all punches and dies will generally not be symmetric, it will place bending moments on the upper and lower die assemblies. Heel blocks/bottom dead point stopper blocks keep the upper and lower dies aligned, by preventing rotation of the dies.

Figure XVI-3 Typical Progressive Die Section – In Action




Figure XVI-3 Typical Progressive Die Section – In Action
The punch would be rigidly attached to the upper die plate. The stripper plate would be attached to the upper die plate with springs. The stripper holds the strip in place against the lower die while it is pierced, blanked, bent, etc. by the punch. The stripper pad also helps to strip the material off of the punch as the punch retreats. The punch may also be located on the lower die, if the corresponding die surface is on the top. The slugs from all but the last stage are scrap. The slug from the final stage may either be scrap, or it may be the final part and the remainder of the workpiece is scrap.

Progressive Dies

Using progressive dies, you can successfully stamp these materials with tolerances measured on the micron level. Remember that the strip surface should be mostly oxide-free to promote tool life.

Materials Used for Progressive Dies

- Die Plates (Shoes)
  - Steel
  - Aluminum
- Guide Pins
  - High strength steel
- Guide Pin Bushings
  - Aluminum bronze (or ToughMet® 3 alloy for increased wear resistance and life)
- Stripper Plate
  - Holds the inserts in place
  - Made from high speed steel or die steel for most applications
  - Can be made from an Al alloy to minimize vibration in very small or high precision parts
- Stripper Insert (Stripper Block)
  - Guides the punches to the strip
  - Typically made from steel or cemented carbide
  - Usually harder than the punches
- Punches and Dies
  - Use cemented carbides (WC, TiC, etc. in Co or Ni binder) for long runs with precise control or smooth finishes
  - Otherwise, tool steels are O.K.
- Lubricants
  - Mineral oils (avoid those containing sulfur or remove immediately)
  - Soap and Water with air knife drying
  - Vanishing Oil

DRAFT

Formability

The formability ratio (R/t), or minimum bend radius to thickness ratio (MBR/t), is the ratio of the minimum recommended bend radius to the strip thickness (t). This value defines the sharpest forming radius allowable prior to failure. A 90 degree bend test using a "vee" block and die generates formability data (Figure XVI-4). An R/t value of 0 defines a material that can form a very sharp bend without failure. Larger R/t values indicate reduced formability (Figure XVI-5). Formability is dependent on the materials' yield strength and elongation with formability decreasing for higher strength and harder tempers.

Figure XVI-4 Vee Block Formability Die




Figure XVI-4 Vee Block Formability Die
The V-block is used to determine the ratio of minimum bend radius to thickness (R/t or MBR/t) in a 90 degree bend for an acceptable bend surface appearance.

Figure XVI-5 Comparison of Various R/t (MBR/t) Ratios




Figure XVI-5 Comparison of Various R/t (MBR/t) Ratios
As the R/t ratio decreases, the bends get tighter. 0 R/t represents a theoretically sharp bend.

MATERION

©2020 Materion Brush Inc.

The actual minimum R/t ratio is the smallest ratio that produces an acceptable bend. Even if the material forms to the desired bend without cracking, the outer surface may not be of acceptable quality. Therefore, the appearance of the outer bend surface is what is used to rate formability. (Figure XVI-6). A smooth surface is ideal, and a crack is an outright failure. In between, there are various degrees of surface distortion, commonly referred to as “orange peel” for its resemblance to the outer surface of an orange. Usually, a bend is rated as passing if there is light to moderate orange peel, while heavy orange peel is considered a failure (Figure XVI-7). Since this means that the test is subjective, closer inspection may be required using more advanced techniques, such as that shown in Figure XVI-8.

Figure XVI-6 Bend Surface Appearance




Figure XVI-6 Bend Surface Appearance
After forming in the V-block die, the bend apex is examined to see if the forming process was successful at this particular R/t ratio.

Figure XVI-7 Bend Acceptability



Figure XVI-7 Bend Acceptability
Generally, smooth to slight “orange peel” is considered acceptable for bends. Cracks are failures. Moderate to heavy orange peel may be acceptable on a finished part, depending on the application requirements. Very heavy orange peel may lead to early fatigue crack initiation.

Figure XVI-8 Closer Evaluation of Bends




Figure XVI-8 Closer Evaluation of Bends
Sometimes, it is difficult to distinguish heavy orange peel from cracking in an optical microscope. In this case, a Keyence Confocal Ultraviolet Laser Microscope is used to examine the bend surface in detail. A 3D height map of the bend apex confirms that the surface is cracked.

DRAFT

Figures XVI-9 through XVI-12 show the effects of formability testing with decreasing R/t ratios. As the bend becomes sharper, the final bend angle decreases due to a reduction in springback and the outer surface of the bend progressively becomes worse.

Figure XVI-9 Gentle Bend

- **Actual R/t >> MBR/t**
- **Springback to >90°, Smooth Bend Surface**




Figure XVI-9 Gentle Bend
With a gentle bend (R/t far larger than the minimum required) there is little potential for cracking, and the bend will be fairly smooth. However, there will be some springback, which may be significant.

Figure XVI-10 Moderate Bend

- **Actual R/T = MBR/t**
- **Bend Angle ≈90°, Some Orange Peel**




Figure XVI-10 Moderate Bend
With a moderate bend (R/t near or slightly larger than the specification minimum), springback is minimized, and the final angle will be close to 90 degrees. There may be some slight orange peel on the bend apex, but not enough to affect fatigue life.

Figure XVI-11 Sharp Bend

- **R/T = 0.0 < MBR/t**
- **Crack!**





Figure XVI-11 Sharp Bend
With an r/t ratio less than the specification minimum, there will certainly be heavy orange peel on the surface, and there is likely to be some cracking as well. There may even be some negative springback (i.e., the bend closes up slightly as the punch is removed).

Figure XVI-12 Formability Comparisons



Gentle Bend
- **Smooth Surface**
- **Springback to > 90°**

Moderate Bend
- **Orange Peel Surface**
- **Negligible Springback**

Sharp Bend
- **Cracked Surface**
- **Apparent Negative Springback**

Figure XVI-12 Formability Comparisons
This image directly compares the formed bend in each of the three previous images. You can more easily compare the change in bend radius, springback, and bend apex condition after forming.

MATERION

©2020 Materion Brush Inc.

The ability to make a sharper bend improves as the strip width decreases at constant thickness. For large width to thickness ratios >8, a plane strain state exists producing reproducible and conservative estimates. When width to thickness ratio decreases below 8, the deformation mode changes from plane strain to plane stress (Figure XVI-13). More localized or necking strain is available to assist forming the latter before fracture ensues. Thin strip is formable to tighter minimum bend radii than suppliers' published minimum bend ratios. However, parts formed with this ratio are more sensitive to edge conditions and damage associated with stamping. Additional information is available in the Materion TechBrief "Formability of Copper Beryllium Strip", as well as Technical Tidbits Issues # 9, 10, 50 and 51.

Figure XVI-13 Width Dependence of Formability





Figure XVI-13 Width Dependence of Formability
At narrower widths, plane stress bending conditions dominate, which improves the formability. The across the width direction on the outer bend surface may narrow, to better accommodate the elongation in the radial direction. With wider beams, this is true at the edges, but not in the middle, so forming cracks are most likely to start in the middle of the bend apex.

MATERION

The contour plots of Figure XVI-14 shows the combined effects of width to thickness ratio and R/t ratio for specific thicknesses of a particular CuBe alloy. Each alloy and thickness combination would need to have its own plot, since there are 4 independent variables (width, thickness, bend radius, and alloy/temper combination) and 1 dependent variable (outer bend surface quality.)

You can improve formability by blanking a slot in the area of the strip to be bent. This effectively decreases the width to thickness ratio of the bend (as you are essentially forming two narrower bends instead of one wider bend.) This can help in extreme cases where you need as much strength as possible but also have very tight forming requirements. However, you will pay a small penalty in reduced contact force and current carrying capability, in proportion to the reduction of the cross sectional area. (See Figure XVI-15 for more information.)

Figure XVI-14 Formability Contours



0.00275 in. HM **0.00591 in. HM**

Ratings

- **1.0 – Smooth**
- **3.0 – Moderate Orange peel**
- **5.0 – Open Crack**

Figure XVI-14 Formability Contours
This is an example of how the width to thickness ratio affects the formability. In these pictures, the vertical axis represents the w/t ratio (narrower width at the bottom, wider at the top) and the horizontal axis represents the R/t ratio (tighter bends on the left, gentler bends on the right). The purple and blue colors represent smooth bends, yellow represents the minimum acceptable bend appearance, and red represents open cracking. Narrower, gentler bends have a much better surface appearance than wider, tighter bends. Thinner material (left side charts) forms better than thicker material (right side charts). In this particular case, the bad way bends seemed to form a little better than the good way bends.

Figure XVI-15 Slotting to Improve Formability




Figure XVI-15 Slotting to Improve Formability
When all else fails, you can slot the contacts to improve the formability by reducing the width to thickness ratio. This method can improve formability up to 50% better than a fully solid bend. However, this will reduce the contact force in proportion to the amount of cross section removed. Be sure to use a full radius, extended into the flat section away from the bend to minimize stress rising effects.

MATERION

©2020 Materion Brush Inc.

Longitudinal Versus Transverse Forming

The directionality of strip properties is a result of cold rolling. Formability is a function of the bend orientation relative to the rolling direction in a cold rolled product. The formability in the longitudinal (good way) direction is usually better than that present in the transverse (bad way) bending direction (Figure XVI-16).

Figure XVI-16 Bending Directions




Figure XVI-16 Bending Directions
Most materials have better formability in the good way direction than the bad way direction. More isotropic materials such as lower strength heat treatable Alloy 25, or Alloy 290 CuBe may not have a preferred direction. In some rare cases of mill hardened materials, particularly in CuNiSi alloys, the formability may actually be better in the bad way direction than in the good way direction.

MATERION

Table XVI-1 presents formability data for various tempers of contact alloys in the strip thickness range typically specified for connector applications (0.010-0.050 inch or 0.25-1.27mm).

Table XVI-1 - Bend Formability [1]

Alloy	Temper	Formability (Min. R/t for 90° Bend) Longi-tudinal	Trans-verse
Materion CuBe			
25	A	0.0	0.0
	1/4 H	0.0	0.0
	1/2 H	0.5	1.0
	H	1.0	3.0
190	AM	0.0	0.0
	1/4 HM	0.5	0.5
	1/2 HM	0.5	1.0
	HM	2.0	2.0
	SHM	2.8	3.2
	XHM	4.0	5.0
	XHMS	5.0	10.0
290	TM00	0.0	0.0
	TM02	0.0	0.0
	TM04	1.0	1.0
	TM06	2.5	2.0
	TM08	3.5	3.0
3	AT	1.0	1.0
	HT	2.0	2.0
174	1/2 HT	0.5	0.5
	HT	1.2	5.0
Brush® 60	3/4 HT	0.7	0.7
	HT	1.5	1.5
390	HT	2.0	2.0 [2]
		5.0	5.0 [3]
390 E	EHT	1.0	1.0 [4]
		2.0	2.5 [5]
		2.5	3.5 [6]
		3.5	3.5 [7]

Alloy	Temper	Formability (Min. R/t for 90° Bend) Longi-tudinal	Trans-verse
Materion CuNiSn and NiBe			
Brush-Form® 158	A	0.0	0.0
	1/4 H	0.0	0.0
	1/2 H	0.0	0.5
	H	0.5	3.0
	EH	-	-
Brush-Form® 158	TM00	0.0	0.0
	TM02	0.0	0.0
	TM04	1.0	1.0
	TM06	2.0	2.0
	TM08	5.0	8.0
	TM10	-	-
Brush-Form® 96	A	0.0	0.0
	1/4 H	1.1	1.7
	1/2 H	1.5	2.0
	H	3.0	6.0
	EH	-	-
Brush-Form® 96	TM00	0.2	0.2
	TM02	0.5	0.5
	TM04	1.0	1.0
	TM06	2.5	3.0
	TM08	5.0	7.0
360	A	0.0	0.0
	1/4 H	0.0	0.0
	1/2 H	0.7	1.2
	H	1.2	2.0
360	MH2	0.0	0.0
	MH4	0.5	0.5
	MH6	1.0	1.2
	MH8	1.2	1.6
	MH10	1.5	2.2
	MH12	2.0	3.0

Alloy	Temper	Formability (Min. R/t for 90° Bend) Longi-tudinal	Trans-verse
Other Copper Alloys			
C26000	H	1.0	1.5
C19400	S	-	-
C51000	1/2 H	0.0	2.0
	H	0.5	3.0
	S	3.0	8.0
C52100	1/2 H	0.0	2.0
	H	0.5	3.0
	S	2.0	7.0
C65400	1/2 H	1.0	1.0
	H	2.0	3.0
	S	4.0	7.0
	XS	5.0	8.0
C68800	1/2 H	1.0	1.0
	H	2.5	3.0
	S	5.0	6.0
	XS	6.0	9.0
C70250	TM02	2.5	1.5
	TM03	2.5	2.0
C72500	1/2 H	2.0	2.0
	H	3.0	3.0
	S	4.0	6.0

[1]Typical formability values for strip 0.010 inches (0.25 mm) and thinner, unless otherwise specified.

[2]For strip 0.004 inches (0.10 mm) and thinner.

[3]For strip greater than 0.004 inches (0.10 mm) thick.

[4]For strip 0.002 inches (0.05 mm) and thinner.

[5]For strip 0.004 inches (0.10 mm) and thinner.

[6]For strip 0.006 inches (0.15 mm) and thinner.

[7]For strip 0.008 inches (0.20 mm) and thinner.

MATERION

©2020 Materion Brush Inc.


Formability Caveats

The R/t ratio as determined above is the minimum bend radius required to prevent cracking in a 90° Vee-block test. The outer surface of the bend may show the wrinkled, textured appearance known as orange peel without actually cracking. The amount of orange peel that is considered acceptable is an individual preference. If no orange peel is desired, then the bend radius must be enlarged to ensure smooth surfaces.

Actual production stamping will be done with much higher strain-rates and greater forces than the hand-operated V-block test. Since the production conditions are more severe than the laboratory test conditions, the production material may be more likely to crack than the material in a formability test.

Sometimes, a bend is formed by using a punch to score the flat blank along the bend centerline, followed by bending the sample in a 4 point, unsupported bend (Figure XVI-17). The material will fold readily along the stress riser produced by the score line. This method can be used to produce a very tight bend radius. However, this method works best on soft tempers that have a great deal of ductility and capacity for strain hardening, since the score line greatly increases the cold work at the bend and significantly reduces the material's formability. For heavily cold worked or strong mill-hardened tempers, this method can easily result in cracking, as shown in Figure XVI-18. Furthermore, it is important that the score line extend all the way to the edge of the strip, or the unscored, folded edge can create a significant stress riser.

Figure XVI-17 Pre-Scoring



- **Locates the bend center line**
- **<u>Decreases</u> formability of strip**

Figure XVI-17 Pre-Scoring
Sometimes, in order to form a tight, precisely located bend, a punch is used to score the strip. While this technically improves the r/t ratio by decreasing the thickness, it greatly work hardens the strip, decreasing overall formability. If the score is too deep, it will cause cracking during bending. Furthermore, if the score does not extend all the way to the edge of the strip, you will have significant stress risers at the edges of the score line, which can cause cracking during bending.

Figure XVI-18 Potential Problems from Pre-Scoring Bends




Figure XVI-18 Potential Problems from Pre-Scoring Bends
As stated in the caption for the previous figure, deep scoring can cause cracking during forming (left image). Also, if the score does not extend all the way to the edge, it can create stress risers that can negatively impact forming and fatigue life. (This particular component also had a very large fracture zone at the bend apex that also functioned as a stress riser, further inhibiting fatigue life.

©2020 Materion Brush Inc.

Profiled Strip (Figure XVI-19)


Materion can supply strip with variable thickness across the width, as an alternative to coining or scoring. By skiving, milling, or grinding the strip to a reduced thickness, you can have the benefit of an effectively increased R/t ratio without the loss of ductility or increase in residual stress that comes with coining or scoring.

Figure XVI-19 Process Technologies: Profiled Machining

Save internal space



Simplify extreme forming operations



Reduce bend radius clearances *Combine with EB zone annealing*


Figure XVI-19 Process Technologies: Profiled Machining
This technology can be used to save space in a design by putting material only where it is needed. It can also be used to improve the formability of strip by effectively increasing the bend radius while reducing the thickness, without significantly work hardening the base metal the way that scoring or coining does. Formability can further be enhanced by zone annealing the reduced cross section.


Zone Annealing (Figure XVI-20)

In addition to welding, an electron beam can be used to soften a base metal in a selective zone along the length of a coil. The softened zone is controlled within a range of approximately 1.5 mm to 6.0 mm (0.060" to 0.0250"), depending on the thickness and conductivity of the metal. The process is most often used to improve forming operations (bad way bends) in otherwise less formable metals.

Figure XVI-20 Electron Beam Welding & Zone Annealing

- Joining Dissimilar Strips
- Zone Annealing








Figure XVI-20 Electron Beam Welding & Zone Annealing
While electron beam welding is typically used to join dissimilar strips of metal, the beam can also be used to selectively soften a down-the-length section of the strip. The image in the lower left is a metallographic cross section of zone annealed strip. The diamond shapes are indentations from micro-indentation hardness tests. The larger indentations signify reduced hardness and thus improved formability relative to the areas with smaller indentations. This image illustrates how the hardness can be dramatically reduced in a very narrow zone.

©2020 Materion Brush Inc.

Springback

Springback causes dimensional changes in formed components after release of the forming tool pressure. When strip is bent, the outer fibers are in tension and the inner fibers are in compression. For permanent forming, the stress in the extreme outer fibers and extreme inner fibers exceed the yield strength, resulting in plastic strain and permanent set. Meanwhile, the inner fibers are stressed elastically, and want to straighten when the load is removed. This results in 4 distinct stress zones through the cross section (Figure XVI-21).

When the load is removed (Figure XVI-22), the inner fibers try to straighten the bend, but are restrained from fully straightening by the yielded outer fibers, which now are placed into an opposite stress state from the neighboring inner fibers. The bend will straighten to the point where the residual stresses from all 4 zones balances out. This is the springback position Figure XVI-23).

Figure XVI-21 Stress Induced During Forming of Bends




Figure XVI-21 Stress Induced During Forming of Bends
When a beam is bent, there is tensile stress on the outside and compressive stress on the inside. This is also the case when strip is formed. The outer fibers on each side will permanently deform (plastic strain), while the inner fibers will be fully elastic and want to recover. This is what generates springback.

Figure XVI-22 Residual Stresses from Forming Bends




Figure XVI-22 Residual Stresses from Forming Bends
After forming, the inner fibers try to fully straighten the material, but they are held back by the plastically deformed outer fibers, which want to remain curved. As a result, the material will spring back to a point where the competing stresses and strains balance each other out. This produces 4 different stress states through the cross section.

Figure XVI-23 Springback of Formed Strip




Figure XVI-23 Springback of Formed Strip
To control springback, you can overbend and allow the bend to springback to its desired angle. Alternatively, you can coin the outside diameter of the bend to convert the tensile stress on the bend outside diameter to compressive stress.

©2020 Materion Brush Inc.

Compensate for spring back by overforming the bend to maintain the desired part geometry. Spring back increases with increasing yield strength and punch radius and with decreasing elastic modulus and strip thickness. Because different tempers will spring back differently, you cannot change the temper once the tooling is built, unless the resultant change in the bend angle is acceptable.

Table XVI-2 – Effect of Material Properties on Springback	
Increases Springback	Decreases Springback
Lower Elastic Modulus	Higher Elastic Modulus
Higher Strength*	Lower Strength
Thinner Strip	Thicker Strip
Larger Bend Radius*	Smaller Bend Radius

*Mill Hardened Strip is Higher Strength and Needs Larger Bend Radius

An empirical equation to describe 90° bend, plane-strain springback (K) for all punch radius/strip thickness ratios is:

$$K = \frac{A_f}{A_0} = \frac{(R_0 + t/2)}{(R_f + t/2)} = -25.54X^3 + 17.91X^2 - 5.85X + 1.08$$

Where X is the dimensionless variable: $X = \frac{YS}{E} \cdot \frac{R_0}{t}$

And
A_f = formed angle
A_0 = bend or die angle (90°)
YS = 0.2% offset yield strength
E = modulus of elasticity
R_0 = punch radius
t = strip thickness
R_f = formed radius after springback

This equation holds relatively well for all spring materials, subjected to a 90° V-bend with a 90° punch and matching 90° die.

Sometimes, stampers will attempt to control springback by coining the outer fibers of the bend with a counter punch in the die. This adds compressive stress to the tensile stress side of the bend, which further constrains the material when it attempts to straighten out. Figure XVI-24 provides some general guidelines, but the exact amount required for your material and your particular stamping operation would need to be determined by trial and error. For more information on springback, please see Technical Tidbits Issue #11.

Figure XVI-24 Coining Bend OD to Control Springback




Figure XVI-24 Coining Bend Outside Diameter to Control Springback
Coining (sometimes known as “Hip-up”, or “Hit-forming”) reduces springback by adding compressive stress to side in tension. The required “H” to material thickness ratio is dependent upon the R/t value of the forming punch tip.

MATERION

©2020 Materion Brush Inc.

Additional Considerations for Processing Thin Foils


You need to take great care to avoid wrinkling of thin foils, which may not even be able to support their own weight. Stamping becomes problematic, as it is difficult to hold down the material without wrinkling it. If you are photoetching it, you must take care to ensure that the material is held flat during the process, to avoid flutter and to keep all the etched features in proper alignment. This may require the use of a vacuum to hold the material flat against the etching table, or the use of tension to hold the material flat during reel to reel etching processes.

Any residual stresses in the material become highly significant, and can lead to distortion. If you take the standard cantilever beam equations, you can rearrange them to solve for deflection as a function of applied stress, as follows:

$$d = \frac{2 \cdot L^2}{3 \cdot E \cdot t} \sigma_{max}$$

As beam length increases and/or as thickness decreases, the amount of deflection (distortion) for a given amount of residual stress increases. Residual stresses that would be insignificant in thicker material can create significant distortion in thin strip or foil.

Figure XVI-25 Response to Age Hardening Treatment



Higher Temperature

•Short time required
•Lower peak strength
•Hard to control exposure time, quick to overage

Lower Temperature

•Longer time required
•Higher peak strength
•Easier to control

Figure XVI-25 Response to Age Hardening Treatment
Heat treating at 600°F/315°C is optimum for Alloy 25. The material reaches peak strength in just 2 to 3 hours, and provides a significant margin of error if the material is left in the furnace too long. (It is difficult to overage and soften the material at this temperature.)

MATERION

©2020 Materion Brush Inc.

Heat Treating

Heat treating copper beryllium alloys is a two-step process that consists of solution annealing and precipitation age hardening. Because Materion performs the required solution anneal on all wrought products prior to shipping, most fabricators' primary concern is the age hardening process for parts to be heat treated after forming. Mill hardened products are age hardened prior to shipment and they require no additional heat treatment by the fabricator. During the age hardening process, microscopic, beryllium rich γ-particles form in the metal, adding strain fields to the crystalline matrix. These strain fields stop dislocations and impart strength. This is a diffusion controlled reaction, and the strength will vary with aging time and temperature.

Recommended or "standard" age hardening time and temperature combinations have been determined for each copper beryllium alloy. Standard times and temperatures allow parts to reach peak strength in two to three hours, without risk of strength decrease due to extended temperature exposure. As an example, the Alloy 25 response curves in Figure XVI-25 indicate how low, standard and high aging temperatures affect both peak properties and the time required to reach peak strength.

At the low temperature of 500°F (260°C), the strength of Alloy 25 increases slowly, and peak strength is not reached until approximately 30 hours. At the standard temperature of 600°F (315°C), Alloy 25 exhibits virtually no change in strength after the first 3 hours of exposure. At the high aging temperature of 700°F (370°C), Alloy 25 reaches peak strength in 30 minutes and declines almost immediately. In short, as aging temperature increases, the time necessary to reach peak strength decreases, as does maximum obtainable strength. This response is similar for all copper beryllium alloys, but at different standard temperatures.

Copper beryllium can be age hardened to varying degrees of strength. The term peak aged refers to copper beryllium aged to maximum strength. Alloys age hardened to a level less than maximum strength are called underaged, and alloys aged to and beyond maximum strength are called overaged. Underaging copper beryllium increases toughness, uniform elongation, and fatigue strength. Overaging increases the alloy's electrical and thermal conductivities and dimensional stability. Copper beryllium never ages at room temperature even after storage for significant lengths of time.

Allowable variances in age hardening time are dependent on furnace temperature and final property requirements. To peak age at standard temperature, furnace time control is typically +/- 30 minutes. More precise time control is required to avoid overaging during high temperature aging. For example, the aging time of Alloy 25 at 700°F (370°C) must be controlled to +/- 3 minutes to hold peak properties. Similarly, underaging requires tight control of the process variables because of the sharp initial increase in the aging response curve. In the standard process, place a thermocouple near the center of mass of the parts to determine when the desired temperature is achieved.

Materion strongly recommends using recirculating air furnaces with controlled atmospheres for heat treating these alloys. The best option is a reducing atmosphere consisting of about 95% N_2 and 5% H_2. Keep the dew point below -40°C (-40°F) and the O_2 level below 15 ppm to ensure very low moisture and/or oxygen in the furnace. Alternatively, pure N_2, H_2, or other inert gas may also be used. Try to keep the temperature within ±10°C (±15°F) of nominal for best results. To prevent excessive oxidation, let the parts cool in the furnace to around 65°C (150°F) or lower before removing them.

Materion's "Guide to Copper Beryllium" contains a complete set of aging response curves. For additional information, please see Materion's TechBrief "Heat Treatment of Copper Beryllium."

MATERION

©2020 Materion Brush Inc.

Heat Treatment Distortion

Shape distortion occurs during the age hardening of heat treatable tempers of copper beryllium after stamping. Mill hardened copper beryllium is not subject to shape distortion. The cause of aging distortion in small parts is non-uniform residual stresses resulting from mechanical forming operation (Figures XVI-26).

There may be variation in the residual stress in the input material depending on how it is fed through the die. It is important to keep track of how you are feeding the coil. For example, is the coil set up or down? Is the burr side up or down?

Residual stresses in the base metal may cause distortion in stamped or machined parts, even before heat treatment. These stresses may come from:

- Slit or stamped edge stresses due to improper die clearances or tool wear
- Residual stamping stresses from coining, thermal expansion, or slippage of the material in the die due to inadequate stripper pressure
- Machined surface stresses from improper feeds, speeds, and cutting depths
- Machined surface stresses from tool wear, thermal expansion, excessive heating, or inadequate cooling
- Residual stresses from straightening rod or flattening/leveling sheet or coil.

The following options may reduce distortion:

- Avoiding the causes of residual stress outlined above
- Changing to a mill hardened temper
- Selecting the hardest temper that will meet formability requirements
- Fixturing during the age hardening process
- Eliminating stress in the parts
- Providing uniformity in stress using a two-step bend process (Figure XVI-27)
- Increasing the age hardening temperature with decreased time at temperature
- Designing the part so that heat treating will move the part into the specified dimension

Figure XVI-26 Distortion During Age Hardening




Figure XVI-26 Distortion During Age Hardening
Compressive stresses promote the aging process and tensile stresses inhibit the aging process, per LeChatelier's Principle. The inside of the bends typically have compressive residual stress, and will respond to the age hardening process more quickly than the outer bend surface. Since the material contracts while hardening, this has the effect of pulling the bend more closed, as the softer outer layers have less strength than the harder, stiffer inside layers, and will not resist the closing movement. Later, as the outer surface shrinks in response to heat treatment, its movement is constricted by the stronger, harder material on the inside of the bend, so the bend does not straighten out as much as expected.

Figure XVI-27 Two-Step Bend Process




Figure XVI-27 Two-Step Bend Process
One method to prevent distortion during age hardening is to use a two step bend process. First, overbend the strip (i.e., form the strip to a tighter angle than required), after natural springback. Secondly, bend it back to the final position. (This is easier to accomplish on a multi-slide tool than on a progressive die.) This operation does create a very complicated stress state through the bend cross section (more than 4 distinct zones), but the stresses will be more balanced, resulting in negligible distortion during heat treatment. Typically, an overbend of 10-15 degrees should be sufficient. The exact amount depends on thickness, bend radius, bend angle, and temper (yield strength and modulus), and may require some tweaking to perfect the angle.

©2020 Materion Brush Inc.

Rules of Thumb for Heat Treating Stamped Parts:

- Material shrinkage during heat treat requires allowance in the die progression.
- The material may require coining in the bend area to achieve a repeatable and predictable movement during heat treat. Excessive coining may cause cracking.
- Degrease before heat treating to ensure that there is no baked-on lubricant, which can cause problems in cleaning before plating, the plating process itself, or increase contact resistance in bare contacts.
- When bulk heat treating parts on a reel in a furnace: (Figure XVI-28)
  - Use an interleaf to prevent part damage or distortion. (Left side of Figure XVI-29). This also will allow the strip to move when it shrinks. The interleaf should be made out of stainless steel or another material with a thermal expansion coefficient comparable to CuBe. A copper beryllium interleaf may be required for extremely fine parts to account for both thermal expansion and heat treat shrinkage.
  - Strip shrinkage requires reel tension control. Spacers (standoffs) may control the winding tension. (Right side of Figure XVI-29).
  - Carrier strip straightness requires heat treat reel diameter consideration. Increasing the reel diameter decreases the bend on the inner windings.

For more detailed information on shape distortion see the Materion TechBrief "Shape Distortion During Age Hardening of Copper Beryllium Parts."

Figure XVI-28 Heat Treating Stamped Reels

- "Pancake" Style
- Hung from Rack




Figure XVI-28 Heat Treating Stamped Reels
Reels can be heat treated horizontally in furnace, "pancake" style, or they can be hung vertically from a rack in the furnace. The coils should be individually wrapped to prevent unwrapping or telescoping. The individual coils are stacked with the coil wraps lined up to provide space between the coils for air to circulate.

Figure XVI-29 Heat Treating Stamped Coils with Interleaf




Figure XVI-29 Heat Treating Stamped Coils with Interleaf
Here, a stainless steel interleaf separates the individual wraps of the stamped parts. The carrier strip contains stamped-in spacer springs whose purpose is to keep the interleaf from crushing the delicate stamped parts.

MATERION

©2020 Materion Brush Inc.

Heat Treatable Versus Mill Hardened

Copper beryllium is available in both heat treatable and mill hardened tempers. Table XVI-3 presents the differences to review prior to selecting the proper temper. For more detailed information on selection of the proper alloy and temper see the Materion TechBrief "Copper Beryllium Strip Temper Selection."

Table XVI-3 - Heat Treatble vs. Mill Hardened Strip

Property	Heat Treatable	Mill Hardened	Cold Rolled Only
Processing	Rolled at mill	Rolled at mill	Rolled at mill
	Shipped to stamper,	Heat treated at mill	Pre-plated if required
	Blanked/formed	Pickled/cleaned at mill	Shipped to stamper
	Cleaned/degreased	Pre-plated if required	Stamped/formed
	Heat treated	Shipped to stamper	Post-plated if required
	Cleaned/pickled if necessary	Blanked/formed	
	Post-plated if required		
Formability	Formed before heat treatment, best possible formability	Formed after heat treatment, limited formability	Limited formability
Yield Strength	Highest strength achievable	Trade-off between strength and formability	Trade-off between strength and formability
Residual Stress	Heat treatment relieves residual stresses from rolling, slitting, blanking, and forming	Contains residual stresses from slitting, blanking, and forming	Contains residual stresses from slitting, blanking, and forming
Directionality/ Baushinger Effect (Figure 87)	Nearly isotropic properties, responds equally to applied strain regardless of direction	Reduced yield strength when applied strain is in reverse direction to forming strain	Hightly directional, reduced yield strength when applied strain is in reverse direction to forming strain
Stability	Minimal stress relaxation at elevated temperatures	Subject to increased stress relaxation due to residual stresses	Limited inherent resistance to stress relaxation
Distortion During Heat Treatment	Shrinkage during heat treatment, non-uniform stresses can cause distortion.	No shrinkage or dimensional change after forming	No shrinkage or dimensional change after forming
Plating	Must be post-plated after forming, heat treatment and surface cleaning	Can be plated before or after forming	Can be plated before or after forming

MATERION

©2020 Materion Brush Inc.

Bauschinger Effect

Section V – Connector Materials and Their Properties discussed the Bauschinger Effect. One of the consequences of this is that formed contacts that are deflected back against the forming direction will experience a lower effective yield strength and earlier than expected permanent set, while those deflected in the opposite direction will experience a higher effective yield strength (due to strain hardening) and reduced permanent set. However, materials that are heat treated after forming will have these residual forming stresses completely relieved, so they can be deflected in either direction. Mill hardened materials, or those that are strengthened by cold work alone like brasses and bronzes, should only be deflected in the forward direction. Those that are heat treated after stamping may be deflected in either direction. (Figure XVI-30)

Figure XVI-30 Heat Treated vs. Mill Hardened Load Cases




Figure XVI-30 Heat Treated vs. Mill Hardened Load Cases
In the top case, the high stress area bend is bent forward (further in the forming direction). Either age hardenable or mill hardened material will work in this scenario. Furthermore, alloys that are strengthened by cold work alone can be used in these circumstances. In the bottom case, the high stress bend area is bent back against the original forming direction. Age hardenable material will work perfectly in this case, since the heat treatment will relieve any residual stresses and the finished part will obtain the full benefit of the heat treated material. Because of the Bauschinger effect, the residual stress in mill hardened or cold worked alloys will result in a net decrease in yield strength, as well as a reduction in stress relaxation resistance.

MATERION

©2020 Materion Brush Inc.

Shape Effects

Flatness is the degree to which a surface of a flat product approaches a plane. Flat strip is preferable with virtually no crown, edge wave or center buckle (oil canning). Coil set (longitudinal curl) is a unidirectional departure from longitudinal flatness. Crown is the variation in thickness from edge to edge and edge to center. See Figure XVI-31 for examples. Input strip shape can be improved by levelling (Figure XVI-32). However, these levelling processes may induce additional residual stresses that can cause distortion during subsequent stamping or heat treating operations. (This is because leveling does not usually relieve stresses, it merely balances them to maintain flatness). Thermal stress reliefs are usually best for removing residual stresses, although BF158 does not thermally stress relieve in a reasonable amount of time, because of its excellent resistance to stress relaxation. For high strength copper beryllium alloys, a treatment time of 1 to 1.5 hours at 200 to 225°C (450 to 500°F) should be sufficient to relieve most stresses. For high conductivity copper beryllium, the temperature can be increased to 300 to 350°C (575 to 650°F). These temperatures are high enough to cause stress relaxation but not high enough to enable metallurgical changes through precipitation hardening.

Figure XVI-31 Potential Shape Problems in Strip




Figure XVI-31 Potential Shape Problems in Strip
These are the defects that all strip materials are prone to experiencing. In most cases, the undesirable deformation is caused by residual stresses and strains, where one part of the strip is longer than another part. Careful processing at the mill will control these potential defects. Some can theoretically be removed later by levelling, but this will add additional residual stress that could result in significant distortion of stamped parts either during stamping or subsequent heat treatment. Stamping processes can also impart some of these shape defects to the stamped coils, even when there was no problem with the input coil.

Figure XVI-32 Levelling Processes to Control Strip Shape

- Roller leveling (repeated bending)
- Tension leveling (stretching)
- Stretch-Bend leveling (both bending and stretching)




Figure XVI-32 Levelling Processes to Control Strip Shape
Tension levelling adds a uniform tensile strain over the entire cross section, which may be locally added to or subtracted from by the residual stresses present before levelling. Roller levelling adds reversing tensile and compressive strain to the upper and lower surfaces, but the effect varies throughout the cross section. The surfaces see the most benefit, and the material at the neutral axis is not affected at all. Stretch bend levelling combines the benefits of both processes, and has the effect of moving the neutral axis in bending closer to the compressive stress side, so all of the cross section experiences the benefit of reversing stress. It is critical to note that in order to be truly effective, the material must be strained to near yield strength. Be aware that these processes balance residual stress and make it more uniform, but they do not eliminate it.

©2020 Materion Brush Inc.

Flatness and straightness are critical to feeding and indexing automated assembly machines. A heat distortion test is one method to measure flatness variation caused by internal stress. Samples are prepared parallel and perpendicular to the rolling direction prior to heat treatment. The samples are heat treated and measured for out-of-plane variation. A second method is to wire EDM narrow fingers in the longitudinal and transverse directions in the strip, and measure the departure from horizontal (Figure XVI-33). A third method would be to wire EDM samples in the longitudinal, transverse and 45° directions, and then chemically etch through half of the thickness, without heat treating. Residual stress gradients through the thickness will cause the samples to bend or curl (Figure XVI-34). Another method is to measure the residual stress in a material with an X-ray diffraction (XRD) technique. The device may be configured to scan the stress in a line across the surface, or by progressively chemically etching through the metal, an XRD device can determine the through-thickness stress gradient. These methods are too time-consuming, labor-intensive or costly to use on a production basis, but they may be used on occasion to monitor processes.

The method to measure internal stress generated in a stamping die is an angular distortion test. Samples are formed to a known angle prior to heat treatment. Following heat treatment, measure the distortion from that angle to determine the level of internal stress.

Figure XVI-33 Wire EDM Residual Stress Testing




Figure XVI-33 Wire EDM Residual Stress Testing
Flat strip going into the die does not necessarily mean flat strip coming out. Often, when strip is leveled to be flat, the levelling process adds significant residual stress, which balance each other out, producing a flat shape. When metal is removed during stamping, photoetching, EDM'ing, etc., the stresses may become unbalanced again, resulting in distortion in stamping or heat treat. The images above were taken during an experiment to deliberately induce residual stress into metal, to illustrate the effectiveness of EDM'ing narrow fingers into the material to quantify or qualify residual stress. The as-produced Alloy 25 and Alloy 190 on the top showed little distortion, while the extreme residual stress case illustrates the effectiveness of the EDM method of qualification of residual stress.

Figure XVI-34 Etching to Half Thickness




Figure XVI-34 Etching to Half Thickness
Another method to gauge residual stress in material is to photochemically machining away half the thickness. These are the same input materials as shown in Figure XVI-32.

©2020 Materion Brush Inc.

Residual Stress in Stamping from Non-Symmetric Loading and Unintended Coining

When the stripper plate comes down to hold the strip in place during stamping, it may coin the surface of the strip on the edges. This so-called hammer effect locally reduces material thickness and potentially induces residual stress that can cause problems later.

This can be even worse if the stripper plate is tilted slightly off center, because of a non-symmetric load distribution among all the dies and punches. (That is, the punches and forming tools will not be laid out symmetrically in the die). This can create shape problems in the strip, such as die exit twist and camber.

Sophisticated stamping presses can use bottom dead point stopper blocks to keep the stripper assembly, punches, tools and dies aligned, and to prevent coining of the input strip. (Figure XVI-35).

Figure XVI-35 Controlling Non-Symmetric Effects

- Bottom Dead Point (BDP) stopper blocks




Figure XVI-35 Controlling Non-Symmetric Effects
The bottom dead point of the die stroke will vary during the stamping process. Bottom Dead Point (BDP) stopper blocks may be used to combat the non-symmetric loading. They prevent rotation of the stripper plate to keep the load symmetric on the X and Y axes. However, as the press heats up during operation, the BDP stopper blocks may lose vertical accuracy due to differential thermal expansion. More sophisticated stamping machines using numerical control can compensate automatically for shifting BDP's.

©2020 Materion Brush Inc.

Slit or Stamped Edge Features

Figure XVI-36 shows a typical blanking or piercing operation. As the punch descends through metal, the material first deforms by rolling over, then fractures form on the top and bottom edges, then as the fractures propagate toward each other, the remainder of the material shears all the way through. This creates the features found on the edge of every stamped part, shown in Figure XVI-37. (Identical features are found on the edge of slit strip.) When you are designing your contact, be sure that the rollover side of the strip is the one in tension, and that the burr side of the strip is in compression. This will minimize stress concentration, reduce permanent set, and improve fatigue life.

Figure XVI-36 What Happens During Blanking




Figure XVI-36 What Happens During Blanking
Here, only the punch, die, and strip material are shown for clarity. After the punch makes contact (1), the material starts to rollover on the top and bottom surfaces (2). The material continues to deform (3), and fractures start forming at the edges (4). Eventually, and with proper clearance, the fractures meet as the remaining material is sheared through (5), and burrs form on the bottom of the material and the top of the slug. The punch retreats, and the slug is allowed to fall through the bottom of the die to be collected as scrap (6).

Figure XVI-37 Stamped/Slit Edge Cross Section – Key Features




Figure XVI-37 Stamped/Slit Edge Cross Section – Key Features
The ideal blanked edge condition is 50-60% Shear (Cut) and 50-40% Break (Tear). This results in minimum burr, low residual stress, less distortion, and longer tool life.

MATERION

©2020 Materion Brush Inc.

Burrs are the thin ridges or roughness left by a cutting operation such as slitting, shearing, blanking or sawing. Extremely localized plastic deformation results from the combination of shearing and fracture. These geometric features of cut or slit edges, such as "roll over," "cut/break ratio" and "burrs") are dependent upon material strength, tooling clearances and cutting tool sharpness (Figures XVI-38 and XVI-39). Improper clearances result in excessive burrs, as shown in Figure XVI-40.

Figure XVI-38 Tooling Clearances for Piercing/Blanking




Figure XVI-38 Tooling Clearances for Piercing/Blanking
The ideal punch guide clearance for precision stamping with micron tolerances is 30-90% of the punch-die clearance.

Figure XVI-39 Tool Clearances Per Side for Blanking

Edge Quality Grades



	A	B	C	D	E
Rollover %	2 - 5	4 - 7	6 - 8	8 - 10	10 - 20
Shear/Burnish %	50 - 70	33 - 55	25 - 50	15 - 25	10 - 20
Fracture/Break %	25 - 45	35 - 50	50 - 60	60 - 75	70 - 80
Fracture Angle (°)	-	6 - 11	7 - 11	8 - 11	14 - 16
Burr Height	Very Large	Large	Normal	Normal	Large
Tool Wear Rate	Very fast	Fast	Normal	Slow	Very Slow
% Clearance Between Punch and Die for CuBe	1.5 - 2.5	3 - 5	7 - 11	12 - 13	23 max.

Punch-Die Clearance (PDC) = strip thickness X
% clearance between the die and punch

Figure XVI-39 Tool Clearances Per Side for Blanking
This table shows the clearances responsible for various edge conditions for CuBe and CuNiSn strip. Note that as the tooling wears, the edge condition will progress from left to right..

Figure XVI-40 Severe Stamping Burrs




Figure XVI-40 Severe Stamping Burrs
This is what severe stamping burrs look like. It is easy to see why they could function as stress risers create significant problems with yielding and/or fatigue.

MATERION

Slit or blanked edge deformation results in work hardening and residual stress extending to a depth of 50-100% of the strip thickness perpendicular to the slit/blanked edge. These edges exhibit a hardness increase of 10-15% over the base metal hardness (DPH scale), and have residual stress up to 20% of the 0.2% offset yield strength of the base metal. The residual stress is more important as width to thickness (w/t) ratio decreases. Edge conditioning is effective in relieving edge stress from slitting and blanking, but only by removing edge material to a depth of approximately 100% of the strip thickness (Figure XVI-41). Fine pitch connectors utilize rough sheared edges after stamping as contact surfaces. To minimize rough edges, keep tools sharp with a punch to die clearance equal to 3% of the stock thickness. Also, 25-50% shear on edge is desirable.

Die exit camber (edgewise curvature) is the lateral departure of the strip edge from a straight line, which may be unidirectional or reversing (Figure XVI-42). Die exit twist is rotation of the strip around the longitudinal axis (Figure XVI-43). These can be controlled by tension leveling or stress relieving the strip before feeding into the die. Alternatively, use a carrier strip on both sides of the die progression (Figure XVI-44), notch the edges of the carrier strip at short intervals (Figure XVI-45) or shave the slit edges off the edge of the strip with the first blanking step (Shown in Figure XVI-46).

Figure XVI-41 Edge Conditioning




Figure XVI-41 Edge Conditioning
First, a pilot hole that is a little smaller than the desired final hole is created by piercing, which leaves significant stress around the edges of the hole. Then, a second operation shaves off the stressed material around the edges, leaving a much smaller amount of residual stress behind.

Figure XVI-42 Die Exit Camber




Figure XVI-42 Die Exit Camber
Die exit camber is in-plane bending caused by residual slitting stresses and uneven working of the sides of the strip. The strip will generally curve toward the less heavily worked (less elongated) side.

MATERION

©2020 Materion Brush Inc.

Figure XVI-43 Die Exit Twist




Figure XVI-43 Die Exit Twist
Die exit twist is down the length rotation caused by unbalanced residual stresses on the sides of the strip, along with uneven stresses on the top and bottom.

Figure XVI-44 Double Carrier Strip to Control Shape




Figure XVI-44 Double Carrier Strip to Control Shape
Using carrier strips on both sides is a last resort option, as it adds to cost (requiring wider strip and resulting in more scrap) and makes subsequent assembly steps more difficult.

Figure XVI-45 Notching to Control Shape




Figure XVI-45 Notching to Control Shape
Notching the carrier strip at evenly spaced intervals minimizes the differential length of each edge that can camber and twist. That is, the edge is free to form many small, discontinuous curves, instead of one continuous curve down the whole length of the carrier strip.

Figure XVI-46 Controlling Shape with Shaved Edges




Figure XVI-46 Controlling Shape with Shaved Edges
One additional method to control distortion is to remove stressed material (stressed width » thickness) from each edge as 1st blanking step (also known as a French cut, French notch or pitch notch). This eliminates residual slitting, blanking, piercing, etc. stress as a potential cause of distortion. The width removed from the edges is shown larger in the figure above for clarity.

©2020 Materion Brush Inc.

When stamping narrow contacts (width-to thickness ratios approximately equal to 1), the material can cock (rotate along the beam axis) in the die, resulting in large fractured areas and heavy burrs on the stamped edge (Figure XVI-47). It is best to ensure that both sides of these beams are blanked simultaneously to prevent the rotation from occurring (Figure XVI-48).

Figure XVI-47 In-Die Rotation of Narrow Beams

- Maximize Fc
- Maximize Fs
- Minimize Fp
- Use Symmetric Blanking




Figure XVI-47 In-Die Rotation of Narrow Beams
The frictional force from the punch on the edge of the beam, can cause rotation of a narrow beam in the die. This results in a non-uniform cross section and a rollover ridge on the burr side (usually bottom) surface. To control:

- Maximize stripper clamping force Fc
- Maximize stripper frictional force Fs
- Minimize punch frictional force Fp
- Use Symmetric Blanking

Figure XVI-48 Symmetric Blanking to Prevent In Die Rollover




Figure XVI-48 Symmetric Blanking to Prevent In Die Rollover
Symmetric blanking prevents down-the-length rotation of stamped beams in the die, helping to keep the residual stresses balanced and the edges symmetric.

MATERION

©2020 Materion Brush Inc.

When forming a bend, it is best to ensure that the burr side of the stamped or slit edge falls on the inside radius (compressive stress side) of the bend. If the fractured edge falls on the tensile side (as shown in Figure XVI-49), the rough edges can function as stress risers that can easily initiate and propagate fatigue cracks, reducing the fatigue life of the contact.

Coining (Figure XVI-50) is beneficial where one area requires high strength and another area requires good formability. Coining affects base metal properties by increasing the yield strength (due to work hardening), reducing the elastic limit, lowering ductility, degrading bend formability and diminishing stress relaxation resistance. Thermal stress relief may partially restore the elastic limit and stress relaxation resistance. The transition between coined and uncoined areas may function as a stress riser that could result in an overstress condition or an early fatigue failure.

Figure XVI-49 Stress Risers on Tensile Stress Side of Bend




Figure XVI-49 Stress Risers on Tensile Stress Side of Bend
In this case, the part shows significant stress risers due to the fracture zone and edge burrs on the tensile stress side of a bend. During operation, this could lead to early fatigue failure, and sooner than expected permanent set. It is usually best to keep the rollover edge on the tensile side of the bend, and the burr edge on the compressive side.

Figure XVI-50 Coining

- Cut Side
- Break Side




Figure XVI-50 Coining
Coining can be done intentionally to precisely locate bends, to increase the R/t ratio (by decreasing the thickness), to provide a “knife-edge” on IDC’s, or to round edges of compliant pins. It could also be unintentional, arising from punch bottoming (the hammer effect). Coining locally increases the yield strength, decreases the elastic limit, decreases ductility/formability, worsens stress relaxation performance, and reduces the elastic modulus. You should avoid coining in areas with high stress (stress concentration at the edge of the coined area leads to fatigue), large deflections, and moderate to severe forming requirements.

©2020 Materion Brush Inc.

Drawing, Embossing and Deep Drawing

Deep drawing operations require good work hardening capacity (high strain hardening exponents). Therefore, lower strength tempers will draw better than higher strength tempers. It may be difficult to do any kind of drawing or embossing operations on high strength mill hardened tempers. For any deep drawing, you should only use annealed temper. The finished parts should be heat treated after all drawing operations are done. Extremely deep draws may require intermediate solution annealing, quenching and cleaning steps to soften the material for further drawing or ironing.

Fineblanking

Fineblanking is a tighter tolerance blanking process that produces much finer edges than conventional blanking. In conventional blanking, a punch moves down through the material into a stationary bottom die, which contains a hole for the slug to fall through. In fineblanking, there is no hole under the material, and a counterpunch holds the strip firmly in place against the punch as it descends. Simultaneously, the bottom die rises around the area to be blanked, and the top side of the strip is held firmly in place against the bottom die as it rises. The net result is that each blanked edge is sheared simultaneous from both the top and bottom, and these shear zones meet in the middle so there is theoretically no fracture zone or burr.

Punches and Dies

Punches and dies are susceptible to wear (Figure XVI-51) and to other forms of damage such as chipping and cracking

(Figure XVI-52). As the punches wear or chip, the tooling clearances are effectively increased. This may make parts that are highly stressed and/or out of geometric tolerance. The best way to improve the life of the tools and to keep making quality stamped parts is to provide the tools with hard, lubricious, wear-resistant coatings

(Figure XVI-53). Some examples are:

- Diamond Black
  - Chemical or Physical Vapor Deposition (PVD or CVD)
  - Ra = 0.03 - 0.09 micrometers
  - 3,000 - 12,000 HV
- Diamond Like Carbon
  - Plasma Assisted CVD
  - 1,200 to 3,000 HV
  - Smoother surface
- Drawbacks
  - Difficulty in adhering to punch and die surfaces
  - Much lower coefficient of thermal expansion than base metal increases stresses
- Chromium Plating
  - Electrodeposition
  - 900 - 1200 HV, can be increased by nitriding the surface
  - Low coefficient of friction, good wear resistance
  - Usually < 0.1% elongation
  - May lower the fatigue strength of the base metal (unless shot peened first)
- Titanium Nitride (TiN)
  - CVD, PVD
  - 2000 - 2200 HV
  - Good wear resistance and lubricity
  - Best for drawing
  - PVD coatings may have some residual compressive stress to aid resistance to fatigue failure
- Titanium Carbide (TiC)
  - CVD
  - 2800 - 3200 HV
  - Low friction, good wear resistance
  - Loses hardness rapidly with temperature; better for low speeds
- Titanium Carbonitride (TiCN)
  - CVD, PVD
  - 2500 - 3000 HV
  - Good wear resistance, holds hardness at temperature.

Figure XVI-51 Tooling Wear




Figure XVI-51 Tooling Wear
The punch and die materials may wear off, or they may adhere to the strip, and vice versa. This effectively changes the dimensions of the tools, by widening the punch die clearance (PDC), and induces more residual stress & strain.

MATERION

©2020 Materion Brush Inc.

Figure XVI-52 Punch Damage




Figure XVI-52 Punch Damage
There are many ways that punches and dies can become damaged over time. This results in changed clearances in the tool as well as poor edge quality and increased residual stress in stamped parts.

Figure XVI-53 Improving Tool Life




Figure XVI-53 Improving Tool Life
Tool life can be greatly improved by polishing and by adding one of the coatings specified in the text.

Other Effects

Tolerance Effects

A number of factors contribute to tolerance variations including production related concerns such as tool dimensions and clearances, tooling set-up, materials, operator and environment. Design related effects such as material width, thickness, length, contact gap and alignment contribute as well. These factors also tend to change over time.

Surface Roughness

The Ra value of surface roughness is an indication of surface irregularity measured by the arithmetic mean of the surface variations. The Rq value of surface roughness is an indication of surface irregularity measured by the root-mean-square (RMS) of the surface variations. Typical values for commercial spring material prior to plating are 4-8 RMS.

Proper Storage of Material Before and After Stamping/ Machining/etc.

To keep the surface clean and ready for plating or soldering, it is important to minimize the potential for oxidation. The best way to keep the surface clean is to avoid condensation. If you are receiving a shipment of strip or wire in a sealed package, it is important to make sure that the material comes to room temperature before you break the seal, particularly if you are in a humid environment. If you are going to store the material for a while before processing, make sure that you keep it in a climate-controlled room (both temperature and humidity regulated), so that condensation is unlikely. See the Tech Brief "Storage of Materion Copper-based Strip Products" for more information. If staining or oxidation does occur, then you would need to clean the material before being able to plate or solder it.

Cleaning (Degreasing and Pickling)

After stamping, you will need to degrease the material before heat treating, plating, etc. to remove any residual rolling or stamping oil on the surface. You may use a high pressure water spray around 50°C or 125°F, with or without soap. Trisodium phosphate and similar alkaline solutions also work well. (Use with ultrasonic agitation for best results) Vapor degreasing is also very effective on these materials.

During aging, the copper beryllium alloys develop a surface oxide composed of beryllium oxide and, depending on the alloy and furnace atmosphere, copper oxides. These oxide films vary in thickness and composition and are often transparent. In a typical age hardening heat treatment (2 hours at 600°F [316°C]) in an "inert" atmosphere, expect a film thickness of about 1.2 µ-inches (300 angstroms) on Alloy C17200. Under solution annealing conditions (1450°F [788°C]), the film can reach as much as 12-50 µ-inches (1000-1200 angstroms).

©2020 Materion Brush Inc.

Even a pure hydrogen atmosphere or a hard vacuum cannot suppress surface oxidation of beryllium during age hardening. However, some atmospheres can minimize the copper oxidation. Plain air atmospheres contribute the most to surface oxide and reducing atmospheres the least. The oxide films must first be removed from the surface in order to plate, braze or solder parts.

Connector manufacturers frequently age harden the copper beryllium after stamping and must clean the parts before subsequent processing. There are many acid combinations which can be used, but those proven most successful in removing films containing beryllium oxide are sulfu-ric/peroxide (20%H_2SO_4, 3%H_2O_2 at 125°F [52°C]) and phosphoric/nitric/acetic (PNA) (38% H_3PO_4, 2% HNO_3, 60% acetic acid at 160°F [71°C]). Nitric acid alone does not do an adequate job of removing beryllium oxide films unless these films are pretreated in hot, concentrated caustic (50-60% NaOH at 265°F [129°C]).

Following is a note of caution when dealing with any copper alloy containing lead, such as Alloy M25 (C17300). Use nitric acid or PNA rather than a sulfuric acid system because of the insolubility of lead sulfate. Following alkaline cleaning, a preplating acid dip for leaded alloys is fluoboric acid (10-25% at room temperature). A cyanide copper strike is a cleaning and activating step essential for plating leaded alloys.

Additional detailed information is available in the Materion Tech Brief “Cleaning Copper Beryllium.”

Soldering and Solderability

Surface cleanliness is the most important material characteristic. Copper can interdiffuse with tin (Sn) to form Cu_3Sn or Cu_2Sn compounds with some copper enrichment ahead of the intermetallic. The environment will determine the stability of the intermetallic phase or Cu rich phase ahead of it when either grows to reach the surface.

A solder dip test (dip and look method) qualitatively assesses solderability. In this test a piece of material or component is dipped in flux, then immersed in a solder pot. The total percentage of surface area wetted is estimated. A more quantitative evaluation may be done with a solder wetting balance test. As in the dip test, a sample is fluxed then immersed in the solder pot. However, in this case the force exerted on the sample by the solder is continuously monitored. Some key parameters are the time it takes for the upward buoyancy force to be overcome by the downward wetting force, as well as the total wetting force, and the rate of increase in wetting force. Some relevant standards are as follows:

Test Standard	Dip & Look Test	Wetting Balance Test
MIL-STD-883	Method 2003	Method 2022.2
MIL-STD-202	Method 208	-
EIA/IPC/JEDEC J-STD-002	Tests B, B1	Tests F, F1
ISO 12224-3	-	
IEC 60068	Parts 2-20, 2-58	Part 2-69
JIS Z3198	-	Part 4

As with most copper alloys, copper beryllium is easily solderable using readily available solder materials. A sound, reliable solder joint requires proper techniques in surface preparation, materials selection, the soldering process and post solder cleaning. Soldering will not affect copper beryllium’s properties.

Surface impurities such as oil, grease, dust, stain inhibitors, tarnish and oxide account for a major share of soldering problems. Flux is not a substitute for adequate surface preparation and will not reliably remove all surface contamination. Conventional cleaning methods, such as organic solvents, vapor degreasing and alkaline cleaners are usually adequate for removing dirt, oil and grease. Ultrasonic agitation enhances these cleaning agents. Rinse all cleaning solutions from all surfaces after use.

Conventional techniques remove the black or reddish oxides of copper when present. Beryllium oxide (BeO is a transparent, tenacious, refractory compound). BeO as thin as 2 µ-inches (0.05 µm or 500 angstroms) can lead to soldering difficulty. Acid pickling removes oxides formed during heat treatment of copper beryllium.

Solder copper beryllium parts as soon as possible after cleaning. If delays are unavoidable, store the parts in a clean, dry, protected area away from shop dust, acid and sulfurous or ammonia fumes.

Soldering copper beryllium presents no special flux selection problems. As a rule, use the mildest flux that will do the job. Classifications of non-corrosive (rosin) fluxes are non-activated (R), mildly activated

(RMA), and fully activated (RA). The main advantage of rosin based fluxes is that they become active only with heating. The most frequently used fluxes in soldering copper beryllium alloys are RMA and RA. Hot or warm water rinsing will remove any flux residue.

When soldering copper beryllium to other metals, often the other metal establishes the soldering parameters. The high thermal conductivity of copper beryllium is a consideration when soldering to lower conductivity metals. To concentrate heat at the joint may require heat sinks. Additional detailed information is available in the Materion TechBrief “Soldering Copper Beryllium.”

Production of Parts Using Rod or Wire

In applications involving miniature and subminiature circular connectors, sockets and coaxial connectors, the process of alloy specification is not significantly different. Here, the nature of the finished contact requires the designer to work with the specified alloy in rod or wire. In addition, the tempers available in the rod and wire product forms vary significantly from those found with strip products (Table 5). Wire is available in coil form, and rod is available in straight lengths. Wire can also be produced in cross sections other than round. The following table lists the mechanical properties of wire for diameters about 0.050 inches (1.27 mm). For diameters less than 0.050 inch (1.27 mm), contact the wire supplier for properties.

Rod Properties

Table XVI-4 lists typical properties of several alloys available in rod form.

©2020 Materion Brush Inc.

Table XVI-4 - Rod Mechanical Properties

Alloy	Temper	Yield Strength[1] 0.2% Offset (ksi)	Yield Strength[1] 0.2% Offset (MPa)	Tensile Strength (ksi)	Tensile Strength (MPa)	Total Elongation (%) min.	Machinability Rating (C36000 = 100)
25, M25	A	20-35	138-241	60-85	414-586	20	20 (Alloy 25), 50 (Alloy M25)
	H	75-105	517-724	90-130	621-896	8	
	AT	145-175	1000-1207	165-200	1138-1379	4	
	HT	160-200	1103-1379	185-225	1276-1551	2	
165	A	20-35	138-241	60-85	414-586	20	20
	H	75-105	517-724	90-130	621-896	8	
	AT	125-155	1000-1207	150-190	1034-1310	4	
	HT	145-185	1103-1379	170-210	1172-1448	2	
3,10	A	10-30	69-207	35-55	241-379	20	40
	H	50-75	345-517	65-80	448-586	10	
	AT	80-100	552-689	100-130	689-896	10	
	HT	95-125	655-862	110-140	758-965	5	
1915, 1916	HT	70-95	483-655	85-105	586-724	4	70, 80
ToughMet® 3	TS160U	150 min	1034 min	160 min	1103 min	5	No data
Other Copper Alloys[2]							
C14500, C14520	1/2 H	39-40	269-276	44-49	303-338	18	85
	H	42-43	290-296	48-53	331-365	10	
C14700, C18700	1/2 H	38-40	262-276	42-43	290-296	18	85
	H	42-50	290-345	48-55	331-379	8	
C33500	1/4 H	15 min.	103 min.	42-65	290-448	10	60
	1/2 H	20 min.	138 min.	50-80	345-552	7	
C34000,	1/4 H	15 min.	103 min.	42-65	290-448	10	70
C35000	1/2 H	20 min.	138 min.	50-80	345-552	7	
C35300	1/4 H	15 min.	103 min.	42-65	290-448	10	90
	1/2 H	25 min.	172 min.	55-80	379-552	7	
C36000	1/2 H	15 min.	103 min.	40 min.	276 min.	10	100
	H	30 min.	207 min.	65 min.	448 min.	4	
C51000	1/2 H	75-92	517-634	80-97	552-669	8	20
	H	103-122	710-841	108-128	745-883	5	
	S	130 min.	896 min.	135 min.	931 min.	2	
C52100	1/2 H	80-105	552-724	95-115	655-793	10	20
	H	120-145	827-1000	125-150	862-1034	3	
	S	135 min.	931 min.	140 min.	965 min.	2	
C53400	H	-	-	50 min.	345 min.	15	70
C53800	S	116 min.	800 min.	131 min.	903 min.	1	80
C54400	H	57-63	393-434	68-75	469-517	15	80
C63000	1/2 H	62-75	427-517	112-118	772-814	15	30
C69750	A	22 min.	152 min.	65 min.	448 min.	50	90
	S	87-119	600-820	102-138	703-952	1	
C72500	H	88	607	95-110	655-758	5	20
	S	82	565	110-125	758-862	3	
C76300	H	80	552	93	641	2	50
C7960	H	68	470	87	600	10	95
C79800	H	102	700	113	779	2	90
C79860	H	104	717	118	814	2	90

* Yield strength values in red font are at 0.5% Extension Under Load. All others are at 0.2% offset.

** Listed properties are ASTM standard properties for the generic UNS numbers, according to the Copper Development Association (www.copper.org). Actual properties may vary from supplier to supplier.

©2020 Materion Brush Inc.

Wire Properties

Table XVI-5 lists typical properties of several alloys available in wire form.

As shown, the specific properties of the various alloys do not change significantly in the transition from strip to rod and wire form. The differences in mechanical properties are a result of the wire drawing process itself. The only exception in the specification process is the fact that the designer must evaluate the alloy's machinability rather than formability.

Table XVI-5 - Wire Mechanical Properties

Alloy	Temper	Yield Strength 0.2% Offset (ksi)	Yield Strength 0.2% Offset (MPa)	Tensile Strength (ksi)	Tensile Strength (MPa)	Total Elongation (%) min.
Materion Alloys						
25, M25	A	20-35	138-241	58-78	400-538	30
	1/4 H	75-105	517-724	90-115	621-793	3
	1/2 H	90-125	621-862	110-135	758-931	2
	3/4 HT	115-150	793-1034	130-155	896-1069	2
	H	130-160	896-1103	140-165	965-1138	1
	AT	145-180	1000-1241	160-200	1103-1379	3
	1/4 HT	165-200	1138-1379	175-210	1207-1448	2
	1/2 HT	170-210	1172-1448	185-215	1276-1482	2
	3/4 HT	175-220	1207-1517	190-230	1310-1586	2
	HT	180-220	1241-1517	195-230	1344-1586	1
3,10	A	10-30	69-207	35-55	241-379	20
	H	55-75	379-517	65-80	448-552	2
	AT	80-110	552-758	100-130	689-896	10
	HT	95-125	655-862	110-140	758-965	10
174	1/2 HT	80-100	552-689	95-115	655-793	10
	HT	100-120	689-827	100-130	689-896	8
1915, 1916	HT	75-100	517-689	85-105	586-724	4
Other Copper Alloys						
C51000	1/2 H	75-92	517-634	80-97	552-669	8
	H	103-122	710-841	108-128	745-883	5
	S	130 min.	896 min.	135 min.	931 min.	2
C52100	1/2 H	80-105	552-724	95-115	655-793	10
	H	120-145	827-1000	125-150	862-1034	3
	S	135 min.	931 min.	140 min.	965 min.	2
C72500	H	88	607	95-110	655-758	5
	S	82	565	110-125	758-862	3

Machinability

The machinability of a given alloy depends on such factors as the operation type, tool life, tooling and tool geometry. A general machinability rating (Table XVI-6) provides the designer with rough machinability guidelines for the available alloys. The machinability rating is determined through the procedure outlined in ASTM E 618. Machinability test specimens as shown in Figure XVI-54 are machined out of 1 inch (25.4 mm) diameter rod. The machining speeds and feeds are adjusted to find the combination that provides a tool life of 8 hours. Tool life is measured by the length of time in which the test pieces produced are within dimensional and surface roughness tolerances. The maximum number of pieces produced per hour at a tool life of 8 hours becomes the machinability rating. It is expressed as a percentage of the number of pieces produced per hour by C36000 free-cutting brass, the most machinable metal.

Note that the machinability rating is not an absolute number. Many factors influence machinability. Material will respond differently to different machining operations.

MATERION

©2020 Materion Brush Inc.

Table XVI-6 - Machinability Rating[1]

Alloy	Composition	Nominal Yield Strength	Minimum Percent Elongation	Electrical Conductivity % IACS	Machinability Rating Per ASTM E618 (Free Cutting Brass = 100%)
Materion Rod and Wire Alloys					
C17200 - 25 HT	CuBe (Cu-1.8%Be)	200 ksi / 1379 MPa	1	25	20%
C17300* - M25 HT	CuBe (Cu-1.8%Be-0.3Pb)	200 ksi / 1379 MPa	1	25	50%
C17510 - 3 HT	CuBe (Cu-2%Ni-0.35Be)	110 ksi / 758 MPa	10	54	40%
C19150* - 1915 HT C19160* - 1916 HT	CuNiPb (Cu-1%Ni-1.0%Pb)	88 ksi / 607 MPa	4	48	75%
C72900 - ToughMet® 3 TS160U	CuNiSn (Cu-15%Ni-8%Sn)	150 ksi / 1035 MPa	5	7	20%
Other Copper Rod and Wire Alloys					
C14500 - H	Tellurium Copper (Cu-0.6%Te-0.008P)	49 ksi / 338 MPa	10	85	85%
C14520 - H	Phosphorous Deoxidized Tellurium Copper (Cu-0.6%Te-0.008P)	49 ksi / 338 MPa	10	75	85%
C14700 - H	Sulfur-Bearing Copper (Cu-0.35%S-0.0035%P)	49 ksi / 338 MPa	10	90	85%
C18700 - H	Free-Machining Copper (Cu-1.2% Pb)	50 ksi / 345 MPa	8	90	85%
C33500 - 1/2 H	Low-Leaded Brass (Cu-37%Zn-0.5%Pb)	25 ksi / 172 MPa	7	26	60%
C34000 - 1/2 H	Medium Leaded Brass (Cu-37%Zn-1.2%Pb-0.15%Fe)	25 ksi / 172 MPa	7	26	70%
C35000 - 1/2 H	Medium Leaded Brass (Cu-37%Zn-1.4%Pb-0.15%Fe)	25 ksi / 172 MPa	7	26	70%
C35300 - 1/2 H	High Leaded Brass (Cu-37%Zn-2%Pb-0.15%Fe)	45 ksi / 310 MPa	25	26	90%
C36000* - 1/2 H	Free-Machining Brass (Cu-35%Zn-3% Pb)	52 ksi / 359 MPa	18	26	100%
C51000 - 1/2 H	Phosphor Bronze A (Cu-5%Sn-0.2%P)	58 ksi / 400 MPa	25	15	20%
C52100 - 1/2 H	Phosphor Bronze C (Cu-8%Sn-0.2%P)	65 ksi / 448 MPa	33	13	20%
C53400* - H	Phosphor Bronze (Cu-4.5%Sn-1%Pb-0.1%P)	63 ksi / 434 MPa	15	20	60%
C53800* - H	Leaded Tin Bronze (Cu-13.5%Sn-0.5%Pb)	116 ksi / 800 MPa	5	9	80%
C54400* - H	Leaded Phosphor Bronze (Cu-4%Sn-3%Zn-4%Pb)	63 ksi / 434 MPa	15	26	80%
C65500* - H	Silicon Bronze (Cu-3.3%Si-0.9%Mn-1.5%Zn-0.5%Pb)	55 ksi / 380 MPa	22	7	30%
C69750* - S	Leaded Silicon Bronze (Cu-16%Zn-2%Si-1%Pb)	102 ksi / 700 MPa	5	9	90%
C72500 - S	Cupronickel (Cu-9.5%Ni-2.3%Sn-0.05%Pb)	82 ksi / 565 MPa	3	11	20%
C76300* - H	Leaded Nickel Silver (Cu-18%Ni-19%Zn-1%Pb)	80 ksi / 552 MPa	2	6	50%
C79600 - H	Leaded Nickel Silver (Cu-7%Ni-3%Pb-2%Mn)	68 ksi / 470 MPa	10	5	95%
C79800 - H	Leaded Nickel Silver (Cu-41%Zn-7%Ni-3%Pb-2% Mn)	102 ksi / 700 MPa	2	7	90%
C79860 - H	Leaded Nickel Silver (Cu-43%Zn-12%Ni-6%Mn-2% Pb)	104 ksi / 717 Mpa	2	5	90%

* Contains Pb for easy chip breaking and improved machinability. RoHS permits up to 4.0% Pb in copper alloys for machinability purposes, so all materials above are RoHS compliant.

[1]Mechanical properties and electrical conductivity are shown after heat treatment to peak strength. These Properties can be customized by changing heat treatment parameters.

©2020 Materion Brush Inc.

Figure XVI-54 Machinability Test Specimen




Figure XVI-54 Machinability Test Specimen
This is the standard ASTM E618 machinability test specimen. The general geometry is rough cut, and a finishing cut removes the indicated area. The ratio of the number of in-tolerance parts produced from a given alloy with an 8 hour tool life relative to the number of in-tolerance produced from free machining brass (C36000 – CuZn37Pb) in the same time and tool life is the machinability rating for that material.

Factors Influencing Machinability

- Input Material Factors
  - Temper and hardness
  - Surface finish
  - Straightness
  - Residual stress
  - Grain size
  - Lead content
- Machine Factors
  - Individual machine
  - Tool material type, hardness, shape, and sharpness
  - Feeds and speeds
  - Operator skill
  - Lubrication/coolant type, cleanliness and amount
- Final Part Factors
  - Shape and size
  - Dimensional tolerances
  - Surface finish requirements
- Particular Machining Operation

Machinable Alloys

Pb is often added to copper-based rod alloys to enable them to machine more easily. The Pb is not soluble in the copper, so it remains in discrete particles. The soft Pb functions as a chip breaker, to keep the machining chips short. It also may function as a solid lubricant to help keep the tooling sharp. The presence of Pb does not affect RoHS compliance. RoHS allows up to 4% Pb in copper alloys for the purpose of improved machinability. Some examples of machinable copper alloys are shown in Table XVI-6.

As shown, the machinability of copper beryllium Alloy 25 and Alloy M25 are nearly equivalent and they are approximately double the machinability of most competitive alloys. Alloy M25 is a high strength copper beryllium alloy (C17300) developed specifically for automatic screw machine operations. The alloy's composition is the same as that for Alloy 25, with the addition of 0.3% lead (Pb) to facilitate discontinuous chip formation during machining. The mechanical properties of Alloy 25 and M25 are equivalent.

Alloy 1915 is a heat treatable leaded copper alloy specifically designed for screw machining and cold heading applications. Alloy 1915 alloy is available in rod or wire in diameters ranging from 0.050 inch (1.27 mm) to 0.500 inch (12.7 mm).

Note that Alloy M25 (0.3% Pb) and Alloy 1915 (0.8% Pb) are both fully RoHS compliant.

Common machining operations on rod alloys include:

- Turning (Figure XVI-55)
- Drilling/Boring (Figure XVI-56)
- Slotting (Figure XVI-57)

Additional detailed machining information is available in the Materion publication "Machining Copper Beryllium." (Figure XVI-58)

©2020 Materion Brush Inc.

Figure XVI-55 Turning




Figure XVI-55 Turning
Turning can be performed on a lathe or by an automatic screw machine. Please consult Materion for optimum parameters.

Figure XVI-56 Boring / Drilling




Figure XVI-56 Boring/Drilling
Drilling/boring of the center hole is usually performed after the outside has been turned. The hole should be drilled beyond the expected base of the tines. Please consult Materion for optimum drilling parameters.

Figure XVI-57 Slotting





Figure XVI-57 Slotting
Slotting is done after turning the outside and boring the center. The slots may be sawed or EDM'ed. If sawing, use as much of a full radius as possible at the base of the slots, in order to avoid cracking and excessive stress concentration at the base of the tines. (The tines function as cantilever beams, and the base of the tines is where the stress is highest, so additional stress concentration there should be avoided.) It may help to drill a hole for the full radius at the slot base before machining the slots. If tines open or close during slotting, it may be necessary to stress relieve before slotting. Even if the tines do not move during the slotting operation, enough residual machining stress may be present to cause the tines to distort during subsequent heat treatment. In this case, it is important to keep the tooling sharp to minimize residual stress formation. Furthermore, the part may be designed so that the slots close up to touch each other at the desired location during heat treatment, so that they support each other and prevent further distortion. However, if the tines open, or there needs to be some gap between the tines at the opening, fixturing may be necessary.

Figure XVI-58 Machining CuBe

For detailed machining information contact Materion Performance Alloy Technical Service Department or see:

Machining Copper Beryllium



Reamer Configuration



Figure XVI-58 Machining CuBe
Consult Materion publication *Machining Copper Beryllium* information on proper feeds, speeds, tool materials, coolant, tool configurations, and appropriate safe handling procedures.

©2020 Materion Brush Inc.

Machining Scrap

Materion will buy back segregated CuBe scrap for recycling. Call 1-800-BUY-BECU or your local sales office for details. Please note that the Pb content in M25 means that its scrap is not recyclable.

Special Machining Information for ToughMet® Alloy

ToughMet® 3 alloy has a tendency to work harden during machining. Due to tooling wear, residual stress may reach problematic levels while the produced parts are still within geometric tolerances. (Figure XVI-59) This could lead to distortion during slotting or heat treatment. ToughMet 3 alloy machinability falls between that of nickel alloys and brass/bronze alloys. (It is most comparable in machinability to manganese bronze.)

Copper nickel tin alloys like ToughMet have excellent resistance to stress relaxation. While this improves the performance of connectors, it also means that the raw material does not thermally stress relieve, so it is important to not add any more residual stress than you have to.

To minimize residual machining stress:

- Keep the tooling sharp (change it more frequently than you normally would.)
- Flood with coolant, as thermal expansion in the tool can leave parts out of tolerance.
- Use positive rake angles (>15°)
- Material work hardens – cut deep enough with each pass to get under the work hardened layer
- Use diminishing cuts (50% less per pass) to minimize the size of the highly stressed work hardened zone at the end of machining.
- Contact Materion for additional special considerations for machining ToughMet 3 rod. (Figure XVI-60)

Figure XVI-59 ToughMet® Alloy Machinability & Tool Wear

Parts coming off the machine may still be within geometric tolerances, but the residual stress may be high enough to cause problems in future operations.




Figure XVI-59 ToughMet Alloy Machinability & Tool Wear

As the tooling wears, a greater amount of residual stress is added to the parts, and the geometric variation would gradually drift out of tolerance. Depending on the part geometry, there will be a level of residual stress that will be sufficient to cause the parts to move out of tolerance during downstream machining or heat treating processes. Machine operators will usually change the tooling when it has worn to the point of producing out of tolerance parts. However, the residual stress builds faster than the geometric variation. The amount of residual stress that would cause distortion problems in downstream operations would happen well before there was any indication of out of tolerance parts. The parts to the left of the shaded area would process properly, and the parts to the right of the shaded area would be out of tolerance coming off the machine. However, the parts that are produced in the shaded area would be within geometric tolerances coming off the machine, but the residual stresses would cause distortion later during subsequent machining or heat treatment operations. It is important to change the tooling before there are any noticeable out of tolerance parts.

Figure XV1-60 Machining ToughMet Alloy

Consult Materion for more information on machining ToughMet Alloy




Figure XV1-60 Machining ToughMet Alloy

ToughMet is more difficult to machine than copper beryllium and most other copper alloys. Therefore Materion provides multiple resources to help you with your machining process, including the publications pictured above, and the Customer Technical Service Department, phone number: 1-800-375-4205.

©2020 Materion Brush Inc.

Crimping Rod and Wire

The keys to getting a proper crimp around a wire with machined contacts are the same as those discussed in Section IV for stamped contacts. Namely, you want to:

- Minimize the wire crimp diameter
- Maximize wire deformation
  - Increases tensile pull-out strength
  - Increases stress/contact force between wires and barrel
  - Encourages localized cold welding
- Minimize the void space between wires
  - Voids can allow the entrance of corrosive agents
- Avoid fracturing wire strands or crimp barrel
  - May require zone annealing first
- Replace punches and anvils frequently to keep tooling sharp

Zone Annealing

In zone annealing you are locally heating the metal to the point where it becomes soft enough to crimp. You can either greatly overage the material to increase the ductility (with some loss of strength and hardness) or you can provide a true solution anneal (which recrystallizes the microstructure and eliminates the strengthening achieved by prior cold work and age hardening).

To zone anneal, you must

- Heat to greater than 800°F (425°C) for overaging. Water quenching is not necessary, but may help to keep the heat affected zone from spreading too far into the spring area of the contact.
- Heat to 1450°F (785°C) for true solution annealing (the part must be water quenched immediately after heating for proper anneal), but less than 1600°F (870°C) to prevent incipient melting of the metal.

Some methods of heating include:

- Induction heating
  - It is very rapid, with little time for heat to conduct away from zone.
  - However, it is easy to overheat and melt the grain boundaries.
  - Please consult your induction heating equipment supplier for proper setup.
- Flame heating
  - It is difficult to precisely control temperature and duration, and may result in some deleterious phases forming in the material that would be avoided in normal processing.

Age Hardening and Prevention of Shape Distortion

Machining and/or forming operations impart residual stress to the contact. During age hardening, unbalanced residual stresses can cause the parts to distort (e.g. tines open or close). It is usually beneficial if the tines close up, as long as the pin can still easily fit among the tines. This will also increase normal force and retention force. The key would be to ensure consistent part to part residual stress, so that distortion is consistent and in the proper direction. To prevent distortion on upon age hardening (or upon slotting the barrel):

- Keep the turning tools sharp to minimize residual stress imparted to the outside diameter of the tines.
- Use sharp drill to bore out hole to minimize residual stress imparted to the inside diameter of the tines.
- Drill the hole beyond the expected base of tines.
- If distortion still causes parts to be out of tolerance, fixturing may be necessary during heat treatment (Figure XVI-61).

Figure XVI-61 Turned Contacts - Fixtures for Heat Treatment




Figure XVI-61 Turned Contacts - Fixtures for Heat Treatment
If the tines open outward, then a sleeve of some kind of inexpensive material may be placed on the end to fixture the part during heat treatment. If the tines close, and a minimum gap is required, then a pin may be inserted between the tines. If the movement is unpredictable, and neither opening nor closing is allowed, a combination sleeve with an internal pin would be used. Sometimes, even just inserting each part into a fixture and then removing them before heat treatment may generate sufficient residual stresses in the appropriate direction that no further fixturing is needed during heat treatment, which reduces the total number of fixtures needed.

©2020 Materion Brush Inc.

In slotted cylindrical contacts, the tines may sometimes move inward during heat treatment. This is usually not an issue, since this improves retention force, unless the tines are so close together that it prevents pin entry. If tines do happen to close too much during heat treatment, dummy steel pins of the same size as the desired gap among the tines may be inserted prior to heat treat cycle. The pins will allow the tines to close up to the desired distance apart, and no closer.

If the tines open outward during heat treatment, this is usually much more severe, as this would generally result in no spring force (and no electrical contact) during mating. In this case, a steel cap may be placed over the end of the tines during heat treatment to keep them within the proper diameter. For extra control, you can use a cap with an integrated pin to completely prevent the tines from moving.

Wire vs. Strip

In certain instance wire and/or flat wire are used instead of strip to produce spring contacts. To produce flat wire to the desired thickness, the appropriate diameter round wire is fed through a rolling mill, for flattening. A set of opposing rolls in the perpendicular direction achieves the correct width and forms the edge, whether round, square, or some special shape. Wire with a width to thickness ratio of greater than 3 to 1 is termed flat wire.

Selection Guide:

- Width – Most wire mills cannot produce flat wire widths greater than 0.750-0.875 inches (19.1-22.2 mm). This is because of the maximum "spreading" achievable from wire. For anything wider, slit strip is usually the better option. The cost advantages of wire are most apparent at widths less than 0.150 inches (3.81 mm).
- Thickness – A strip mill can roll foil gauges down to 0.001 inch (0.025 mm). The limit on wire mills is also 0.001 inch (0.025 mm). For gauges less than 0.001 inch (0.025 mm), contact the wire supplier.
- Tolerances – Strip will provide closer gauge tolerances up to 0.050 inch (1.27 mm), although flat wire also has good gauge tolerances below 0.050 inch (1.27 mm). Flat wire has tighter width tolerances than strip. Typical wire width tolerances are +/- 0.0003 inch (0.008 mm). Width tolerances are not as tight on round edge wire as flat wire.
- Continuous Unwelded Length – Compared to strip, flat wire is available in longer continuous lengths without welds. Flat wire must be supplied on traverse wound coils.
- Edges – Strip coming off a slitter will have a burr along both edges caused by the shearing action of the knives. Rounding or squaring the edges removes the burr. This does not temper or work harden the edge. However, it incurs an additional cost, and the operation can be time-consuming for large quantities. On a wire mill, rolling creates a smooth, uniform edge for the entire length. For smaller diameter wire, the corner allowance becomes more important. At gauges above 0.010 inch (0.25 mm), the corner allowance specifies 0.003 inch (0.08 mm) whereas below 0.010 inch (0.25 mm) gauge a rounded corner is standard.
- Width-to-Thickness Ratio – As the ratio between width and thickness narrows to 5:1 or 6:1 and below, it can become more difficult to maintain camber, flatness, and other shape parameters when slitting strip. On a wire mill, it is possible to get the ratio down to 1:1 for a square cross section and as high as 20:1 for flat wire.
- Tooling – Knives for slitters and carbide rolls for wire mills are readily available and changeable. In most applications, the major issue is the burr created during slitting. If the condition of the edges is not important, slit strip may be the better choice. When burs are a factor, the choice comes down to the cost of slitting and deburring or edge conditioning versus the cost of flat wire. The cost of flat wire is typically 30-50% greater than that of strip.

Materion supplies wire in diameters from 0.500 inch (12.7 mm) down to 0.050 inch (1.27 mm) with tolerances listed in Section V – Design & Analysis of this guide. Any one of a number of copper beryllium wire redrawers supply finer wire.

MATERION

©2020 Materion Brush Inc.

Quality

Quality Philosophy

Materion is committed to our customers' success. Accordingly, we recognize the need to provide high quality products and services as a condition of doing business. The markets we serve include some of the most demanding in the world when it comes to quality of systems, products, distribution and services. We have long been recognized for our quality, excellence and leadership by these highly demanding markets. We back our products up with technical service capabilities as well as an outstanding world-wide service center, distribution network.

We base our quality initiatives on the Lean Six Sigma and supply chain management philosophies of eliminating wasteful activities, reducing variation and improving system performance. Lean Production drives a relentless elimination of "waste" - producing what is needed, when it is needed, in exactly the right quantities, with a minimum amount of resources. Six Sigma is a process-focused data-driven problem solving discipline that drives variation reduction and the elimination of process defects. supply chain management optimizes the material flows to facilitate production from the supply base through internal operations to our customers. To maintain high standards of quality, we provide ongoing training in the quality tools to all employees.

Quality Statement

"We are dedicated to excellence in customer satisfaction by providing superior products and services."

Materion Approach to Quality

- Implement world class safety practices to provide an injury and illness free workplace
- Implement lean manufacturing to reduce cycle times, increase capacity and provide industry leading service to our customers
- Implement supply chain management to provide exactly what is needed, when it's needed, to where it's needed in exactly the right quantity for the right cost; to reduce inventory and streamline material and information flows
- Implement Six Sigma to provide industry leading product quality and reduce cost
- Implement total productive maintenance to provide industry leading equipment reliability

The Elmore, Ohio facility is responsible for the primary processing of strip product. The Reading, Pennsylvania facility performs the finishing operations. The final location prior to customer shipment is a Service Center.

Statistical Process Control (SPC) is a statistical procedure for catching or detecting variations in production caused by operators, machinery and extraneous factors. Materion is committed to SPC for monitoring critical product and process characteristics as part of its Lean Six Sigma philosophy. Prior to implementing new SPC applications on process characteristics, the appropriate procedures are reviewed for completeness. A Failure Mode & Effects Analysis (FMEA) identifies the key process characteristics. Analysis of historical data determines if the process is under control and normally distributed. After meeting these criteria, a control chart is implemented.

Conformance with process specifications as well as customer specifications is attainable through lot to lot consistency. Melt composition (chemistry), mechanical properties (tensile and yield strength, elongation, hardness), grain size, conductivity, gauge and surface finish are tracked and controlled. Attribute and variable control charts monitor the processes. Each order is traceable back to a heat number.

New products are implemented using Voice of the Customer (VOC) and Design for Six Sigma (DFSS) tools and methodology. This ensures that new products and services provide solutions for the customers' Critical to Satisfaction (CTS) needs and issues.

Process Potential, Cp

The process potential of an actual or postulated manufacturing parameter only considers the process spread in relation to the allowable engineering specification spread (Figure XVI-62).

$$C_p = \frac{USL - LSL}{6\sigma}$$ (Bilateral case)

$$C_p = \frac{USL - \mu}{3\sigma}$$ (Unilateral case)

$$C_p = \frac{\mu - LSL}{3\sigma}$$ (Unilateral case)

Where: USL = Upper Specification Limit
LSL = Lower Specification Limit
σ = standard deviation
μ = process mean

©2020 Materion Brush Inc.

Process Capability Index, Cpk

This index measures the ability of a process to produce product within specification. The capability index measures the degree of centering of the actual process spread with respect to the allowable spread.

$$C_{pk} = C_p(1-\kappa)$$

Where: $\kappa = \dfrac{|\text{Nominal} - \mu|}{(USL - LSL)/2}$

The specification minimums on Materion data sheets are derived with a Cpk =1. For more detailed information on process capability, please see Technical Tidbits issues 92 through 95.

Figure XVI-62 Concepts Underlying Cp and Cpk




Figure XVI-62 Concepts Underlying Cp and Cpk

There are several aspect s to process capability, and we will discuss two of them. The first is how well the results of the process fall within the specification limits (the process potential - Cp). The second is how close the process results come to hitting the nominal (targeted) values (the process capability index - Cpk). The process capability is a ratio of the allowable spread (based on specification limits) to the actual spread. If 6 standard deviations fit exactly within the specification limits, the process potential (Cp) is equal to one. 99.73% of all outputs would be within specification, and fewer than 0.3% would fall outside the specification. Cp numbers greater than one indicate a higher percentage within the specification range, and numbers less than one indicate a higher percentage outside the specification range. A Cp equal to 2.0 shows 12 standard deviations between the specification limits, and only 2 failures per billion opportunities.

Process Capability Index, (Cpk)

This index measures the ability of a process to produce product within specification. The capability index measures the degree of centering of the actual process spread with respect to the allowable spread. In the equation above, κ is the distance between the nominal (target) value and the process mean. Divide that distance by half of the specification range to get a ratio the off-center distance. A perfectly centered process would have a ratio κ equal to zero, and the Cpk would then be equal to the Cp. If the process mean is on one of the specification limits, then half of the outputs would be out of specification. The κ ratio would be one, and the Cpk would be zero. The Cpk value essentially is a deration of the Cp value to account for deviations from the target. Cpk will always be less than or equal to Cp, so it is a more conservative measure of process capability. The specification minimums and ranges on Materion data sheets are derived with a minimum Cpk of 1. This means that at least 99.7% of all produced material will fall within the data sheet limits, meaning the probability of having to rework is 0.3%

MATERION

©2020 Materion Brush Inc.

Quality Certifications

ISO 9002 Certification

The Reading, PA plant became ISO 9002 certified in mid-1993 and QS 9000 certified in 1996. The Elmore, OH plant achieved ISO 9002 certification in 1994, and QS 9000 certified in 1999. Both facilities also are certified to ISO 9001:2000 and AS9100-B. The quality Operating System (QOS) monitors internal and external product performance along with the implementation of the quality system. Overall performance tracking and monthly reviews utilize measurements developed by the management teams at each plant.

ISO/IEC Guide 25-1999

The Reading Plant Production Mechanical Testing and the Elmore Plant Chemical Analysis and Metallurgical Laboratories have received accreditation to ISO/IEC Guide 25-1999 by the American Association of Laboratory Accreditation. (A2LA). The requirements of Guide 25 include and go beyond the relevant requirements of ISO 9002. Some of the additional requirements are as follows:

- Laboratory quality manual
- Determination of the best test method
- Measurement systems for gage repeatability and reproducibility studies
- Calibration control
- Training procedures that ensure operator competency
- Purchase and maintenance records on major equipment items

To provide evidence of our quality, Materion:

- Provides material certifications which report test results demonstrating compliance to customer specifications.
- On request, will provide detail of statistical process capability and product quality.
- Encourages visits to our operating facilities for the purpose of auditing our quality systems.

MATERION

©2020 Materion Brush Inc.

Section XVII: Cost Reduction Exercise

While the connector is being designed to achieve the mechanical requirements of normal force and design stress, the manufacturing aspects must not be ignored. Two critical areas require addressing. The first is to form the contact to the correct geometry as specified on drawing, while also achieving the mechanical requirements. The second is to manufacture the contact to the specification in a cost effective manner.

We will now do an illustration of how the use of high performance materials can help to reduce the total cost of making a connector, even if the raw material costs may be higher.

Copper beryllium or copper nickel tin can often be the lowest cost solution in high performance applications, especially when used in the following conditions:

- High temperature (excellent stress relaxation resistance)
- High current (high conductivity)
- High reliability (high fatigue strength, excellent stress relaxation resistance)
- Miniaturized design (high yield strength & conductivity, good formability)
- Heavy vibrations (good stiffness, high yield & fatigue strength)
- Shock & impact (high yield and fatigue strength, good stiffness)
- Complex forming operations (excellent formability vs strength characteristics)

Connector Cost

The proper way to analyze material cost is to examine the value of the metal and its properties versus the overall cost and performance of the connector. A method of performing this analysis is to evaluate the material cost in dollars per pound or kilogram versus the overall connector cost per X contacts. In a typical connector the cost components are the cost of the base metal, stamping, plating, housing and assembly. Following is a typical cost breakdown for a precious metal plated connector:

Contacts (Base metal & stamping)	10-30%
Gold plating	20-30%
Housing / hardware	10-25%
Labor	10-20%
Overhead	25-35%

In addition, scrap value and material quality should factor into the equation when determining manufacturing costs.

Some Overall Cost Considerations:

- Raw Materials:
  - Spring Base Metal
  - Precious/Non-precious Metal Plating/Cladding
  - Plastic Resin or Metal for Housing
- Component + Assembly Unit Hours:
  - Molding
  - Stamping
  - Plating
  - Assembly
  - Quality Control & Testing
  - Packaging
- Warranty Costs
- Scrap Separation and Buyback Value
- Engineering Line Support
- Tooling Amortization
- Your Profit Margin vs. Your Selling Price

Cost Reduction Exercise

It is a common belief that copper beryllium alloys are more expensive than other copper alloys. Is this statement true? It is true that copper beryllium alloys will have a higher price in terms of dollars per pound or kilogram. However, copper beryllium alloys may save you money in the long term. They possess exceptional combinations of strength, conductivity, formability and stress relaxation. This means that connectors produced using these alloys will be reliable, high performance connectors. As connectors continue to follow a miniaturization trend, only copper beryllium alloys will be able to provide the required properties. Other alloys will require larger contacts in order to meet the performance requirements of new designs. In comparison to the smaller contacts allowed by using copper beryllium, larger contacts mean a lot more metal to buy, more metal to stamp, more surface area to plate, and more plastic to mold around. Factor in the added reliability of copper beryllium, and there will be fewer failures, warranty claims, or other quality-related costs, and copper beryllium alloys will often be the most cost-effective solution!

Several components comprise the connector cost. Included are the base materials, the stamping or machining costs, the plating costs, the molded plastic or machined metal housing costs and lastly the assembly costs. In addition, secondary operations, such as heat treating, inherent in the use of an age hardenable alloy, can greatly affect processing costs. On the other hand, mill hardened tempers may provide sufficient strength and formability with no subsequent heat treatment and cleaning costs.


MATERION

©2020 Materion Brush Inc.

One way that you might be tempted to reduce costs would be to purchase a less expensive base metal. However, you might increase your warranty costs, or be required to redesign your connector to be slightly bigger, which carries additional penalties (Figure XVII-1). You may also consider changing a heat treatable alloy to a mill hardened alloy, to eliminate the cost of heat treatment and post plating. You also may be able save money by using the same input base metal part number for many different contacts.

Material properties also come into play when determining the overall cost of a metal (Figure XVII-2). By using a higher strength material, one can shorten the beam length of a contact spring. If the spring is laid out transversely on the carrier strip, then the stamper can use a narrower input coil, meaning that they will be purchasing fewer pounds or kilograms of metal. Greater formability in a material allows the contacts to be stamped closer together, meaning that more contacts can be stamped out of a given amount of metal, so again a lower quantity of metal can be purchased. A more reliable material can provide a higher end-of-life contact force at a given thickness, or can provide the same end-of-life contact force at a reduced thickness, again enabling the purchase of a lower quantity of metal. This principle was demonstrated in the previous miniaturization example. The material properties that govern reliability are stress relaxation resistance, fatigue strength and elastic resilience.

Figure XVII-1 Cost Reduction Opportunities



*with same or better strength, formability, and conductivity than heat treatable alloy

Figure XVII-1 Cost Reduction Opportunities

The design criteria for cost is obvious - As Low As Possible!

- It is tempting to substitute a cheaper material in your design to save costs. However, you will have reduced reliability, which would increase warranty costs. Alternatively, you will need to make design changes that increase the total amount of material required, and defeat other engineering requirements such as the need to miniaturize, reduce weight, and increase current or power.
- If you are heat treating material, you can substitute a mill hardened material, provided that it gives you comparable strength, conductivity, and formability as the original material.
- You can also consolidate part numbers, and use the same input material to make multiple parts, which generates economies of scale to reduce the overall price you pay.

Figure XVII-2 Better Cost Reduction Opportunities




Figure XVII-2 Better Cost Reduction Opportunities

By switching to a higher performance material, you have the freedom to make geometry changes to reduce the amount of material you need to buy, offsetting the higher price, while improving function and reliability.

- Higher modulus materials allow use of thinner materials to achieve comparable contact force. (Thinner material – more contacts per a given weight of material.)
- For a small design envelope, higher yield strength materials allow use of shorter beams without exceeding yield strength. (Narrower material - more contacts per a given width of material)
- Better formability allows stamping on tighter centerline spacing. (Shorter material - more contacts per a given length of material.)
- Lower Density material allows more contact per pound of material. (Volume x Density = Weight)

©2020 Materion Brush Inc.

The following example is an extremely simplified comparison of the cost of using different materials in an application. Bearing in mind that the base metal raw material costs are typically around 3% of a connector cost, you can use a more expensive, high performance base metal to reduce size, increase reliability, and even reduce the overall cost!

Assume that the design is a box terminal contact of the type shown in Figure XVII-3. Furthermore, assume the following design parameters:

- 100 grams contact force required at end of life
- 125°C operating temperature
- 1000 hours of service (for simplicity of stress relaxation calculations)
- 10 Amps of current flow
- 0.127 mm (0.005 inch) thickness
- 1.0 R/t good way and bad way formability requirements
- 3.2 mm (0.125 inch) deflection in service
- 0.175 mm (0.007 inch) thickness of beam

In this analysis, we are assuming that we know the thickness and deflection, and the unknown dimensions are width and length. The reason we have chosen this methodology is to make the mathematics of the iterative solution easier, since width appears in only one of the equations, making it easy to use the other equation to solver for L, and the first equation can then solve for w.

In real life design situations, you will usually have a known contact footprint (length and width), and you will have to solve for thickness and deflection. This would make the mathematics far more difficult, because thickness and deflection are interdependent, and changes in thickness also influence the temper choice based on base metal formability requirements. These interdependencies have the potential to generate infinite loops in the solution.

Figure XVII-3 Cost Comparison Example




Figure XVII-3 Cost Comparison Example
This is a typical configuration for an automotive box terminal contact, but the principles can be extended to any electrical contact/connector design. This particular configuration was chosen to make the mathematics easy to follow, as described in the text. It features a straight cantilever beam style spring section, with tight good way and bad formability requirements in non-spring section.

Assume also that many millions of contacts will be required, and that the metal is purchased at minimum price. The following materials will be considered:

- Alloy 25 Copper Beryllium
- Alloy 290 Copper Beryllium
- Brush® 60 strip Copper Beryllium
- C26000 Cartridge Brass
- C52100 Phosphor Bronze
- C19400 Copper Iron
- C70250 Copper Nickel Silicon

The only missing dimensions are the length and width of the beam. These will be calculated with an iterative procedure. The temperature rise associated with using each material will be calculated as well.

The following cantilever beam equations apply:

$$\sigma_{Max} = \frac{3 \cdot d \cdot E \cdot t}{2 \cdot L^2} \qquad F_{Initial} = \frac{w \cdot d \cdot E \cdot t^3}{4 \cdot L}$$

Where: t = thickness
d = deflection
L = length
w = width
E = elastic modulus
σ_{Max} = maximum design stress
$F_{Initial}$ = initial contact force

MATERION

©2020 Materion Brush Inc.

Iterative solution

First, select the maximum strength temper of each alloy that meets the stringent formability requirements (per Figure XVII-4). The choices are shown in Figure XVII-5, along with each temper's yield strength and electrical conductivity.

Figure XVII-4 Selecting the Proper Temper




Figure XVII-4 Selecting the Proper Temper
Choose the highest strength temper that still meets the 1.0 R/t formability requirements in both directions. Heat treatable or mill hardened alloys show improved strength/formability relationships over materials that are strengthened by cold work alone.

Figure XVII-5 Tempers to be considered

Alloy	Temper	0.2% Offset Yield Strength (ksi)	0.2% Offset Yield Strength (MPa)	Electrical Conductivity (%IACS)
25	1/2 HT	171	1179	22
290	TM04	116.3	802	17
Brush® 60	HT	115	793	50
260	H	67.5	465	28
521	1/2 H	63	434	13
194	HTM00	65	448	60
7025	TM00	77.5		40

Figure XVII-5 Tempers to be considered
These are some of the relevant properties of the tempers that meet the design requirements, useful in the first two steps of the iterative solutions.

Next, the design stress for each of the materials will be determined, per the procedure outlined in Figure XVII-6. Assume that the design stress will be equal to 75% of the yield strength. This will provide a safety factor against overstressing, and will optimize the stress relaxation performance of the material. For a highly cycled application, fatigue strength must also be considered. The design stress from a fatigue point of view would be equal to the maximum stress at which the contact would be expected to survive the required number of cycles. The design stress to use in an analysis such as this would be the lower of the fatigue strength or 75% of the yield strength.

Figure XVII-4 Selecting the Proper Temper




Figure XVII-4 Selecting the Proper Temper
Choose the highest strength temper that still meets the 1.0 R/t formability requirements in both directions. Heat treatable or mill hardened alloys show improved strength/formability relationships over materials that are strengthened by cold work alone.

©2020 Materion Brush Inc.

Stress relaxation must be considered next. Since the contact force will decrease over time, the initial contact force must be increased to ensure that it will not fall below the required contact force at end of life. Using the data in Figure XVII-7, we can determine the stress relaxation of each material at the ambient temperature. Then, the initial contact force is calculated as follows, assuming no temperature rise for the first iteration:

$$\text{Initial Contact Force} = \frac{\text{End} - \text{of} - \text{Life Contact Force}}{\%\ \text{Stress Remaining after 1000 hours at Temperature}}$$

For more precise calculations of stress relaxation, it would be wise to curve-fit the stress relaxation data into formats that can be used in FEA or calculation software, as shown in Figure XVII-8.

Figure XVII-7 Estimating Stress Relaxation and EOL Force




Figure XVII-7 Estimating Stress Relaxation and EOL Force
This data is used to estimate the stress relaxation after 1000 hours at the operating temperature. You can clearly see that a 25°C temperature rise can have a significant impact on the overall stress relaxation resistance. As ambient temperatures become higher, the effect becomes more pronounced.

Figure XVII-8 Curve-Fitting Stress Relaxation Data

- **Modified Time Hardening Stress Relaxation Equation (Common in FEA)**

$$\varepsilon_{cr} = \left[C_1 \cdot \sigma^{C_2} \cdot t^{(C_3+1)} \cdot e^{(C_4/T)}\right]/(C_3+1)$$

- **Curve fit stress relaxation data to calculate creep strain (ε_{cr}) at given time (t), temperature (T), and stress level (σ)**

Figure XVII-8 Curve-Fitting Stress Relaxation Data
For more accurate stress relaxation calculations, you can curve-fit stress relaxation data to the above equation, so you can solve explicitly for creep strain due to stress relaxation at various time, temperature, and initial stress level combinations. This formula is commonly used to predict the stress relaxation of components in finite element analysis (FEA).

MATERION

©2020 Materion Brush Inc.

The following calculations are used in order to find the unknown dimensions and the temperature rise (from Section V-Connector Base Materials and their Properties):

$$L = \sqrt{\frac{3 \cdot d \cdot E \cdot t}{2 \cdot \sigma_{Max}}} \qquad w = \frac{4 \cdot F_{Initial} \cdot L}{d \cdot E \cdot t^3} \qquad \Delta T = \frac{J^2 \cdot L^2}{2 \cdot \varepsilon \cdot \kappa \cdot (w \cdot t)^2}$$

Where: t = thickness

d = deflection

L = length

w = width

E = elastic modulus

σ_{Max} = maximum design stress

$F_{Initial}$ = initial contact force

ΔT = temperature rise

J = electric current

ε = electrical conductivity

κ = thermal conductivity

The first two equations are the standard cantilever beam equations rearranged to solve for L first, then for w. The third equation is the temperature rise estimation equation.

After the missing dimensions and the temperature rise are found, the operating temperature is calculated as the sum of the ambient temperature and the temperature rise from joule heating. The operating temperature is then used to calculate the stress relaxation. This is then used to determine the new value for initial contact force, and the calculations are iterated until they converge, with results shown in Figure XVII-9.

Figure XVII-9 Operational Results

Alloy	25	290	Brush 60	260	521	194	7025
Temper	1/2 HT	TM04	HT	H	1/2 H	H	TM00
Initial Contact Force (grams)	109	107	106	166	309	135	108
Operating Temperature (°C)	130	128	125	125	125	125	125

Figure XVII-9 Operational Results
The high reliability of copper beryllium alloys allows for higher operating temperatures and lower initial contact force (which translates into lower insertion force). Lower priced materials will require much higher initial stress levels to account for the increased amount of stress relaxation, which will dramatically increase insertion force and contact footprint.

The final width and thickness mark the footprint of this example (Figures XVII-10 and XVII-11). This determines the amount of space required to house the contact. A larger area means a larger connector, as well as more metal to purchase and to plate. Some of the materials will require a contact too large to use. These materials may have absurdly large initial contact forces, making insertion nearly impossible.

Figure XVII-10 Contact Footprint




Figure XVII-10 Contact Footprint
The materials with good stress relaxation resistance require less initial contact force, and therefore do not need to be as wide. Some of the less expensive alloys require contacts that would need to be wider than they are long, so they are completely impractical in this particular scenario. For overall plating or cladding, the length and width determine the cost. For a localized stripe of plating or cladding, the width determines the amount of precious or non-precious metal that must be put down on the input strip.

Figure XVII-10 Contact Footprint

Alloy	25	290	Brush 60	260	521	194	7025
Temper	1/2 HT	TM04	HT	H	1/2 H	H	TM00
Width (mm)	7.7	13.5	14.1	44.1	91.0	39.6	25.3
Length (mm)	11.4	13.9	14.5	16.9	17.5	18.0	17.2
Contact Footprint (mm²)	88	188	205	747	1595	714	435
Mass of 1 Million Contacts (kg)	92	200	229	809	1783	808	487

Alloy	25	290	Brush 60	260	521	194	7025
Temper	1/2 HT	TM04	HT	H	1/2 H	H	TM00
Width (in)	0.303	0.533	0.555	1.738	3.583	1.558	0.995
Length (in)	0.450	0.548	0.571	0.667	0.690	0.710	0.678
Contact footprint (in²)	0.137	0.292	0.317	1.158	2.472	1.107	0.675
Weight of 1 million contacts (lbs)	203	441	504	1784	3931	1782	1073

Figure XVII-11 Base Metal Required for 1,000,000 Contacts
High performance alloys allow for much smaller contacts and require much less metal. They also require less surface area to plate, further reducing cost

DRAFT VERSION

Now that we know how much metal we need to buy, we need to determine how much the metal would cost. If we are using pre-plated or preclad material, we would need to know the cost of the whole metal system, as shown in Figure XVII-12.

Figure XVII-12 Cost Estimation




Figure XVII-12 Cost Estimation
For a rough estimation of cost, multiply the amount of material that is needed for each candidate alloy by the purchase price to get the base metal cost. Then, multiply the surface area of the contacts by the cost to plate or clad such an area to the desired thickness. This is the total raw material cost, not including the housing.

The total cost difference between the various metals is even more pronounced when plating or cladding is factored in, as shown in Figures XVII-13 though XVII-15. Here, the lowest price base metals have much higher total costs than the higher priced, higher performance base metals.

Figure XVII-13 Estimated Base Metal Cost for 1,000,000 Contacts

Alloy	25	290	Brush 60	260	521	194	7025
Temper	1/2 HT	TM04	HT	H	1/2 H	H	TM00
UnPlated Contacts	$4,527	$12,270	$12,856	$11,952	$36,822	$16,810	$12,465
Plated Cost/lb.	$33.23	$36.59	$34.18	$23.51	$24.50	$24.36	$25.85
Clad Cost/lb.	$33.12	$36.48	$34.08	$23.41	$24.40	$24.26	$25.75
Plated Cost/kg	$73.25	$80.66	$75.35	$51.83	$54.01	$53.70	$56.98
Plated Cost/kg	$73.02	$80.43	$75.12	$51.60	$53.78	$53.48	$56.76
Contact Footprint (in²)	0.137	0.292	0.317	1.158	2.472	1.107	0.675
Contact Footprint (mm²)	88	188	205	747	1595	714	435
Plated Contacts	$6,760	$16,120	$17,230	$41,938	$96,301	$43,410	$27,733
Clad Contacts	$6,739	$16,073	$17,180	$41,752	$95,906	$43,232	$27,626

Figure XVII-13 Estimated Base Metal Cost for 1,000,000 Contacts
Despite having a higher price per pound of metal, high performance alloys can provide the lowest total cost solution.

Figure XVII-14 Estimated Cost for 1,000,000 Contacts




Figure XVII-14 Estimated Cost for 1,000,000 Contacts
This is a graphical representation of the required contact footprint, and the estimated (base metal and plating only) raw material cost.

Figure XVII-15 Relative Cost

Alloy	25	290	Brush 60	260	521	194	7025
Temper	1/2 HT	TM04	HT	H	1/2 H	H	TM00
Bare Metal Cost	100%	271%	284%	264%	813%	371%	275%
Clad* Cost	100%	238%	255%	620%	1424%	642%	410%
Plated† Cost	100%	239%	255%	620%	1423%	642%	410%

*** Au inlay is assumed with one 5 um Ni and 1 um Au stripe 0.100" wide**

† Au plating is assumed with overall 2 um Ni and 1 um Au stripe (0.100" wide)

Note: Alloy 25 would typically be plated after stamping and heat treatment, so this cost analysis is not a direct comparison. Given the additional required heat treatment costs, Alloy 290 TM04 is the best option to meet all the design requirements at minimum cost.

Figure XVII-15 Relative Cost
Based on base metal price alone, C17200 appears to be the lowest cost option. However, this material would require heat treatment and plating after forming, so there would be additional costs associated with this material. Therefore, Alloy 290 TM04 would be the best option. This is before any additional costs such as molding and machining the housing are taken into account, which would only relatively increase the costs of the lower performance alloys.

The more reliable materials, although potentially priced higher than the less reliable metals, may end up saving money in the long term, particularly when there is high current, high ambient temperature, miniaturized designs, etc. This is because contacts made with lower priced metals have to be dramatically overde-signed in order to survive such harsh operating conditions. If the design requirements are lessened, however, some of the lower priced metals may become more cost effective. The purchasing price, reliability, and design requirements must all be balanced (Figure XVII-16). The most cost effective material would be the least expensive one that meets all the design requirements. This would need to be determined on a case by case basis. Higher performance base metals become more cost effective as the con-nector size is reduced, reliability requirements are increased, and environmental harshness (shock, vibration, temperature, corrosive agents, increased current, etc.) increases (Figure XVII-17).

©2020 Materion Brush Inc.

Figure XVII-16 Cost Trade-off




Figure XVII-16 Cost Trade–off
When specifying materials, it is important to balance the purchasing price of the base metal per kilogram or pound against the volume of material and the cost to plate or clad it. Be aware that there are hidden costs to using cheaper materials.

Figure XVII-15 Relative Cost




Figure XVII-17 Most Cost-Effective Option
As you go down the vertical axis (tighter formability requirements, smaller size required for miniaturization) and to the right on the horizontal axis (higher ambient temperature, higher current, increased shock and vibration, or greater reliability required) the higher performance metals become your most cost effective option, despite the greater price per kg.

One word of caution on this analysis is that the prices of spring and plating materials are constantly changing. As demonstrated, the more reliable, higher priced metals such as copper beryllium may provide a cost advantage over less reliable, commodity alloys, depending on the severity of the application. Lower priced metals may have hidden costs such as more metal, plating, and plastic required. They may also prevent miniaturization, and may require enlargement of the design. As Figure XVI-18 shows, Cost is more than price!

Figure XVII-18 Price vs. Cost




Figure XVII-18 Price vs. Cost
The cost of a material is far more than just the purchasing price. However, the purchasing price is what people can see, much like the proverbial tip of an iceberg extending above the surface of the sea. However, just as the vast majority of the mass of an iceberg is hidden below the surface, a large portion of the total cost of using material does not appear on the purchase order. While a material may appear to be cheaper on the surface, it may contain many hidden costs that actually make it more expensive than a more reliable alloy with a higher purchase price. This is particularly true when high reliability is required and/or when the use environment is harsh.

Conclusions

Lower priced base metals have hidden costs

- Performance requires larger contacts and more metal
- Larger contacts require more plating
- Larger contacts require more plastic in the housing
- Larger contacts prevent miniaturization

Materion's High Performance Materials

- Require less metal for equal performance
- Allow for miniaturization
- Allow for higher operating temperatures
- Allow for lower insertion forces
- Have lower post-stamping hidden costs (plating, plastic housing, etc.)
- Have higher scrap buyback value
- Provide greater reliability and reduced warranty costs
- Are backed by Materion's technical service and design assistance capabilities
- May provide the lowest total cost solution, especially in demanding applications requiring high design stress, high current (power), high reliability, high operating temperatures, miniaturized designs, tight forming requirements and high operating cycles

Further Reading

Reynolds, Ed. "What Do Connectors Really Cost?" Connector and Cable Assembly Supplier 5/5/2014

Palesko, Amy "Using cost modeling to make better design decisions" Chip Scale Review September-October 2015 pp 37-40

©2020 Materion Brush Inc.

Section XVIII:
Design Example – One-piece Automotive Box Terminal

Background

As of 2017, there are approximately 90 million light passenger vehicles (personal cars and trucks) produced each year, worldwide. There are approximately 250 electrical connectors per vehicle. (Although this number is rising, as an ever greater number of electrical systems, sensors, and electronic control units are added to vehicles over time.)

Simple arithmetic shows that there are approximately 22.5 billion connectors produced per year for use in light passenger vehicles. If we assume that these vehicles are replaced every 5 years on average, then at any given time there will be about 5 production years of vehicles currently on the road. This means that there will be about 112.5 billion electrical connectors currently on the road. If only 0.00034% (a six sigma failure rate) of connectors fail in a year, then 382,500 connectors will fail this year!

If over a quarter of a million connectors fail each year, is that significant? That would depend on whether or not the connector is part of a critical system. A failure of a connector that powers the car's radio would be an annoyance, but a failure in a critical safety system could result in injury or death.

In 2014, there were more than 50 million vehicles recalled for various reasons in the United States alone! This set an all-time record, as shown in Figure XVIII-1. Vehicle reliability and the costs of poor quality (such as death and injury, lawsuits, court costs, government fines, warranty claims, and brand damage) are on the forefront of everyone's mind throughout the automotive supply chain.

At the same time, vehicles are continuing the trend of becoming more electrical than mechanical. Vehicles have multiple electronic systems, many more sensors, and multiple electronic control units overseeing them all. All of these are linked together through the electrical connectors in the wiring harness. It is these separable connections that are most vulnerable to environmental conditions, and where failure is most likely to occur.

Connectors per Vehicle	
Vehicle Type	**# of Connectors**
Low Cost	100-200
Economy	200-225
Mid Range	375-400
Premium	450-500

Source: "World Automotive Connector Market" Research Report M-1010-15
© Bishop & Associates, September 2015

Here are some current trends in automotive design:

- Increasing electrification & contact density
  - Miniaturization of contacts in connectors
  - More safety-critical features handled by electronics (brake by wire, steering by wire, electronic stability control, etc.
- Higher voltage/current
  - 12V moving to 48V in gasoline/diesel engines
  - 100V to 600 V in electric and hybrid electric vehicles
- New ways for the driver and vehicle to interact
  - Head up displays and augmented reality
  - Gesture control
  - Voice control
  - Infotainment
  - Connectivity with smart phones (In 2016, poor connectivity with smartphones became the #1 complaint of new car owners.)
- More complex reliability & safety systems
  - Automated parking or parking assistance
  - Adaptive cruise control & lane keeping
  - Collision avoidance (autonomous emergency braking and steering)
  - Multiple, redundant sensor technologies working in tandem to compensate for each other's inherent weaknesses (seeing through fog/rain/snow/dust/sun glare/etc.)
- Ultrasonic sensors for parking assistance and nearby distance detection through fog/snow/rain/dust/etc.
- Short range and long range radar to see through fog/snow/rain/dust etc. to detect distance and movement of other vehicles/pedestrians/etc.
- LIDAR for 3D mapping of the environment in all light conditions
- Cameras for reading traffic signs and signals, and lane keeping in clear weather
- More stringent fuel efficiency and emissions standards (Figure XVIII-2)
  - Euro 6 standard
  - US CAFÉ standards
  - China's National Action Plan on climate change
- Light weighting for fuel efficiency
  - Leads to increased vibration, shock & impact loads
- Increasing under hood temperatures for improved fuel efficiency
  - 185°C - 200°C

No discussion of current automotive trends would be complete without mention of autonomous vehicles. SAE international currently defines 5 levels of autonomy, as shown in Figure XVIII-3.

NOT FOR PRODUCTION

©2020 Materion Brush Inc.

Figure XVIII-1 Recalls/Cost of Poor Quality




Figure XVIII-1 Recalls/Cost of Poor Quality

Both the total number of vehicle recalls and the total number of vehicles recalled in each calendar year are clearly increasing over time. This is likely a result of both the increasing complexity of modern vehicles and a continued emphasis on reducing manufacturing costs at the expense of reliability.

Figure XVIII-2 European Emissions and CO_2 Regulations

Euro 5 Standard - Regulation (EC) No 715/2007 By 2021:



- Fleet fuel consumption targets
  - Gasoline engines: 24 km/liter (57 miles per gallon)
  - Diesel engines: 28 km/liter (65 miles per gallon)
- Emissions reductions relative to 2005
  - 55% less CO
  - 50% fewer hydrocarbons
  - 47% less NO_x
- No more than 95 grams/km CO_2 emitted per car
  - Penalty for missing target = €95 / km / car

Figure XVIII-2 European Emissions and CO_2 Regulations

The only way to achieve these targets is to run the engines hotter, with higher pressures, and at higher RPM's. Note the substantial penalty for missing the carbon dioxide target. For example, with a fleet of 100,000 cars emitting 98 grams/km of CO_2, the penalty would be 3 (grams over limit) x 100,000 (cars) x 95 Euros, for a total fine of €28.5 million.

Figure XVIII-3 Levels of Autonomy – SAE International Standard J3016

SAE level	Name	Narrative Definition	Execution of Steering and Acceleration/ Deceleration	*Monitoring* of Driving Environment	Fallback Performance of *Dynamic Driving Task*	System Capability *(Driving Modes)*
***Human driver* monitors the driving environment**						
0	No Automation	the full-time performance by the *human driver* of all aspects of the *dynamic driving task*, even when enhanced by warning or intervention systems	Human driver	Human driver	Human driver	n/a
1	Driver Assistance	the *driving mode*-specific execution by a driver assistance system of either steering or acceleration/deceleration using information about the driving environment and with the expectation that the *human driver* perform all remaining aspects of the *dynamic driving task*	Human driver and system	Human driver	Human driver	Some driving modes
2	Partial Automation	the *driving mode*-specific execution by one or more driver assistance systems of both steering and acceleration/ deceleration using information about the driving environment and with the expectation that the *human driver* perform all remaining aspects of the *dynamic driving task*	**System**	Human driver	Human driver	Some driving modes
***Automated driving system* ("system") monitors the driving environment**						
3	Conditional Automation	the *driving mode*-specific performance by an *automated driving system* of all aspects of the dynamic driving task with the expectation that the *human driver* will respond appropriately to a *request to intervene*	System	**System**	Human driver	Some driving modes
4	High Automation	the *driving mode*-specific performance by an automated driving system of all aspects of the *dynamic driving task*, even if a *human driver* does not respond appropriately to a *request to intervene*	System	System	**System**	Some driving modes
5	Full Automation	the full-time performance by an *automated driving system* of all aspects of the *dynamic driving task* under all roadway and environmental conditions that can be managed by a *human driver*	System	System	System	**All driving modes**

Copyright © 2014 SAE International. The summary table may be freely copied and distributed provided SAE International and J3016 are acknowledged as the source and must be reproduced AS-IS.

Figure XVIII-3 Levels of Autonomy – SAE International Standard J3016

As vehicles become ever more autonomous, they will need additional computing power to enable fusion of all the sensor data. Steering, acceleration, and braking must all be done electronically. Level 5 (full) autonomy will most likely require complimentary use of cameras, radar, LIDAR, ultrasonic sensors, and V2X communication. Vehicles will need to communicate with other vehicles (V2V), the infrastructure (V2I) and pedestrians (V2P) in order to exchange data on speed, direction, traffic, weather, and potential obstacles. Vehicles will also need to communicate with their manufacturers through the cloud (V2C) in order to exchange data and receive the latest software updates. All of this will require a lot of sensors, control units, transmitters and receivers, as well as the connectors to link all these systems together.

©2020 Materion Brush Inc.

With fully autonomous vehicles, there will also need to be more ways for the vehicle itself to communicate with its surroundings and other vehicles (V2X communication):

- Vehicle to Vehicle (V2V) communication
  - Braking, speed, turning/merging intention
  - Communications of hazards/road conditions to trailing vehicles
- Vehicle to Infrastructure (V2I) communication
  - Traffic light timing
  - Reduced speeds required
  - Parking fees/tolls
- Vehicle to Pedestrian (V2P) communication
- Vehicle to Cloud (V2C) communication
  - Real time/real world driving data
  - Maintenance alerts
  - Software updates
- More accurate positioning data via GPS or wireless network triangulation

Approximately 2/3 of automotive electrical and electronic system failures are caused by connector failures. Several hundred thousand connectors can be expected to fail in a given year, resulting in warranty claims, high replacement costs, lost sales, and bad public relations. Current automotive connector design engineers are facing many challenges including reduction in insertion force, miniaturization of connectors, and increasing power while maintaining reliability and reducing cost. This is compounded by the fact the electronic systems are expected to last at least 10 years!

Each connector must pass electrical current and/or electronic signals through without distorting them. Any such distortion could result in incorrect operation or failure of the myriad devices in a car. To prevent signal distortion, reliable connectors provide and maintain adequate contact force in order to keep the resistance low and stable over the life of the connector. This requires mechanical stability in the connector, as well as strength, stiffness, formability, conductivity, and stress relaxation resistance in the base metal, along with adequate hardness and lubricity in the plating.

Connectors can fail by many mechanisms. Contact force will decay over time due to stress relaxation, increasing contact resistance. This means that a contact will have to be over-designed at the beginning of life in order to compensate for the loss of force at end-of-life, unless it is made from a material resistant to stress relaxation. Furthermore, the electrical resistance of the connector generates an increase in temperature. This temperature rise results in accelerated corrosion and stress relaxation. High conductivity material will minimize any such resistive heating. Vibration will result in fretting corrosion and intermittencies in the circuit across the connector. Fretting corrosion can be mitigated by providing a stable contact interface, adequate contact force, the proper choice of plating, and the use of lubrication where possible.

The peak insertion force for a connector depends on the number of contacts, the contact force, the contact angle, and frictional characteristics of the plating. Insertion force can be reduced by changing the geometry of the contacts and by minimizing friction. However, the contact force should not be reduced. An optimum balance can be found with the proper choice of base metal and plating. As connectors become smaller, higher stresses are required to generate the necessary contact force in the contacts and the temperature rise increases. The connector base metal must provide adequate strength on the contact end of the terminal, but must still be formable enough to crimp on to the wire at the other end. A design example to follow shows how higher performance materials are becoming necessary to meet these challenges.

Materion has been serving the automotive electronics market for decades. Copper beryllium has long been the alloy of choice in critical electrical connectors, providing unparalleled reliability in difficult, corrosive and high temperature environments, like those found under the hood of today's cars and light trucks. (See Figure XVIII-4 for a full list of benefits.)

Figure XVIII-4 High Performance Alloy Benefits




Figure XVIII-4 High Performance Alloy Benefits
Copper beryllium has an unmatched combination of high strength and conductivity, while still retaining good formability. Copper nickel tin has lower conductivity, but even better stress relaxation resistance and improved corrosion resistance. Nickel beryllium has similar attributes to copper nickel tin, but can withstand far higher temperatures, has exceptional resistance to stress relaxation, and the outstanding corrosion resistance of a nickel alloy.

©2020 Materion Brush Inc.

Materion provide materials that support

- Miniaturization
- Weight Reduction
- Increasing electrification/electronics density
- Greater power
- Higher temperatures
- More severe vibration
- Larger impact & shock loads
- Lower insertion force
- Stability
- Reliability
- Lower total cost

Increasing electrification/electronics density – As more electrical and electronic devices are included in cars, more circuits will be required to connect and power these devices, and each connector will see a greater number of circuits. This means more contacts must be placed in each connector, reducing the space available for contacts. This in turn means the contacts must be miniaturized.

Miniaturization – When contacts are made smaller, the only way to maintain good contact force is to increase the stress in the material during normal operation. Copper beryllium has the high strength required to withstand this additional stress, and the conductivity required to pass high current through a smaller cross sectional area without overheating or falling victim to thermal runaway. Copper beryllium also has the formability required to form small contacts in tight spaces, without sacrificing strength.

Greater power – As more electronic devices are placed in cars, a greater amount of power will be required to drive them. This requires some combination of higher voltage (potentially increasing the potential for galvanic corrosion and electrical arcing on contact connection and disconnection) and/or higher current (requiring higher conductivity to minimize temperature rise through resistive heating and greater stress relaxation resistance in materials to withstand the higher temperatures generated.)

Higher temperatures – As engines are run ever hotter to increase efficiency, connectors under the hood will need to be able withstand higher temperatures. Copper beryllium retains a high percentage of its room temperature strength at elevated temperatures, and has excellent resistance to stress relaxation. Because it will not lose as much force over time as lower performance materials, it can be designed with a lower initial contact force, promoting miniaturization and lowering insertion force. Higher temperatures may also increase the tendency to corrode, making corrosion resistance of the plating and base metal more important.

Weight reduction – As cars are made smaller and lighter, there will be less mass above the suspension system in the car, meaning that a greater amount of shock loads and vibration from the road/tire interface will find its way into the cabin and under the hood, requiring higher strength to resist them. Smaller, lighter wires and cables with smaller connectors can run hotter, given the elevated temperature strength and stress relaxation resistance of copper beryllium.

More severe vibration – Copper beryllium provides the stiffness and contact force required to prevent intermittent contact and minimize fretting corrosion due to vibration.

Larger impact & shock loads – Copper beryllium has the resilience and toughness required to absorb suddenly applied high forces without permanent deformation.

Lower insertion force – Since they retain force so well under extreme conditions, contacts made with copper beryllium can be designed with a lower initial contact force, more closely matched to the end of life contact force. This reduces insertion force per contact, allowing more contacts to be placed into a connector without increasing the required mating force beyond ergonomic limits.

Stability – Copper beryllium's high elevated temperature strength and resistance to stress relaxation means that the contact force changes very little over time. This means that the contact resistance starts low and remains stable over the life of the connector.

Reliability – Copper beryllium has the greatest resistance to loss of contact force over time, even in miniaturized designs carrying high current at elevated temperatures and under heavy vibration. Electronic signals and electrical power will pass through a properly designed connector without unacceptable distortion whether the car is 1 day old or 10 years old.

Lower cost – High performance alloys can contribute to lower overall cost in two ways. One is through miniaturization. Contacts and connectors can be made smaller with high performance alloys. This means that there is less metal to buy per a given number of contacts, as well as less surface area to plate, and less plastic to mold around the connector. All of this creates cost savings that are not reflected in the purchase price in terms of dollars per pound, but that show up elsewhere on the balance sheet. (See Section XVII – Cost Effective Material Usage and Cost Reduction Exercise).

©2020 Materion Brush Inc.

Design Process Example – One-piece Automotive Box Terminal Socket

Design Exercise

The exercise will walk through a typical connector design utilizing the process flowchart discussed earlier. Design decisions are never one dimensional. The first step is to identify the critical design criteria for each application. The second step is basing the material selection decision on those criteria. The simplified flowchart in Figure XVIII-5 illustrates a typical design process. We will discuss an automotive wiring harness box terminal (Figure XVII-6) as an example.

Figure XVIII-5 Design Example Flowchart




Figure XVIII-5 Design Example Flowchart
This chart illustrates the basic steps in the design process, and includes the material properties that come into play at each step.

Figure XVIII-6 Automotive Box Terminal and Blade




Figure XVIII-6 Automotive Box Terminal and Blade
In this case, we will be looking at the female box terminal (lower right), such as could be found in the automotive connector in the lower left.

©2020 Materion Brush Inc.

Review of Holm Contact Theory: An ideal electrical connector is transparent to the current or signal that passes through it. In reality, the electrical resistance of the interface will cause the current to lose some power. In order to ensure performance of the contact, the resistance must not be allowed to increase to the point of functional degradation. The resistance is directly proportional to the hardness of the contact surfaces and inversely proportional to the contact force between the two halves of the interface. The hardness is determined by the plating. The contact force is determined by the geometry of the design and the base material properties. In order to assure the continued proper functioning of the connector, a minimum contact force must be established and maintained over the life of the contact.

Figure XVIII-7 Holm's Theory of Contact Resistance




Figure XVIII-7 Holm's Theory of Contact Resistance
The contact resistance is directly proportional to the hardness of the plating, and inversely proportional to the contact force. Bulk resistance is determined by the conductivity of the base metal, while film resistance is determined by the resistivity of oxides or other surface contaminants. The only way to ensure low and stable contact resistance is to provide sufficient contact force, so that any variation in contact force (due to vibration, thermal expansion, stress relaxation, plastic deformation, etc.) does not result in unacceptable increases in contact resistance. The plating or cladding on the surface determines what level of contact force is sufficient. For Sn-coated contacts, 100-200 grams of force are required.

©2020 Materion Brush Inc.

Geometry: Figure XVIII-8 shows a cutaway view of a simplified one-piece female box terminal next to a two-piece terminal. One-piece female terminals typically use curved cantilever beams to provide the necessary contact force. The box and spring are part of one continuous piece of metal. In a two-piece design, the box is formed from a soft alloy, and a simply supported or louvered spring stamped from a stronger alloy is placed inside the box. Two-piece designs provide a greater spring rate, but require multiple assembly steps. One-piece designs require a good combination of strength for good spring performance and ductility to form the sharp bends and crimp around the wire.

Figure XVIII-8 One-Piece vs. Two-piece Design

One-Piece Design

- High lead in angles
- Higher insertion force

Two-piece Design

- Low lead-in angles
- Lower insertion force





Figure XVIII-8 One-Piece vs. Two-piece Design
The left side is an example of a one-piece female box terminal. Note the tight formability requirements for the base metal, as the cantilever beams must be bent over in a thin space, and the edges of the box are folded tightly for space savings. The two-piece design has the box folded around a spring stamped out of a second piece of metal. The two-piece design typically has lower insertion force due to having only one contact surface with low lead-in angles. The one-piece design has two contact surfaces, typically with higher lead-in angles, creating a higher insertion force.

One-Piece Terminal Example

The electrical contact is established when an inserted male blade deflects the pair of curved cantilever beams inside the female half of the connector. The important dimensions of the cantilever beams are shown in Figure XVIII-9. This particular configuration is chosen since design parameters such as stress, contact force, and allowable deflection are easily calculated by the standard curved cantilever beam equations, as shown in Figure XVIII-10.

Figure XVIII-9 Design Example Dimensions



100 grams contact force from each of the 2 cantilever beams inside the terminal


15 Amps maximum current split between the two beams

Figure XVIII-9 Design Example Requirements
The key dimensions are the bend radius at the fixed end, the width, thickness and applied deflection. The elastic modulus determines both the maximum stress and the spring rate (force per unit deflection), limited by the yield strength of the material.

Figure XVIII-10 Curved Cantilever Beam Definitions

$$F = \frac{E \cdot w \cdot t^3}{12 \cdot R^3 \cdot [NDT_1]} \cdot d$$

$$\sigma_{max} = \frac{E \cdot t \cdot (L+R)}{2 \cdot R^3 \cdot [NDT_1]} \cdot d$$



$$[NDT_1] = \left[\frac{1}{3}\cdot\left(\frac{L}{R}\right) + \left(\frac{L}{R}\right)\cdot\left(\theta\cdot\frac{\pi}{180}\right) + 2\cdot\left(\frac{L}{R}\right)\cdot(1-\cos\theta) + \left(\frac{\theta}{2}\cdot\frac{\pi}{180}\right) - \frac{\sin 2\theta}{4}\right]$$

Figure XVIII-10 Curved Cantilever Beam Definitions
These equations describe the normal force on the end of a cantilever beam that is curved at the fixed end. The reaction force is equal and opposite the applied deflection.

©2020 Materion Brush Inc.

Design Parameters: For this exercise, assume an ambient temperature of 150°C for a typical automotive application. The terminal will be coated with tin. This will require a minimum of 100 grams of contact force on each beam. Not only must the beam be designed to provide this contact force upon initial insertion, it must be designed to maintain this force over the expected life of the connector.

Coating (Plating/Cladding/Hot Dipped/etc.) Materials

Since electrical contact (and the all-important contact resistance) occurs mostly at the plating/clad surface, the type of coating becomes the first important decision. Once the plating is decided, then the normal force requirements can be determined. Here are some important properties of coating materials:

- Lubricity
  - Reduces friction
  - reduces insertion force
- Hardness (trade-off)
  - Increases wear resistance
  - Reduces friction
  - Reduces Insertion force
  - But increases contact resistance
- Conductivity
  - Reduces contact resistance
- Corrosion Resistance
  - Reduces contact resistance

Some plating options and considerations are shown in Figure XVIII-11. For this design, we will use standard Sn plating.

Base Metal (Spring) Materials: The spring materials listed in Table XVIII-1 are used throughout the world in various automotive connectors. The list includes several types of alloy systems, including a stainless steel. The goal is to find one that meets the design requirements. Some of these alloys are not suitable for box terminals, as will be shown shortly. However, they are included to make the listing as thorough as possible.

Table Convention: Materials in blue font are produced by Materion, while those in black font are alloys produced by other materials suppliers. In subsequent tables, if a particular material fails to meet the specification for the performance characteristic in that table, the font is changed to red.

Figure XVIII-11 Plating Options

	Normal Force Required	Typical Coefficient of Friction	Relative Cost	Typical Uses in Automotive Connectors
Sn	100 - 150 g	0.2 - 1.0	Very low	Standard terminals
SnPb	100 - 150 g	0.5 - 0.8	Very low	
SnAg	100 g	0.4 - 0.6	Low	Higher reliability terminals
Ag	100 g	0.5 - 0.8	Moderate	High current connectors and charging contacts
Hard Au	30 g	0.2 - 0.5	High	Signal connectors on critical safety components such as airbag connectors
PdNi, PdCo	50 g	0.3 - 0.5	High	
Pd	50 g	0.3 - 0.5	Very High	

Increasing Reliability

Figure XVIII-11 Plating Options
Sn or SnPb are used for most low-cost terminals. SnAg may be used for higher performance or greater reliability requirements, since it has increased hardness and lower friction than Sn or SnPb, with electrical performance similar to Ag at lower cost. If even greater reliability is required, then it is time to use precious metals.

Table XVIII-1 - Alloys Used In Analysis

Name	UNS#	Type	Name	UNS#	Type	Name	UNS#	Type
25	C17200	CuBe	STOL® 76	C19010	Hi Cu	MAX 251C	C64725	CuNiSi
190	C17200	CuBe	NB 109	C19025	Hi Cu	MAX 375	C64727	CuNiSi
290	C17200	CuBe	194	C19400	CuFe	654	C65400	Si Bronze
174	C17410	CuBe	197	C19700	CuFe	688	C68800	Al Bronze
Brush® 60	C17460	CuBe	199	C19900	CuTi	7025	C70250	CuNiSi
BrushForm® 158	C72900	CuNiSn	260	C26000	Cart. Brass	NKC 388	C70252	CuNiSi
BrushForm® 158	C72900	CuNiSn	425	C42500	Sn Brass	7026	C70260	CuNiSi
Wieland-K88®	C18080	Hi Cu	KLF™-5	C50715	P Bronze	STOL® 94	C70310	CuNiSi
MZC1	C18141	Hi Cu	510	C51000	P Bronze	Wieland-K57	C70350	CuNiSi
186	C18600	Hi Cu	519	C51900	P Bronze	725	C72500	CuNiSn
MSP®1	C18665	Hi Cu	521	C52100	P Bronze	301 SS	S30100	Stainless

Wieland-K57 & Wieland-K88 are registered trademarks of Wieland-Werke AG.
KME Germany GmbH & Co.
Kobe Steel, Ltd.

©2020 Materion Brush Inc.

Fabrication Criteria

Formability: Deciding the formability of the contact addresses a number of questions. Will the contact require stamping or machining? If stamping, what will the stamping progression be and what are the parameters? The most commonly used criterion for forming is the ratio of minimum bend radius divided by the thickness of the strip (R/t). This data is available for most connector alloys in both the longitudinal and transverse directions. Checking the part dimensions verifies the critical bend radii of the part as well as their compliance with the material property. The formability data (R/t ratio) versus yield strength for the selected alloys is shown in Figures XVIII-12 and XVIII-13. Alloys with the most desirable combination of low R/t ratio and high yield strength will be on the lower right side of the charts. Here is where the age hardenable materials have the greatest advantage, being very formable before heat treatment and very strong after heat treatment.

This design example has stringent formability requirements. There is a 90° bad way (transverse) bend with a 1.0 R/t ratio. There is also a 175° good way (longitudinal) bend with a 1.0 R/t ratio. For each of the alloys listed above, select the temper with the highest yield strength that meets the formability requirements. It helps to look at alloys with high yield strengths and good formability. Table XVIII-2 below shows the tempers selected, along with the good way and bad way formability for 90° bends.

Figure XVIII-12 Longitudinal Formability




Figure XVIII-12 Longitudinal Formability
This shows the relationship between strength and longitudinal (good way) formability for each temper of the alloys considered. Each family of alloys has their own color scheme, so you can see that similar alloy systems have similar performance. The best strength/conductivity relationships are found in the alloys that are heat treated after forming, namely Alloys 25 and BrushForm® 158 strip. For each alloy, we will select the highest strength temper that still falls below the design requirement line.

Figure XVIII-13 Transverse Formability




Figure XVIII-13 Transverse Formability
This shows the relationship between strength and transverse (bad way) formability for each temper of the alloys considered. Note that there are fewer options under the design requirement line for the transverse direction bends than there are for the longitudinal direction bends shown in Figure XVIII-12.

Table XVIII-2 - Strongest Temper Usable Based on Formability Requirement

Alloy	Temper	GW	BW	Alloy	Temper	GW	BW	Alloy	Temper	GW	BW
25	1/2 HT	0.5	1.0	C19010	R460	0.5	1.0	C64725	1/2 H	0.3	0.6
190	1/2 HM	0.5	1.0	C19025	H	0.0	1.0	C64727	1/2 H	1.0	1.0
290	TM04	1.0	1.0	C19400	1/2 H	0.8	1.1	C65400	1/2 H	1.0	1.0
174	1/2 HT	0.5	0.5	C19700	EH	1.0	1.0	C68800	1/2 H	1.0	1.0
Brush® 60 strip	3/4 HT	0.7	0.7	**C19900**	**TM01**	**1.0**	**1.5**	C70250	TM00	1.0	0.5
BrushForm® 158	1/2 HT	0.0	0.5	C26000	H	0.4	0.9	C70252	EH	1.0	1.0
BrushForm® 158	TM04	1.0	1.0	C42500	1/2 H	0.0	0.0	C70260	TM02	0.5	1.0
C18080	TM08	0.5	0.5	C50715	H	0.5	1.0	C70310	R660	1.0	1.0
C18141	H	0.5	0.6	C51000	1/4 H	0.3	0.4	**C70350**	**TM04**	**1.0**	**1.5**
C18600	TM02	0.5	0.5	C51900	1/2 H	0.0	0.0	C72500	1/2 H	1.0	1.0
C18665	1/4 H	0.1	1.1	C52100	1/2 H	0.0	1.0	S30100	H	1.0	1.0

©2020 Materion Brush Inc.

Mechanical Criteria

The first criteria in the design of a contact are the mechanical properties, namely contact force and design stress. A “gas tight” interface requires adequate normal force to provide and maintain electrical contact. A contact should achieve the normal force without excessive stress during normal operation.

Yield Strength: The yield strength of the highest strength temper for each of the selected alloy systems is shown in Figure XVIII-14, while Figure XVIII-15 shows the maximum yield strength at the required formability level of 1.0 R/t in both directions. The difference in these charts illustrates how important both strength and formability are when considering materials for use in designs.

The yield strength at the required formability level of the selected alloys is shown in Table XVIII-3. It is desirable to keep the maximum stress in the design around 75% of the yield strength. Higher stress levels will provide higher initial contact forces, but will tend to accelerate stress relaxation over time, and will probably result in lower contact forces at end of life. Lower stress levels will reduce the initial contact force, but will provide no advantage in stress relaxation. A stress level of 75% of the yield strength provides a margin of safety against overstressing. This will minimize the risk of field failures and warranty claims.

Figure XVIII-14 Maximum Yield Strength without Regard to Formability




Figure XVIII-14 Maximum Yield Strength at R/t=1.0 GW/BW
This is the maximum strength available in each alloy system, including all tempers (even those that are not easily formable).

Figure XVIII-15 Maximum Yield Strength at R/t=1.0 GW/BW




Figure XVIII-15 Maximum Yield Strength at R/t=1.0 GW/BW
This is the maximum strength available in each alloy system that would still meet the tight forming requirements of this design example.

Table XVIII-3 - Highest Yield Strength (MPa/ksi) that Meets Formability Requirements

		Strength				Strength				Strength	
Alloy	Temper	MPa	ksi	Alloy	Temper	MPa	ksi	Alloy	Temper	MPa	ksi
25	1/2 HT	1224	178	C19010	R460	434	63	C64725	1/2 H	558	81
190	1/2 HM	758	110	C19025	H	317	46	C64727	1/2 H	703	102
290	TM04	862	125	C19400	1/2 H	345	50	C65400	1/2 H	545	79
174	1/2 HT	621	90	C19700	EH	465	67.5	C68800	1/2 H	634	92
Brush® 60 strip	3/4 HT	724	105	C19900	TM01	703	102	C70250	TM00	621	90
BrushForm® 158	1/2 HT	1034	150	C26000	H	352	51	C70252	EH	820	119
BrushForm® 158	TM04	793	115	C42500	1/2 H	331	48	C70260	TM02	669	97
C18080	TM08	552	80	C50715	H	558	81	C70310	R660	593	86
C18141	H	552	80	C51000	1/4 H	255	37	C70350	TM04	758	110
C18600	TM02	483	70	C51900	1/2 H	396	57.5	C72500	1/2 H	483	70
C18665	1/4 H	359	52	C52100	1/2 H	434	63	S30100	H	965	140

©2020 Materion Brush Inc.

Table XVIII-4 - Elastic Modulus (MPa/ksi)

Alloy	Temper	Elastic Modulus MPa	Elastic Modulus ksi	Alloy	Temper	Elastic Modulus MPa	Elastic Modulus ksi	Alloy	Temper	Elastic Modulus MPa	Elastic Modulus ksi
25	1/2 HT	131	19	C19010	R460	135	19.6	C64725	1/2 H	130	18.9
190	1/2 HM	131	19	C19025	H	130	18.9	C64727	1/2 H	131	19
290	TM04	131	19	C19400	1/2 H	121	17.5	C65400	1/2 H	117	17
174	1/2 HT	138	20	C19700	EH	119	17.2	C68800	1/2 H	117	17
Brush® 60 strip	3/4 HT	138	20	C19900	TM01	127	18.4	C70250	TM00	131	19
BrushForm® 158	1/2 HT	128	18.5	C26000	H	110	16	C70252	EH	123	17.8
BrushForm® 158	TM04	128	18.5	C42500	1/2 H	121	17.5	C70260	TM02	131	19
C18080	TM08	140	20.3	C50715	H	121	17.5	C70310	R660	132	19.1
C18141	H	137	19.9	C51000	1/4 H	110	16	C70350	TM04	131	19
C18600	TM02	128	18.5	C51900	1/2 H	119	17.2	C72500	1/2 H	138	20
C18665	1/4 H	125	18.1	C52100	1/2 H	110	16	S30100	H	193	28

Nominal Design Stress: A number of methods can calculate the design or working stress. The simplest method uses cantilever beam equations and assumes the maximum surface stress corresponds to the working or design stress as shown in the following equation, where E is the elastic modulus (Table XVIII-4 and Figure XVIII-16) of the material and the other dimensions were as shown in Figure XVIII-9:

$$\sigma_{max} = \frac{E \cdot t \cdot (L+R)}{2 \cdot R^3 \cdot \left[\frac{1}{3} \cdot \left(\frac{L}{R}\right)^3 + \left(\frac{L}{R}\right)^2 \cdot \left(\theta \cdot \frac{\pi}{180}\right) + 2 \cdot \left(\frac{L}{R}\right) \cdot (1 - \cos\theta) + \left(\frac{\theta}{2} \cdot \frac{\pi}{180}\right) - \frac{\sin 2\theta}{4}\right]} \cdot d$$

Figure XVIII-16 Modulus of Elasticity




Figure XVIII-16 Modulus of Elasticity
A higher modulus of elasticity provides greater contact force and greater resistance to vibration, protecting against fretting corrosion and intermittent electrical contact.

In reality, you would most likely use Finite Element Modeling to arrive at a design stress via Von Mises stresses, since very few designs are simple enough for simple closed form equations. For either FEA or hand calculations you would use the nominal or worse case contact deflection. In both cases it is desirable to have a design stress below the yield strength of the spring material to provide a safety factor. If the design stress exceeds the yield strength of the material, plastic deformation, also known as permanent set, will occur. In cases where entering into the plastic regime of the material is unavoidable, it is advantageous to use a material that is resistant to permanent set. Age hardenable or mill hardened materials are more resistant to permanent set in that they do not rely solely on cold work to provide their strength. Here, the maximum allowable stress is set as 75% of the yield strength. Higher stress levels will accelerate stress relaxation, and lower stress levels will provide reduced contact force and reliability.

Using the above equation, the nominal stress in the design is computed and compared to the maximum allowable stress determined earlier. These results are displayed in Table XVIII-5. The stress levels in the 15 alloys shown in red exceed the allowable limit, and, thus, are unsuitable in this particular design.

©2020 Materion Brush Inc.

Table XVIII-5 - Design Stress (ksi/MPa) vs. Maximum Allowable Stress (ksi/MPa)

Alloy	Temper	Design Stress ksi	Allowable Stress ksi	Design Stress MPa	Allowable Stress MPa	Safety Factor
25	1/2 HT	64	133	442	918	2.1
190	1/2 HM	64	83	442	569	1.3
290	TM04	64	94	442	646	1.5
174	1/2 HT	68	68	466	465	1.0
Brush® 60 strip	3/4 HT	68	79	466	543	1.2
BrushForm® 158	1/2 HT	62	113	431	776	1.8
BrushForm® 158	TM04	62	86	431	595	1.4
C18080	TM08	69	60	473	414	0.9
C18141	H	67	60	463	414	0.9
C18600	TM02	62	53	431	362	0.8
C18665	1/4 H	61	39	421	269	0.6
C19010	R460	66	47	456	326	0.7
C19025	H	61	39	421	269	0.6
C19400	1/2 H	66	47	456	326	0.7
C19700	EH	64	35	440	238	0.5
C19900	TM01	59	38	407	259	0.6
C26000	H	58	51	400	349	0.9
C42500	1/2 H	62	77	428	527	1.2
C50715	H	54	38	373	264	0.7
C51000	1/4 H	59	36	407	248	0.6
C51900	1/2 H	54	38	373	264	0.7
C52100	1/2 H	59	36	407	248	0.6
C64725	1/2 H	64	61	440	419	1.0
C64727	1/2 H	64	77	442	527	1.2
C65400	1/2 H	57	59	396	409	1.0
C68800	1/2 H	57	69	396	476	1.2
C70250	TM00	64	68	442	465	1.1
C70252	EH	60	89	414	615	1.5
C70260	TM02	64	73	442	502	1.1
C70310	R660	64	65	445	445	1.0
C70350	TM04	64	83	442	569	1.3
C72500	1/2 H	68	53	466	362	0.8
S30100	H	95	105	652	724	1.1

Table XVIII-6 - Design Force (g) vs. Maximum Permissible Force (g) [Minimum Required Force = 100 g]

Alloy	Temper	Design Force	Actual Force
25	1/2 HT	114	114
190	1/2 HM	114	114
290	TM04	114	114
174	1/2 HT	120	119
Brush® 60 strip	3/4 HT	120	120
BrushForm® 158	1/2 HT	111	111
BrushForm® 158	TM04	111	111
C18080	TM08	122	106
C18141	H	119	106
C18600	TM02	111	93
C18665	1/4 H	109	69
C19010	R460	118	84
C19025	H	113	61
C19400	1/2 H	105	66
C19700	EH	103	90
C19900	TM01	110	110
C26000	H	96	68
C42500	1/2 H	105	64
C50715	H	105	105
C51000	1/4 H	96	49
C51900	1/2 H	103	76
C52100	1/2 H	96	84
C64725	1/2 H	113	107
C64727	1/2 H	114	114
C65400	1/2 H	102	102
C68800	1/2 H	102	102
C70250	TM00	114	114
C70252	EH	107	107
C70260	TM02	114	114
C70310	R660	115	114
C70350	TM04	114	114
C72500	1/2 H	120	93
S30100	H	168	168

Initial Contact Force: Using the following equation, the contact or normal force of a cantilever beam connector is determined from the physical dimensions of the contact and the stiffness of the materials (modulus of elasticity, E):

$$F = \frac{E \cdot w \cdot t^3}{12 \cdot R^3 \cdot \left[\frac{1}{3}\cdot\left(\frac{L}{R}\right)^3 + \left(\frac{L}{R}\right)^2 \cdot \left(\theta \cdot \frac{\pi}{180}\right) + 2 \cdot \left(\frac{L}{R}\right) \cdot (1-\cos\theta) + \left(\frac{\theta}{2} \cdot \frac{\pi}{180}\right) - \frac{\sin 2\theta}{4}\right]} \cdot d$$

The beam length and thickness are most important since they are cubic functions in the equation. The critical material property here is the modulus of elasticity and the range of values for high performance spring alloys is from 110 to 140 GPa (16 to 20 million psi). The modulus is independent of temper. Given that the beam dimensions and deflection remain constant, the modulus can account for contact force variation of +/- 11%. However, if the contact design uses a modulus of 110 GPa (16 million psi) to achieve the desired contact force, a contact redesign for a smaller beam volume would need to use a higher modulus material.

Using the design geometry and the allowable stress, we calculate the initial contact force, shown in Table XVIII-6. The design force is derived from the cantilever beam equations. The actual force is equal to the design force in the alloys with a design stress lower than the allowable limit. For the remainder of the alloys (previously eliminated in the last step), the actual force is defined as the contact force at the maximum allowable stress level. In other words, if the design stress exceeds the yield strength, the initial force is appropriately de-rated to be the contact force at the yield stress.

©2020 Materion Brush Inc.

Ergonomic (Insertion Force) Criteria

Current ergonomic regulations require no more than 75 N force be required to mate connectors. As more contacts are included on each connector, each contact's individual contribution to insertion force must be reduced in order to meet this goal.

Figure XVIII-17 shows the insertion force calculation for inserting a blade between two cantilever beams, while Figure XVIII-18 shows a schematic example of how the insertion force peaks at a level much higher than the withdrawal force. The withdrawal force must be kept high to prevent accidental unmating, while the insertion force must be kept as low as possible. This may require latching mechanisms to be built into the connector housing itself to prevent unintended withdrawal.

As a designer, your goal is to minimize the insertion force without compromising the electrical performance.

You can achieve this by:

- Using a higher performance metal to maintain adequate end-of-life contact force for lower initial contact force.
  - Materials that are resistant to stress relaxation allow for lower initial contact forces without sacrificing normal force requirements.
- Minimizing the coefficient of friction (μ)
  - Use lubrication (usually polyphenol ether).
  - Use a harder, more lubricious plating like SnAg.
- Minimizing the contact angle (μ)
  - This will probably also reduce normal force.
  - Two-piece designs will also have lower contact angles than one-piece designs.

Allowable Deflection: If the maximum allowable deflection is equal to the nominal deflection, there is no margin for error in insertion of the blade. A value higher than the nominal would allow for any potential over-deflection due to misalignment of the blade and socket. This means that the connector would be better resistant to accidental overstressing during connector insertion or removal. The maximum allowable deflection is calculated as follows:

$$d_{yield} = \frac{2 \cdot R^3 \cdot \left[\frac{1}{3} \cdot \left(\frac{L}{R}\right)^3 + \left(\frac{L}{R}\right)^2 \cdot \left(\theta \cdot \frac{\pi}{180}\right) + 2 \cdot \left(\frac{L}{R}\right) \cdot (1 - \cos\theta) + \left(\frac{\theta}{2} \cdot \frac{\pi}{180}\right) - \frac{\sin 2\theta}{4}\right]}{t \cdot (L + R)} \cdot \frac{\sigma_{yield}}{E}$$

The material property that governs the maximum deflection is elastic resilience, which is the yield strength divided by the elastic modulus. A greater resilience means a greater deflection range in the design. The elastic resilience of each of our selected materials is shown in Figure XVIII-19 and Table XVIII-7. The maximum allowable deflection, shown below in Table XVIII-8 is calculated at the maximum allowable stress level.

Figure XVIII-17 Insertion Force Calculation

$$F_{Insertion} = N \cdot P_{Normal}\left(\frac{\sin\alpha + \mu \cdot \cos\alpha}{\cos\alpha - \mu \cdot \sin\alpha}\right)$$




Figure XVIII-17 Insertion Force Calculation
This equation demonstrates why the insertion force increases far beyond the peak extraction force. The withdrawal force is entirely governed by frictional forces, while the insertion force also includes the force required to deflect the contacts on the female side. While the male blade is inserted, the contact angle (α) continuously decreases, while the normal force continuously increases.

Table XVIII-7 - Elastic Resilience (Times 1000) at 1.0 R/t Bad Way

Alloy	Temper	Elastic Resilience	Alloy	Temper	Elastic Resilience	Alloy	Temper	Elastic Resilience
25	1/2 HT	9.3	C19010	R460	3.2	C64725	1/2 H	4.3
190	1/2 HM	5.8	C19025	H	2.4	C64727	1/2 H	5.4
290	TM04	6.6	C19400	1/2 H	2.9	C65400	1/2 H	4.6
174	1/2 HT	4.5	C19700	EH	3.9	C68800	1/2 H	5.4
Brush® 60 strip	3/4 HT	5.3	C19900	TM01	5.5	C70250	TM00	4.7
BrushForm® 158	1/2 HT	8.1	C26000	H	3.2	C70252	EH	6.7
BrushForm® 158	TM04	6.2	C42500	1/2 H	2.7	C70260	TM02	5.1
C18080	TM08	3.9	C50715	H	4.6	C70310	R660	4.5
C18141	H	4.0	C51000	1/4 H	2.3	C70350	TM04	5.8
C18600	TM02	3.8	C51900	1/2 H	3.3	C72500	1/2 H	3.5
C18665	1/4 H	2.9	C52100	1/2 H	3.9	S30100	H	5.0

©2020 Materion Brush Inc.

Environmental Criteria

After determining the contact force and design stress, it is important to analyze the other connector constraints due to electrical, thermal and environmental requirements. This includes resistance to shock and vibration. However, the most critical connector material requirement is its current carrying capability. Here, the electrical conductivity has a direct impact on the connector resistance and therefore its reliability.

Vibration Resistance: Figure XVIII-20 shows the USCAR test requirements for connectors located in various areas of the car, including required resistance to shock and vibration (as well as temperature). As stated earlier, with current light weighting trends, there will less vehicular mass to offset the shock and vibrations coming from the road, meaning connectors will experience a greater amount of relative acceleration.

Figure XVIII-18 Insertion and Extraction Forces




Figure VXIII-18 Insertion and Extraction Forces
During insertion, the force required increases until the contacts are deflected to their maximum amount. Then, the force drops down during a steady state sliding condition. The withdrawal force will be approximately equal to the steady state insertion force, and its peak will be much less than the peak insertion force.

Figure XVIII-19 Elastic Resilience at 1.0 R/t GW/BW




Figure XVIII-19 Elastic Resilience at 1.0 R/t GW/BW
This provides a measure of how tolerant the material is to overdeflection due to misalignment when mating or unmating the connector. Note that this unit is dimensionless, so that it is the same in SI or US Imperial units.

Figure XVIII-20 USCAR* Performance/Reliability Requirements

Location	Firewall	Engine	Brake	Exhaust Manifold
Device	ECU	ECU	Sensor	Sensor
Temperature	125°C	125°C	250°C	400°C
Vibration	3 g	10 g	20 g	40 g
Shock	20 g	30 g	60 g	50 g

*United States Council for Automotive Research LLC
Requirements governed by the Electrical Wiring Component Applications Partnership (EWCAP)

Figure XVIII-20 USCAR Performance/Reliability Requirements
Here are some general requirements for connector performance in various locations. Some are far more severe than others, but connnectors located there are still expected to function reliably for at least 10 years.

Table XVIII-8 - Maximum Permissible Deflection (in/mm) [Design Deflection = 0.008 in/0.2 mm]

Alloy	Temper	Max. Def. in	Max. Def. mm	Alloy	Temper	Max. Def. in	Max. Def. mm	Alloy	Temper	Max. Def. in	Max. Def. mm
25	1/2 HT	0.017	0.42	C19010	R460	0.006	0.14	C64725	1/2 H	0.008	0.19
190	1/2 HM	0.010	0.26	C19025	H	0.004	0.11	C64727	1/2 H	0.010	0.24
290	TM04	0.012	0.30	C19400	1/2 H	0.005	0.13	C65400	1/2 H	0.008	0.21
174	1/2 HT	0.008	0.20	C19700	EH	0.007	0.18	C68800	1/2 H	0.010	0.24
Brush® 60 strip	3/4 HT	0.009	0.24	C19900	TM01	0.010	0.25	C70250	TM00	0.008	0.21
BrushForm® 158	1/2 HT	0.014	0.36	C26000	H	0.006	0.14	C70252	EH	0.012	0.30
BrushForm® 158	TM04	0.011	0.28	C42500	1/2 H	0.005	0.12	C70260	TM02	0.009	0.23
C18080	TM08	0.007	0.18	C50715	H	0.008	0.21	C70310	R660	0.008	0.20
C18141	H	0.007	0.18	C51000	1/4 H	0.004	0.10	C70350	TM04	0.010	0.26
C18600	TM02	0.007	0.17	C51900	1/2 H	0.006	0.15	C72500	1/2 H	0.006	0.16
C18665	1/4 H	0.005	0.13	C52100	1/2 H	0.007	0.18	S30100	H	0.009	0.22

©2020 Materion Brush Inc.

For understanding reliability in the face of vibration, the first thing to consider is the natural frequency of a cantilever beam:

$$f = \frac{t}{2 \cdot L^2}\left(\frac{E}{\rho}\right)^{1/2}$$

Here, E is the elastic modulus, ρ is the density, and L is the unsupported beam length. It is obvious that materials with high elastic modulus (high stiffness) are more resistant to vibration

Now, the following is the required minimum force to prevent sliding due to shock or vibration, per the Ney Contact Manual:

$$F = \frac{3 \cdot \rho \cdot V}{8\mu} g$$

Here, F is the contact force, ρ is the density of the spring material, V is its volume, μ is the coefficient of friction, and g is the acceleration due to shock or vibration. (Here, g is not grams, but is the gravitational acceleration of the Earth at sea level).

As the friction coefficient increases, the required minimum contact force is reduced. However, ergonomic requirements are driving design in the other direction, so overall friction is reduced. The number of g's of acceleration is determined by the environment, so we have no control over it. We have little control over density as well, since most copper alloys have similar density. The only variable operating in our favor is volume, since smaller contacts reduce the required minimum contact force, and thus require a lower contact force to keep from sliding. In the end, however, higher contact force means less chance of vibrating loose.

Fretting Corrosion

Fretting corrosion (see Section X – Considerations for Harsh Environments) occurs on Sn and SnPb surfaces due to micro-motion of the contact interface. (This can be from mechanical vibrations or differential thermal expansion.) In order to minimize the potential for fretting corrosion, tin surfaces should be lubricated. This reduces the tendency for fretting corrosion, and extends the life of the contact, as shown schematically in Figure XVIII-21.

Temperature Rise: The temperature rise in a contact material depends upon the current flowing in the material, the physical dimensions of the contact (beam length and cross sectional area) and the electrical and thermal conductivity. The following equation approximates temperature rise:

$$\Delta T = \frac{J^2 L^2}{2\gamma\kappa w^2 t^2}$$

Here ΔT is the temperature rise (°F), J is the current (amps), L is the beam length (in), A is the cross-sectional area (in^2), γ is the electrical conductivity and κ is the thermal conductivity. In order to be useful, the data requires conversion into compatible units for this equation. Convert electrical conductivity in (%IACS) to amps/volt-in by multiplying by 14700. Thermal conductivity must be converted to volts-amps/inch-°F by multiplying BTU/ft-hr-F by 0.0244. Table XVIII-9 and Figure XVIII-22 show the electrical conductivities of the various materials. The thermal conductivity is directly proportional to the electrical conductivity. The temperature rise for each material is shown on table XVIII-10

Figure XVIII-21 Effect of Lubrication on Fretting Corrosion




Figure XVIII-21 Effect of Lubrication on Fretting Corrosion
Lubrication protects the contact interface against fretting corrosion, by preventing the formation of oxides at the interface. Full lubrication is best, but if there is a seal failure, then even partial lubrication provides increased reliability and longer life than unlubricated contacts.

Figure XVIII-22 Electrical Conductivity




Figure XVIII-22 Electrical Conductivity
Higher conductivity minimizes temperature rise, and permits greater current to flow through a smaller area. This means that the current may be increased for a given connector size, and/or a smaller cross section may be used for the same current in order to reduce the contact size and squeeze more circuits into each connector.

©2020 Materion Brush Inc.

Stress Relaxation: Consider the ambient heating due to the environment as a contributing factor to the rise in temperature due to resistive heating. Combining these is a worse case scenario for a connector. The elevated temperature conditions have a large impact on the mechanical properties of the contact spring material. The contact force may degrade due to this temperature exposure. Degradation of a connector's normal force may have a direct impact on its reliability if the value drops below the critical requirement for a stable contact system. When choosing a material it is critical to select a material that will provide adequate normal force at the end of its operating life based on the conditions under which it will function. Figure XVIII-23 shows a plot of the thermal relaxation characteristics of several spring contact materials.

Figure XVIII-23 Effect of Temperature on Stress Relaxation




Figure XVIII-23 Effect of Temperature on Stress Relaxation

The precipitation hardened materials like CuBe, CuNiSn, and CuNiSi retain their stress levels (and thus contact force and reliability) far longer and at much higher temperatures than materials that are strengthened by cold work alone.

Table XVIII-9 - Electrical and Thermal Conductivity

Alloy	Temper	Electrical % IACS	Thermal W/m °C
25	1/2 HT	22	104
190	1/2 HM	17	104
290	TM04	17	104
174	1/2 HT	50	234
Brush® 60 strip	3/4 HT	50	222
BrushForm® 158	1/2 HT	8	29
BrushForm® 158	TM04	8	29
C18080	TM08	80	320
C18141	H	82	317
C18600	TM02	70	287
C18665	1/4 H	63	265
C19010	R460	50	261
C19025	H	35	163
C19400	1/2 H	65	260
C19700	EH	80	320
C19900	TM01	13	54
C26000	H	28	121
C42500	1/2 H	26	116
C50715	H	30	121
C51000	1/4 H	15	69
C51900	1/2 H	21	69
C52100	1/2 H	36	107
C64725	1/2 H	37	159
C64727	1/2 H	43	156
C65400	1/2 H	7	36
C68800	1/2 H	17	69
C70250	TM00	40	169
C70252	EH	35	159
C70260	TM02	40	156
C70310	R660	40	185
C70350	TM04	50	201
C72500	1/2 H	31	93
S30100	H	2	16

Table XVIII-10 - Temperature Rise and Operating Temperature (°C) [Typical Requirement <25°C Temperature Rise)


Alloy	Temper	Temp Rise	Operating Temp
25	1/2 HT	3	153
190	1/2 HM	4	154
290	TM04	4	154
174	1/2 HT	1	151
Brush® 60 strip	3/4 HT	1	151
BrushForm® 158	1/2 HT	32	182
BrushForm® 158	TM04	32	182
C18080	TM08	0	150
C18141	H	1	151
C18600	TM02	0	150
C18665	1/4 H	0	150
C19010	R460	1	151
C19025	H	1	151
C19400	1/2 H	0	150
C19700	EH	0	150
C19900	TM01	11	161
C26000	H	2	152
C42500	1/2 H	2	152
C50715	H	2	152
C51000	1/4 H	7	157
C51900	1/2 H	9	159
C52100	1/2 H	2	152
C64725	1/2 H	1	151
C64727	1/2 H	2	152
C65400	1/2 H	29	179
C68800	1/2 H	6	156
C70250	TM00	1	151
C70252	EH	2	152
C70260	TM02	1	151
C70310	R660	2	152
C70350	TM04	1	151
C72500	1/2 H	3	153
S30100	H	189	339

©2020 Materion Brush Inc.

Once the temperature rise is known, the operating temperature and stress relaxation will be calculated. Stress relaxation data is available for most of these alloys at 1000 hours for temperatures at 100, 150, and 200°C. From this data, the stress remaining in a contact made from each of these alloys can be approximated at the operating temperature, as shown numerically below in Table XVIII-11 and graphically in Figure XVIII-24.

Remaining Contact Force: The contact force remaining for each of the alloys is shown in Table XVIII-12. Only two alloys remain in consideration. The other alloys are not adequate in this application because they will permanently deform, operate at too high a temperature or fail to retain sufficient contact force. Two of the five copper beryllium alloys make the cut, as does the copper titanium alloy.

Figure XVIII-24 Stress Relaxation at Operating Temperature



Stress Remaining after 1000 hours at Operating Temperature,
Initial Stress Level = 75% of the 0.2% Offset Yield Strength

Figure XVIII-24 Stress Relaxation at Operating Temperature
Again, the higher performance materials show little loss of contact force, while the lower performance alloys quickly degrade at temperatures over 150°C.

Alloy Selection: As a final step, a non-linear finite element analysis would verify the suitability of each of these three alloys. Alloys 25 ½ HT and Brush 60 ¾ HT copper beryllium alloys will work in this application. Alloy Brush 60 ¾ HT meets all of the minimum requirements, and has the lowest cost. Consequently, Alloy Brush 60 ¾ HT would seem to be the optimal material choice for this application. A final summary of the results is shown in Table XVIII-13. Cells shaded in green indicate results that exceed the minimum requirements, cells shaded in yellow show questionable results that are the on the border between success and failure (meaning that they have no margin for error), and cells shaded in red show values that fail to meet the basic design and reliability specifications by a significant margin.

Important base metal properties:

- Yield Strength
  - Maximizes allowable deflection, aids miniaturization
- Elastic Modulus
  - Provides normal force (most important property when stresses are below the yield strength)
  - Improves vibration resistance
  - Prevents buckling while crimping
- Conductivity
  - Decreases overall resistance
  - reduces temperature rise
  - decreases stress relaxation
- Stress Relaxation Resistance
  - Increases EOL force
  - reduces insertion force (by reducing initial normal force requirement)
- Formability
  - Aids crimping
  - Reduces springback by allowing tighter bends
  - Aids miniaturization

Table XVIII-11 - Stress Remaining after 1000 hours at Operating Temperature

Alloy	Temper	Remaining Stress	Alloy	Temper	Remaining Stress	Alloy	Temper	Remaining Stress
25	1/2 HT	88%	C19010	R460	83%	C64725	1/2 H	87%
190	1/2 HM	66%	C19025	H	80%	C64727	1/2 H	83%
290	TM04	86%	C19400	1/2 H	70%	C65400	1/2 H	50%
174	1/2 HT	82%	C19700	EH	70%	C68800	1/2 H	25%
Brush® 60 strip	3/4 HT	85%	C19900	TM01	94%	C70250	TM00	82%
BrushForm® 158	1/2 HT	88%	C26000	H	41%	C70252	EH	80%
BrushForm® 158	TM04	86%	C42500	1/2 H	47%	C70260	TM02	70%
C18080	TM08	84%	C50715	H	70%	C70310	R660	70%
C18141	H	90%	C51000	1/4 H	80%	C70350	TM04	83%
C18600	TM02	96%	C51900	1/2 H	40%	C72500	1/2 H	87%
C18665	1/4 H	80%	C52100	1/2 H	80%	S30100	H	95%

MATERION

©2020 Materion Brush Inc.

The choice of material will greatly depend on the actual location of the connector (as was shown in Figure XVIII-20). Typically, as the environment gets more severe, higher performance materials will be required, as shown in Figure XVIII-25 and XVIII-26. Typically, you will use the lowest cost material that meets the requirements, bearing in mind that this is not necessarily the lowest priced material, as discussed in Section XVII – Cost Effective Material Usage and Cost Reduction Example.

Table XVIII-12 Force Remaining (g) after 1000 hours of Operation (End-of-Life) [100 g Requirement]

Alloy	Temper	Remaining Force	Alloy	Temper	Remaining Force	Alloy	Temper	Remaining Force
25	1/2 HT	100	C19010	R460	69	C64725	1/2 H	94
190	1/2 HM	75	C19025	H	49	C64727	1/2 H	95
290	TM04	98	C19400	1/2 H	46	C65400	1/2 H	51
174	1/2 HT	98	C19700	EH	63	C68800	1/2 H	25
Brush® 60 strip	3/4 HT	102	C19900	TM01	104	C70250	TM00	93
BrushForm® 158	1/2 HT	98	C26000	H	28	C70252	EH	85
BrushForm® 158	TM04	95	C42500	1/2 H	30	C70260	TM02	80
C18080	TM08	89	C50715	H	73	C70310	R660	80
C18141	H	96	C51000	1/4 H	39	C70350	TM04	95
C18600	TM02	89	C51900	1/2 H	31	C72500	1/2 H	81
C18665	1/4 H	55	C52100	1/2 H	67	S30100	H	160

Table XVIII-13 - Results Summary

Alloy	Temper	Formability Good Way	Formability Bad Way	Safety Factor	Maximum Force (g)	Temperature Rise (°C)	End of Life Force (g)
25	1/2 HT	0.50	1.0	2.1	114	3	100
190	1/2 HM	0.50	1.0	1.3	114	4	75
290	TM04	1.00	1.0	1.5	114	4	98
174	1/2 HT	0.50	0.5	1.0	119w	1	98
Brush® 60 strip	3/4 HT	0.70	0.7	1.2	120	1	102
BrushForm® 158	1/2 HT	0.00	0.5	1.8	111	32	98
BrushForm® 158	TM04	1.00	1.0	1.4	111	32	95
C18080	TM08	0.50	0.5	0.9	106	0	89
C18141	H	0.50	0.6	0.9	106	1	96
C18600	TM02	0.50	0.5	0.8	93	0	89
C18665	1/4 H	0.10	1.1	0.6	69	0	55
C19010	R460	0.50	1.0	0.7	84	1	69
C19025	H	0.00	1.0	0.5	61	1	49
C19400	1/2 H	0.75	1.1	0.6	66	0	46
C19700	EH	1.00	1.0	0.9	90	0	63
C19900	TM01	1.00	1.5	1.2	110	11	104
C26000	H	0.40	0.9	0.7	68	2	28
C42500	1/2 H	0.00	0.0	0.6	64	2	30
C50715	H	0.50	1.0	1.0	105	2	73
C51000	1/4 H	0.30	0.4	0.5	49	7	39
C51900	1/2 H	0.00	0.0	0.7	76	9	31
C52100	1/2 H	0.00	1.0	0.9	84	2	67
C64725	1/2 H	0.30	0.6	1.0	107	1	94
C64727	1/2 H	1.00	1.0	1.2	114	2	95
C65400	1/2 H	1.00	1.0	1.0	102	29	51
C68800	1/2 H	1.00	1.0	1.2	102	6	25
C70250	TM00	1.00	0.5	1.1	114	1	93
C70252	EH	1.00	1.0	1.5	107	2	85
C70260	TM02	0.50	1.0	1.1	114	1	80
C70310	R660	1.00	1.0	1.0	114	2	80
C70350	TM04	1.00	1.5	1.3	114	1	95
C72500	1/2 H	1.00	1.0	0.8	93	3	81
S30100	H	1.00	1.0	1.1	168	189	160

©2020 Materion Brush Inc.

Figure XVIII-25 Generalized Performance vs. Time




Figure XVIII-25 Generalized Performance vs. Time

This chart schematically compares the generalized performance of various alloy families, from lower performance commodity materials on the bottom left through progressively higher performance materials on the upper right. The X axis represents the combined effect of increasing time and increasing environmental harshness. As the environment gets harsher, the performance requirements become more stringent, and/or the expected lifetime or warranty replacement period gets longer, you will need to use higher performance materials to ensure that they meet the minimum performance standard over the expected life of the connector.

Figure XVIII-26 Appropriate Material Choices

Use the proper combination of base metal and plating properties to prevent failures and warranty claims

1 Ensure adequate safety factor for contact resistance
2 Minimize insertion force
3 Minimize cost




Figure XVIII-26 Appropriate Material Choices

Again, brass and phosphor bronze are perfectly acceptable for low severity environments and non-critical, easily replaced applications. As the need for reliability increases, you will need to shift to more high performance materials. For a one-piece design, conductivity and formability are critical. For a two-piece design, formability and conductivity are not as important as being able to provide high spring force.

MATERION

©2020 Materion Brush Inc.

MATERION

Appendix

Materion Product Offerings and Forms

High Strength Copper Beryllium Alloys

C17200

- **Alloy 25** is an age hardenable alloy that possesses the highest strength and hardness of any commercial copper alloy. It is available in strip, rod, bar, plate, wire and tube forms.
- **Alloy 190** is a mill hardened strip product (similar to Alloy 25). It is available in strip form only. It is cost effective because it eliminates age hardening and cleaning after stamping
- **Alloy 290** is a mill hardened strip alloy similar to Alloy 190 with improved formability.

C17300

- **Alloy M25** is a free machining version of Alloy 25 with lead added to promote formation of finely divided chips during automated screw machining processes. It is available in rod form only.

C17000

- **Alloy 165** contains less beryllium than Alloy 25 for lower strength and cost. It is available in rod, bar, wire, plate and tube forms, although it is no longer available in strip form – use Alloy 25, 190, or 290 instead.

High Conductivity Copper Beryllium Alloys

C17510

- **Alloy 3** is a moderate yield strength, 40-60% IACS alloy. It has both heat treatable and mill hardened tempers available in strip, rod, bar, plate, wire and tube forms.

C17500

- **Alloy 10** has the same properties as Alloy 3, although it uses cobalt instead of nickel as an alloying element. It is no longer available in strip form – use Alloy 3 instead.

C17410

- **Alloy 174** shows upgraded performance over phosphor bronze. It has high conductivity and stress relaxation resistance. Alloy 174 is a mill hardened strip product only.

C17460

- **Brush® 60 strip** is similar to Alloy 174 with improved formability. It is available in mill hardened strip form only.
- **Alloy 390® strip** shows an outstanding combination of strength and conductivity (135 – 153 ksi, 930 – 1060 MPa yield strength @ 45% IACS conductivity). It is available in mill hardened strip form only.

Alloy 390E

- **Alloy 390E** shows an outstanding combination of strength and conductivity (135 – 153 ksi, 930 – 1060 MPa yield strength @ 45% IACS conductivity). It is available in mill hardened strip form only.

Other Copper Alloys

C19150

- **Brush 1915 rod** is a cold-headable, free-machining leaded nickel copper alloy, available in rod form only.

C19160

- **Alloy C19160** is a free-machining leaded nickel copper alloy, available in rod form only.

C72900

- **ToughMet® 3 alloy** is a copper-nickel-tin alloy with strength and hardness approaching that of Alloy 25. ToughMet® 3 alloy is available in rod, bar, plate and tube form. All forms are available as mill hardened.
- **BrushForm® 158 strip** is a copper-nickel-tin strip alloy with strength and hardness comparable to Alloy 25. It is available in both age hardenable and mill hardened form.

C72700

- **BrushForm® 96 strip** is another spinodally hardened copper nickel tin strip alloy available in age hardenable or mill hardened form. It has higher conductivity than the BrushForm® 158 strip at slightly lower strength levels.

Nickel Beryllium

N03360

- **Alloy 360** contains approximately 2% beryllium and like copper beryllium alloys, it is age hardenable. Nickel beryllium alloys are magnetic. Alloy 360 is available in strip form.

Availability

Materion maintains a worldwide network of service centers, independent distributors and authorized agents. People in this network can answer your inquiry, process your order and assist with your special requirements. These resources maintain stocks of copper beryllium alloy products in a wide range of alloys, tempers and sizes to expedite your orders. They also provide precision slitting, sawing, tension leveling, traverse winding and other custom services to meet your exacting requirements.

Strip: Materion's strip products are available in gauges as thin as 0.00098 inch (0.025 mm), with widths from 0.050 to 18 inches (1.27 to 457.2mm). In instances where reduced gauges are necessary, Materion will provide assistance in locating suitable suppliers. While Materion's strip product is typically shipped in flat coil, it is also available on traverse wound reels up to 1000 pounds (454 Kg). Thinner gauges may be available from rerollers.

Wire: Materion's wire product is available in round, square and rectangular forms in gauges ranging from 0.050 to 0.250 inches (1.27 to 6.35mm). Thinner diameters are available from redrawers. Please contact Materion for availability.

Rod: Materion's rod product is readily available in 12 feet (3.66m) maximum straight lengths with diameters 0.050 inches (1.27 mm) and greater. Custom lengths are available on request.

Tube, Bar and Plate: Materion Performance Alloys manufactures its copper beryllium products in tube, bar and plate forms. You should address questions regarding specific availability to Materion's Sales Engineering Department.

MATERION

©2020 Materion Brush Inc.

Materion Process Capabilities and Product Offerings

Process Capabilities

Electroplating Materion's reel-to-reel electroplating technology enables thin layers of metals to be deposited onto coils of base metals or onto pre-stamped parts. As one of Technical Materials' core hybrid material technologies, we have nearly 30 years of experience offering high quality electroplated materials. As with all of our materials, electroplating may also be combined with our other process technologies (including cladding and electron beam welding) to create unique material systems.

Technical Materials routinely processes a wide range of electroplated materials:

- Hard Gold
- Soft Gold
- Palladium
- Silver
- Nickel
- Tin (Matte & Bright)
- Tin/Lead (Matte & Bright)
- Copper

Each of these materials may be combined with others as layers or in separate locations on the substrate. Our process experts will evaluate your requirements and discuss with you the best process for your application.

Materion's electroplating capability combines dissimilar metals together with precision locations to deposit them only where they are needed. This process is customized to meet your specific requirements.

- Overall Plating
- Controlled Depth
- Precision Masking
- Tooled Selective Strip
- Selective Spot

For fast turn-around of tooled mask applications, our in-house tool room guarantees high quality equipment without the long wait.

Cladding

- **Overlay Cladding** Solid state diffusion cladding of full-width layers creates true metallurgical bonding between alloy layers. Materion clads over 200 ductile alloys in a wide range of sizes. Layer thicknesses range from 1 mm on 1 mm (50%) clads to 0.5 micron layers on one or both sides. Multiple layers are also possible. This includes multiple alloys and up to as many as 2000 layers in our proprietary "Microlaminate" bonding.
- **Inlay Cladding** Using the same clad metal technology as with overlays, Materion can also produce inlay stripes with various alloys. Inlays are bonded into profiled substrates. This creates stripes as thin as 1% or as thick as 55% of the total substrate thickness. Multiple stripes can be located across the width of both the top and bottom surfaces. Often stripes are composed of multiple alloy layers for functionality. Examples of this approach are seen in high-temperature electronic connectors where a stripe is capped with 0.25 micron Au on 2 microns of PdAg on top of a 4 micron Nickel diffusion barrier. This is then inlaid into a Copper alloy substrate. Clad metal inlays offer design options for reducing total cost when using expensive alloys.
- **Dovetail Clad® Strip** COPPER ALUMINUM DOVETAIL CLAD® strip is a breakthrough technology for joining copper and aluminum side-by-side in long continuous master coils. These coils can easily be stamped and formed to create busbars or lead tabs, enabling high-volume, low-cost laser assembly especially fitted to automotive format lithium-ion battery packs. Based on nearly 50 years of expertise in cladding aluminum to copper for high-reliability automotive lead frame applications, Materion has taken their state-of-the-art metal cladding technology to a new level to meet the challenges facing every lithium-ion battery cell and pack designer: how to join copper and aluminum in your battery pack.
  - Superior mechanical, electrical, & thermal performance over ultrasonic or bolted attachments.
  - No resistance or thermal rise at dovetail joint
  - Narrow joint widths (< 5mm)
  - Overall thickness range from 0.1mm to 2.0mm
  - Overall widths up to 165mm

  Materion's cladding process achieves an excellent metallurgical bond by combining extreme reductions in cross-sectional area and thermal diffusion to create a controlled formation of a "thin" intermetallic compound resulting in a robust copper-aluminum dovetail joint which matches the strength and fatigue toughness of the aluminum alloy.

Solder Coating Materion offers three separate technologies for continuous solder coating of strip metals. Print-on and thermal reflow technologies provide all solder alloy compositions in selective locations on copper alloy substrates. These solders can be deposited in thicknesses up to 0.5 mm thicknesses. Thinner depositions of Sn and SnPb can be continuously electroplated on strip as well. A wide variety of solder alloys can also be clad or inlaid to create otherwise impossible combinations and geometries of solder and substrates.

Electron Beam Welding (EBW) is a robust and cost effective technique for joining dissimilar materials. The continuous strip welding process allows materials of dissimilar alloys, tempers, and thicknesses to be joined side by side, providing performance not available in a single material. Additionally, Electron Beam Welding can be combined with Materion' other metals processing expertise such as inlay and overlay cladding, rolling, solder coating, or electroplating to produce novel, high-performing constructs.

- Capabilities: Thicknesses from 0.075mm to 3.0mm and widths up to 210mm.

Contour Profiling Grinding, milling, and fixed tool skiving of continuous metal strip are core technologies at Materion. These capabilities are often combined with other processes at Materion to enable new radically different combinations of shapes and alloys. All profile combinations of solid alloy and composites are processed in continuous lengths for subsequent stamping and forming into complex parts.

Special Processing

- **Stretch Bend Levelling** To provide the flattest stress-free strip and best shape tolerances in the industry, Materion offers specialty processing of strip metals through unique Stretch Bend Leveling equipment. This capability removes residual stresses and produces exceptionally flat tolerances, even with high strength composites or specialty alloys. We offer gauge charts with SPC data for each coil processed. Size Ranges:
  - 0.003" - 0.032" (0.076 mm – 0.813 mm) thick: 7.8" (19.8 cm) width maximum
  - 0.032" - 0.090" (0.813 mm – 2.286 mm) thick: 5.0" (12.7 cm) width maximum
- **Specialty Precision Rolling** with extraordinary gauge tolerancing -- Do you think .012" thick Stainless Steel rolled to a standard deviation of .000044" is impossible? Not for us. This is a commercial product made every day at Materion. Specialty rolling services are available on a toll basis with customers' strip alloys. Our precision mills are capable of producing gauge tolerances far beyond standard mill tolerances. This unique capability, along with our atmospherically-controlled strip furnaces, offers performance advantages in many demanding, high-reliability applications.

©2020 Materion Brush Inc.

- **Customized Tempers**

Base Metals Available

Copper and High Copper Alloys

- **C10200** (Oxygen Free High Conductivity OFHC Copper)
- **C10700** (Oxygen Free with Silver OFS Copper)
- **C11000** (Electrolytic Tough Pitch ETP Copper)
- **C12200** (Phosphorous Deoxidized, High Residual Phosphorous DHP Copper)
- **C14415**
- **C14530** (Tellurium Bearing Copper)
- **C15100** (ZHC Copper)
- **C15500**
- **C18080** (K88)
- **C19025** (NB109)
- **C19210** (XP10)
- **C19400** (Copper Iron)
- **C19500**
- **C19700**

Copper Beryllium

- **C17200** (Alloy 25)
- **C17410** (Alloy 174)
- **C17460** (Brush 60)
- **C17510** (Alloy 3)

Brass

- **C21000** (Gilding Metal)
- **C22000** (Commercial Bronze)
- **C23000** (Red Brass)
- **C24000** (Low Brass)
- **C26000** (Cartridge Brass)
- **C26800** (Yellow Brass)
- **C42200**
- **C42500**
- **C42520** (Olin Alloy 4252)

Bronze

- **C51000** (Phosphor Bronze A)
- **C51100**
- **C51180** (Modified Phosphor Bronze)
- **C51900**
- **C52100** (Phosphor Bronze C)
- **C52180** (Modified Phosphor Bronze)
- **C50725**
- **C63800** (Olin Alloy 638)
- **C65500** (Silicon Bronze A)
- **C66300**
- **C68800** (Olin Alloy 688)

Copper Nickel

- **C70250** (Corson Bronze)
- **C70260** (Corson Bronze)
- **C70600** (Cupronickel)
- **C71500** (Cupronickel)
- **C72500** (Copper Nickel)
- **C72900** (BrushForm® 158 strip)
- **C73500** (Nickel Silver)
- **C75200** (Nickel Silver)
- **C76200** (Nickel Silver)
- **C77000** (Nickel Silver)

Steel and Iron

- **S30100** (301 Stainless)
- **S30200** (302 Stainless)
- **S30403** (304L Stainless)
- **S30500** (305 Stainless)
- **S31008** (310S Stainless)
- **S31600** (316 Stainless)
- **S32100** (321 Stainless)
- **S40900** (409 Stainless)
- **S43000** (430 Stainless)
- **G10080** (AISI 1008 Low Carbon Steel)
- **K00100** (Iron)

Aluminum

- **A91100** (Aluminum 1100)
- **A91145** (Aluminum 1145)
- **A93003** (Aluminum 3003)
- **A95052** (Aluminum 5052)
- **A96061**(Aluminum 6061)

Refractory Metals

- **R04200** (Reactor Grade Niobium)
- **R05200** (Tantalum)
- **R50250** (Titanium)
- **R60702** (Zirconium)

Low Expansion Alloys

- **K93600** (Invar 36)
- **K94100** (Alloy 42)
- **K 94610** (Kovar)

Zinc

- **Z13004**
- **Z41321**

An Innovator with Broad Experience

For more than 40 years, Materion has been a leader in creating innovative materials solutions for customers going to market with next-generation telecom, solar, automotive electronics and other high-tech products. We collaborate with our customers to create specialty metal systems that help scientists and product engineers solve complex design challenges. With an extensive staff of metallurgists, over 100 work centers and six core processing technologies under one roof, Materion is the leading global resource for composite metal solutions.

Custom Metal Systems

Rarely does a single alloy offer the range of diverse properties required by today's sophisticated electronic and electrical applications. Our clad metal process, electron beam welding, electroplating and related technologies offer designers the flexibility to meet today's performance challenges. Metal cladding, the process of joining dissimilar metals by applying high pressure without brazing alloys or adhesives, creates a system custom-engineered to the application. Because of our experience with virtually every base metal and cladding combination, we are able to help our customers optimize surface and core metal characteristics.

The Experience and the Technology

Materion creates innovative metals systems that enable new performance levels in a wide variety of high-technology devices. Whether the challenge is thermal, electrical or mechanical, we have the expertise to design creative new material combinations and one-of-a-kind technologies to bring those designs to market. We continue to reinvest in our process capabilities and can now claim the widest array of technologies available under one roof in any single-metal fabrication facility: the most precision mills, the tightest tolerances and the broadest array of custom-built process equipment. We have not only improved upon existing methods to help reduce cost and assure reliable performance of many sophisticated end-products, we are pioneering new techniques in composite metal production to expand design options and create previously unattainable metal combinations.

Unmatched Flexibility and Agility

At Technical Materials we don't have a catalog of products; we create innovative custom solutions for global market leaders. We design materials, fabricate prototypes and get samples into your hands quickly with the primary focus always being quality and performance. We also provide gold reclamation services, as well as global sales and technical support, drawing on the extensive advanced materials expertise of the worldwide Materion organization. Our product solutions can be found in a broad variety of technology-driven industries – including automotive electronics, medical, alternative energy and consumer electronics – and we continue to expand into new emerging markets.

MATERION

©2020 Materion Brush Inc.

Standard Rectangular Cross Section Cantilever Beam Equation Transforms		
Given	**Find**	**Equations**
DPL	WT	$W = \frac{6\,LP}{T^{2}\,S}$ $T = \frac{2\,SL^{2}}{3\,DE}$
WLP	DT	$D = \frac{4\,PL^{3}}{WET^{3}}$ $T = 2\sqrt{\frac{3\,LP}{2\,WS}}$
WTL	DP	$D = \frac{4\,PL^{3}}{WET^{3}}$ $P = \frac{WST^{2}}{6\,L}$
WDL	TP	$T = \frac{2\,SL^{2}}{3\,DE}$ $P = \frac{WST^{2}}{6\,L}$
WTP	LD	$L = \frac{WST^{2}}{6\,P}$ $D = \frac{4\,PL^{3}}{WET^{3}}$
WDT	LP	$L = \sqrt{\frac{3\,DET}{2\,S}}$ $P = \frac{WDET^{3}}{4\,L^{3}}$
DWP	TL	$T = \frac{3}{S}\sqrt[3]{\frac{2\,DEP^{2}}{W^{2}}}$ $L = \frac{WST^{2}}{6\,P}$
DTP	LW	$L = \sqrt{\frac{3\,DET}{2\,S}}$ $W = \frac{4\,PL^{3}}{DET^{3}}$
TLP	WD	$W = \frac{6\,LP}{ST^{2}}$ $D = \frac{4\,PL^{3}}{WET^{3}}$












Where

E = Modulus of Elasticity
T = Beam Thickness
W = Beam Width
L = Beam Length
D = Deflection
P = Load (Normal Force)
S = Stress (Maximum Surface)

Knowing any three variables and S, these equations can calculate the remaining two variables. For the value of S (stress), use the maximum allowable stress with the required safety factor against fatigue failure or plastic deformation, whichever is the most important failure mechanism in your design.

MATERION

Cantilever Beam Equations

Beam Type	Beam Sketch	Moment of Inertia	Maximum Distance from Neutral Axis	Force (Deflection)	Maximum Stress (Force)	Maximum Stress (Deflection)
Generic Cantilever Beam		I	y_{max}	$F = \frac{3 \cdot E \cdot I}{L^3} \cdot d$	$\sigma_{max} = \frac{3 \cdot E \cdot d}{L^2} \cdot y_{max}$	$\sigma_{max} = \frac{3 \cdot E \cdot d}{L^2} \cdot y_{max}$
Straight Beam, Rectangular Cross Section		$I = \frac{w \cdot t^3}{12}$	$y_{max} = \frac{t}{2}$	$F = \frac{E \cdot w \cdot t^3}{4 \cdot L^3} \cdot d$	$\sigma_{max} = \frac{3 \cdot E \cdot t}{2 \cdot L^2} \cdot d$	$\sigma_{max} = \frac{3 \cdot E \cdot t}{2 \cdot L^2} \cdot d$
Straight Beam, Round Cross Section		$I = \frac{\pi \cdot r^4}{4}$	$y_{max} = r$	$F = \frac{3 \cdot \pi \cdot E \cdot r^4}{4 \cdot L^3} \cdot d$	$\sigma_{max} = \frac{3 \cdot E \cdot r}{L^2} \cdot d$	$\sigma_{max} = \frac{3 \cdot E \cdot r}{L^2} \cdot d$
Curved Cantilever Beam, Rectangular Cross Section, Bend Angle Less than 90 Degrees		$I = \frac{w \cdot t^3}{12}$	$y_{max} = \frac{t}{2}$	$F = \frac{E \cdot w \cdot t^3}{12 \cdot R^3 \cdot [NDT_1]} \cdot d$	$\sigma_{max} = \frac{E \cdot t \cdot (L + R \cdot \sin\theta)}{2 \cdot R^3 \cdot [NDT_1]} \cdot d$	$\sigma_{max} = \frac{E \cdot t \cdot (L + R \cdot \sin\theta)}{2 \cdot R^3 \cdot [NDT_1]} \cdot d$
Curved Cantilever Beam, Rectangular Cross Section, Bend Angle Between 90 and 180 Degrees		$I = \frac{w \cdot t^3}{12}$	$y_{max} = \frac{t}{2}$	$F = \frac{E \cdot w \cdot t^3}{12 \cdot R^3 \cdot [NDT_1]} \cdot d$	$\sigma_{max} = \frac{E \cdot t \cdot (L + R)}{2 \cdot R^3 \cdot [NDT_1]} \cdot d$	$\sigma_{max} = \frac{E \cdot t \cdot (L + R)}{2 \cdot R^3 \cdot [NDT_1]} \cdot d$
Curved Cantilever Beam, Round Cross Section, Bend Angle Less than 90 Degrees		$I = \frac{\pi \cdot r^4}{4}$	$y_{max} = r$	$F = \frac{\pi \cdot E \cdot r^4}{4 \cdot R^3 \cdot [NDT_1]} \cdot d$	$\sigma_{max} = \frac{E \cdot r \cdot (L + R \cdot \sin\theta)}{R^3 \cdot [NDT_1]} \cdot d$	$\sigma_{max} = \frac{E \cdot r \cdot (L + R \cdot \sin\theta)}{R^3 \cdot [NDT_1]} \cdot d$
Curved Cantilever Beam, Round Cross Section, Bend Angle Between 90 and 180 Degrees		$I = \frac{\pi \cdot r^4}{4}$	$y_{max} = r$	$F = \frac{\pi \cdot E \cdot r^4}{4 \cdot R^3 \cdot [NDT_1]} \cdot d$	$\sigma_{max} = \frac{E \cdot r \cdot (L + R)}{R^3 \cdot [NDT_1]} \cdot d$	$\sigma_{max} = \frac{E \cdot r \cdot (L + R)}{R^3 \cdot [NDT_1]} \cdot d$
Curved Cantilever Beam, Rectangular Cross Section, 180 Degree Bend Angle, Load Applied before Fixed End		$I = \frac{w \cdot t^3}{12}$	$y_{max} = \frac{t}{2}$	$F = \frac{E \cdot w \cdot t^3}{12 \cdot R^3 \cdot [NDT_2]} \cdot d$	$\sigma_{max} = \frac{E \cdot t \cdot (L_2 - L_1)}{2 \cdot R^3 \cdot [NDT_2]} \cdot d$	$\sigma_{max} = \frac{E \cdot t \cdot (L_2 - L_1)}{2 \cdot R^3 \cdot [NDT_2]} \cdot d$
Curved Cantilever Beam, Rectangular Cross Section, 180 Degree Bend Angle, Load Applied beyond Fixed End		$I = \frac{w \cdot t^3}{12}$	$y_{max} = \frac{t}{2}$	$F = \frac{E \cdot w \cdot t^3}{12 \cdot R^3 \cdot [NDT_2]} \cdot d$	$\sigma_{max} = \frac{E \cdot t \cdot (L_1 + R)}{2 \cdot R^3 \cdot [NDT_2]} \cdot d$	$\sigma_{max} = \frac{E \cdot t \cdot (L_1 + R)}{2 \cdot R^3 \cdot [NDT_2]} \cdot d$
Curved Cantilever Beam, Round Cross Section, 180 Degree Bend Angle, Load Applied before Fixed End		$I = \frac{\pi \cdot r^4}{4}$	$y_{max} = r$	$F = \frac{\pi \cdot E \cdot r^4}{4 \cdot R^3 \cdot [NDT_2]} \cdot d$	$\sigma_{max} = \frac{E \cdot r \cdot (L_2 - L_1)}{R^3 \cdot [NDT_2]} \cdot d$	$\sigma_{max} = \frac{E \cdot r \cdot (L_2 - L_1)}{R^3 \cdot [NDT_2]} \cdot d$
Curved Cantilever Beam, Round Cross Section, 180 Degree Bend Angle, Load Applied beyond Fixed End		$I = \frac{\pi \cdot r^4}{4}$	$y_{max} = r$	$F = \frac{\pi \cdot E \cdot r^4}{4 \cdot R^3 \cdot [NDT_2]} \cdot d$	$\sigma_{max} = \frac{E \cdot r \cdot (L_1 + R)}{R^3 \cdot [NDT_2]} \cdot d$	$\sigma_{max} = \frac{E \cdot r \cdot (L_1 + R)}{R^3 \cdot [NDT_2]} \cdot d$
Straight Cantilever Beam, Curved Cross Section, Outer Surface		$y_O = R \cdot \left[1 - 2 \cdot \frac{\sin\alpha}{3 \cdot \alpha} \cdot \left(1 - \frac{t}{R} + \frac{1}{2 - t/R}\right)\right]$		$F = \frac{3 \cdot E \cdot I}{L^3} \cdot d$	$\sigma_{max_O} = \frac{3 \cdot E \cdot y_O}{L^2} \cdot d$	$\sigma_{max_O} = \frac{3 \cdot E \cdot y_O}{L^2} \cdot d$
Straight Cantilever Beam, Curved Cross Section, Inner Surface		$y_I = -R \cdot \left[\frac{2\sin\alpha}{3\alpha\left(2 - t/R\right)} + \left(1 - \frac{t}{R}\right)\left(\frac{2\sin\alpha - 3\alpha \cdot \cos\alpha}{3\alpha}\right)\right]$			$\sigma_{max_I} = \frac{3 \cdot E \cdot y_I}{L^2} \cdot d$	$\sigma_{max_I} = \frac{3 \cdot E \cdot y_I}{L^2} \cdot d$
Multifingered Cantilever Beam, Base of Fingers, Rectangular Cross Section		$I = \frac{w_F \cdot t^3}{12}$	$y_{max} = \frac{t}{2}$	$F = \frac{E \cdot t^3}{4 \cdot L_1^3 \cdot [NDT_3]} \cdot d$	$\sigma_{max_{Fingers}} = \frac{3 \cdot E \cdot t}{2 \cdot L_1^2 \cdot w \cdot [NDT_3]} \cdot d$	$\sigma_{max_{Fingers}} = \frac{3 \cdot E \cdot t}{2 \cdot L_1^2 \cdot w \cdot [NDT_3]} \cdot d$
Multifingered Cantilever Beam, Fixed End, Rectangular Cross Section		$I = \frac{w_B \cdot t^3}{12}$	$y_{max} = \frac{t}{2}$	$F = \frac{E \cdot t^3}{4 \cdot L_1^3 \cdot [NDT_3]} \cdot d$	$\sigma_{max_{Base}} = \frac{3 \cdot E \cdot t \cdot (L_1 + L_2)}{2 \cdot L_1^3 \cdot w \cdot [NDT_3]} \cdot d$	$\sigma_{max_{Base}} = \frac{3 \cdot E \cdot t \cdot (L_1 + L_2)}{2 \cdot L_1^3 \cdot w \cdot [NDT_3]} \cdot d$
Tapered Cantilever Beam, Taper Less than 50% of the Deflection		$I = \frac{w \cdot t^3}{12}$	$y_{max} = \frac{t}{2}$	$F = \frac{E \cdot w_B \cdot t^3}{4 \cdot L^3 \cdot [NDT_4]} \cdot d$	$\sigma_{max} = \frac{3 \cdot E \cdot t}{2 \cdot L^2 \cdot [NDT_4]} \cdot d$	$\sigma_{max} = \frac{3 \cdot E \cdot t}{2 \cdot L^2 \cdot [NDT_4]} \cdot d$
Tapered Cantilever Beam, Taper Greater than 50% of the Deflection		$I = \frac{w \cdot t^3}{12}$	$y_{max} = \frac{t}{2}$	$F = \frac{E \cdot w_B \cdot t^3}{4 \cdot L^3 \cdot [NDT_5]} \cdot d$	$\sigma_{max} = \frac{3 \cdot E \cdot t}{2 \cdot L^2 \cdot [NDT_5]} \cdot d$	$\sigma_{max} = \frac{3 \cdot E \cdot t}{2 \cdot L^2 \cdot [NDT_5]} \cdot d$

MATERION

©2020 Materion Brush Inc.

	Maximum Deflection (Yield Strength)	Maximum Force (Yield Strength)	Maximum Strain Energy	Extra Non-Dimensional Terms
	$d_{yield} = \frac{L^2}{3 \cdot E \cdot y_{max}} \cdot \sigma_{yield}$	$F_{yield} = \frac{I}{L \cdot y_{max}} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{I \cdot L}{y_{max}^2} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	—
	$d_{yield} = \frac{2 \cdot L^2}{3 \cdot E \cdot t} \cdot \sigma_{yield}$	$F_{yield} = \frac{w \cdot t^2}{6 \cdot L} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{w \cdot t \cdot L}{3} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	—
	$d_{yield} = \frac{L^2}{3 \cdot E \cdot r} \cdot \sigma_{yield}$	$F_{yield} = \frac{\pi \cdot r^3}{4 \cdot L} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{\pi \cdot r^2 \cdot L}{4} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	—
	$d_{yield} = \frac{2 \cdot R^3 \cdot [NDT_1]}{E \cdot t \cdot (L + R \cdot \sin\theta)} \cdot \sigma_{yield}$	$F_{yield} = \frac{w \cdot t^2}{6 \cdot (L + R \cdot \sin\theta)} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{R^3 \cdot w \cdot t \cdot [NDT_1]}{(L + R \cdot \sin\theta)^2} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$[NDT_1] = \left[\frac{1}{3} \cdot \left(\frac{L}{R}\right)^3 + \left(\frac{L}{R}\right)^2 \cdot \left(\theta \cdot \frac{\pi}{180}\right) + 2 \cdot \left(\frac{L}{R}\right) \cdot (1 - \cos\theta) + \left(\frac{\theta}{2} \cdot \frac{\pi}{180}\right) - \frac{\sin 2\theta}{4}\right]$
	$d_{yield} = \frac{2 \cdot R^3 \cdot [NDT_1]}{E \cdot t \cdot (L + R)} \cdot \sigma_{yield}$	$F_{yield} = \frac{w \cdot t^2}{6 \cdot (L + R)} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{R^3 \cdot w \cdot t \cdot [NDT_1]}{(L + R)^2} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$[NDT_1] = \left[\frac{1}{3} \cdot \left(\frac{L}{R}\right)^3 + \left(\frac{L}{R}\right)^2 \cdot \left(\theta \cdot \frac{\pi}{180}\right) + 2 \cdot \left(\frac{L}{R}\right) \cdot (1 - \cos\theta) + \left(\frac{\theta}{2} \cdot \frac{\pi}{180}\right) - \frac{\sin 2\theta}{4}\right]$
	$d_{yield} = \frac{R^3 \cdot [NDT_1]}{E \cdot r \cdot (L + R \cdot \sin\theta)} \cdot \sigma_{yield}$	$F_{yield} = \frac{\pi \cdot r^3}{4 \cdot (L + R \cdot \sin\theta)} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{R^3 \cdot \pi \cdot r^2 \cdot [NDT_1]}{4 \cdot (L + R \cdot \sin\theta)^2} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$[NDT_1] = \left[\frac{1}{3} \cdot \left(\frac{L}{R}\right)^3 + \left(\frac{L}{R}\right)^2 \cdot \left(\theta \cdot \frac{\pi}{180}\right) + 2 \cdot \left(\frac{L}{R}\right) \cdot (1 - \cos\theta) + \left(\frac{\theta}{2} \cdot \frac{\pi}{180}\right) - \frac{\sin 2\theta}{4}\right]$
	$d_{yield} = \frac{R^3 \cdot [NDT_1]}{E \cdot r \cdot (L + R)} \cdot \sigma_{yield}$	$F_{yield} = \frac{\pi \cdot r^3}{4 \cdot (L + R)} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{R^3 \cdot \pi \cdot r^2 \cdot [NDT_1]}{4 \cdot (L + R)^2} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$[NDT_1] = \left[\frac{1}{3} \cdot \left(\frac{L}{R}\right)^3 + \left(\frac{L}{R}\right)^2 \cdot \left(\theta \cdot \frac{\pi}{180}\right) + 2 \cdot \left(\frac{L}{R}\right) \cdot (1 - \cos\theta) + \left(\frac{\theta}{2} \cdot \frac{\pi}{180}\right) - \frac{\sin 2\theta}{4}\right]$
	$d_{yield} = \frac{2 \cdot R^3 \cdot [NDT_2]}{E \cdot t \cdot (L_2 - L_1)} \cdot \sigma_{yield}$	$F_{yield} = \frac{w \cdot t^2}{6 \cdot (L_2 - L_1)} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{w \cdot t \cdot R^3 \cdot [NDT_2]}{(L_2 - L_1)^2} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$[NDT_2] = \left[\frac{1}{3} \cdot \left(\frac{L_1}{R}\right)^3 + \frac{1}{3} \cdot \left(\frac{L_2}{R}\right)^3 + \left(\frac{L_1}{R}\right)^2 \cdot \left(\frac{L_2}{R} + \pi\right) + \left(\frac{L_1}{R}\right) \cdot \left(4 - \left(\frac{L_2}{R}\right)^2\right) + \frac{\pi}{2}\right]$
	$d_{yield} = \frac{2 \cdot R^3 \cdot [NDT_2]}{E \cdot t \cdot (L_1 + R)} \cdot \sigma_{yield}$	$F_{yield} = \frac{w \cdot t^2}{6 \cdot (L_1 + R)} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{w \cdot t \cdot R^3 \cdot [NDT_2]}{(L_1 + R)^2} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$[NDT_2] = \left[\frac{1}{3} \cdot \left(\frac{L_1}{R}\right)^3 + \frac{1}{3} \cdot \left(\frac{L_2}{R}\right)^3 + \left(\frac{L_1}{R}\right)^2 \cdot \left(\frac{L_2}{R} + \pi\right) + \left(\frac{L_1}{R}\right) \cdot \left(4 - \left(\frac{L_2}{R}\right)^2\right) + \frac{\pi}{2}\right]$
	$d_{yield} = \frac{R^3 \cdot [NDT_2]}{E \cdot r \cdot (L_2 - L_1)} \cdot \sigma_{yield}$	$F_{yield} = \frac{\pi \cdot r^3}{4 \cdot (L_2 - L_1)} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{3 \cdot \pi \cdot r^2 \cdot R^3 \cdot [NDT_2]}{4 \cdot (L_2 - L_1)^2} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$[NDT_2] = \left[\frac{1}{3} \cdot \left(\frac{L_1}{R}\right)^3 + \frac{1}{3} \cdot \left(\frac{L_2}{R}\right)^3 + \left(\frac{L_1}{R}\right)^2 \cdot \left(\frac{L_2}{R} + \pi\right) + \left(\frac{L_1}{R}\right) \cdot \left(4 - \left(\frac{L_2}{R}\right)^2\right) + \frac{\pi}{2}\right]$
	$d_{yield} = \frac{R^3 \cdot [NDT_2]}{E \cdot r \cdot (L_1 + R)} \cdot \sigma_{yield}$	$F_{yield} = \frac{\pi \cdot r^3}{4 \cdot (L_1 + R)} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{3 \cdot \pi \cdot r^2 \cdot R^3 \cdot [NDT_2]}{4 \cdot (L_1 + R)^2} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$[NDT_2] = \left[\frac{1}{3} \cdot \left(\frac{L_1}{R}\right)^3 + \frac{1}{3} \cdot \left(\frac{L_2}{R}\right)^3 + \left(\frac{L_1}{R}\right)^2 \cdot \left(\frac{L_2}{R} + \pi\right) + \left(\frac{L_1}{R}\right) \cdot \left(4 - \left(\frac{L_2}{R}\right)^2\right) + \frac{\pi}{2}\right]$
	$d_{yield} = \frac{L^2}{3 \cdot E \cdot y_O} \cdot \sigma_{yield}$	$F_{yield} = \frac{I}{L \cdot y_O} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{I \cdot L}{y_O^2} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$I = \left[\left(1 - 3 \cdot \frac{t}{2 \cdot R} + \frac{t^2}{R^2} - \frac{t^3}{4 \cdot R^3}\right) \cdot \left(\alpha + \sin\alpha \cdot \cos\alpha - 2 \cdot \frac{\sin^2\alpha}{\alpha}\right) + t^2 \cdot \frac{\sin^2\alpha}{3 \cdot R^2 \cdot \alpha \cdot \left(2 - t/R\right)} \cdot \left(1 - \frac{t}{R} + \frac{t^2}{6 \cdot R^2}\right)\right]$
	$d_{yield} = \frac{L^2}{3 \cdot E \cdot y_I} \cdot \sigma_{yield}$	$F_{yield} = \frac{I}{L \cdot y_I} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{I \cdot L}{y_I^2} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	
	$d_{yield} = \frac{2 \cdot L_1^2 \cdot w_F \cdot [NDT_3]}{3 \cdot E \cdot t} \cdot \sigma_{yield}$	$F_{yield} = \frac{w_F \cdot t^2}{6 \cdot L_1} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{w_F^2 \cdot t \cdot L_1 \cdot [NDT_3]}{3} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$[NDT_3] = \left[\frac{1}{w_F} + \frac{1}{w_B} \cdot \left[\left(\frac{L_2}{L_1}\right)^3 + 3 \cdot \left(\frac{L_2}{L_1}\right)^2 + 3 \cdot \left(\frac{L_2}{L_1}\right)\right]\right]$
	$d_{yield} = \frac{2 \cdot L_1^3 \cdot w_B \cdot [NDT_3]}{3 \cdot E \cdot t \cdot (L_1 + L_2)} \cdot \sigma_{yield}$	$F_{yield} = \frac{w_B \cdot t^2}{6 \cdot (L_1 + L_2)} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{w_B^2 \cdot t \cdot L_1^3 \cdot [NDT_3]}{3 \cdot (L_1 + L_2)^2} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$[NDT_3] = \left[\frac{1}{w_F} + \frac{1}{w_B} \cdot \left[\left(\frac{L_2}{L_1}\right)^3 + 3 \cdot \left(\frac{L_2}{L_1}\right)^2 + 3 \cdot \left(\frac{L_2}{L_1}\right)\right]\right]$
	$d_{yield} = \frac{2 \cdot L^2 \cdot [NDT_4]}{3 \cdot E \cdot t} \cdot \sigma_{yield}$	$F_{yield} = \frac{w \cdot t^2}{6 \cdot L} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{w \cdot t \cdot L \cdot [NDT_4]}{3} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$[NDT_4] = \left[\frac{15}{(1 - w_T/w_B)^2} \cdot \left(1 - 3 \cdot \frac{w_T}{w_B} - \frac{2 \cdot (w_T/w_B)^2}{1 - w_T/w_B} \cdot \ln\left(w_T/w_B\right)\right)\right]$
	$d_{yield} = \frac{2 \cdot L^2 \cdot [NDT_5]}{3 \cdot E \cdot t} \cdot \sigma_{yield}$	$F_{yield} = \frac{w \cdot t^2}{6 \cdot L} \cdot \sigma_{yield}$	$W_{yield} = \frac{2}{3} \cdot \frac{w \cdot t \cdot L \cdot [NDT_5]}{3} \cdot \frac{\sigma_{yield}^2}{2 \cdot E}$	$[NDT_5] = \left[15 \cdot \left(1 - w_T/w_B\right) + 3 \cdot \left(w_T/w_B\right)^2 \cdot \sum_{n=3}^{n=7} \frac{(1 - w_T/w_B)^n}{n}\right]$

MATERION

Conversion Factors

Quantity	To Convert from	To	Multiply By
Length, Distance	in	mm	25.4 [exact]
		mil (10^{-3} in)	1000 [exact]
		µ in (10^{-6} in)	1 x 10^{6} [exact]
		µ m (10^{-6} m, micron)	25400 [exact]
		Angstrom	2.54 x 10^{8} [exact]
	mm	in	0.0394
		mil (10^{-3} in)	39.37
		µ in (10^{-6} in)	39370
		µ m (10^{-6} m, micron)	1000 [exact]
		Angstrom	= 1.0 x 10^{7} [exact]
	mil (10^{-3} in)	in	0.001 [exact]
		mm	0.0254 [exact]
		µ in (10^{-6} in)	1000 [exact]
		µ m (10^{-6} m, micron)	25.4 [exact]
		Angstrom	2.54 x 10^{5} [exact]
	µ in (10^{-6} in)	in	1 x 10^{-6} [exact]
		mm	2.54 x 10^{-5} [exact]
		mil (10^{-3} in)	0.001 [exact]
		µ m (10^{-6} m, micron)	0.0254 [exact]
		Angstrom	254 [exact]
	µ m (10^{-6} m, micron)	in	3.937 x 10^{-5}
		mm	0.001 [exact]
		mil (10^{-3} in)	0.03937
		µ in (10-6 in)	39.37
		Angstrom	1.0 x 10^{4} [exact]
	Angstrom	in	3.937 x 10^{-9}
		mm	0.0001
		mil (10^{-3} in)	3.937 x 10^{-6}
		µ in (10^{-6} in)	0.003937
		µ m (10^{-6} m, micron)	0.0001 [exact]
Area	in^2	cm^2	6.4516
		mm^2	645.16
	mm^2	in^2	1.55 x 10^{-3}
		cm^2	0.01
	cm^2	in^2	0.155
		mm^2	100.0000
Volume	in^3	m^3	1.6387 x10^{-5}
		cm^3	16.38706
	m^3	in^3	6.102 x 10^{-4}
		cm^3	1 x 10^{6} [exact]
	cm^3	in^3	0.06102
		m^3	1 x 10^{-7} [exact]

Quantity	To Convert from	To	Multiply By (or Perform Indicated Operation)
Electrical Conductivity & Resistivity	% IACS	µ ohm-in (10^{-6} ohm-in)	= 67.878 / (%IACS)
		µ ohm-cm (10^{-6} ohm-cm)	= 172.41 / (%IACS)
		n ohm-m (10^{-9} **ohm-m**)	= 1724.1 / (%IACS)
		circular mil-ohm/ft	= 1037.1 / (%IACS)
		siemens/m	5.8108 x 10^{5}
		Amp/Volt-in	14732
		Amp/Volt-mm	580.01
	µ ohm-in (10^{-6} ohm-in)	% IACS	= 67.878 / (µ ohm-in)
		µ ohm-cm (10^{-6} ohm-cm)	2.54 [exact]
		n ohm-m (10^{-9} **ohm-m**)	25.4 [exact]
		circular mil-ohm/ft	15.2789
		siemens/m	= 3.937 x 10^{7} / (µ ohm-in)
		Amp/Volt-in	= 1 x 10^{6} / (µ ohm-in) [exact]
		Amp/Volt-mm	= 3.937 x 10^{4} / (µ ohm-in)
	µ ohm-cm (10 ohm-cm)	% IACS	= 172.41/ (µ ohm-cm)
		µ ohm-in (10^{-6} ohm-in)	0.3937
		n ohm-m (10^{-9} **ohm-m**)	10 [exact]
		circular mil-ohm/ft	6.0153
		siemens/m	= 1 x 10^{8} / (µ ohm-cm) [exact]
		Amp/Volt-in	= 2.54 x 10^{6} / (µ ohm-cm) [exact]
		Amp/Volt-mm	= 1 x 10^{5} / (µ ohm-cm) [exact]
	n ohm-m (10^{-9} **ohm-m**)	% IACS	= 1724.1 / (n ohm-m)
		µ ohm-in (10^{-6} ohm-in)	0.03937
		µ ohm-cm (10^{-6} ohm-cm)	0.1 [exact]
		circular mil-ohm/ft	0.6015
		siemens/m	= 1 x 10^{9} / (n ohm-m) [exact]
		Amp/Volt-in	= 2.54 x 10^{7} / (n ohm-m)
		Amp/Volt-mm	= 1 x 10^{6} / (n ohm-m) [exact]
	circular mil-ohm / ft	% IACS	= 1037.1 / (circular mil-ohm/ft)
		µ ohm-in (10^{-6} ohm-in)	0.06545
		µ ohm-cm (10^{-6} ohm-cm)	0.1662
		n ohm-m (10^{-9} **ohm-m**)	1.662
		siemens/m	= 6.015 x 10^{8} / (circular mil-ohm/ft)
		Amp/Volt-in	= 1.528 x 10^{7} / (circular mil-ohm/ft)
		Amp/Volt-mm	= 6.015 x 10^{5} / (circular mil-ohm/ft)
	siemens/m	% IACS	1.721 x 10^{-6}
		µ ohm-in (10^{-6} ohm-in)	= 3.937 x 10^{7} / (siemens/m)
		µ ohm-cm (10^{-6} ohm-cm)	= 1 x 10^{8} / (siemens/m) [exact]
		n ohm-m (10^{-9} **ohm-m**)	= 1 x 10^{9} / (siemens/m) [exact]
		circular mil-ohm/ft	= 6.015 x 10^{8} / (siemens/m)
		Amp/Volt-in	0.0254 [exact]
		Amp/Volt-mm	0.001 [exact]

MATERION

©2020 Materion Brush Inc.

Conversion Factors *(con't)*

Quantity	To Convert from	To	Multiply By
Force	lbf	kgf	0.4536
		N	4.4482
		g	453.5924
		oz	16 [exact]
	kgf	lbf	2.2046
		N	9.8067
		oz	35.2740
		g	1000 [exact]
	N	lbf	0.2248
		kgf	0.1020
		oz	3.5969
		g	101.9716
	g	lbf	2.2046×10^{-3}
		oz	0.03527
		kg	0.001 [exact]
		N	9.8067×10^{-3}
	oz	lbf	0.0625 [exact]
		kgf	0.02835
		N	0.2780
		g	28.3495
Stress & Pressure	ksi	MPa (N/mm²)	6.8948
		GPa (kN/mm²)	0.006895
		kg/mm²	0.7031
	MPa (N/mm²)	ksi	0.1450
		GPa (kN/mm²)	0.001 [exact]
		kg/mm²	0.1020
	GPa (kN/mm²)	ksi	0.1450
		MPa (N/mm²)	1000 [exact]
		kg/mm²	0.1020
	kg/mm²	ksi	1.4223
		GPa (kN/mm²)	0.009807
		MPa (N/mm²)	9.8067
Density	lb/in³	**kg/m³**	27679.9
		g/cm³	27.6799
	kg/m³	lb/in³	3.6127×10^{-5}
		g/cm³	0.001 [exact]
	g/cm³	lb/in³	0.03613
		kg/m³	1000 [exact]

Quantity	To Convert from	To	Multiply By (or Perform Indicated Operation)
Thermal conductivity	BTU/ft-hr-°F	**W/m-K**	1.7310
		cal/cm-sec-°C	4.1344×10^{-3}
		kcal/hr-m-°C	1.4884
		Volt-Amp/in-°F	0.0244
		Volt-Amp/mm-°C	0.00173
	W/m-K	BTU/ft-hr-°F	0.5778
		cal/cm-sec-°C	2.3885×10^{-3}
		kcal/hr-m-°C	0.8598
		Volt-Amp/in-°F	0.0141
		Volt-Amp/mm-°C	0.001 [exact]
	cal/cm-sec-°C	BTU/ft-hr-°F	241.87
		W/m-K	418.68
		kcal/hr-m-°C	360 [exact]
		Volt-Amp/in-°F	5.902
		Volt-Amp/mm-°C	0.4182
	kcal/hr-m-°C	BTU/ft-hr-°F	0.6719
		W/m-K	1.1630
		cal/cm-sec-°C	2.778×10^{-3}
		Volt-Amp/in-°F	0.01639
		Volt-Amp/mm-°C	0.001162
Specific Heat	**J/kg-K**	BTU/lb-°F	2.3886×10^{-4}
	BTU/lb-°F	**J/Kg-K**	4187
Temperature	°F	°C	$T_C = (T_F - 32) / 1.8$
		K	$T_K = T_F / 1.8 + 255.37$
		°R	$T_R = T_F + 459.67$
	°C	°F	$T_F = 1.8 \times TC + 32$
		K	$T_K = T_C + 273.15$
		°R	$T_R = 1.8 \times T_C + 491.67$
	K	°F	$T_F = 1.8 \times T_K - 459.67$
		°C	$T_C = T_K - 273.15$
		°R	$T_R = 1.8 \times T_K$
	°R	°F	$T_F = T_R - 459.67$
		°C	$T_K = T_R / 1.8 - 273.15$
		K	$T_K = T_R / 1.8$

Note: In these calculations, % IACS is considered as a whole number between 0 and 100, not as a percentage between 0% and 100%. For example, 22% IACS would be enterred in these equations as 22, not as 0.22. So to calculate, 22% IACS = 67.878 / 22 = 3.085 micro ohm inches

Proper SI base units are listed in **bold** font.

MATERION

Further Reading

Accelerated Life Testing

- Accelerated Life Testing Reference ReliaSoft Corporation
- Fundamentals of HALT/HASS Testing Keithley Instruments, Inc. 2000
- Hobbs, Gregg K. Ph.D., P.E. "HALT and HASS The Accepted Quality and Reliability Paradigm" Hobbs Engineering Corporation 19 May 2008
- Hobbs, Gregg K. Ph.D., P.E. "Reflections on HALT and HASS" Evaluation Engineering December 2005
- Life Data Analysis Reference ReliaSoft Corporation
- Mroczkowski, Dr. Robert S. “Dr Bob on Acceleration Factors and Connector Testing" Connector Supplier September 2, 2008
- Peel, Max. “Acceleration Factors: How Long do We Have to Wait" Connector Supplier July 30 2014
- weibull.com (ReliaSoft Corporation website)
- Wilkins, Dennis J. "The Bathtub Curve and Product Failure Behavior Part One - The Bathtub Curve, Infant Mortality and Burn-in" Reliasoft Corporation
- Wilkins, Dennis J. "The Bathtub Curve and Product Failure Behavior Part Two - Normal Life and Wear-Out" Reliability Hotwire December 2002

Contact & Connector Design

- AMI Doduco Data Book of Electrical Contacts AMI Doduco GmbH 2010
- Connector Tips Design Guide EE World www.connectortips.com
- Connector Types and Technologies Poised for Growth Bishop & Associates Inc. 2012
- Connectors and Interconnections Handbook Volumes 1-5, 1982 Electronic Connector Study Group, Fort Washington
- Crane, J.; Mroczkowski, R.; Jeannotte, D. “Materials Issues for Advanced Electronic and Opto-Electronic Connectors,” Journal of Materials September 1990, Volume 42, Issue 9, pp 37–39 Minerals, Metals & Materials Society
- Diller, John Spring Contact Probe Technology in Product Connector Applications 2nd Edition Synergetix
- Garver, Bill "Connector Basics: Evolving Levels of Interconnection" Connector Supplier January 6, 2014
- Garver, Bill "Connector Design Checklist" 2015 Connector and Cable Assembly Supplier
- Holm, R. Electric Contacts, 4th edition, 1967 Springe-Verlag, New York
- Horn, Jochen "Shape Optimization of Connector Contacts for Reduced Wear and Reduced Insertion Force" AMP Journal of Technology Vol. 2 November, 1992
- Hult, Bob "The Connector Selection Process: Making the Right Choice" Connector Supplier April 3, 2012
- Kanai, Tsuneo; Ando, Yauhiro and Inagaki, Shuichiro "Design of a Compliant Press-Fit Connection" Proceedings of the 29th IEEE Holm Conference on Electrical Contacts IEEE 1983
- Lee Spring Engineering Guide 2004 Lee Spring
- Mancini, Hank. "Preventing Failure in Medical Cable Assemblies" 2013 Connector Supplier connector-supplier.com/strain-relief -design-for-medical-connectors-090313
- Mroczkowski, R. Electronic Connector Handbook, 1998 McGraw-Hill
- Pitney, Kenneth E. Ney Contact Manual, 1973 The JM Ney Company
- Reynolds, Ed & Locati, Ron. "The Importance of Contact/Housing Retention" 2015 Connector and Cable Assembly Supplier
- RF Connector Guide 4th edition Huber + Suhner, AG 2007
- Slade, P. Electrical Contacts: Principles and Applications, 1999 Marcel Dekker, Inc.
- The Connector and Cable Specifier Guide Connector and Cable Assembly Supplier 2016
- Timsit, Dr. Roland "Fundamental Properties of Electrical Contacts" Tutorial Presentation BiTS Workshop 2006

Cost Estimation

- Palesko, Amy “Using cost modeling to make better design decisions” Chip Scale Review September-October 2015 pp 37-40
- Reynolds, Ed. “What Do Connectors Really Cost?” Connector and Cable Assembly Supplier 5/5/2014

Design and Analysis

- Carlson, Harold Spring Designer's Handbook Marcel Dekker, Inc. 1978
- Hibbeler, R. C. Engineering Mechanics - Statics Sixth Edition Macmillan Publishing Company 1992
- Hibbeler, R. C. Mechanics of Materials Macmillan Publishing Company 1991
- James, M. L. et al. Vibration of Mechanical and Structural Systems Second Edition 1994 Harper Collins College Publishers
- Kinsler, Lawrence E. et al. Fundamentals of Acoustics Third Edition John Wiley & Sons 1982
- MacNeal, Finite Elements: Their Design and Performance, 1983 Marcel Dekker, Inc.
- Seraphin, D.; Lasky,R.; Li,C.Y. Principles of Electronic Packaging, 1989 McGraw Hill
- Young, W. Roark’s Formulas for Stress & Strain, 6th edition, 1989 McGraw Hill

Electromagnetic Compatibility and Signal Integrity

- "Anatomy of an Eye Diagram" Tekronix Application Note 2010 Tektronix
- "Fundamentals of Signal Integrity" 2008 Tektronix
- "Passive Intermodulation (PIM) Tech Note" 2013 W. L. Gore & Associates, Inc.
- "The 10 Basic Steps for Successful EMC Design" Washington Laboratories Ltd.
- "Understanding and Minimizing Ground Bounce" Fairchild Semiconductor Application Note 2003 Fairchild Semiconductor Corporation
- "Understanding Jitter Calculations: Why Dj Can Be Less Than DDj (or Pj)" 2014 Teledyne Lecroy
- Bogatin, Eric. Signal and Power Integrity – Simplified, 2010, Prentice Hall.
- Breed, Gary "Analyzing Signals Using the Eye Diagram" High Frequency Electronics November 2005 pp 50-54
- Brewer, Ron "Seam Aperture Leakage in Aerospace Enclosures" Evaluation Engineering March 1, 2009 pp 64-70
- Carlson, Bruce "RF/Microwave Connector Design for Low Intermodulation Generation" Interconnection Technology July 1993.
- Engineering Design and Shielding Product Selection Guide, 1999 Instrument Specialties Corporation Delaware Water Gap, PA
- Fenical, Gary "The Basic Principles of Shielding" In Compliance 2012 Annual Reference Guide pp 86-92
- Frenzel, Louis E. "Back to Basics: Impedance Matching (Parts 1, 2 and 3)" 2012 Electronics Design
- Gerke, Daryl and Kimmel, Bill "EMI and Signal Integrity: How to Address Both in PCB Design" 2015 In Compliance Magazine
- Gerke, Daryl and Kimmel, Bill "So You are a New EMC Engineer…Now What" In Compliance 2012 Annual Reference Guide pp 28-31
- Hartvigsen, Jay "Impedance and Crosstalk Control in Connectors and Pin Grid Arrays" Motorola, Inc. 1990

MATERION

©2020 Materion Brush Inc.

- Henn, Christian "Intermodulation Distortion (IMD)" Burr-Brown Application Bulletin 2010 Texas Instruments
- Interconnect Signal Integrity Handbook, 2007, Samtec Inc.
- Ishikawa, S. et al. "Connector Parts and High Frequency Impedance Properties of Copper Beryllium and Phosphor Bronze for High Speed, High Density Connectors" Proceedings of the 10th Annual Connector and Interconnection Technology Symposium IICIT 1997
- Joffe, Elya B. & Lock, Kai-Song Grounds for Grounding: A Circuit to System Handbook, 2010 Wiley – IEEE Press
- Johnson, Howard & Graham, Martin. High Speed Digital Design: A Handbook of Black Magic, 1993 Prentice-Hall
- Johnson, Howard. High Speed Signal Propagation: Advanced Black Magic, 2003 Prentice-Hall
- Kimmel, William D. PE and Gerke, Daryl D. "Connectors are a Major EMI Weakness" Evaluation Engineering October 2009 pp 46-49
- Kodali, V. Prasad Engineering Electromagnetic Compatibility: Principles, Measurements, and Technologies, 1996, IEEE Press
- Kraz, Vladimir and Gagnon, J. E. Patrick "How Good Is Your Ground?" 2001 Evaluation Engineering
- Mardiguian, Michel. Controlling Radiated Emissions by Design, 2014, Springer
- Morrison, Ralph. Grounding and Shielding: Circuits and Interference, 2016 Wiley
- Orange Book of Knowledge, 6th Edition. 2015 AR
- Ott, Henry W. Electromagnetic Compatibility Engineering, 2009 Wiley
- Ott, Henry W. Noise Reduction Techniques in Electronic Systems, 1998 Wiley-Interscience
- Paul, Clayton R. Introduction to Electromagnetic Compatibility, 2006 Wiley-Interscience
- Pawlikowski, Gregory T. "Effects of Polymer Material Variations on High Frequency Dielectric Properties" MRS 2009 Spring Meeting, Vol. 1156
- Pawlikowski, Gregory T.and Nixon, Allen C "The Effects of Moisture and Temperature on the High Frequency Dielectric Properties of Engineering Thermoplastics " Society of Plastic Engineers ANTEC 2010
- Signal Integrity Handbook 2007 Samtec, Inc.
- Tong, Xingcun Colin Advanced Materials and Design for Electromagnetic Interference Shielding CRC Press 2009
- Trompeter's PCB Design Guide Trompeter Electronics, Inc.
- Understanding PIM 2012 Anritsu Company
- Vijayaraghavan, G et al. "Electrical Noise and Mitigation Parts 1, 2 and 3" Automotive Design Line December 16, 23, and 30 2008
- Weinstein, David "Passive Intermodulation Distortion in Connectors, Cable and Cable Assemblies" Amphenol Corporation
- Williams, Tim EMC for Product Designers, 2007 Newnes
- Yamaguchi, M. "High Frequency Impedance of CuBe Solid Pins Used for Fast Computer Connectors" IEEE Transactions on Magnetics, Vol 23, No 5 September 1997

Fabrication (Crimping, Molding, Soldering, etc.)

- "Laser Cutting Competing and Complimenting Processes Part 2" EDM Today March/April 2002
- "Surface Mount Technology Integration of device connection technology in the SMT process" 2014 Weidmüller Interface GmbH & Co. KG
- "The Prototyping Challenges with Micro Molding: A Comparative Study of Prototyping Methods for Micro Molding Applications" 2009 Accumold
- "Understanding Statistical Tolerance Analysis" Sigmetrix retreived from http://www.sigmetrix.com/case-studies-2/tolerance-analysis-case-studies-white-papers/statistical-tolerance-analysis/
- "Wire EDM Competing and Complimenting Processes Part 1" EDM Today January/February 2002
- 3D Hubs Infographic "Additive Manufacturing Technologies"
- Accumold, "5 Things Everyone Should Know about Micro-molding"
- Allen, D. M. Photochemical Machining and Photoelectroforming DM Allen 2015
- Altan, T. et al. Metal Forming Fundamentals and Applications ASM International 2000
- Baillie, Charles "Improving Crimp Quality" Electronic Production December 1989 pp 12-13
- Bastow, Eric "5 Solder Families and How They Work" Advanced Materials and Processes December 2003 pp 26-29
- Bock, Ed. "Increase Contact Performance by Pre-Stressing" 2015 Connector and Cable Assembly Supplier
- Campbell, F. C. Metals Fabrication - Understanding the Basics 2013 - ASM International
- Clark, Emily "Mold Tool Design and Fabrication" 2015 Connector and Cable Assembly Supplier
- Deiter, G.E.; Kuhn, H.A. & Semiatin, S.L. Handbook of Workability and Process Design 2003 ASM International
- Doyton, Pete "Improve Crimp Quality to Increase Productivity" 2015 Connector and Cable Assembly Supplier.
- Fundamentals of Rockwell Hardness Testing Wilson Instruments wilsoninstruments.com
- Garcia-Cota, Gustavo "Crimp Force Monitoring – The Recipe for Success" 2013 Cable Assembly Supplier
- Goldberg, Dana "The History of 3D printing" (retrieved on 09/16/2014 - 11:36am): http://www.pddnet.com/articles/2014/09/history-3d-printing?type=cta
- Guitrau, E. Bud. The EDM Handbook Hanser Gardner Publications 1997
- Hanson, Kip "The arrival of DMLS" Appliance Design April 2016 pp 28-30
- Humpston, Giles & Jacobson, David M. Principles of Soldering and Brazing ASM International1993
- Kempg, Randy J. "How to Recognize a Good Conductor Crimp" Electronic Design March 28, 1991 pp 89-92
- Kerns, Jeff "What's the Difference Between SLA and SLS" Machine Design April 2015
- Kuvin, Brad F. "Waterjet Cutting - The Right Tool for the Job" Metalforming February 2015 pp 30-32
- Lascoe, O.D. Handbook of Fabrication Processes ASM International 1988
- Mann, Lindsay "A New Look at Micromolding" 2016 Medical Design and Outsourcing January 2016 pp 58-66
- Mercer, Jerry "EDM's Effect on Surface Integrity" MoldMaking Technology February 2008
- Quality Crimping Handbook 1996 Molex, Inc.
- Samtec's Surface Mount Interconnect Handbook 3rd Edition Samtec 1993
- SLM Solutions, NA "7 Questions Every Manufacturing Professional Must Ask Before Buying a Metal Additive Manufacturing Machine"
- Soldering Manual American Welding Society 1959
- The Good Crimping Guide 2014 TE Connectivity
- The Photofabrication Process: Design Guide to Photochemical Machining Photofabrication Corp.
- Thryft, Ann R. "9 New 3D Printing Technologies: Metals & More Metals, Printed Circuit Boards & Enclosed Electronics" Design News February 2016

©2020 Materion Brush Inc.

- Vyas, Kashyap "DFM and Sheet Metal" Machine Design November 2016

Failure Mechanisms

- Brooks, Charlie R. & Choudhury, Ashok Metallurgical Failure Analysis 1993 McGraw Hill
- Electrostatic Handbook 2010 Keyence Corporation
- Munukutla, Aravind & Kurella, Anil "Intermittent Connector Failures in Electronic Assemblies" SMTA International Conference Proceedings 2011
- Wulpi, Donald J. Understanding How Components Fail 1985 American Society for Metals (ASM International)

Fatigue

- ASM Handbook Volume 19: Fatigue and Fracture, 1996 ASM International
- Boyer, Howard E. Atlas of Fatigue Curves, 1997 ASM International
- Dowling, N. E.; Calhoun, C.A. and, A. "Mean Stress Effects in Stress-Life and Strain-Life Fatigue" Journal of Fatigue and Fracture of Engineering Materials and Structures Volume 32, Issue 3 March 2009 Pages 163–179 John Wiley and Sons
- Dowling, N.E. "A Discussion of Methods for Estimating Fatigue Life", 1982 SAE International
- Dowling, N.E. "A Review of Fatigue Life Prediction Methods" 1987 SAE International
- Dowling, Norman E. "Mean Stress Effects in Stress-Life and Strain-Life Fatigue", 2004 SAE International
- Khosrovaneh, Abolhassan; Pattu, Ravi; Schnaidt, William "Discussion of Fatigue Analysis Techniques in Automotive Applications" 2004 SAE International
- Landgraf, R.W. "Fundamentals of Fatigue Analysis" 1982 SAE International
- SAE Fatigue Design Handbook, 3rd Edition 1997 SAE International

High Voltage/Power/Current

- Collin, Dr. R. E. "Material Properties Affecting Electrical Switch Design" Case Western Reserve University April, 1976
- Corman, Ned. E. and Mroczkowski, Robert S. "Fundamentals of Power Contacts/Connectors" Proceedings of the 23rd Annual Connector and Interconnection Technology Symposium IICIT 1990
- Jemaa, N. Ben et al. "Break Arc Study for the New Electrical Level of 42 V in Automotive Applications" IEEE Transactions on Components and Packaging Technologies, Vol 25, No 3. September 2002 IEEE 2002
- Murray, Charles "High Voltage Amps Up the Automobile" Design News March 2012
- Murty, K. A. Simonsen, Jr. and Taniguchi, Y. "Heat Generation in Connector Alloys" Proceedings of the 20th Annual Connectors and Interconnection Technology Symposium October 19-21 1987 Electronic Study Group 1987
- Pope, Richard A. and Schoenbauer, David J. "Temperature Rise and Its Importance to Connector Users," 37th Annual Electronic Components Conference Proceedings, pp. 1-8, 1987.

Lubrication, Wear and Fretting Corrosion

- "Frequently Asked Questions on the Use of Polyphenol Ether Connector Lubricants" Monsanto Company
- "Lubricants for Stationary Separable Electrical Connectors" Nye Lubricants Inc. 1995
- "Synthetic Lubes Protects Electrical Connections, Reduce Warranty Claims" Nye Synthetic Lubricants 1999
- Akin, Kevin D. "Using Connector Lubricants for Warranty Reduction" Connector Specifier August 1999
- Antler, M. "Survey of Contact Fretting in Electrical Connectors" Proceedings of the 30th IEEE Holm Conference on Electrical Contacts IEEE 1984
- Auckland, Neil et al. "The Effect of Fretting at Elevated Temperatures on a Clad Material (65Au21Pd14Ag) and an Electroplated Soft Gold over Palladium-Nickel Material System" IEEE Transactions on Components and Packaging Technology Vol 23, No 2 June 2000
- Aujla, S. and Wiltshire, B. "Connector Insertion Force Characteristics" Proceedings of the 31st IEEE Holm Conference on Electrical Contacts IEEE 1985
- Bock, E. M. & Whitley, J. H. "Fretting Corrosion in Electrical Contacts" Twentieth Annual Holm Seminar on Electrical Contacts October 29-31, 1974
- Contact Lubricants Eletrolube
- Dorsey, Glenn P.E. "What Nanotribologists are Teaching Us about Electrical Contacts" Moog Components Group White Paper
- Joaquim, Manuel E. "Key Benefits of Connector Lubricants" Connector Specifier October 2002
- Johnson, Jim and Flanagan, Patrick M. "Evaluation of a Precision Fretting Corrosion Test System" Proceedings of the IICIT Connector & Interconnection Technology Symposium IICIT 2001
- Kerns, Jeff. "What's the Difference between Types of Wear?" Machine Design January 2016 pp 34-37
- Mroczkowski, Robert S. "Connector Contact Lubricants" 2013 Connector Supplier
- Mroczkowski, Robert S. "Dr. Bob on Connector Wear Mechanisms" 2013 Connector Supplier
- Peel, Max. "Fretting and Electrical Erosion: A Possible Failure Mechanism" Contech Research, Inc.
- Rice, Don W. et al. "Corrosion Inhibiting Lubricants for Separable Connectors" IEEE Transactions on Components, Hybrids, and Manufacturing Technology, Vol. CHMT-8, No. 4 December 1985 IEEE 1985
- Scopelliti, David P. "The Pain of Fretting Corrosion" 2013 Samtec, Inc.
- van Dijk, Piet "Some Effects of Lubricants and Corrosion Inhibitors on Electrical Contacts" AMP Journal of Technology Vol. 2 November 1992 Amp Incorporated 9912
- van Dijk, Piet & van Meijl, Frank "Contact Problems Due to Fretting and Their Solutions" AMP Journal of Technology Vol. 5 June, 1996 Amp Incorporated 1996
- Whitley, James H. "Investigation of Fretting Corrosion Phenomena in Electric Contacts" Proceedings of the 8th International Conference on Electric Contact Phenomena, The Institution of Electrical Engineers of Japan 1976 pp 659-665

Material Selection

- Balance, John B. "Metallurgical Phenonena in High Strength Beryllium Copper Alloys Which Affect Electrical Component Design" Proceedings of the 10th Annual Connector Symposium 1977
- Copper in Electrical Contacts Copper Development Association and European Copper Institute July 2015
- Copper Rod Alloys for Machined Products Copper Development Association December 1992
- Harkness, J.C. et al. "Beryllium-Copper and Other Beryllium-Containing Alloys" ASM Handbook Vol 2 Properties and Selection: Nonferrous Alloys and Special-Purpose Materials ASM International 1990 p 403–427
- Ishikawa, T. et al. "Properties of C17200 Beryllium Copper Alloy for High Performance Connectors" Proceedings of the 4th Annual Connector and Interconnection Technology Symposium IICIT 1991
- Johnson, Aaron and Ankeny, Iowa "Materials Fit for Micromolding" Machine Design October 20, 2011
- Larson, Eric "Plastic Material Selection: The Four Performance Killers" Global Plastics Report 2016

©2020 Materion Brush Inc.

- Lowenthal, William and Harkness, John "Material Performance Comparison in Low Deflection Contacts" Proceedings 15th Annual Connectors and Interconnection Symposium, Electronic Connector Study Group November 1-2, 1982
- Lowenthal, William S. "Four Key Metallurgical Parameters that Influence Connector Performance" Brush Wellman
- Mroczkowski, Robert S. "Connector Design/Materials and Connector Reliability" 1993 AMP, Inc.
- Mroczkowski, Robert S. "Materials Consideration in Connector Design" ASM World Material Congress September 1988
- Spiegelberg, William D. "Elastic Resilience and Related Properties in Electronic Connector Alloy Selection" Proceedings of ASM International's 3rd Electronic Materials & Processing Congress August 1990 pp 215-223
- Zarlingo, S. Paul "New Insights for the Specification of Copper Alloy Strip Metals for Connectors" Proceedings, 46th Electronic Components and Technology Conference 1996.
- Zarlingo, S. Paul. "Evaluation of Metals with Intermediate Conductivity for Connector Springs, Switches & Terminals" Proceedings of the 6th Annual Connector and Interconnection Technology Symposium IICIT 1993

Materials Science and Mechancial Engineering

- Braithwaite, Nicholas & Weaver, Graham Electronic Materials Second Edition 1998 The Open University
- Campbell, F. C. Phase Diagrams - Understanding the Basics 2012 - ASM International
- Carter, Giles F. & Paul, Donald E. Materials Science and Engineering 1991 ASM International
- Chandler, Henry Metallurgy for the Non-Metallurgist 1998 ASM International
- Davis, et al. ASM Handbook Vol 2 Properties and Selection: Nonferrous Alloys and Special-Purpose Materials, 1990 ASM International
- Dieter, G. Mechanical Metallurgy, 2nd edition, 1976 McGraw Hill
- Dieter, G.E. et al. Handbook of Workability and Process Design ASM International 2003
- Edwards, Lyndon & Endean, Mark Manufacturing with Materials 1990 The Open University
- Guide to Alloy Products Materion Corporation 2015
- Harkness, John C. et al. "Strength and Stiffness in Bending of Mill Hardened CuBe Alloys As Determined by Three Different Test Methods" Proceedings of the 36th Annual IICIT Connector & Interconnection Technology Symposium & Trade Show IICIT 2003
- Harper, C. and Sampson, R. Electronic Materials & Processes Handbook, 2nd edition, 1994 McGraw Hill
- Hayden, H.W.; Moffatt, W.G.; Wulff, J. The Structure and Properties of Materials Volume III-Mechanical Behavior, 1965 Wiley
- Juvinall, Robert C. & Marshek, Kurt M. Fundamentals of Machine Component Design, 1991 John Wiley & Sons
- Newey, Charles & Weaver, Graham Materials Principles and Practice 1990 The Open University
- Shigley, Joseph Edward & Mischke, Charles R. Mechanical Engineering Design, 1989 McGraw-Hill Inc.
- Technical Materials Alloy Guide Materion Corporation 2011
- Tisza, M. Physical Metallurgy for Engineers 2001 ASM International and Freund Publishing House, Ltd.
- Weidmann, George & Reid, Nick Structural Materials 1990 The Open University

Miniaturization

- Arden, Wolfgang et. Al. "More than Moore White Paper." ITRS (International Technology Roadmap for Semiconductors)
- Hult, Bob "It's a Small World" Connector Supplier June 5, 2012
- MacWilliams, John "Connector Miniaturization Happens" November 6, 2012 Connector Supplier
- Moore, Gordon E. "Cramming More Components onto Integrated Circuits" Electronics April 19, 1965 (Reproduced in PROCEEDINGS OF THE IEEE, VOL. 86, NO. 1, JANUARY 1998)
- Stanton, Bob "Miniature, Microminiature, and Ultraminiature: How Small Can Connectors Go?" 2015 Connector and Cable Assembly Supplier

Plating, Cladding, Contact Resistance and Corrosion

- "Golden Rules: Guidelines For The Use Of Gold On Connector Contacts" AMP Technical Report 2004 by Tyco Electronics Corporation
- Antler, M. "Guidelines in the Selection of Noble Metal Connector Contact Finishes: Sliding Friction and Wear" Connection Technology January 1989
- Antler, Morton "Gold-Plated Contacts: Effect of Thermal Aging on Contact Resistance" Plating and Surface Finishing December 1988
- Antler, Morton "New Developments in the Surface Science of Electric Contacts." Plating Vol 53 December 1966
- Bimetallic Corrosion 2000 National Physical Laboratory (UK)
- Bock, Ed "Low-Level Contact Resistance Characterization" AMP Journal of Technology Vol 3 November, 1993
- Bock, Ed "Silver: A Superior Finish for High-Current Applications" Connector and Cable Assembly Supplier 2015
- Bock, Ed "Why Minor Increases in Contact Resistance Matter" Connector and Cable Assembly Supplier 2014
- Bock, Edward "Mateability of Tin to Gold, Palladium, and Silver" 40th Conference Proceedings on Electronic Components and Technology May 20-23 1990 pp 840-844
- Bushman, James B. P.E. "Corrosion and Cathodic Protection Theory" Bushman & Associates, Inc.
- Chen, Lichun Leigh; Njoes, Barry and Williams, David W. M. "Inlay Clad Metal for High Temperature Connector Applications" Proceedings of the 54th IEEE Holm Conference on Electrical Contacts 1988 IEEE 1988
- Cowieson, D. et al. "Contact Resistance Measurements on Aged Tin and Tin Alloy Coatings" Transactions of Institute of Metal Finishing 1986
- Deeg, Emil W. "New Algorithms for Calculating Hertzian Stresses, Deformations, and Contact Zone Parameters"AMP Journal of Technology Vol. 2 November, 1992
- Durney, L. Electroplating Engineering Handbook, 4th edition, 1984 Von Nostrand Reinhold
- Edwards, J Coating and Surface Treatment Systems for Metals Finishing Publications, Ltd & ASM International 1997
- Fluss, H. S., “Hertzian Stress as a Predictor of Contact Reliability,” Connection Technology, March, 1989 pp 14-22. December, 1990 pp 12-21
- Gabel, Nickole; Hardee, Harry and Lees, Phillip "Comparison of Coefficient of Friction and Contact Resistance During Sliding Wear on Clad Gold-Nickel Surfaces" Proceedings of the Annual Holm Conference on Electrical Contacts February 2001

©2020 Materion Brush Inc.

- Geckle, Raymond J. and Mroczkowski, Robert S. "Corrosion of Precial Metal Plated Copper Alloys Due to Mixed Flowing Gas Exposure" AMP Incorporated 1990
- Haimovich, Joseph "Hot Air Leveled Tin: Solderability and Related Properties" Proceedings of the 39th Electronic Components Conference May1989
- Kantner, E. A. and Hobgood, L. D., “Hertz Stress as an Indicator of Connector Reliability,” Connection Technology, March, 1989 pp 14-22.
- "Keeping Tin Solderable" AMP Incorporated 1999
- Krumbein, Simeon J."Metallic Electromigration Phenomena" Proceedings of the 33rd IEEE Holm Conference on Electrical Contacts September 1987
- Lees, P. W. "The Influence of Manufacturing Technology on the Effectiveness of Nickel Diffusion Barriers for High-Temperature Dry Circuit Applications" Materion Technical Materials Technical Paper #8
- Lees, Philip W. "Development and Application of Connector Contact Material Systems for Elevated Temperature Exposure" Annual Connectors and Interconnection Technology Symposium Proceedings, Volume 36 Electronic Connector Study Group, 2003
- Lees, Philip W. "On the Upper Temperature Limit for Tin Connector Contact Surfaces" Proceedings of the 37th Annual IICIT Connector Symposium September 2005
- Maucci, Robert D. "Effects of Wipe on Contact Resistance of Aged Surfaces" IEEE Transactions Components, Packaging, and Manufacturing Technology - Part A Vol. 18, No. 3, September 1995
- Michelson, Robert A. “The Anatomy of a Pore in Gold Plated Contacts" Connector Supplier July 20 2010
- Miéville, Jacques "How Connectors Perform in Harsh Corrosive Environments, and Why Reliability Matters" Fischer Connectors Whitepaper
- Mroczkowski, Dr. Robert S. "Corrosion and Contact Resistance" 2014 Connector and Cable Assembly Supplier
- Mroczkowski, Dr. Robert S. “Dr. Bob’s Nickel’s Worth: Nickel Underplates" Connector Supplier October 2012
- Mroczkowski, Dr. Robert S. “Porosity: The (w)Hole Story" Connector Supplier April 2 2013
- Mroczkowski, R. S. “Corrosion and Electrical Contact Interfaces” AMP Incorporated 1984
- Mroczkowski, Robert “Concerning Hertz Stress as a Connector Design Parameter,” Proceedings of the 24th Annual Connector and Interconnection Technology Symposium October, 1991 pp 327-337
- Mroczkowski, Robert “Connector Surfaces - Where the Action Is” AMP Incorporated 1983
- Munukutla, Aravind and Kurella, Anil "Intermittent Connector Failures in Electronic Assemblies" SMTA International Conference 2011 Proceedings October 16, 2011
- Myers, Marjorie "Comparison of Hard Au versus Hard Au Flashed PdNi as a Contact Finish" Proceedings of the 56th IEEE HOLM 2010 Conference on Electrical Contacts, September 2010
- Myers, Marjorie "Overview of the Use of Silver in Connector Applications" 2009 Tyco Electronics Corporation
- Myers, Marjorie "The Performance Implications of Silver as a Contact Finish in Traditionally Gold Finished Contact Applications" Proceedings of the 55th IEEE HOLM 2009 Conference on Electrical Contacts, September 2009
- Peel, Max. “Nickel Underplates: Then and Now" Connector Supplier August 7 2012
- Peel, Max. “Porosity: Real World Concerns" Connector Supplier March 5 2013
- Puttock, M. J. Nd Thwaite, E.G. "Elastic Compression of Spheres and Cylinders at Point and Line Contact- National Standards Laboratory Technical Paper No 25" Commonwealth Scientific and Industrial Research Organization, Australia 1969
- Révay, Laslo “Surface Accumulation of Diffusing Species on Thin Gold Electroplates” IEEE Transactions on Components, Hybrids, and Manufacturing Technology, Vol 15, No 4, October 1992
- Richards, John T. "Corrosion Resistance of Beryllium Copper" Proceedings of the Ninth Annual Conference, National Association of Corrosion Engineers March 16-20, 1953
- Samant, Anand V. and Grensing, Fritz C. "Corrosion of Copper Alloys in Consumer Electronics Environments" Materials Performance December 2015
- Turn, John C. "Corrosion Behavior of Beryllium Copper in Simulated Industrial Environments" Paper Number 337, Corrosion 89 April 17-21, 1989 National Association of Corrosion Engineers 1989
- Whitley, J. H. "Connector Surface Plating: A Discussion of Gold and the Alternatives" IICIT News Summber 1989 pp 13-19
- Whitley, J. H. "The Tin Commandments: Guidelines For The Use Of Tin On Connector Contacts" AMP Technical Report 2004 by Tyco Electronics Corporation
- Whitley, J. H. and Mroczkowski, R. S. "Concerning Normal Force Requirements for Gold Plated Contacts" AMP Incorporated 1987
- Williams, David W. M. "The Effect of Test Environment on the Creep of Base Metal Surface Films over Precious Metal Inlays" Materion Technical Materials Technical Paper #9

Plastic Resins, Epoxies and Potting Compounds

- "Versatile Epoxy Compounds for Electronic Applications" Masterbond Inc. Whitepaper
- Burroughts, Bruce "Selecting the Right Housing Material" Connector Specifier January 2000 pp 30-31
- Cura, Carl and Brown, Damon "Designed to Beat the Heat" Machine Design April 20, 2000 pp 50-58
- Johnson, Aaron "Materials Fit for Micromolding" Machine Design October 20, 2011 pp 58-63
- Orstad, Richard "How to Specify Electrical Insulating Material" 2016 Connector and Cable Assembly Supplier
- Schultz, Nick "Potting and Encapsulating Electronic Components"2016 Nordson Sealant Equipment
- Technical Sealing Guide 2011 Rogers Corporation

Reliability

- "APPLICATION NOTE 5068 STERILIZATION METHODS AND THEIR IMPACT ON MEDICAL DEVICES CONTAINING ELECTRONICS" 2014 Maxim Integrated Products, Inc.
- "Designing for Mechanical and Signal Integrity in Handheld Medical Treatment Applications " January 2017 New England Wire Technologies White Paper
- "Fundamentals of Electrostatic Discharge – Parts 1 to 6" 2010 In Compliance Magazine
- "Robust Interconnect Solutions Mean Product Reliability" 2015 Connector and Cable Assembly Supplier
- "White Paper # 4- Understanding Electrical Overstress" April 2016 Industry Council on ESD Target Levels
- Bazovsky, Igor Reliability Theory and Practice, 2004 Dover Publications, Inc.
- Bock, Ed. "Contact Design Considerations For Long-Term Reliability" 2015 Connector and Cable Assembly Supplier

©2020 Materion Brush Inc.

- Boesing, Danny "Rugged Industrial Interconnects: The Design Behind the Description" Connector and Cable Assembly Supplier March 21, 2017
- Brosnan, David P. P.E."Human Error and Structural Engineering" Structure Magazine September 2008 pp 36-49
- Dunlevey, Frank "Connector Reliability: The Role of Contact Spring Alloys" Connector Supplier April 2008
- Electrostatic Discharge (ESD) Suppression Design Guide 2016 Littelfuse
- http://www.weibull.com/ Reliability engineering Resources
- Hunt, Derek. "Connector Requirements for Space Electronics" 2016 Connector and Cable Assembly Supplier
- Kraz, Vladimir"Electric Overstress (EOS) and Its Effects on Today's Manufacturing" 2016 Evaluation Engineering
- Mroczkowski, Dr. Robert S. "Connector Design/Materials and Connector Reliability" AMP Incorporated 1993
- Pickering, Paul "What makes a Harsh Environment a Harsh Environment" ECN January 2016
- Roettjer, Phil "Reliability Screening for Electromechanical Relays" Evaluation Engineering April 2013
- Summerville, Nicholas Basic Reliability, 2004 Author House
- Wesher, Dr. Terry L. "Rethinking Electrical Overstress" April 2016 In Compliance Magazine

Standards and Regulations

- "Medical Connectors: Characteristics and Regulations" 2014 Connector and Cable Assembly Supplier
- Manchen, Ken "It's BAAACK: Ready or not, here comes RoHS 2" ECN Magazine (retrieved on 01/04/2013 - 8:31am): http://www.ecnmag.com/blogs/2013/01/its-baaack-ready-or-not-here-comes-rohs-2

Stamping, Drawing, Formability, Springback

- "How to Draw Round Cups Deeper" Stamping Journal March/April 1999
- "Pressworking Lubricants and Applications" November 29, 2000 Smith & Associates 1993, 2000
- "Principles of Shearing, Blanking, and Piercing, Metalworking: Sheet Forming", Vol 14B, ASM Handbook, ASM International, 2006, p 28–38
- Benson, Steve "Bending Basics: The hows and whys of springback and springforward" THE FABRICATOR® JULY 2014
- Carnes, Robert E. "Guide for Selecting Tooling Materials" Advanced Materials and Processes January 2000
- Castro, A. López et al. "A Closed Form Solution for Predicting Springback in Bending of Beams Including Hardening Effect" Advanced Steel Construction Vol. 5, No. 2, pp. 127-135 (2009)
- Cattell, Dennis "Stamping 101: Anatomy of a Mechanical Press" STAMPING JOURNAL JANUARY/FEBRUARY 2008
- Chamberlain, Steve "Combating Tool Wear with Coatings: When Will a Coating Help?" Stamping Journal November/December 2002
- Dadras, P. "Stress-Strain Behavior in Bending" ASM Handbook Vol 8 Mechanical Testing and Evaluation ASM International, 2000, p 109–114
- Dayton Progress Problem Solving Guide October 2012 Dayton Progress
- Evans, John "The Basics of Deep-Drawn Springs" Machine Design September 20, 2012
- Harkness, John C. "Prediction of Elastic Springback in Forming of Heat Treatable and Mill Hardened Tempers of Beryllium Copper Strip"
- Harkness, John. C "Elastic Springback of Mill Hardened Beryllium Copper Strip" Brush Wellman Technical Memorandum TM-693 May 5, 1983
- Harkness, John. C "The Influence of Coining Reduction During Stamping on the Properties of Mill Hardened Cu-Be Strip" Brush Wellman Technical Memorandum TM-1477 March 22, 2005
- Hedrick, Art "Attempting to Defy the Laws of Physics, Part 1: Variables Make Part Tolerancing a Pipe Dream" Stamping Journal March/April 2011
- Hedrick, Art "Carrier Design for Progressive Dies Parts 1 and 2" Stamping Journal January/February 2003 and March/April 2003
- Hedrick, Art "Controlling Flow and Obtaining Stretch in Deep Draw Operations" Stamping Journal March/April 2000
- Hedrick, Art "Die basics 101 starts with eight basic components"THE FABRICATOR AUGUST 2006
- Hedrick, Art "Fundamentals of Drawing" Stamping Journal May/June 2016
- Hedrick, Art "Key Design Principles for Successful Deep Drawing" Stamping Journal March/April 1999
- Hedrick, Art "Reading Progressive-die Strips Part II" Stamping Journal June 2008
- Hedrick, Art "The Process of Fineblanking" Stamping Journal July 2006
- Hedrick, Art "Understanding Deep Drawing and Stretching Variables" STAMPING JOURNAL JANUARY/FEBRUARY 2008
- High Speed Stamping March 2003 Dayton Progress
- Ivaska, Joseph Jr. "Examining Pressworking Lubricants" Stamping Quarterly pp 66-72
- Ján,Slota and Miroslav, Jurčišin "Sprinback Prediction in Sheet Metal Forming Processes" Journal for Technology of Plasticity, Vol. 37 (2012), Number 1
- Keeler, Stuart "A graphical explanation of n-value" Metal Forming November 2016
- Keeler, Stuart "Handle Elastic Stresses to Manage Springback and Improve Dimensional Stability" Metal Forming September 2012
- Keeler, Stuart "High-Speed Forming" Metal Forming August 2007
- Keeler, Stuart "How Much Does Metal Thin" Metal Forming August 2004
- Keeler, Stuart "Is Metalforming Failure Predictable" Metal Forming June 2011
- Keeler, Stuart "More Ways to Let Your Supplier Help" Metal Forming April 2011
- Keeler, Stuart "Strain Rate Hardening: Small Number, Big Impact" Metal Forming June 2014
- Keeler, Stuart "Stress-Strain Curves Give Visual Clues About Formability" Metal Forming July 2015
- Keeler, Stuart "Stretch, Bend, and Draw: Different Forming Methods" Metal Forming January 2016
- Keeler, Stuart "The Battle Between Tension and Compression" Metalforming November 2015
- Keeler, Stuart "Troubleshooting Cup Drawing" Metalforming May 2006
- Keeler, Stuart "What is the r Value?" Metal Forming November 2005
- Keeler, Stuart and Ulintz, Peter "Deep Drawing from Z to Z" Metal Forming July 2008
- Korneli, Michael. "Designing Progressive Dies" Stamping Journal January/February 1999
- Kuhn, Brad F. "Mirror Finish Helps Dies Release 'Sticky' Parts" MetalForming July 2001
- Madorsky, Yury and Thompson, Matthew "Coating for stamping and forming tools" The Fabricator March 8, 2005
- Mandigo, Frank and Tyler, Derek "Forming of Copper and Copper Alloys" , ASM Handbook Vol 14B Metalworking: Sheet Forming ASM International, 2006, pp 609–624

©2020 Materion Brush Inc.

- Mandigo, Frank N. "Bending Ductility Tests" ASM Handbook Vol 8 Mechanical Testing and Evaluation ASM International, 2000, p 172–184
- Metco Fourslide Line Card 2012 Metco Fourslide Mfg, Inc
- Oshima, Seijiro "The Importance of the Contact Angle in Deep Drawing" Stamping Journal March/April 2001
- Osman, MA et al. "Springback prediction in V-die bending: modeling and experimentation" Journal of Achievements in Materials and Manufacturing Engineering Vol. 38, Issue 32 February 2002
- Parsons, Andy Spence "The Formula for Successful Punching" The Fabricator August 2006
- Punicki, Chester J. "Designing Precision Progressive Dies for Thin Material Parts 1, 2 and 3" Stamping Journal July/August 1999, September/October 1999 and November/December 1999
- Queener, C. A. & De Angeles, R. J. "Elastic Springback and Residual Stresses in Sheet Metal Formed by Bending" Transactions of ASM, Vol 61, 1968, pp 757-768
- Ratka, John O. and Harkness, John C. "Width, Thickness and Other Factors Affecting Formability"
- Ratka, John O."The Influence of the Bauschinger Effect in the Performance of Connector Materials"
- Reich, Ronald "Selecting and Maintaining Pressworking Lubricants Parts 1 and 2" Stamping Quarterly Summer 1994 and Fall 1994
- Seo, Young "Improving Blank Edge Conditions in Progressive Stamping" Stamping Journal July/August 2003
- Shuldes, Glen "7 Strategies for Punching Success" The Fabricator March 2016
- Stamping Basics: Fundamentals and Technology March 2003 Dayton Progress
- Stephens, Tim "First Easy Piece: Cutting Theory" Metalforming January 2004
- Stephens, Tim "Sixth Easy Piece: Forming Practice" Metalforming June 2004
- Tarkany, Nick "Improving Perforating Die Performance: The Effects of Stress, Clearance, Material" Stamping Journal March/April 2003
- Thies, Eric "Trapped Stresses and Unpredictability: The Case of the 'Uptight' Coil" MetalForming January 1996
- Tittel, Viktor and Bernadičm Ľuboš "A Review of Methods and Precautions against Slug Pulling" Int. J. Pure Appl. Sci. Technol., 12(1) (2012), pp. 7-15
- Tseng, A.A. et al. "A Formability Analysis of Beryllium Copper Strip." Proceedings of the Annual Connector and Interconnection Technology Symposium IICIT 1992
- Tseng, A.A. et al. "Forming Properties and Springback Evaluation of Copper Beryllium Sheets" Metallurgical and Materials Transactions A Volume 26A, August 1995 pp 2111-2121
- Ulintz, Peter "Cutting Terminology" MetalForming June 2008
- Ulintz, Peter "Deep Drawing-Advanced Topics" MetalForming July 2008
- Ulintz, Peter "Deep-Drawing Guidelines - Boxes" MetalForming May 2007
- Ulintz, Peter "Deep-Drawing Guidelines - Cups Part 1" MetalForming February 2007
- Ulintz, Peter "Drawing Cups with Flanges" MetalForming September 2007
- Ulintz, Peter "Solving Stretching and Forming Problems" MetalForming January 2014
- Ulintz, Peter "Troubleshooting Guidelines for Deep Drawing" MetalForming June 2007
- Weber, Ross "Flight of a Complex Progressive Stamping - From Print to Finished Part" Stamping Journal May/June 2015
- Windingstad, Ron "Tooling Tips to Promote Profitable Punching" MetalForming December 2012
- Wojnicz, L. et al. "Bend Formability - Characterization and Performance" Proceedings of Materials Science and Technology (MS&T) September 16-20, 2007
- Yi, H.K. et. Al. "Analytical prediction of springback based on residual differential strain during sheet metal bending" Proc. Institute of Mechanical Engineers Vol. 222 Part C: J. Mechanical Engineering Science IMechE 2008
- Yoshida, Toru et. Al. "Material Modeling for Accuracy Improvement of the Springback Prediction of High-strength Steel Sheets" NIPPON STEEL TECHNICAL REPORT No. 102 JANUARY 2013

Test and Degradation Mechanisms

- Abbot, W. H.; Neer, J. H. and Healy, H.J. "Effects of Test Procedures and Sequences on the Performance of Tin-Plated Connectors" Proceedings of IEEE Holm Conference on Electrical Contacts September 27-29, 1993 IEEE 1993
- Bishop, Margaret "Testing Appliance Cables and Connectors" applianceDESIGN March 2017 pp 36-38
- Bock, Ed. "Typical Connector Failure Modes and Mechanisms" Connector and Cable Assembly Supplier 2014
- Mackie, Dr. Andy "Electromigration (EM) and Electrochemical Migration (ECM)" Indium Corporation January 30th, 2011
- MIL-STD-202G United States Department of Defense 28 June 2013
- Mroczkowski, Dr. Robert S. "Comparison and Performance: EIA 364D Test Group 2" Connector and Cable Assembly Supplier 2014
- Mroczkowski, Dr. Robert S. "Connector Degradation Mechanism - Corrosion Part 1" Connector and Cable Assembly Supplier 2014
- Mroczkowski, Dr. Robert S. "Connector Degradation Mechanism - Corrosion Part 2" Connector and Cable Assembly Supplier 2014
- Mroczkowski, Dr. Robert S. "Connector Degradation Mechanism - Wear" Connector and Cable Assembly Supplier 2014
- Mroczkowski, Dr. Robert S. "Connector Testing EIA 364D Test Group 3" Connector and Cable Assembly Supplier 2014
- Mroczkowski, Dr. Robert S. "Degradation Mechanisms - Loss of Contact Normal Force" Connector and Cable Assembly Supplier 2014
- Mroczkowski, Dr. Robert S. "Dr. Bob on Connector Degradation Mechanism" Connector and Cable Assembly Supplier 2014
- Mroczkowski, Dr. Robert S. "Measure Twice, Test Once" Connector and Cable Assembly Supplier 2014
- Mroczkowski, Dr. Robert S. "MFG - A Corrosion Oriented Test" Connector and Cable Assembly Supplier 6/3/2008
- Mroczkowski, Dr. Robert S. "Shock, Rattle, and Vibrate with the EIA 364D – Group 1 Test" Connector and Cable Assembly Supplier 2015
- Mroczkowski, Dr. Robert S. "Stress Relaxation - Test Group 5" Connector and Cable Assembly Supplier 2014
- Mroczkowski, Dr. Robert S. "Test Group 4: Let's Not Be Too Harsh" Connector and Cable Assembly Supplier 2014
- Mroczkowski, Dr. Robert S. "The How and Why of Connector Testing Programs" Connector and Cable Assembly Supplier 2015
- Mroczkowski, Dr. Robert S. "Dr. Bob Relates Connector Degradation Mechanisms to Connector Testing" Connector and Cable Assembly Supplier 2014
- Nute, Richard "Testing Purposes" In Compliance August 31, 2015
- Pecht, Michael G. "Establishing a Relationship Between Warranty and Reliability" IEEE Transactions on Electronics Packaging Manufacturing Vol. 29, No. 3, July 2006

©2020 Materion Brush Inc.

- Peel, Max “Devil or Angel - Connector Testing" Connector and Cable Assembly Supplier 2014
- Peel, Max “Vibration: The Good, the Bad, and the Ugly" Connector and Cable Assembly Supplier October 2013
- Smith, Jim Ph.D. ABD "The Curse of The Curse of IPC-A-610 and IPC-J-STD-001" Assembly Magazine April 27, 2011
- Yashuda, Kei-ichi et al. "Evaluation of Contact Resistance Characteristics for Tin-Plated Connector Contacts in Accelerated Degradation Tests" Electronics and Communications in Japan, Part 2 Vol 70, No 7, 1987
- Zhou, Yilin et. al. "Electrochemical Migration Failure of the Copper Trace on Printed Circuit Board Driven by Immersion Silver Finish" Chemical Engineering Transactions VOL. 33, 2013

Tin Whiskers, Intermetallics and Pb-Free Solders

- "Current Tin Whiskers Theory and Mitigation Practices Guideline" JEDEC Sold State Technology Association and IPC Association Connecting Electronics Industries March 2006
- "Interim Recommendations on Lead-Free Finishes for Components Used in High-Reliability Products" NEMI Tin Whisker User Group March 2004
- "Soldering 101 - A Basic Overview " Indium Corporation Application Note
- Albrecht, H.-J. et al. "Pb-Free Alloy Alternatives: Reliability Investigation" SMTA International Conference Proceedings October 4, 2009
- Baated, Alongheng et al. "Effects of Reflow Atmosphere and Flux on Tin Whisker Growth of Sn-Ag-Cu Solder" 2009 SMTA International Conference Proceedings pp 802-808
- Delserro, Gary P.E. "Lead-Free Reliability and Test Methods" Evaluation Engineering June 2006 pp 48-52
- Gaylon, George T. "A History of Tin Whisker Theory: 1946 to 2004" IBM 2004
- Gaylon, George T. "Annotated Tin Whisker Bibliography" NEMI Tin Whisker User Group July 2003
- Gupta, Abhishek "Don't let Tin Whiskers Destroy Your Design" Electronic Design October 15, 2003
- Gupta, Abhishek "Hard-Won Knowledge Mitigates Effects Of Tin Whiskers" Electronic Design June 6, 2014
- Haimovich, Joseph "Cu-Sn Intermetallic Compound Growth in Hot-Air-Leveled Tin at and below 100°C" AMP Journal of Technology Vol. 3 November, 1993
- Hunt, Christopher "Implementation and Reliability Issues with Lead-Free Solders" SMTA International Conference Proceedings 2014
- Lavery, Patrick "Tin Whiskers: Avoid Stubble Trouble" Electronic Design January 11, 2007
- Mackie, Andy C. & Lee, Ning-Cheng "Solder Alloy Trends and Technologies in Semiconductor Packaging and assembly" Chip Scale Review July-August 2014 pp 14-17
- Olson, Aaron "What are Intermetallics and How Can We Overcome the Failures Associated with Them?" STI Electronics, Inc. Whitepaper
- Osterman, M. "Mitigation Strategies for Tin Whiskers" CALCE August 28, 2002
- Parent, J.O.G. et al. "Effects of Intermetallic Formation at the Interface between Copper and Lead-Tin Solder" Journal of Materials Science Vol 23 1988 pp 2564-2572
- Roubaud, Patrick et al. "Impact of Intermetallic Growth on the Mechanical Strength of Pb-Free BGA Assemblies" Proceedings of APEX 2001
- Sampson, Michael and Leidecker, Dr. Henning "Basic Info on Tin Whiskers" NASA June 16, 2009 retrieved from http://nepp.nasa.gov/whisker./background/index.htm
- Schueller, Randy Ph.D. et al. "Second Generation Pb-Free Alloys" SMTA International Conference Proceedings 2010
- Siewert, Dr. Thomas et al. "Properties of Lead-Free Solders Release 4.0" National Institute of Standards and Technology & Colorado School of Mines February 11, 2002
- Smetana, Joe et al. "Pb-free Solder Joint Reliability in a Mildly Accelerated Test Condition" SMTA International Conference Proceedings 2011
- Tsujimoto, Masanobu "The Elimination of Whiskers from Electroplated Tin" IPC APEX EXPO Conference Proceedings 2011

Disclaimer: Only the buyer can determine the appropriateness of any suggested processing practice, end-product or application. Materion is not able to make any warranty regarding its recommendations, the suitability of Materion's product, or its processing suggestions for buyer's end product, application or equipment.

Materion Connector
Engineering Design Guide

6070 Parkland Blvd, Mayfield Heights, OH 44124
OH 44124 USA Toll-free: 1.800.375.4205

Materion.com/Connectors

MATERION